

Store Presentation Kit

Kit Contents

This presentation kit should be used for any special events in your store. Each kit includes:

- An Epson All-In-One projector, including:
 - o Built in DVD player
 - o Built in speakers
 - o VGA Cable
 - o Microphone
 - o Remote with Batteries
 - o Soft case
- Projector Screen (84 inch diagonal)
- Targus Presentation Remote
- HDMI cable
- VGA to Thunderbolt adapter (for Macbook Air/Pro laptops)
- 20 foot extension cord
- Storage Container

Using the Projector

The Store Presentation Kit includes a “Quick Setup” guide that covers the basic steps required to begin using the Epson projector. Please refer to that guide for instructions on playing a DVD, connecting to multiple sources, and adjusting the image.

Control Overview

Turning the projector on

1. Plug the projector in using the included power cable.
2. Next press the power button (located next to the “Source Search” button on top of the projector)
3. The projector will beep and the power light (located above the power button) will flash green as the projector warms up.
4. When the power light stays continuously green, the projector is ready to use

Selecting a Source

The Epson PowerLite projector will accept multiple input sources, including DVD, HDMI, VGA (for PC laptops, and Mac laptops with the VGA to Thunderbolt adapter). To use any of these inputs, simply plug the proper cable into the corresponding input on the back of the projector. If you are using a laptop computer, be sure to select the output if it is not done automatically.

If you have multiple input sources plugged into the projector, you can choose between them by pressing the “Source Search” button on the top of the projector. This will display a menu

showing the available options. To select your source, simply scroll through the menu using the up or down arrow keys located above and below the “Enter” button.

If you are using a laptop, be sure to adjust your computer settings to properly display video. Note: HDMI connections are capable of playing audio and video.

Image Controls

The **focus ring** is located closest to the front of the projector. To adjust the focus, turn the focus ring as needed.

The **zoom ring** is located next to the focus ring. To adjust the zoom (size) of the image, turn the zoom ring as needed.

If the image appears skewed or off-center, make sure the projector directly faces the screen. Also, check the adjustable feet by pressing the foot adjustment levers to lift the front of the projector.

Volume Controls

The volume of the speakers can be adjusted using the Volume controls on the top of the projector. The maximum volume of the Epson projector should be enough for most in-store presentation scenarios, however, there are a few things that can be done to ensure everyone can hear the presentation:

- Be sure the projector is set up far enough away from any running refrigeration equipment to prevent conflicting noise.
- Turn off any store music
- Keep the event confined to a limited space while video is playing
- External speakers can be used if your store is particularly noisy

Presentation Kit Storage

To increase the life of the projector and its accessories, please store these items in the clear tote when not in use. Be sure to collapse the projector screen as soon as possible to avoid any possible damage to the viewing surface. Finally, remember to return the kit to your respective hub store as soon as possible so that others may enjoy it.