



- NOTES:
- CONDENSATE PUMP SUCTION CAN VENT SHALL BE ROUTED CONTINUOUSLY UPWARD TO THE CONDENSATE RECEIVER WITHOUT LOW POINTS.
 - EXPANSION JOINT INSTALLED DIRECTLY ON PUMP SUCTION FLANGE.
 - SEE KIEWIT DWG: 94.03.62.125-PD-0001-001
SEE VENDOR DWG: 0920034533
 - THREADED HALF COUPLING TO BE INSTALLED DURING SHIPPING FOR THREAD PROTECTION. COUPLING MAY BE REMOVED AFTER PIPING INSTALLATION.