

live value setup
system variables \$SRC_GRP %SCR_GPR_T \$MCH_POS_ENB = TRUE Addressing : \$SCR_GRP[1].\$MCG_POS_X (last letter to be access data is needed for)

Register List (copy for each axis)
tool position (live x value at moment cal sensor activates flag (used to prevent multiple triqqers of sensor Diff (difference in unit position and tool position) unit position (actual location of calibration sensor from base)

Other Data
Uframe (this must be at 0,0,0 for calibration program) Utool (whatever Utool will be used for porgram) RP (data written here from program then to utool)

BG setup instructions
Menue/setup/setup2/BGlogic set Program you wish to run continuously

