

TriggerSource [Enum] R/W

Determines how an image frame is initiated within an acquisition stream.

Note



An acquisition stream must be started in order to trigger/receive individual frames. For *Freerun* and *FixedRate* the first frame is synchronized to *AcquisitionStart* trigger.

<i>Freerun</i>	[Default] Camera runs at maximum supported frame rate depending on the exposure time and region of interest size
<i>Line1</i>	External trigger <i>Line1</i>
<i>Line2</i>	External trigger <i>Line2</i>
<i>Line3</i>	External trigger <i>Line3</i>
<i>Line4</i>	External trigger <i>Line4</i>
<i>FixedRate</i>	Camera self-triggers at a fixed frame rate defined by <i>AcquisitionFrameRateAbs</i>
<i>Software</i>	Software initiated image capture