



## FAQ (Frequently Asked Questions)

**Q: Why is my RHS (driven side) auger not turning?**

**A:** There are u-joints and hex shaft assemblies as well as shear bolts in the center assembly. It is possible that a shear bolt broke, and things are just spinning inside the u-joint yoke. Inspect the center assembly and you will be able to see if the shear bolts are still intact.

**Q: Do you have replacement parts for the center assembly?**

**A:** Yes, we have center drive rebuild kits that include hex shafts and bolt in hubs. These are the components that will wear over time.

**Q: My drive motor is not working, what is the problem?**

**A:** It is tough to pinpoint the issue with a hydraulic motor without complete disassembly. If there has not been part failure anywhere else in the hydraulic system, a replacement motor will likely solve the problem.

**Q: Can I turn off the motor when I don't need to use the pea auger?**

**A:** There is no isolation valve to turn off the motor, but the hydraulic lines can be removed and coupled together to ensure that the system stays clean, then simply hook the canvas drive back to the factory position.

**Q: How does the speed of the auger change?**

**A:** The auger is plumbed in line with the canvas drive system. When the canvas speed is increased or decreased, the speed of the auger will change as well.

**Q: My auger is turning backwards, how do I fix this?**

**A:** Switch the hoses at the motor and it will turn the proper way.

Thank you again for purchasing your Pea Auger Kit



from Combine World. Any questions, please call us at **1-800-667-4515**.