

RR-4.14: REMOTE AIR THERMISTOR ASSEMBLY (pg 1 of 2)



Removal

1. Remove Enclosure Assembly ([RR-1.3](#)).
2. Remove Protective Wire Cover ([RR-2.7](#)).
3. Tilt Card Cage back ([RR-8.0](#)).
4. Remove Remote Air Thermistor Assembly:
 - a. Disconnect Remote Air Thermistor Assembly Cable from Motor Driver Board (P16).
 - b. Remove Remote Air Thermistor Assembly mounting screw.
 - c. Remove assembly.

Replacement

1. Install Remote Air Thermistor Assembly:
 - a. Place Remote Air Thermistor Assembly over mounting hole.
 - b. Secure assembly with mounting screw.
 - c. Connect Remote Air Thermistor Assembly Cable to Motor Driver Board (J16).
2. Reposition and secure Card Cage.
3. Install Protective Wire Cover.
4. Install Enclosure Assembly.

RR-4.14: Remote Air Thermistor Assembly (pg 2 of 2)

Verification

Perform MEIA Temperature Calibration
(VP-29).

