

VP-65: AVR SENSOR CHECK (pg 1 of 1)



Time: 5 minutes

Purpose: To verify that the AVR sensor operates properly

1. Place the AVR arm in the LOCKED (home) position.
2. Enter Dispense Hand Controls:
 - MONITOR
 - HND_CNTL
 - DISPENSE
3. Displayed AVR sensor status should be YYY.
4. Move AVR arm to UNLOCKED position. Displayed status should change to YYN. If display does not indicate correct AVR arm position, refer to [IP-87](#) for corrective actions.