

## RR-3.19 RETAINER CLIP ASSEMBLY

(pg 1 of 2)



### Removal

1. Remove Enclosure Assembly ([RR-1.3](#)).
2. Disconnect Retainer Clip Cable (P1) at LLS Board (J1):
  - a. Remove screw on upper left corner of LLS Board.
  - b. Slide LLS Board out to access connectors.
  - c. Disconnect Retainer Clip Connector (P1) at LLS Board.
3. Remove Retainer Clip:
  - a. Remove mounting screw.
  - b. Remove Retainer Clip.

### Replacement

1. Install Retainer Clip:
  - a. Place Retainer Clip over mounting holes in Boom Assembly.
  - b. Secure Clip with 2 mounting screws.
2. Connect Retainer Clip cable at LLS Board:
  - a. Connect Retainer Clip Connector (P1) at LLS Board (J1).
  - b. Slide LLS Board in place.
  - c. Install screw on upper left corner of LLS Board.

### Verification

Perform these procedures:

- Boom Check (VP-7)
- Level Sense Check (VP-11)
- Dispense Check (VP-13)
- MEIA Performance Panel (VP-47)

