



Removal

1. Remove Enclosure Assembly (RR-1.3).
2. Raise Display to upright position (RR-8.1.1).
3. Disconnect cable (P1) from side of Lamp Power Supply.
4. Disconnect Lamp High Voltage Cable from front of Lamp Power Supply.
5. Remove Lamp Power Supply:
 - a. Remove mounting screw.
 - b. Slide Power Supply right to remove.

Replacement

1. Install Lamp Power Supply:
 - a. Place Lamp Power Supply against sheet metal assembly.
 - b. Slide Lamp Power Supply left into notch.
 - c. Secure with mounting screw.
2. Connect Lamp High Voltage Cable at front of Lamp Power Supply.
3. Connect Cable (P1) at side of Lamp Power Supply.
4. Reposition and secure Display Assembly.
5. Install Enclosure Assembly.

RR-4.4: Lamp Power Supply (pg 2 of 2)

Verification

1. Update parameter 31.25 (MEIA LMP REF #) with R= value with lamp on and stabilized for approximately 10 minutes.
2. Perform MEIA Initialization Photo Calibration ([VP-27](#)).

