



### Removal

1. Remove Enclosure Assembly ([RR-1.3](#)).
2. Remove CPU and Digital I/O boards ([RR-7.1/7.10](#)).
3. Remove Card Cage Assembly:
  - a. Loosen both captive post screws on front of Card Cage.
  - b. Remove 2 hinge screws at base.
  - c. Remove cables from Card Cage.
  - d. Remove Card Cage Fan Power Cable from Main Power Supply.
  - e. Lift out Card Cage Assembly.



### Replacement

1. Install Card Cage Assembly:
  - a. Place Card Cage Assembly over base mounting holes.
  - b. Fasten Card Cage hinge to the base plate with 2 screws.
  - c. Connect cables to Card Cage.
  - d. Put cable back on Main Power Supply.
  - e. Secure both captive post screws at front of Card Cage.
2. Insert CPU and Digital I/O boards.
3. Install Enclosure Assembly.

### Verification

Perform Card Cage Adjustment ([VP-3](#)).

## RR-7.7: Card Cage Assembly (pg 2 of 3)



