



### Removal

1. Remove Enclosure Assembly ([RR-1.3](#)).
2. Disconnect printer cables and ground cable.
3. Remove cables from cable clamp.
4. Remove 4 printer mounting screws and Printer Assembly.

### Replacement

1. Place Printer Assembly over mounting holes; secure with 4 mounting screws.
2. Connect Printer Assembly cables and ground cable.
3. Secure cables in cable clamp.
4. Install Enclosure Assembly.

### Verification

1. Perform printer self test:
  - a. Turn power OFF.
  - b. Hold Printer Paper Feed Switch down and turn power ON.
  - c. Printout should include all characters repeatedly.
  - d. Turn power OFF to stop self test.
2. Perform Printer Test ([VP-41](#)).

## RR-6.3: Printer Assembly (pg 2 of 2)

