



Removal

1. Remove Enclosure Assembly (RR-1.3).
2. Remove Printer Assembly (RR-6.3).
3. Tilt back Card Cage (RR-8.0).
4. Disconnect Power Supply Cables and LLS Board cables.
5. Remove Power Supply:
 - a. Remove 4 mounting screws.
 - b. Disconnect Ground Cable.
 - c. Remove LLS Guideplate (2 screws).
 - d. Disconnect/remove LLS Board.
 - e. Remove Power Supply.
6. Remove Fan Baffle from Power Supply; set aside.

7. Remove bottom 2 mounting screws, then remove Baffle.

Replacement

CAUTION !

Ensure that no wires are pinched between the Power Supply and Base.

1. Set the Power Supply Voltage Selection Switch for 110V or 220V, as required.
2. Install Fan Baffle on new Power Supply:
 - a. Install Fan Baffle.
 - b. Secure with 2 bottom screws.
 - c. Install LLS Guideplate (2 screws) and LLS Board.

RR-6.13: Main Power Supply (pg 2 of 3)

Replacement (cont)

3. Install Power Supply:
 - a. Place Power Supply over mounting holes.
 - b. Connect Ground Cable.
 - c. Secure Power Supply with 4 mounting screws.
4. Connect Power Supply Cables and LLS Board cables.
5. Install Printer Assembly.
6. Reposition and secure Card Cage.

Verification

Perform these procedures in this order:

1. Power Supply Check ([VP-1](#))
2. Dispense Check ([VP-13](#))

RR-6.13: Main Power Supply (pg 3 of 3)

