

CHAPTER TABLE OF CONTENTS

Chapter overview	3- 2
Supplemental Tools/Supplies	3- 4
PL-1 Covers	3- 5
PL-2 Internal Covers	3- 8
PL-3 Front View	3- 11
PL-4 Optics	3- 14
PL-5 Pump	3- 17
PL-6 Printer/Main Power Supply	3- 19
PL-7 Card Cage	3- 22
PL-8 Analog/Motor Driver/Display	3- 24

PL-9	Ground Cable	3- 27
PL-10	VDE Covers	3- 29

WARNING !

Procedures to remove/replace items illustrated in this chapter require following biohazard, electrical hazard, and electrostatic discharge precautions.



CHAPTER OVERVIEW

This chapter provides:

- illustrations of parts of the LCx® Analyzer
- part numbers and descriptions
- cross-references to applicable Removal/Replacement procedures (RRs) in Chapter 4


This chapter provides exploded isometric views of all field spared parts or FRUs (field replacement units) and their configurations. Each part is indexed to the item number and description on the Parts List (PL).

Each parts list consists of two items: a listing of parts by number, and a drawing showing how each part is attached in the analyzer.

Determining RR numbers

Numbers for the RR procedures are based upon the part list and item number assigned to each part.

Example: RR 2.5 is the Removal & Replacement procedure for the item on Parts List PL-2, line item 5.



WARNING !

Tools must be decontaminated before and after servicing the analyzer.

Tools must be decontaminated before they are returned to the tool kit.

Decontaminate using procedures in [VP-60: Decontamination](#).

[Chapter
Contents](#)

[Manual
Contents](#)

[CD Main
Screen](#)

[Index](#)