

**1**

NXKR\_YoungSikYang

Exported on 02/27/2024

## Table of Contents

1	Driver Model .....	3
1.1	UCLASS_DRIVER and UCLASS_DEVICE .....	3
2	Device Tree.....	4
2.1	What is Device Tree? .....	4
2.2	Why Use Device Tree? .....	4
2.3	Device tree structure.....	5
3	FDT.....	6
3.1	What is Flattened Device Tree (FDT)? .....	6
3.2	Using fdt_get, fdt_set, fdt list.....	6
3.2.1	Intialization .....	6
4	menuconfig .....	9
4.1	Install dependencies.....	9
4.2	Run menuconfig.....	9
4.3	Exclude the i2c device driver.....	9
4.4	Exclude the i2c command .....	12
4.4.1	Uncheck the command line in menuconfig.....	12
4.4.2	Make a defconfig file and copy it to the configs directory.....	13
4.4.3	Delete the tmp folder for clean build before building the modified u-boot .....	13
4.4.4	Rebuild u-boot .....	14
4.5	Check if the i2c command was successfully excluded.....	14

# 1 Driver Model


- **Standardization:** The driver model in U-Boot aims to standardize the way in which hardware drivers are written and integrated. Each driver under this model has a standard set of functions. This helps in maintaining consistency across different hardware platforms.

## 1.1 UCLASS\_DRIVER and UCLASS\_DEVICE

These are 2 classes within the U-Boot Driver Model:

- **UCLASS\_DRIVER:**
  - This is an abstraction class of drivers that allows U-Boot to handle drivers of a similar kind in a uniform way, irrespective of the underlying hardware specifics.
  - Each driver class typically corresponds to a certain type of hardware functionality, like serial I/O, disk interfaces, etc.
- **UCLASS\_DEVICE:**
  - Refers to the actual devices that are instantiated based on the drivers(UCLASS\_DRIVER).
  - UCLASS\_DEVICE allows for the actual hardware-specific operations to be performed. It's where the physical device is managed, and it interacts with the UCLASS\_DRIVER to ensure the correct functioning of the hardware.
  - Each device under UCLASS\_DEVICE will be initialized according to the specifications of its corresponding UCLASS\_DRIVER.

## 2 Device Tree




### 2.1 What is Device Tree?

- **Hardware Description:** The Device Tree is a tree data structure where each node represents a hardware component in a system.
- **Formats:** The Device Tree can exist in two formats:
  - **Device Tree Source (DTS):** This is a human-readable and editable text file that describes the hardware.
  - **Device Tree Blob (DTB):** This is a binary file compiled from the DTS, used by the operating system or bootloader.

### 2.2 Why Use Device Tree?

- **Hardware Abstraction:** The Device Tree provides a way to abstract the hardware details. It allows the software to adapt to different hardware without needing changes in the code. It enables the addition of new hardware configurations without requiring modifications in the kernel source code.
- **Bootloader and Kernel Simplification:** The Device Tree simplifies the bootloader and kernel code by removing the need for hard-coded hardware information. This makes the code cleaner and more maintainable.
- **Device configuration parameters:** The Device Tree includes information about device parameters, interrupt lines, memory addresses, etc., which are crucial for the correct operation of the hardware.

## 2.3 Device tree structure



## 3 FDT

### 3.1 What is Flattened Device Tree (FDT)?

1. **Purpose of FDT:** The Flattened Device Tree, also called `Device Tree Blob (DTB)`, is a compact binary representation of the device tree. It's designed to be easily parsed by software, particularly by the bootloader, and the kernel.
2. **Structure:** The FDT is essentially a serialized version of the device tree in a format that is simpler for software to process.

### 3.2 Using `fdt_get`, `fdt_set`, `fdt list`

These commands are used in a bootloader or operating system that needs to interact with the FDT

#### 3.2.1 Initialization

**`fdt ddr [-c] <addr>`:** Set the fdt location to <addr>

```
bitminer# fdt addr -c
The address of the fdt is 0x4daa1800
bitminer# fdt addr 0x4daa1800
```

#### **`fdt list`**

This command is used to list the contents of the FDT.

```

bitminer# fdt list
/ {
    #address-cells = <0x00000001>;
    #size-cells = <0x00000001>;
    model = "Bitminer board based on Nexell s5p6818";
    cpu-model = "S5p6818";
    compatible = "nexell,bitminer", "nexell,s5p6818";
    chosen {
    };
    aliases {
    };
    memory {
    };
    mmc@c0069000 {
    };
    mmc@c0068000 {
    };
    mmc@c0062000 {
    };
    ethernet@c0060000 {
    };
    i2c@c00a4000 {
    };
    i2c@c00a5000 {
    };
    i2c@c00a6000 {
    };
    dp@c0102800 {
    };
    dp@c0102c00 {
    };
    usbhost@c0030000 {
    };
    dwc2otg@c0040000 {
    };
    gpio@c001a000 {
    };
    gpio@c001b000 {
    };
    gpio@c001c000 {
    };
    gpio@c001d000 {
    };
    gpio@c001e000 {
    };
    gpio@c0010800 {
    };
    pinctrl@c0010000 {
    };
    i2c_gpio@0 {
    };
    voltage-regulators {
    };
};

```

### fdt\_set

`fdt_set` is used to modify the FDT. This could involve changing a hardware configuration parameter before the kernel is booted.

```
fdt set / model "hi hello"
bitminer# fdt list
/ {
    #address-cells = <0x00000001>;
    #size-cells = <0x00000001>;
    model = "hi hello";
    ...
```

### fdt\_get

The `fdt get value` command is used to retrieve a property value from a node in the FDT and store it in a U-Boot environment variable.

```
bitminer# fdt get value my_model / model
bitminer# print my_model
my_model=hi hello
```



## 4 menuconfig

menuconfig is used to configure options of Linux, U-boot, etc

### 4.1 Install dependencies


```
sudo apt-get install libncurses5-dev
```


### 4.2 Run menuconfig

```
cd [workspace]/dunfell-bitminer/sources/boot/u-boot/u-boot-2016.01  
make menuconfig
```

### 4.3 Exclude the i2c device driver

This is done to test how to modify u-boot through menuconfig







This results in an error in the build.

## 4.4 Exclude the i2c command

### 4.4.1 Uncheck the command line in menuconfig






#### 4.4.2 Make a defconfig file and copy it to the configs directory.

```
make savedefconfig
cp defconfig ./configs/s5p6818_bitminer_defconfig
```

The i2c command is excluded in the build.

#### 4.4.3 Delete the tmp folder for clean build before building the modified u-boot



#### 4.4.4 Rebuild u-boot

```
bitbake u-boot-nexell
bitbake boot-binary
bitbake optee-build
```

#### 4.5 Check if the i2c command was successfully excluded

```
U-BootDRAM: 219 MiB
POFFHIS: NONE
PONHIS : PWRONPON
CHGS : CHG OFF
DCDC1 : 1250mV, En, dclim:1303026384, dclimsden:0
DCDC2 : 1200mV, En, dclim:1303026384, dclimsden:0
DCDC3 : 3300mV, En, dclim:1303026384, dclimsden:0
DCDC4 : 1500mV, En, dclim:1303026384, dclimsden:0
DCDC5 : 1500mV, En, dclim:1303026384, dclimsden:0
MMC: NEXELL DWMMC: 0
In: serial
Out: serial
Err: serial
Net:
Warning: ethernet@c0060000 (eth0) using random MAC address - 86:e2:d9:ef:ec:60
eth0: ethernet@c0060000
Hit any key to stop autoboot: 0
bitminer#
bitminer#
bitminer#
bitminer#
bitminer#
bitminer# i2c
Unknown command 'i2c' - try 'help'
```