



User MANUAL

Car Control

Team 5

Ahmed Salama

Ahmed Emad

Ahmed Barakat

Seif Habib

Farah Samir

Ezz El Gaby

September 2020

USER'S MANUAL

TABLE OF CONTENTS

	<u>Page #</u>
A. GENERAL INFORMATION.....	A-1
1.1 System Overview	A-1
B. GETTING STARTED.....	B-1
2.1 Setting the Car in Forward Mode.....	B-1
2.2 Setting the Car in Reverse Mode	B-1
2.3 Setting the Car Direction	B-1
2.3 Moving the Car.....	B-2
2.3 Setting the Car in Res Mode.....	B-3
C. Appendix.....	C-1

1.0 GENERAL INFORMATION

A. GENERAL INFORMATION

1.1 System Overview

A remote-controlled car:

- Five modes: Rest, Forward (Speed 1, Speed 2, Speed 3), Reverse.
- Two directions: Left and Right.
- Four different buttons to control the car, Gear(G), Move(M), Left(L) and Right(R).
- Two motors to run the car.
- Operational status:
 - Fully Operation

2.0 GETTING STARTED

B. GETTING STARTED

The car is initially at rest.

2.1 Setting Car in Forward Mode

- Press button G to initiate first speed.
- Press on button G to change speeds, each press upgrades to the next speed, there are three speeds.

2.2 Setting Car in Reverse Mode

- Press on button G after reaching last and third speed to set the car in reverse mode.

2.3 Setting the Car Direction

- Set the car in forward mode.
- Press on button L or R to set the direction of the car to left or right.
- The car can only turn right or left in speed 1, no matter which speed is set.

2.4 Moving the Car

- To move the car, press and hold button M.
- To stop the car, release button M, car is still in the same mode.

2.5 Setting the Car in Rest Mode

- Press on button G when in reverse mode to go back to rest mode.

3.0 APPENDIX

C. APPENDIX

Buttons


