


## Manual

33505 Receiver GR-12S HoTT

33506 Receiver GR-12 HoTT



### CONTENTS:

<b>1. General Note .....</b>	<b>01</b>
<b>2. Functions.....</b>	<b>01</b>
2.1. Binding.....	01
2.2. Binding Multiple Receivers .....	01
2.3. Fail-Safe Function.....	02
<b>3. Receiver .....</b>	<b>02</b>
3.1. Connections .....	02
3.2. Low Voltage Warning .....	02
3.3. Temperature Warning .....	03
<b>4. Firmware Update.....</b>	<b>03</b>
4.1. Receiver .....	03
4.2. Update Procedure.....	03
<b>5. Declaration of Conformity.....</b>	<b>05</b>
<b>6. FCC Information.....</b>	<b>06</b>
<b>7. Warranty .....</b>	<b>08</b>

Thank you for purchasing the Graupner HoTT 2.4 System Please read through this entire manual before you attempt the installation and usage of your Graupner HoTT 2.4 System!

These operating instructions are part of this product. They contains important notes to the operation and handling. Please take this into consideration when you pass on the product to third parties. Neglect of the operating instructions and the safety instructions lead to expiring the warranty.

Graupner constantly work on the advancement of all remote control systems; changes of the scope of delivery in form, technology and equipment we must reserve ourselves therefore. Please have understanding for the fact that from data and illustrations of this operating instructions no requirements can be derived. *Please keep these instructions for further reference!*

## 1. GENERAL NOTE

When switching on or adjusting the radio control system it is essential to keep the transmitter aerial at least 15 cm away from the receiver aerials at all times. If the transmitter aerial is too close to the receiver aerials, the receiver will be overloaded, causing the green LED starts flashing. The transmitter responds by emitting a beep once every second; the red LED also goes out. The radio control system is now in Fail-Safe mode.

If this should occur, simply increase the distance between the aerials until the audible warning signal ceases, and the red LED on the transmitter lights up again; at the same time the green LED on the receiver should glow constantly.

## 2. FUNCTIONS

### 2.1. Binding

When you wish to use the Graupner HoTT 2.4 GHz receiver with a particular transmitter, the first step must always be to "bind" the unit to "its" Graupner HoTT 2.4 GHz RF module (transmitter). This "binding" procedure only needs to be carried out once for each combination of receiver and RF module. The units supplied in the set are already bound to each other at the factory, i.e. the binding procedure described in the following section only needs to be carried out when you wish to use an additional receiver. However, it can also be repeated at any time if required, e.g. after changing transmitters. When binding is required, this is the procedure:

- Switch the transmitter and receiver on.
- Locate the BIND / RANGE button on the back of the transmitter, and hold it pressed in while you press and hold the SET button on the receiver. Both LEDs on the back of the transmitter now glow constantly, and the green LED on the receiver flashes.
- If the green flashing LED on the receiver begins to glow permanently within about ten seconds, this indicates that the binding process is complete. You can now release both buttons, and your transmitter / receiver combination is ready for use.
- However, if the green LED on the receiver continues to flash for longer than ten seconds, then the binding process has failed. If this should occur, repeat the whole procedure.

### 2.2. Binding "multiple receivers in one model"

If required, it is also possible to bind multiple receivers to the transmitter for a particular model. The first step is to bind each receiver individually using the procedure already described.

When the system is in use, the receiver which was bound last is the Master receiver. Any telemetry sensors installed in the model must be connected to this unit, as only the Master receiver transmits sensor data using the downlink channel. The second and all further receivers operate in parallel with the Master receiver but in Slave mode, with the downlink channel switched off.

The control functions can also be distributed amongst multiple receivers; this is carried out using the Channel Mapping function of the SMART-BOX (Order No. 33700). In the same way it is possible to assign one control function to multiple receiver outputs; a typical example would be the use of two servos for each aileron instead of only one, etc.


### 2.3. Fail-Safe function

In its default state (as delivered) the receiver is set to “Hold” mode, i.e. if a fail-safe situation occurs, all the servos connected to it maintain the last position detected as valid. In this mode the green LED on the receiver starts flashing when interference occurs, and the red LED on the transmitter goes out. The transmitter also starts beeping about once per second as an audible warning.

You can exploit the safety potential of the fail-safe option by at least programming the throttle channel to respond to a fail-safe situation: the throttle channel of an engine-powered model should be set to idle, the throttle channel of an electric-powered model to “stop”, and the throttle channel of a model helicopter to “Hold”. If interference should occur, these settings will help prevent the model flying out of control, possibly causing personal injury or property damage.

*Please refer to the appropriate section in your RC system instructions for the procedure.*

## 3. RECEIVER



### 3.1 Connections

Plug the servos into the row of sockets on the right-hand end of the receiver. The connector system is polarised; note the small chamfer on one edge. Never use force - the plugs should engage easily and fully. The socket polarity is also marked on the case: brown wire (-), red (+) and orange (signal).

The servo sockets of the Graupner-HoTT 2.4 receiver are numbered. The socket marked “- +/B” is intended for the battery. If necessary, a servo can be connected to this socket in parallel with the power supply; a Y-lead (Order No. 3936.11) is required for this.


It is also possible to program channel 6 for the sum signal using the SMART-BOX (Order No. 33700). This is important for certain optional devices which require this signal.

### Power supply for receiver 33506

When using High Power servos, connect the receiver power supply/s preferably to the vertical ports of the receiver. If necessary, the servos can be connected to this sockets in parallel with the power supply; a Y-lead (Order No. 3936.11) is required for this.

When using a dual power supply, use the sockets on the outside:

Receiver 33506 (GR-12): Channel 1 and 6 (or 2 and 5)



The socket marked “5” - channel 5 - is intended for the optional telemetry sensors and is used for loading firmware updates in conjunction with the USB interface. When using the receiver GR-12S (Order No. 33505) the adapter cable Order No. 23048 is also needed.

**Note: to use the telemetry function of channel 5, select the telemetry menu SETTING AND DATA VIEW of the transmitter or Smart-Box, go to the Display „RX CURVE“ and “5CH FUNCTION” and select „SENSOR“ instead of „SERVO“.** With telemetry sensors connected to socket 5, servos will not longer work at this output! As standard the servo function is enabled on channel 5 - „SERVO“

displayed.

### 3.2. Low voltage warning

If the receiver voltage falls below 3.8 V, the transmitter's RF module generates a low voltage warning in the form of a "general alarm sound": a steady beeping at intervals of about one second.

### 3.3. Temperature warning


If the receiver temperature falls below -10° C or exceeds +70° C, the transmitter's RF module generates a temperature warning in the form of a "general alarm sound": a steady beeping at intervals of about one second.

## 4. FIRMWARE UPDATE GRAUPNER-HOTT 2.4 RECEIVER 33505 / 33506

Firmware updates for the transmitter RF module or receiver can be transferred via the DATA or telemetry interface in conjunction with a PC running Windows XP, Vista or 7. For this you also require the USB interface, Order No. 7168.6, and the adapter lead, Order No. 7168.6A, which are available separately. When using the receiver GR-12S (Order No. 33505) the adapter cable Order No. 23048 is also needed.

The programs and files required for this are available from [www.graupner.de](http://www.graupner.de) in the Download area for the corresponding products.

Install the Firmware Update Utility Graupner and the USB drivers on your computer. Check the system requirements!



The first step is to cut through the central red wire in the adapter lead, Order No. 7168.6A, then connect the lead to the USB interface, Order No. 7168.6. This socket is also polarised; note the small chamfer on one edge. Never use force - the plug should engage easily and fully.

### 4.1. Receiver



Receiver GR-12 (Order No. 33506):

Connect the adapter lead to the socket Channel 5 of the receiver, as shown in the illustration. This socket is also polarised; note the small chamfer on one edge. Never use force - the plug should engage easily and fully.


The black wire (-) must be on top, the white wire (T) down.

Receiver GR-12S (Order-No. 33505): the adapter cable Order No. 23048 is also needed.

### 4.2. Update procedure

Ensure that the adapter lead is configured as shown in the illustrations, and is connected correctly to the transmitter or receiver.

Start the Graupner Firmware Update Utility.



Under [COM Port Setup] select the correct COM port, i.e. the one to which the USB lead is connected. If you are not sure of this, press the button „Search“ and select in the pop-up window „Silicon Labs CP210x USB to UART Bridge“ and press „OK“.

Baud Rate: 19200.

Under [Interface Type] click on Signal 2:Vcc3:Gnd.


Now click on the „Browse“ button and select the folder containing the previously loaded firmware file ending in \*.bin. If everything is correct, the file will appear in the corresponding window.

The firmware files are encoded in product-specific form, i.e. if

you accidentally select a file which does not match the product (e.g. transmitter update file instead of receiver file), then the pop-up window “Product code error” will appear, and you will not be able to start the update procedure.

Press the “Program” button in the software. Wait briefly until you see movement in the progress bar. This may take up to five seconds, depending on the computer.


**Receiver:** press the SET button, and switch the receiver on while you hold it pressed in.



After a few seconds the Status screen displays the message “Found target device...”; you can now release the button, and the firmware update process commences.

If the device is not recognised, if the pop-up window “Target device ID not found” appears, or if the process fails before 100% is reached, you must restart the update procedure. Repeat all the steps as described above.

The Status display and the Progress bar show the progress of the firmware update. The update is completed when the message “Complete...100%” or “Complete!!” appears.



During the update process both LEDs on the transmitter glow constantly. When it is complete, the red LED goes out and you will hear a brief confirmation melody. The green LED on the receiver also light up; when the process is complete, the green LED starts flashing.

Switch your transmitter / receiver off, and disconnect the adapter lead.

**Caution:** after completing an update process, you must initialise the device before using it, i.e. reset it to the factory default values.

### Initialisation:

Press and hold the SET button on the receiver, switch it on, and release the SET button again. After about two or three seconds the green LED on the receiver lights up to confirm that your radio control system has been re-initialised.

### Please note:

The initialisation procedure erases ALL the settings you have entered. Where necessary, you will need to program your preferred settings again.

When initialisation is complete, the transmitter will be in Fail-Safe set-up mode. You can therefore immediately continue by programming your fail-safe settings.

If you previously set your transmitter's Country setting to “France” mode, you must also re-enter the Country setting.

*Please refer to the appropriate section in your RC system instructions for the procedure.*

**Any settings you have entered using the SMART-BOX are also lost when you initialise the receiver. If you carry out a receiver firmware update, you will need to re-enter these settings.**

## DECLARATION OF CONFORMITY

**Konformitätserklärung gemäß dem Gesetz über Funkanlagen und  
Telekommunikationsendeinrichtungen (FTEG) und der Richtlinie 1999/5/EG (R&TTE)**  
Declaration of Conformity in accordance with the Radio and Telecommunications Terminal Equipment  
Act (FTEG) and Directive 1999/5/EG (R&TTE)

Graupner GmbH & Co. KG  
Henriettenstraße 94-96  
D-73230 Kirchheim/Teck

erklärt, dass das Produkt:  
declares that the product

**mx-12 HoTT - No. 4754, mx-16 HoTT - No. 4755,  
GR-12S HoTT - No. 33505, GR-12 HoTT - No. 33506,  
GR-16 HoTT - No. 33508, GR-24 HoTT - No. 33512,  
GR-32 HoTT - No. 33516**

Geräteklasse:  
Equipment class

**2**

den grundlegenden Anforderungen des § 3 und den übrigen einschlägigen Bestimmungen des  
FTEG (Artikel 3 der R&TTE) entspricht.  
complies with the essential requirements of § 3 and the other relevant provisions of the FTEG (Article 3 of the  
R&TTE Directive).

Angewendete harmonisierte Normen:  
Harmonised standards applied

**EN 60950:2006**

Gesundheit und Sicherheit gemäß § 3 (1) 1. (Artikel 3 (1)a)  
Health and safety requirements pursuant to § 3 (1) 1. (Article 3 (1) a)

**EN 301 489-1 V1.7.1  
EN 301 489-3 V1.4.1**

Schutzanforderungen in Bezug auf elektromagnetische  
Verträglichkeit § 3 (1) 2, Artikel 3 (1) b))  
Protection requirement concerning electromagnetic compatibility  
§ 3 (1) 2, Artikel 3 (1) b))

**EN 300 328 V1.7.1**

Maßnahmen zur effizienten Nutzung des Frequenzspektrums  
§ 3 (2) (Artikel 3 (2))  
Measures for the efficient use of the radio frequency spectrum  
§ 3 (2) (Article 3 (2))



Kirchheim, 08. Dezember 2010

Stefan Graupner, Geschäftsführer  
Stefan Graupner, Managing Director

**Graupner GmbH & Co. KG Henriettenstraße 94-96 D-73230 Kirchheim/Teck Germany**  
Tel: 07021/722-0 Fax: 07021/722-188 Email: [info@graupner.de](mailto:info@graupner.de)

## **FCC INFORMATION**

Graupner GR-12S and GR-12 HoTT #33505 and #33506

FCC ID: ZKZ-33505 and ZKZ-33506

### **FCC Label Compliance Statement**

This device complies with Part 15C of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

### **WARNING:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **NOTE**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15C of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **RF Exposure Statement**

This device has been evaluated to meet the FCC RF exposure requirement when used in combination with the genuine Graupner HoTT accessoires and operated with a minimum distance of 20 cm between the antenna and your body.

## ENVIRONNEMENTAL PROTECTION NOTES



When this product comes to the end of its useful life, you must not dispose of it in the ordinary domestic waste. The correct method of disposal is to take it to your local collection point for recycling electrical and electronic equipment. The symbol shown here, which may be found on the product itself, in the operating instructions or on the packaging, indicates that this is the case.



Individual markings indicate which materials can be recycled and re-used. You can make an important contribution to the protection of our common environment by re-using the product, recycling the basic materials or recycling redundant equipment in other ways.

Remove batteries from your device and dispose of them at your local collection point for batteries.

In case of R/C models, you have to remove electronic parts like servos, receiver, or speed controller from the product in question, and these parts must be disposed of with a corresponding collection point for electrical scrap.

If you don't know the location of your nearest disposal centre, please enquire at your local council office.



Garantie von  
warrantied for  
garantie de **24** Monaten  
months  
mois

Die Fa. Graupner GmbH & Co. KG, Henriettenstraße 94-96, 73230 Kirchheim/Teck gewährt ab dem Kaufdatum auf dieses Produkt eine Garantie von 24 Monaten. Die Garantie gilt nur für die bereits beim Kauf des Produktes vorhandenen Material- oder Funktionsmängel. Schäden, die auf Abnutzung, Überlastung, falsches Zubehör oder unsachgemäße Behandlung zurückzuführen sind, sind von der Garantie ausgeschlossen. Die gesetzlichen Rechte und Gewährleistungsansprüche des Verbrauchers werden durch diese Garantie nicht berührt. Bitte überprüfen Sie vor einer Reklamation oder Rücksendung das Produkt genau auf Mängel, da wir Ihnen bei Mängelfreiheit die entstandenen Unkosten in Rechnung stellen müssen.

Graupner GmbH & Co. KG, Henriettenstraße 94-96, 73230 Kirchheim/Teck, Germany guarantees this product for a period of 24 months from date of purchase. The guarantee applies only to such material or operational defects which are present at the time of purchase of the product. Damage due to wear, overloading, incompetent handling or the use of incorrect accessories is not covered by the guarantee. The user's legal rights and claims under guarantee are not affected by this guarantee. Please check the product carefully for defects before you make a claim or send the item to us, since we are obliged to make a charge for our cost if the product is found to be free of faults.

La société Graupner GmbH & Co. KG, Henriettenstraße 94-96, 73230 Kirchheim/Teck, Allemagne, accorde sur ce produit une garantie de 24 mois à partir de la date d'achat. La garantie prend effet uniquement sur les vices de fonctionnement et de matériel du produit acheté. Les dommages dus à de l'usure, à de la surcharge, à de mauvais accessoires ou à d'une application inadaptée, sont exclus de la garantie. Cette garantie ne remet pas en cause les droits et prétentions légaux du consommateur. Avant toute réclamation et tout retour du produit, veuillez s.v.p. contrôler et noter exactement les défauts ou vices.

**Servicestellen / Service / Service après-vente**

Graupner-Zentralservice  
Graupner GmbH & Co. KG  
Henriettenstrasse 94-96  
D-73230 Kirchheim / Teck

Servicehotline  
☎ (+49) 01805 47 28 76  
Montag - Freitag 7:30 - 11:45  
und 12:30 - 16:00 Uhr

Belgie/Nederland  
Jan van Mouwerik  
Slot de Houvelaan 30  
NL 3155 Maasland VT  
☎ (+31)10 59 13 59 4

Luxembourg  
Kit Flamang  
129, route d'Arion  
L 8009 Strassen  
☎ (+35) 23 12 23 2

Ceska Republika/Slovenská Republika  
RC Service Z. Hnizdil  
Letecka 666/22  
CZ-16100 Praha 6 - Ruzyně  
☎ (+42) 2 33 31 30 95

Schweiz  
Graupner Service Schweiz  
CD-Electronics GmbH  
Kirchweg 18  
CH-5614 Sarmentorf  
☎ (+41) 56 66 71 49 1

Espana  
Anguera Hobbies  
C/Terrassa 14  
E 43206 Reus (Tarragona)  
☎ (+34) 97 77 55 32 0

Sverige  
Baltechno Electronics  
P.O. Box 5307  
S 40227 Göteborg  
☎ (+46) 31 70 73 00 0

France  
Graupner Service France  
Gérard Altmayer  
86, rue St. Antoine  
F 57601 Forbach-Oeting  
☎ (+33) 3 87 85 62 12

UK  
Graupner Service UK  
Brunel Drive  
GB, NEWARK, Nottinghamshire  
NG242EG  
☎ (+44) 16 36 61 05 39

Italia  
GiMax  
Via Manzoni, no. 8  
I 25064 Gussago  
☎ (+39) 30 25 22 73 2

**Garantie-Urkunde**

Warranty certificate / Certificate de garantie

33505 Receiver GR-12S  
33506 Receiver GR-12

Übergabedatum  
Date of purchase/delivery  
Date de remise

Name des Käufers  
Owner's name  
Nom de l'acheteur

Straße, Wohnort  
Complete address  
Domicile et rue

Firmenstempel und Unterschrift  
des Einzelhändlers  
Stamp and signature of dealer  
Cachet de la firme et signature  
du détaillant

[illegible]

[illegible]



Graupner GmbH & Co. KG  
Henriettenstraße 94 – 96  
D-73230 Kirchheim/Teck  
Germany  
[www.graupner.de](http://www.graupner.de)

Änderungen sowie Liefermöglichkeiten vorbehalten. Lieferung durch den Fachhandel. Bezugsquellen werden nachgewiesen. Für Druckfehler kann keine Haftung übernommen werden.

Specifications and availability subject to change. Supplied through specialist model shops only. We will gladly inform you of your nearest supplier. We accept no liability for printing errors.

Sous réserve de modifications et de possibilité de livraison. Livraison uniquement au travers de magasins spécialisés en modélisme. Nous pourrions vous communiquer l'adresse de votre revendeur le plus proche. Nous ne sommes pas responsables d'éventuelles erreurs d'impression.

Con riserva di variazione delle specifiche e disponibilità del prodotto. Fornitura attraverso rivenditori specializzati. Saremmo lieti di potervi indicare il punto vendita più vicino a voi. Si declina qualsiasi responsabilità per errori di stampa.