



SM1000S

Installation and Operation Manual



CAMBRIDGE TECHNOLOGY INC.

SM1000S Installation and Operation Manual

© Cambridge Technology Inc. September 2013

Cambridge Technology Inc. is a registered trademark.

P/N: P0900-0137

Rev: D

Cambridge Technology, Inc. International Headquarters

125 Middlesex Turnpike

Bedford, MA 01730

Tel: +1-781-266-5700

Fax: +1-781-266-5114

E-mail: scanners@cambridgetechnology.com

Cambridge Technology Europe Headquarters

Munchener Strasse 2a

D-82152 Planegg

Germany

Tel: +49-89-31707-0

Fax: +49-89-31707250

E-mail: scanners-europe@camtech.com

Cambridge Technology Asia Headquarters

1F, NOF Kanda Iwamoto-cho Bldg,

3-8-16, Iwamoto-cho

Chiyoda-ku, Tokyo 101-0032, Japan

Tel: +81 (3) 5825-8853

Fax: +81 (3) 5825-8858

E-mail: scanners-asia@camtech.com

Website: <http://www.camtech.com/>

Table of Contents

IMPORTANT INFORMATION AND DELIVERY	1
Product Overview.....	1
Related Documentation	1
About This Operating Manual.....	2
Safety during Installation	2
Operational Guidelines and Standards	2
Electrical Ratings	3
Environmental Specifications.....	3
Laser Safety	4
Laser Shutter	4
ESD Warning	5
Unpacking	6
Warranty Information.....	6
Customer Support.....	6
 INTRODUCTION	 7
 PRINCIPLES OF OPERATION.....	 9
 INSTALLATION AND OPERATION	 12
System Overview	12
Mechanical	13
Electrical Connections	14
AC Power	14
Scan-head Power	15
J7 - Analog Command (Optional)	15
J6 – XY2-100 Digital Command	16
Connections and Signal Descriptions	17
Clock	17
Sync	17
X, Y, & Z Data	17
Status Data.....	18
Test Operation.....	19

J13 - Mark-on-the-Fly.....	20
J16 – Status	21
J9 – Laser 1.....	22
J21 – Laser 2.....	23
J22 – Interlock and Auxiliary Control.....	25
J10 – User I/O	28
J17 – Auxiliary Digital Inputs	30
J8 - Auxiliary Digital Outputs.....	31
J12 – COM1 RS-232.....	32
J14 & J15 – Auxiliary COM Ports.....	32
J20 – Ethernet and J18 & J19 – USB.....	33
 OPERATION	 34
Power-Up	34
Status	36
Logging In.....	36
Change Settings.....	37
Running Stored Jobs.....	39

List of Tables

<i>Table 1 Scan-head Power.....</i>	<i>15</i>
<i>Table 2 J7: Analog Command Signal Pin Assignment</i>	<i>16</i>
<i>Table 3 J6/J11: XY2-100 Signal Pin Assignments</i>	<i>16</i>
<i>Table 4 XY2-100 Control Bit Definitions</i>	<i>18</i>
<i>Table 5 XY2-100 Status Bits</i>	<i>19</i>
<i>Table 6 Mark-on-the-Fly Signal Pin Assignments.....</i>	<i>20</i>
<i>Table 7 System Status Signal Pin Assignments.....</i>	<i>21</i>
<i>Table 8 J9 Signal Pin Assignments.....</i>	<i>22</i>
<i>Table 9 J21 Laser 2 Signal Pin Assignment.....</i>	<i>24</i>
<i>Table 10 Interlock and Auxiliary Control Signal Pin Assignments</i>	<i>25</i>
<i>Table 11 J10: User I/O Signal Pin Assignments.....</i>	<i>28</i>
<i>Table 12 J17: Auxiliary Extended Digital Input Signal Pin Assignments.....</i>	<i>30</i>
<i>Table 13 J8: Auxiliary Extended Digital Output Signal Pin Assignments.....</i>	<i>31</i>
<i>Table 14 J12: COM1 Signal Pin Assignments.....</i>	<i>32</i>
<i>Table 15 COM2 & COM3 Signal Pin Assignments.....</i>	<i>32</i>

List of Figures

<i>Figure 1 Basic SM1000 Configuration</i>	<i>8</i>
<i>Figure 2 SM100 Mechanical Layout</i>	<i>13</i>
<i>Figure 3 SM1000S Rear Panel.....</i>	<i>14</i>
<i>Figure 4 Single-ended vs. Differential Voltage</i>	<i>15</i>
<i>Figure 5 XY2-100 Signal Timing.....</i>	<i>18</i>
<i>Figure 6 Mark-on-the-Fly Signal Conditioning</i>	<i>20</i>
<i>Figure 7 Figure Status Signal Conditioning</i>	<i>21</i>
<i>Figure 8 Laser 1 Control Signal Conditioning</i>	<i>23</i>
<i>Figure 9 Laser 1 Digital Data Signal Conditioning</i>	<i>23</i>
<i>Figure 10 Interlock Signal Conditioning</i>	<i>26</i>
<i>Figure 11 Laser Power Supply Control.....</i>	<i>26</i>
<i>Figure 12 Laser Shutter Control</i>	<i>27</i>
<i>Figure 13 User Output Signal Conditioning</i>	<i>29</i>
<i>Figure 14 User Input Signal Conditioning</i>	<i>29</i>
<i>Figure 15 Auxiliary Extended Digital Input Signal Conditioning</i>	<i>30</i>
<i>Figure 16 Auxiliary Extended Digital Output Signal Conditioning</i>	<i>31</i>

Important Information and Delivery

Product Overview

Congratulations and thank you for purchasing a Cambridge Technology SM1000 Scan-system controller. The configuration you have received can be identified by the label found on the rear of the product. The label identifies the model name, part number and serial number.

This manual covers the standard SM1000S system.

Related Documentation

The ScanMaster documentation set (in addition to this manual) includes the following:

Part No.	Name & Description
N/A	ScanMaster Designer (SMD) online help <i>The primary information source for the SMD software user interface</i>
P0900-0156	ScanMaster Designer User Manual <i>Guide to the SMD software user interface in book format</i>
P0900-0151	ScanMaster API Reference Manual <i>Guide and reference to the ScanMaster Application Programming Interface</i>
P0900-0135	EC1000 Software Reference Manual <i>Software programming API for the EC1000 Scan System Control Board</i>
P0900-0134	EC1000 Hardware Reference Manual <i>Product description, installation, operation, and troubleshooting for the EC1000 Scan System Control Board</i>

About This Operating Manual

Please read these instructions carefully before installing and operating the SM1000. If there are any questions regarding the contents of this manual, please contact Cambridge Technology Inc. Keep the manual available for servicing, repairs and product disposal. This manual should accompany the product if ownership changes hands. Cambridge Technology Inc. reserves the right to update this operating manual at any time without prior notification.

Safety during Installation

The SM1000 is designed to work with Cambridge Technology Scan Heads and high-power lasers. To reduce the risk of injury, please observe the laser safety guidelines suggested in this section. Where possible, the Cambridge Technology Scan Head should be inter-connected for software shut down of the laser. This will ensure safety during operation, error or recovery of the scan head. In all cases, we recommend that you fully enclose and interlock the zone of hazard for your application to prevent possible beam deflections while the laser is energized.

Refer to ANSI Z136.1 to determine what protective equipment is required. At no time should you stare into the beam, place any parts of your body in the beam path, or expose yourself to reflections of powerful beams. You should use a Class 1 HeNe Laser for alignment. If this is not possible, you should use the available laser's lowest power. Using optical instruments with this product increases eye hazard. Additional Safety requirements may be applicable during initial alignment of the optical system. Final analysis of the system should be performed by a Laser Safety Officer, or a competent specialist in this field.

Operational Guidelines and Standards

When operating the SM1000, the following guidelines and standards apply:

- EC-Guideline 73/23/EWG — Low Voltage Guidelines
- EC-Guideline 89/336/EWG — Electromagnetic compatibility (including revision 92/31/EWG)
- EC-Guideline 89/392/EWG — Machine Guidelines (including revisions 91/368/EWG and 93/44/EWG)
- EN 60825 Laser Equipment Safety, Part 1 (1994): — Classification of Equipment, Requirements, and User Guidelines (VDE 0836)
- EN 60204 Electrical Equipment Part 1: General Requirements (June, 1993) — Complying with the Relevant Standards for the CE Label.

In addition, a technical survey of laser safety requirements can be found in ANSI Z136.1, "American National Standard for the Safe Use of Lasers". This is available from:

American National Standards Institute, Inc.
1430 Broadway
New York, NY 10018

www.ansi.org

Among the many other sources of laser safety information, the following institution offers several excellent publications:

The Laser Institute of America
5151 Monroe Street, Suite 118W
Toledo, OH 43623

www.laserinstitute.org

NOTE: The SM1000 is delivered as an OEM component for integration into a laser scanning system. The system manufacturer bears responsibility for complying with the standards and guidelines required for the CE label. Please contact Cambridge Technology Inc. for further information about this product and applicable guidelines.

Electrical Ratings

100 – 240VAC, 50/60 Hz

5 A

Environmental Specifications

10 to 40 C (operating)

0 to 50 C (shipping)

10% to 90% R.H. (non-condensing)

Laser Safety

Please read all operating instructions completely before installing and using the SM1000 system.



Laser Radiation: Do not stare directly into a laser beam. Follow all system laser safety requirements during installation and operation. Cambridge Technology recommends the use of a shutter to prevent unwarranted emission of laser radiation, where practical.

Use of controls, adjustments, or procedures other than those specified in this manual without consulting a competent safety professional may result in component damage, and/or exposure to potential hazards. Always follow established industrial safety practices when operating equipment.

This system is designed to be operated in conjunction with a laser. Therefore, all applicable rules and regulations for safe operation of lasers must be known and applied when installing and operating the system. Since Cambridge Technology Inc. has no influence over the employed laser or the overall system, the customer is solely responsible for the laser safety of the entire system.


Laser Shutter

The scan head may have no shutter and no device to decrease the laser output power. Because each laser is unique, it is the responsibility of the user to include such a device as required.

CFR 1040.10 [f] [6] states: "A beam attenuator is required on Class II, IIIa, IIIb and IV laser systems. The beam attenuator is a mechanical or electrical device such as a shutter or attenuator that blocks emission. The beam attenuator blocks bodily access to laser radiation above Class I limits without the need to turn off the laser. The beam attenuator must be available for use at all times during operation. Power switches and key controls do not satisfy the attenuator requirement." Please refer to CFR 1040.10 for additional information.

The beam shutter should be installed between the laser and the Scan Head. The following figure shows the recommended location of the shutter. It also shows the laser's internal and external optical path towards the target plane, specifically the location of the hazard zone as the optical beam passes through the scan head.

We strongly recommend that you specify a laser with a vendor-supplied shutter mechanism. If this is not possible, consult the laser vendor to design a proper safety shutter.



ESD Warning



The electronics that Cambridge Technology manufactures - including the SM1000 controller - are electrostatic discharge (ESD) sensitive. Improper handling could therefore damage these electronics. Proper handling is required.

Cambridge Technology has implemented procedures and precautions for handling these devices and we encourage our customers to do the same. Upon receiving your components, you should note that it is packaged in an ESD-protected container with the appropriate ESD warning labels. The equipment should remain sealed until you are located at a proper static control station.

A proper static control station should include:

- A soft grounded conductive tabletop or grounded conductive mat on the tabletop.
- A grounded wrist strap with the appropriate (1 Meg) series resistor connected to the tabletop mat and ground.
- An adequate earth ground connection such as a water pipe or AC ground.
- Conductive bags, trays, totes, racks or other containers used for storage.
- Properly grounded power tools.
- Personnel handling ESD items should wear ESD protective garments and ground straps.

Note: Any equipment returned to the factory must be shipped in anti-static packaging.

Unpacking

The package you received includes those items listed on the packing list.

- Carefully unpack the contents from the box.
- Save the shipping container and packaging material in case you need to return a unit for service.
- Protect the SM1000 from contaminants.
- Check contents of the box against the packing list to ensure all parts were received.
- Inspect each item to ensure it was not damaged during shipment.

Warranty Information

The Customer shall examine each shipment within 10 days of receipt and inform Cambridge Technology of any shortage or damage. If no discrepancies are reported, we shall assume the shipment was delivered complete and defect free. Cambridge Technology warrants products against defects up to 1 year from manufacture date, barring unauthorized modifications or misuse. Repaired product is warranted 90 days after the repair is made, or one year after manufacture date - whichever is longer.

Contact Customer Service at +1-781-541-1600 to obtain a Return Materials Authorization (RMA) number before returning any product for repair.

All orders are subject to the Cambridge Technology Terms and Conditions and Limited Warranty. Contact your local sales office for the latest version of these documents and other useful information.

IMPORTANT: Customers assume all responsibility for maintaining a laser-safe working environment. OEM customers must assume all responsibility for CDRH (Center for Devices and Radiological Health) certification.

Customer Support

Cambridge Technology has support services to address your questions or concerns with either the product or the manual you are using. Before calling for assistance, be sure to refer to any appropriate sections in the manual that may answer your questions. Call Cambridge Technology's Customer Service Department at +1-781-541-1600. Hours are Monday through Friday between 8 A.M. and 5 P.M. local time (GMT -05:00 Eastern Time (US & Canada)). Customer service personnel will be able to give you direct assistance and answers to your questions. See the [Copyright](#) page for International, European and Asian contact information.

Introduction

The Cambridge Technology SM1000 is an integrated subsystem that contains:

- A Cambridge Technology EC1000 Ethernet based scan-system control module
- Dual power supplies capable of driving a Cambridge Technology scan head
- A touch panel display to facilitate local stand-alone operation and administration
- A connector panel for distributing the EC1000 function-specific control signals to industry standard D-Sub style for connectors.

An SM1000 subsystem can control one or two (2- or 3- axis) scan heads that use the industry standard XY2-100 serial digital protocol. Analog command output is available as an option. Standard cable connectors are provided for IPG Photonics, YLP series and SPI Lasers, G3 series lasers, with other laser types supported through custom cabling configurations.

Outputs are provided to programmatically control laser power supply sequencing with key-switch/interlock protection, and laser shutter mechanism drive and state detection. In addition there are sixteen undedicated bits of optically-isolated inputs and outputs, and two RS232 serial ports to facilitate communication with a PLC or other automation equipment.

Mechanically, the SM1000 is designed as a 2U high half-rack with enclosure suitable for installation in automation equipment racks or for use on a lab bench.

The following diagram shows a typical SM1000 configuration for a fiber laser.




Figure 1 Basic SM1000 Configuration

Principles of Operation

The SM1000 internally uses the CTI EC1000 controller to provide scan-head, laser and local user interface control. It can be run stand-alone, or in conjunction with a PC via an Ethernet connection. PC based software uses a CTI supplied Application Programming Interface (API) to facilitate communication with, and control of the EC1000 module. The API is explained in detail in the *EC1000 Software Reference* manual supplied as part of the ScanMaster Software Suite installation CD.

Jobs are prepared offline using CTI's ScanMaster Designer software or by user developed custom software based on the ScanMaster high-level API or the base-level EC1000 API. A simple editor (EC1000 MiniEditor) supplied on the ScanMaster Software Suite CD is designed to illustrate the capabilities of the EC1000. This can also be used to develop some types of jobs. Jobs can be tested by streaming them to the SM1000, and then once satisfied with the results, can be saved to Flash memory in the SM1000, or to an external USB Flash memory stick attachable to a USB device socket on the front or rear of the SM1000.

Installation and Operation

System Overview

A basic galvo based laser system using a SM1000 controller is comprised of the following components:

- Laser
- Laser Power Supply
- Beam Expander (depending on laser)
- Scan-head
- F-theta Focusing Lens and Lens Spacer
- System Controller (SM1000) — providing scan head power and sends synchronized signals to the laser and the scan head
- Grid Calibration File — resident in the SM1000
- PC or Laptop — to control/program the SM1000 Controller
- Basic Cables
 - SM1000 → Laser
 - SM1000 → Scan Head signal and power (CTI 6016-9P-xxx, 6016-9D-xxx)
xxx = length in inches
 - SM1000 → PC workstation or laptop (Ethernet)
 - Laser Power Supply → Laser
- Optional Cables
 - SM1000 → Shutter mechanism

- SM1000 → Laser DC Power control relay
- SM1000 → System interlocks

Mechanical

Mechanically, the SM1000 is designed as a 2U high half-rack width enclosure suitable for installation in automation equipment racks or for use on a lab bench. The following figure shows the dimensions and mounting-hole locations.




Figure 2 SM100 Mechanical Layout

Electrical Connections

The rear panel of the SM1000 presents connectors that expose all of the features of the unit. The connectors are assigned in functional groups to facilitate system cabling. Industry standard D-Sub connectors are used where possible because of their high reliability, low-cost, and wide availability.

The picture below shows the back panel connectors and their function. In the following set of figures, each connector is defined in detail illustrating the signal names, internal signal conditioning provided by the SM1000, and expected user connectivity.






Figure 3 SM1000S Rear Panel

AC Power



The SM1000 uses a standard IEC AC power socket to introduce power to the unit. An AC power cord suitable for use in the USA is provided with the system. AC Input requirements are 100 – 240V AC 50/60Hz. Maximum power consumed is 815 Watts.

Scan-head Power



The SM1000 provides DC power for a single scan-head unit via a female 4-pin AMP CPC connector. Pre-fabricated scan-head power cables of various lengths are available from CTI. The part numbers of these cables are of the form 6016-9P-xxx where xxx defines the length in inches of the cable. Please contact your CTI sales for available lengths.

Pin	Signal
1	+ PWR
2	GND
3	-PWR
4	CHASSIS

Table 1 Scan-head Power

J7 - Analog Command (Optional)



Analog command signals for a scan-head are available via a 25P-D connector. The output voltages for X, Y, and Z axes are available as differential (Diff) signals or as ground-referenced single-ended (SE) signals. The output range is

programmable as:

+/-2.5V SE (+/-5V Diff), +/-5V SE(+/-10V Diff), +/-10V SE(+/-20V Diff)

The relationship between SE and Diff voltages is illustrated in the following diagram:




Figure 4 Single-ended vs. Differential Voltage

Signal assignments are as follows:

Pin	Signal	Pin	Signal
1-3, 6-9, 14-16, 18-19	N/C	20	ENA-X
4, 10-11	AGND	21	ENA-Y
5, 17	+Z, -Z	22	RDY-Y
12, 24	+Y, -Y	23	RDY-X
13, 25	+X, -X		


Table 2 J7: Analog Command Signal Pin Assignment

The command signals present 20 Ohm source impedance and can drive +/-30 mA.

The ENA signals are 5V TTL compatible and are software programmable

The RDY signals are 5V TTL compatible and can be programmed to cause software event alerts on either assertion level.

J6 – XY2-100 Digital Command



Command signals to a scan-head can be transmitted digitally using the industry standard XY2-100 protocol available via 25P-D connectors. The SM1000 has two such connectors referred to as J11 – XY2-100 – E, and J6 – XY2-100 both of which support the standard 3-axis command protocol. The same vector command stream is used for both ports with separate distortion correction tables for each.

Signal assignments are as follows:



Pin	Signal	Pin	Signal
1	-CLK	14	+CLK
2	-FS	15	+FS
3	-DATA-X	16	+DATA-X
4	-DATA-Y	17	+DATA-Y
5	-DATA-Z	18	+DATA-Z
6	-STATUS	19	+STATUS
7	Reserved	20	Reserved
8 - 13	N/C	21 - 25	N/C

Table 3 J6/J11: XY2-100 Signal Pin Assignments

The XY2-100 Serial Link (also known as Serial Link 1 and XYZ-100) is a synchronous TIA/EIA-422-B differential digital interface for the communication of three 16-bit position words and a single 16-bit status word for two- and three-axis servo applications.

Connections and Signal Descriptions

A male DB-25 connector is used for the position data generator, female for the position data receiver, and may optionally include differential power as shown in the accompanying diagram. If a separate DB-9 is used for power, its gender should be opposite that of the data connector and wired as shown. Signaling is differential 3.3-5V TIA/EIA-422-B. Sync and data are sampled on the falling edge of the clock and must observe a 50ns setup and 50ns hold. The voltage of a logical "1" is $V_{+LINE} > V_{-LINE}$.

	<p>Serial Link: DB-25.</p> <p>CK: clock, 2MHz nominal</p> <p>SYNC: indicates start of 20-bit data word</p> <p>XCH: 20-bit X-axis data send</p> <p>YCH: 20-bit Y-axis data send</p> <p>ZCH: 20-bit Z-axis data send</p> <p>STATOUT: 20-bit status return</p>
	<p>Power: DB-9. Used when power is not integrated into the Serial Link connection.</p>

Clock

The Clock is transmitted by the position data generator, 20 cycles per frame. Its nominal frequency is 2MHz.

Sync

The frame Sync is a single logical "0" pulse, once per frame, transmitted by the position data generator one clock cycle prior to the first bit of the frame.

X, Y, & Z Data

The X, Y, & Z Data are three 20-bit serial data streams consisting of a 3-bit control code, one 16-bit position word (unsigned, MSB first), and a parity bit (even parity).




Figure 5 XY2-100 Signal Timing

Improper control codes, parity error, or a missing sync on the 21st clock cycle will cause the position data word for the affected channel to be discarded. As the following table shows, the only supported control code is 001.

Control Bits [2:0]	Function
0 0 0	Reserved
0 0 1	16-bit position data follows
0 1 0	Reserved
0 1 1	test (reserved)
1 x x	18-bit Serial Link 2 data follows (odd parity, reserved)

Table 4 XY2-100 Control Bit Definitions

Status Data

The Status Data is a 20-bit serial data stream consisting of a 3-bit control code, one 16-bit status word, and a parity bit (even parity). CTI products latch the Status received from the Scan Head on the falling edge of the 2MHz CLK.

Status data bits are shown in the following table:

Bit	2-axis status
C2	0
C1	1
C0	1
S15	Power Status
S14	Temperature Status
S13	In-field
S12	X Position Acknowledge
S11	Y Position Acknowledge
S10	1
S9	0
S8	1
S7	Power Status
S6	Temperature Status
S5	In-field
S4	X Position Acknowledge
S3	Y Position Acknowledge
S2	1
S1	0
S0	1
Par	x (no parity)

Table 5 XY2-100 Status Bits

Test Operation

If the position data receiving hardware supports a test mode, data for the selected axis will be echoed in the status data with the test control word.

J13 - Mark-on-the-Fly



Mark-on-the-Fly (MOTF) patterning is supported through the use of digital quadrature input signals from an external encoder attached to a conveying system. The SM1000 demodulates the quadrature signal and compensates for a moving object by directly integrating the positional changes into the position and motion of the scan-head

galvos.

Quadrature signaling rates up to 12.5 MHz are supported.

Pin	Signal	Pin	Signal
1	MOTFA_POS	6	MOTFA_NEG
2	MOTFB_POS	7	MOTFB_NEG
3	INTLOCK2_POS	8	INTLOCK2_NEG
4	+5V_FUSED	9	GND
5	MOTFZ_POS		

Table 6 Mark-on-the-Fly Signal Pin Assignments




Figure 6 Mark-on-the-Fly Signal Conditioning

J16 – Status



System status and synchronization signals are available at connector J16. Optically isolated output signals indicate job execution status and optically isolated inputs provide synchronization for starting a job based on external conditions.

Pin	Signal	Pin	Signal
1	ERROR_POS	6	BUSY_POS
2	MRKINPRG_POS	7	JOBACTIVE_POS
3	STRTMRK_NEG	8	STATUS_VPOS
4	+5V_FUSED	9	STATUS_GND
5	GND		

Table 7 System Status Signal Pin Assignments




Figure 7 Figure Status Signal Conditioning

J9 – Laser 1



Laser connector J9 is an IPG YLP compatible connector suitable for direct connection to an IPG YLP laser with a type “B” interface. Signals on this connector are 5V TTL compatible and are also suitable for connection to other

laser devices, but custom cabling may be required. Please see your laser manual for additional details. Some signals on this connector are shared with signals on connector J21.

Pin	SM1000 Signal	IPG Signal	Pin	SM1000 Signal	IPG Signal
1	D0_BUF	D0	14	LASERFPK ¹	GND
2	D1_BUF	D1	15	N/C	GND
3	D2_BUF	D2	16	USERIN2_NEG	ALRMSTAT1
4	D3_BUF	D3	17	+5V_FUSE	AUX_5V
5	D4_BUF	D4	18	LASERENABLE	MO
6	D5_BUF	D5	19	LASERON1	PA
7	D6_BUF	D6	20	LASERMOD1	PRR
8	D7_BUF	D7	21	USERIN1_NEG	ALRMSTAT0
9	LASERMOD2	DLATCH	22	LASERON2	GUIDE
10	GND	GND	23	EMERGSTOP	EMERGSTOP
11	GND	GND	24	GND	GND
12	GND	GND	25	LASERRSRVD ²	RESRVD
13	GND	GND			

¹LASERFPK is enabled as an option on this pin via a zero Ohm jumper resistor

²LASERRSRVD is enabled as an option on this pin via a zero Ohm jumper resistor

Table 8 J9 Signal Pin Assignments




Figure 8 Laser 1 Control Signal Conditioning




Figure 9 Laser 1 Digital Data Signal Conditioning

J21 – Laser 2




signals on this connector are shared with connections on J6.

Laser connector J21 is an SPI G3 HS compatible connector suitable for direct connection to an SPI G3 laser. Some

Pin	SM1000 Signal	SPI Signal	Pin	SM1000 Signal	SPI Signal
1	N/C	N/C	35	N/C	N/C
2	N/C	SEED LASER FIRE	36	N/C	GND_ISOD
3	USERIN2_POS	SEED LASER T FLT	37	USERIN2_NEG	GND_ISOD
4	N/C	N/C	38	N/C	N/C
5	LASERON1	LASER EM GATE H	39	GND	LASER EM GATE L
6	LASERON2	ALIGN LASER EN H	40	GND	ALIGN LASER EN L
7	LASERENABLE	GLOBAL EN H	41	GND	GLOBAL EN L
8	N/C	BASE PLATE T FLT	42	GND	GND_ISOD
9	N/C	PRE-AMP CUR FLT	43	GND	GND_ISOD
10	N/C	PWR-AMP CUR FLT	44	N/C	GND_ISOD
11	N/C	BEAM COLM FLT	45	N/C	GND_ISOD
12	N/C	RSRVD FLT	46	N/C	GND_ISOD
13	LASERMOD1	EXT PULSE TRIG H	47	GND	EXT PULSE TRIG L
14	USERIN1_POS	LASER READY	48	USERIN1_NEG	GND_ISOD
15	INTLOCK3_POS	LASER DISABLE H	49	GND	LASER DISABLE L
16	N/C	PWR SUP FLT	50	GND	GND_ISOD
17	D0_BUF	STATE SEL BIT 0	51	D4_BUF	STATE SEL BIT 4
18	D1_BUF	STATE SEL BIT 1	52	D5_BUF	STATE SEL BIT 5
19	D2_BUF	STATE SEL BIT 2	53	N/C	STATE SEL BIT 6
20	D3_BUF	STATE SEL BIT 3	54	N/C	STATE SEL BIT 7
21	D7_BUF	PULSE/CW MODE H	55	GND	PULSE/CW MODE L
22	N/C	INT FREQ REF	56	N/C	GND_ISOD
23	N/C	N/C	57	N/C	N/C
25	N/C	5V FOR FAST OPTOS	58	N/C	0V FOR FAST OPTOS
25	2RS232_TXD2	RS-232 TX	59	GND	GND_RS
26	2RS232_RXD2	RS-232 RX	60	GND	GND_RS
27	N/C	N/C	61	N/C	N/C
28	N/C	GND_AN	62	N/C	BASE TEMP MON
29	N/C	GND_AN	63	N/C	PWR-AMP CUR MON
30	ANA_GND	GND_AN	64	AOUT2P	PWR_AMP SIMMER
31	ANA_GND	GND_AN	65	AOUT1P	PWR-AMP SETPNT
32	N/C	GND_AN	66	N/C	PRE-AMP CUR MON
33	N/C	N/C	67	N/C	N/C
34	N/C	N/C	68	N/C	N/C

Table 9 J21 Laser 2 Signal Pin Assignment

J22 – Interlock and Auxiliary Control



Interlock signals may be introduced into the SM1000 for the purpose of terminating galvo and laser activity in the case of emergency or operator safety intervention. If configured properly in software, an interlock break can generate a software event which can be used by an application to alert a user to take appropriate recovery action.

NOTE: Use of these signals is for system integration convenience, not as a substitute for full safety interlock handling.

The interlock connectors also provide access to auxiliary functions that can be used by an integrator. Programmable laser shutter and power supply control, and key-switch detection are supported. See the figures following the signal table for details on how to use these signals.

Section	Pin	Signal	Purpose
A	1	INTLOCK2_POS	General purpose usage
	2	INTLOCK2_NEG	
	3	INTLOCK3_POS	Laser interlock (emergency stop). Short together to enable lasers connected to J9 or J21
	4	GND	
B	1	+APWR	Laser power supply relay
	2	INTLOCK1_NEG, RELAY_SINK	
	3	LASER_KEY_POS	Laser power supply enable key
	4	LASER_KEY_NEG	
C	1	+APWR	Shutter actuator
	2	INTLOCK4_NEG, ACTUATOR_SINK	
	3	SHUTTER_KEY_POS	Shutter key-switch
	4	SHUTTER_KEY_NEG	
D	1	USERIN0_POS	Shutter state sensing
	2	USERIN0_NEG	
	3	+5V_FUSED	
	4	GND	

Table 10 Interlock and Auxiliary Control Signal Pin Assignments

The mating connectors are 3M Series 371 2.00MM IDC Wiremount Mini-Clamp type. Part number 37104-2124-000 FL 100 is suitable.






Figure 10 Interlock Signal Conditioning



AC Relay is rated for 1A.

Figure 11 Laser Power Supply Control



AC Relay is rated for 1A.

Figure 12 Laser Shutter Control

J10 – User I/O



The user I/O connector provides access to the standard digital I/O signals and to the auxiliary analog output ports.

Pin	Signal	Pin	Signal
1	+5V_FUSED	14	USEROUT4_POS
2	USEROUT3_POS	15	USEROUT2_POS
3	USEROUT1_POS	16	USEROUT_PWR
4	+5V_FUSED	17	USEROUT_COM
5	GND	18	GND
6	+5V_FUSED	19	ANALOG_GND
7	AOUT1P	20	ANALOG_GND
8	AOUT2P	21	GND
9	USERIN4_NEG	22	USERIN3_NEG
10	USERIN2_NEG	23	USERIN1_NEG
11	USERIN_COM	24	+5V_FUSED
12	GND	25	GND
13	+5V_FUSED		

Table 11 J10: User I/O Signal Pin Assignments




Figure 13 User Output Signal Conditioning




Figure 14 User Input Signal Conditioning

J17 – Auxiliary Digital Inputs



The auxiliary digital input connector provides access to sixteen additional bits of isolated digital inputs.

Pin	Signal	Pin	Signal
1	EXTIO_DIN0	14	EXTIO_DIN1
2	EXTIO_DIN2	15	EXTIO_DIN3
3	EXTIO_DIN4	16	EXTIO_DIN5
4	EXTIO_DIN6	17	EXTIO_DIN7
5	EXTIO_DIN_COM	18	EXTIO_DIN_GND0
6	EXTIO_DIN8	19	EXTIO_DIN9
7	EXTIO_DIN10	20	EXTIO_DIN11
8	EXTIO_DIN12	21	EXTIO_DIN13
9	EXTIO_DIN14	22	EXTIO_DIN15
10	EXTIO_DIN_COM	23	EXTIO_DIN_GND1
11	+5V_FUSED	24	GND
12	+5V_FUSED	25	GND
13	N/C		

Table 12 J17: Auxiliary Extended Digital Input Signal Pin Assignments




Figure 15 Auxiliary Extended Digital Input Signal Conditioning

J8 - Auxiliary Digital Outputs



The auxiliary digital output connector provides access to sixteen additional bits of isolated digital outputs.

Pin	Signal	Pin	Signal
1	EXTIO_DOUT0	14	EXTIO_DOUT1
2	EXTIO_DOUT2	15	EXTIO_DOUT3
3	+5V_FUSED	16	GND
4	EXTIO_DOUT4	17	EXTIO_DOUT5
5	EXTIO_DOUT6	18	EXTIO_DOUT7
6	EXTIO_DOUT_PWR0	19	EXTIO_DOUT_GND0
7	EXTIO_DOUT8	20	EXTIO_DOUT9
8	EXTIO_DOUT10	21	EXTIO_DOUT11
9	+5V_FUSED	22	GND
10	EXTIO_DOUT12	23	EXTIO_DOUT13
11	EXTIO_DOUT14	24	EXTIO_DOUT15
12	EXTIO_DOUT_PWR1	25	EXTIO_DOUT_GND1
13	N/C		

Table 13 J8: Auxiliary Extended Digital Output Signal Pin Assignments




Figure 16 Auxiliary Extended Digital Output Signal Conditioning

J12 – COM1 RS-232



The SM1000 provides three RS-232 serial ports for specialized and general purpose usage. COM1 is generally reserved for attaching a QTERM J10 terminal. This terminal can be used to manipulate the functions of the SM1000 if use of the touch panel is not convenient.

The COM1 port is equivalent to the COM1 port on a PC from the signaling perspective.

Pin	Signal	Pin	Signal
1	DCD	6	DSR
2	RXD	7	RTS
3	TXD	8	CTS
4	DTR	9	RI
5	GND		

Table 14 J12: COM1 Signal Pin Assignments

J14 & J15 – Auxiliary COM Ports

COM2 COM3




1..6 1..6

There are two additional COM ports available for general purpose use. These are referred to as COM2 and COM3. These ports can be accessed via the Remote Control Protocol described in the *EC1000 Software Reference Manual*. The connectors accept an RJ11 telephone connector cord which can be used in conjunction with an RJ11 to 9P-D adaptor to connect to standard equipment. L-Com part number RA096F and Monoprice.com part number 1150 are suitable adaptors.

RJ11 Pin	Signal	DB-9M Pin	L-Com RA096F wire color
1	N/C		
2	TXD	2	Black
3	GND	5	Red
4	GND		
5	RXD	3	Yellow
6	N/C		

Table 15 COM2 & COM3 Signal Pin Assignments

J20 – Ethernet and J18 & J19 – USB



The primary means of communications between the SM1000 and the outside world is via a standard 100Base-T Ethernet port. This port is auto-negotiating to permit direct PC-to-SM1000 connections as well as hub or switch based connections.

The USB connector can be used to attach an external mouse or keyboard, or for attaching a USB Flash memory device to upload jobs or to provide extended job storage. A second USB port is provided on the front panel and serves the same purpose. Both ports may be active simultaneously with different devices attached, however two Flash storage devices are not supported.


Operation

The SM1000 has an integrated touch panel interface that can be used for local administration and job control. The interface is comprised of a set of menu pages that are selected via button push. The menu pages are organized by major function:

- Status — (The main page)
- Login
- Settings
- Job Control

Power-Up


Upon powering up, you will see the following screen:



This screen shows that the EC1000 is booting up and the operating system is functioning. After a short time, the following screen appears:



This screen indicates that the local user interface program has started and is waiting for the EC1000 server software to finish initializing. When this is done, the following screen appears:




This screen appears when the EC1000 is fully booted. It indicates that the utility is in a suspended mode where it will remain until local interaction is required.

This mode permits remote PC connection and control of the SM1000 without requiring operator intervention to enable it. Note that in the upper left hand corner, the "Friendly Name" of the SM1000, in this example "MY CONTROLLER" and the IP address (192.168.100.1) that is in use by the SM1000 are shown. The IP address may have been assigned by a DHCP server, or may be statically assigned. This can be controlled via the *Settings* screen.

If you press the **Resume** button, the screen will change as shown in the following illustration:

Status



This screen is the main *Status* screen which indicates:

- The SM1000 “Friendly Name”
- The IP address
- Which host has control of the box
- Current job execution status

Along the bottom are buttons that allow you to transition to other screens.

Logging In

The *Login* screen is used to set the access privileges for the interface. There are two access privileges:

- Administrator
- Operator

You must log in to run any locally stored jobs. Both administrators and operators can select and run jobs.

To login, press the **Login** button, and the following screen appears:




This screen allows you to login as an administrator by pressing the **Admin** button or as an operator by pressing the **Operator** button.

In this example, the administrator is logging in. By default, the administrator and operator passwords are set to the 6 character string "000000". These passwords should be changed if security is an issue in the installation and use of the system. This can be done via the remote administration tool provided with the EC1000 API software.

After entering the password and pressing the **OK** button, you will return to the *Status* screen and now the **Jobs** button will be enabled.

Change Settings

To change the network settings, press the **Settings** button on the *Status* screen and the following screen appears:



You can change the network configuration and node name of the SM1000 via this screen.

There are two buttons that switch between automatic IP addressing via a DHCP server and static IP addressing. In this example, the **Obtain IP address automatically** button is highlighted because that is the current configuration


If you want to switch to a fixed IP address, then press the **Use the following IP address** button. The screen will change so that the address parameters are high-lighted as shown below

The parameter can be changed by just touching the white strip that contains the text of the parameter. When you do this, a pop-up text editor will appear as shown below on the left. Use the keypad buttons to enter the new information.

The **Node Name** can be changed in a similar way, but the popup will appear differently as shown on the right.


When all of the changes are made, press the **OK** button on the *Settings* screen and this will cause the changes to be written to Flash memory. This will take several seconds after which, the following dialog box appears. You should press the **Yes** button. The SM1000 will then

automatically reboot with the new parameters applied. **NOTE:** These settings can also be changed using the remote administration tool provided with the EC1000 API software.



Running Stored Jobs

After logging in as either an operator or administrator, you can access the *Job* screen to select and run locally stored jobs. When you press the **Job** button, the following screen appears.



The list box displays all of the jobs found stored in local Flash memory on the SM1000. If a USB flash device is plugged in, then jobs stored there will also be displayed.

A job is selected by touching the name of the job. The selected job can then be run by pressing the **Run Once** or **Run Loop** button.

Run Once will run the job a single time. If a job has looping constructs built into it, the job may run forever or for a finite number of iterations. If a job is constructed for a single execution, then it can be looped by pressing the **Run Loop** button.

Job execution can be stopped at any time by pressing the **Stop** button. [End of document]

CAMBRIDGE TECHNOLOGY
SM1000S INSTALLATION AND OPERATION MANUAL



CAMBRIDGE TECHNOLOGY
SM1000S INSTALLATION AND OPERATION MANUAL



