


# system\_error\_monitor should have less "ERROR" messages #4018

**felixf4xu** started this conversation in **General**

 **felixf4xu** on Nov 26, 2023

These are some error messages during my planning-simulation, if a system has so many errors, there might be serious problems.

```
[system_error_monitor-16] [ERROR] [1700965291.544590469] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544624346] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544634743] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544642016] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544649370] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544656283] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544663005] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544670499] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544680279] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544687866] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544731837] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544741977] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544748662] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544755354] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544762738] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544769052] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544786409] [system_er
[system_error_monitor-16] [ERROR] [1700965291.544792889] [system_er
```

I did nothing but continue to set the current vehicle pose, and the goal potions, then the system continues to run, without any problem.

This is strange to me as to the ERROR design:

When there is an **ERROR**, something needed to be done before the system can continue to run.

If the system can run without any error correction operations, should they be just **INFO**?

Category

## General

## Labels

None yet


1 participant

1 comment

Oldest

Newest

Top

 **felixf4xu** on Nov 26, 2023 Author

```
[system_error_monitor-16] [ERROR] [1700965291.544649370]  
[system_error_monitor  
/autoware/planning/node_alive_monitoring/topic_status/topic_state_mo  
nitor_mission_planning_route: planning_topic_status]: [Single Point  
Fault]: OK
```

There is an error but the error message is **OK**? It's very confusing.

↑ 1

0 replies