



10.3. BEEPER INTENSITY

bPr

The beeper intensity can be adjusted from 0-10. 0 is off, 1 is a small, infrequent chirp and a 10 is a frequent, loud beep. The factory default is 4. If you have multiple pits, this feature is useful for distinguishing one pit from another, by giving each one a unique beep duration.

10.4. OPEN LID DETECT

This feature will allow quick recovery to the setpoint temperature after the lid is opened. When the

open lid is set to **oLy** (open lid yes), open lid detect is enabled. When the lid is opened, the temperature will drop. This can cause the blower to over-fire the coals and cause overshoot when the lid is shut. This mode detects when the pit's lid is open and minimizes the blower running during that time. Some overshoot will always be present when the pit's lid is opened and closed even if the blower

is off, because it still introduces oxygen to the fire. The factory default is **oLy**, so disable this feature if there are problems with excess air currents in the pit. To disable this feature, set it to