


Important Note:

Some Azimuth rotors doesn't include the C1 capacitor in the external rotor, so it must be added and connected at J1-2 and J1-8 terminals of the ARS-USB Unit



Yaesu control unit replacement - 5400/5600	
TITLE: RCI_USB_Yaesu_5400	
Document Number:	REV:
Date: 26/02/2013 20:38:48	Sheet: 1/1