



***Multimeter/Clamp Meter
Communication Protocol
Version 2.6***

***Created by Carlos Chu
2016/2/16***

Table of Contents

Chapter 1: Basic Configure

Applicable Models	1
UART Configure	1
Basic Communication Format	2
Command Code	2

Chapter 2: Command Format

0x00: Read information	3
0x01: Read display	3
0x10: Read calibration	4
0x1A: Read EEPROM	4
0x1B: Read harmonics	5
0x80: Enter calibration mode	6
0x85: Write function code	6
0x87: Write range code	7
0x8A: Write EEPROM	7
0x8F: Exit calibration mode	8

Chapter 3: Data Format

Model Name	9
Series Number	9
Display Data (main display, sub display)	9
Display Data (Datalog, Memory)	10
Calibration Data	10

Chapter 4: Table

Table 1: Word code	11
Table 2: Status 0 (Scope code)	12
Table 3: Status 1 (main display, sub display)	13
Table 4: Status 2 (Datalog, Memory)	13
Table 5: Rotary code	14
Table 6: Function code	15
Table 7: Range code (506/506B)	16
Table 8: Range code (208/208B)	17
Table 9: Range code (150/150B)	18
Table 10: EEPROM Map (506/506B/208/208B)	20
Table 11: EEPROM Map (150/150B)	21

Table of Contents

Applicable Models

Company	Model Name	Model ID
APPA	150	00001
	150B	00002
	208	00003
	208B	00004
	506	00005
	506B	00006

UART Configure

Baud Rate	9600 bps
Data Bits	8 Bits
Stop Bits	1 Bit
Parity	No Parity

Basic Communication Format

Start 0	Start 1	Command Code	Data Length	Data	Checksum
---------	---------	--------------	-------------	------	----------

Start 0 & 1: The start bytes are both 0x55

Command Code: This byte is the command code

Data Length: This byte is the length of data

Data: Transfer data of UART packet

Checksum: This byte is sum of all data array without carry

Command Code

Command Code	Operation	PC to Meter Data Length	Meter to PC Data Length
0x00	Read information	0 byte	52 bytes
0x01	Read display	0 byte	12 bytes
0x10	Read calibration	0 byte	23 bytes
0x1A	Read EEPROM	4 byte	1 to 64 bytes
0x1B	Read harmonics	0 byte	50 bytes
0x80	Enter calibration mode	0 byte	0 byte
0x85	Write function code	1 byte	0 byte
0x87	Write range code	1 byte	0 byte
0x8A	Write EEPROM	1 to 64 bytes	0 byte
0x8F	Exit calibration mode	0 byte	0 byte

Note: the 0x85, 0x87, 0x8A, 0x8F command code have to command in calibration mode.

Command Format

● 0x00: Read information

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x00	0x00	N/A	0xAA

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x00	0x34	See Below	??

Data String [0...31]: Model Name [0...31], ASCII code format

Data String [32...47]: Serial Number [0...15], ASCII code format

Data String [48, 49]: Model ID [0, 1]

Data String [50, 51]: Firmware Version [0, 1]

● 0x01: Read display

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x01	0x00	N/A	0xAB

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x01	0x0C	See Below	??

Data String [0]: Function code

Data String [1]: Range code

Data String [2...6]: Main display data [0...4]

Data String [7...11]: Sub display data [0...4]

● 0x10: Read calibration

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x10	0x00	N/A	0xBA

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x10	0x17	See Below	??

Data String [0]: Rotary code

Data String [1]: Function code

Data String [2...6]: Main display data [0...4]

Data String [7...10]: Original data 1 [0...3], 32-bit signed integer, LSB to MSB

Data String [11...14]: Original data 2 [0...3], 32-bit signed integer, LSB to MSB

Data String [15...18]: Offset data [0...3], 32-bit signed integer, LSB to MSB

Data String [19...22]: Gain data [0...3], 32-bit signed integer, LSB to MSB

● 0x1A: Read EEPROM

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x1A	0x04	See Below	0xAB

Data String [0]: Device Number

Data String [1, 2]: EEPROM Address [0, 1], LSB to MSB

Data String [3]: Data Length, max 64 bytes

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x1A	n	See Below	??

Data String [0...n-1]: Data of EEPROM, LSB to MSB

- **0x1B: Read harmonics**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x1B	0x00	N/A	0xC5

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x1B	0x32	See Below	??

Data String [0,1]: H1_LSB,H1_MSB

Data String [2,3]: H2_LSB,H2_MSB

...

Data String [48,49]: H25_LSB,H25_MSB

Example:

 $H_1 = H1_LSB + H1_MSB \ll 16$ $H_n = Hn_LSB + Hn_MSB \ll 16$ $H_n\% = H_n / H_1 * 100\%$

$$THD = \frac{\sqrt{H_2^2 + H_3^2 + \dots + H_{25}^2}}{H_1} \times 100\%$$

Note: if the mode is not HARMONICS mode when rotary switch in V / A / FlexA, the meter will return the error command: 0x55, 0x55, 0x70, 0x00, 0x1A

- **0x80: Enter calibration mode**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x80	0x00	N/A	0x2A

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	See Below	0x00	N/A	??

Note: If the command code is 0x7F, the command accept by meter. If the code is 0x70, the command is invalid.

- **0x85: Write function code**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x85	0x01	See Below	??

Data String [0]: Function code

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	See Below	0x00	N/A	??

Note: If the command code is 0x7F, the command accept by meter. If the code is 0x70, the command is invalid.

● **0x87: Write range code**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x87	0x01	See Below	??

Data String [0]: Range code

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	See Below	0x00	N/A	??

Note: If the command code is 0x7F, the command accept by meter. If the code is 0x70, the command is invalid.

● **0x8A: Write EEPROM**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x8A	4+n	See Below	??

Data String [0]: Device Number

Data String [1, 2]: EEPROM Address [0, 1], LSB to MSB

Data String [3]: Data Length, max 64 bytes

Data String [4...n+3]: Data, max 64 bytes

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	See Below	0x00	N/A	??

Note: If the command code is 0x7F, the command accept by meter. If the code is 0x70, the command is invalid.

- **0x8F: Exit calibration mode**

PC to Meter

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	0x8F	0x00	N/A	39

Meter to PC

Start 0	Start 1	Command Code	Data Length	Data	Checksum
0x55	0x55	See Below	0x00	N/A	??

Note: If the command code is 0x7F, the command accept by meter. If the code is 0x70, the command is invalid.

Data Format

- **Model Name: 32-byte ASCII string**

Data LSB					Data MSB
A	P	P	A	...	
0x41	0x50	0x50	0x41	...	0x20

Default is a null string, all byte are 0x20.

- **Series Number: 16-byte ASCII string**

Data LSB					Data MSB
0	1	2	3	...	
0x30	0x31	0x32	0x33	...	0x20

Default is a null string, all byte are 0x20.

- **Display Data (main display, sub display): 5-byte**

Data LSB				Data MSB
Reading			Status 0	Status 1

Reading: 24-bit signed integer, LSB to MSB. If the range of reading is 0x700000 to 0x7FFFFF, then the reading is a word code, else is a number.

Status 0: Scope code

Status 1: Data content

- **Display Data (Datalog, Memory): 5-byte**

Data LSB				Data MSB
Reading			Status 0	Status 2

Reading: 24-bit signed integer, LSB to MSB. If the range of reading is 0x700000 to 0x7FFFFFFF, then the reading is a word code, else is a number.

Status 0: Scope code

Status 2: Data content

- **Calibration Data (ADC original data, offset, gain): 4-byte**

Data LSB			Data MSB
32-bit signed integer, LSB to MSB			

Table**• Table 1: Word code**

Reading	
0x700000: Space	0x700020: RATE
0x700001: Full	0x700021: SAVE
0x700002: Beep	0x700022: LOAd
0x700003: APO	0x700023: YES
0x700004: b.Lit	0x700024: SEnd
0x700005: HAZ	0x700025: Ahold
0x700006: On	0x700026: Auto
0x700007: Off	0x700027: Cntin
0x700008: Reset	0x700028: CAL
0x700009: Start	0x700029: Version
0x70000A: View	0x70002A: OL (not use)
0x70000B: Pause	0x70002B: FULL
0x70000C: Fuse	0x70002C: HALF
0x70000D: Probe	0x70002D: Lo
0x70000E: dEF	0x70002E: Hi
0x70000F: Clr	0x70002F: digit
0x700010: Er	0x700030: rdy
0x700011: Er1	0x700031: dISC
0x700012: Er2	0x700032: outF
0x700013: Er3	0x700033: OLA
0x700014: Dash	0x700034: OLV
0x700015: Dash1	0x700035: OLVA
0x700016: Test	0x700036: bAd
0x700017: Dash2	0x700037: TEMP
0x700018: bAtt	
0x700019: diSLt	
0x70001A: noiSE	
0x70001B: Filtr	
0x70001C: PASS	
0x70001D: null	
0x70001E: 0-20	
0x70001F: 4-20	

● Table 2: Status 0 (Scope code)

Bit	Content
7...3	Unit: 0x00: None 0x10: kHz 0x01: V 0x11: Hz 0x02: mV 0x12: °C 0x03: A 0x13: °F 0x04: mA 0x14: sec 0x05: dB 0x15: ms 0x06: dBm 0x16: us 0x07: mF 0x17: ns 0x08: uF 0x18: uA 0x09: nF 0x19: min 0x0A: GΩ 0x1A: kW 0x0B: MΩ 0x1B: PF 0x0C: kΩ 0x0D: Ω 0x0E: % 0x0F: MHz
2...0	Dot: 0x00: None 0x01: 9999.9 0x02: 999.99 0x03: 99.999 0x04: 9.9999

● Table 3: Status 1 (main display, sub display)

Bit	Content
7	0: Not Overload 1: Overload
6...0	Data content: <div> <div>0x00: Measuring data</div> <div>0x01: Frequency</div> <div>0x02: Cycle</div> <div>0x03: Duty</div> <div>0x04: Memory Stamp</div> <div>0x05: Memory Save</div> <div>0x06: Memory Load</div> <div>0x07: Log Save</div> <div>0x08: Log Load</div> <div>0x09: Log Rate</div> <div>0x0A: REL Δ</div> <div>0x0B: REL %</div> <div>0x0C: REL Reference</div> <div>0x0D: Maximum</div> <div>0x0E: Minimum</div> <div>0x0F: Average</div> </div> <div> <div>0x10: Peak Hold Max</div> <div>0x11: Peak Hold Min</div> <div>0x12: dBm</div> <div>0x13: dB</div> <div>0x14: Auto Hold</div> <div>0x15: Setup</div> <div>0x16: Log Stamp</div> <div>0x17: Log Max</div> <div>0x18: Log Min</div> <div>0x19: Log TP</div> <div>0x1A: Hold</div> <div>0x1B: Current Output</div> <div>0x1C: CurOut 0-20mA %</div> <div>0x1D: CurOut 4-20mA %</div> </div>

● Table 4: Status 2 (Datalog, Memory)

Bit	Content
7	0: Not Overload 1: Overload
6...0	Same as function code (bit 6...0)

● Table 5: Rotary code

Bit	Content		
7...0	506/506B	208/208B	150/150B
	0x00: None	0x00: None	0x00: None
	0x01: ACV	0x01: ACV	0x01: V
	0x02: ACmV	0x02: ACmV	0x02: A
	0x03: DCV	0x03: LoZ	0x03: Watt
	0x04: DCmV	0x04: DCV	0x04: Ohm
	0x05: Ohm	0x05: DCmV	0x05: Cap
	0x06: A	0x06: Ohm	0x06: Flex ACA
	0x07: Temp	0x07: A	0x07: Temp
	0x08: LoZ	0x08: Freq	
		0x09: Temp	

● Table 6: Function code

Bit	Content	
7	0: Manual Test 1: Auto Test	
6...0	0x00: None 0x01: AC V 0x02: DC V 0x03: AC mV 0x04: DC mV 0x05: Ohm 0x06: Continuity 0x07: Diode 0x08: Cap 0x09: AC A 0x0A: DC A 0x0B: AC mA 0x0C: DC mA 0x0D: °C 0x0E: °F 0x0F: Frequency 0x10: Duty 0x11: Hz (V) 0x12: Hz (mV) 0x13: Hz (A) 0x14: Hz (mA) 0x15: AC+DC (V) 0x16: AC+DC (mV) 0x17: AC+DC (A) 0x18: AC+DC (mA) 0x19: LPF (V) 0x1A: LPF (mV) 0x1B: LPF (A) 0x1C: LPF (mA) 0x1D: AC uA 0x1E: DC uA 0x1F: DC A out	0x20: DC A out (Slow Linear) 0x21: DC A out (Fast Linear) 0x22: DC A out (Slow Step) 0x23: DC A out (Fast Step) 0x24: LoopPower 0x25: 250ohmHart 0x26: VoltSense 0x27: PeakHold (V) 0x28: PeakHold (mV) 0x29: PeakHold (A) 0x2A: PeakHold (mA) 0x2B: LoZ AC V 0x2C: LoZ DC V 0x2D: LoZ AC+DC (V) 0x2E: LoZ LPF (V) 0x2F: LoZ Hz (V) 0x30: LoZ PeakHold (V) 0x31: Battery 0x32: AC W 0x33: DC W 0x34: PF 0x35: Flex AC A 0x36: Flex LPF (A) 0x37: Flex PeakHold (A) 0x38: Flex Hz (A) 0x39: Vharm 0x3A: Inrush 0x3B: Aharm 0x3C: Flex Inrush 0x3D: Flex Aharm 0x3E: PeakHold (uA)

● Table 7.1: Range code (506/506B)

Rotary	Function	Range	
		Bit 7	Bit 6...0
0x00: None	0x00: None	0: Manual Range	0x00: None
0x01: ACV	0x01: AC V 0x19: LPF (V) 0x27: PeakHold (V)	0: Manual Range 1: Auto Range	0x00: 4.0000V 0x01: 40.000V 0x02: 400.00V 0x03: 1000.0V
	0x11: Hz (V)	0: Manual Range 1: Auto Range	0x00: 400.00Hz 0x01: 4.0000kHz 0x02: 40.000kHz 0x03: 100.00kHz
0x02: ACmV	0x03: AC mV 0x1A: LPF (mV) 0x28: PeakHold (mV)	0: Manual Range 1: Auto Range	0x00: 40.000mV 0x01: 400.00mV
	0x12: Hz (mV)	0: Manual Range 1: Auto Range	0x00: 400.00Hz 0x01: 4.0000kHz 0x02: 40.000kHz 0x03: 100.00kHz
0x03: DCV	0x02: DC V 0x15: AC+DC (V)	0: Manual Range 1: Auto Range	0x00: 4.0000V 0x01: 40.000V 0x02: 400.00V 0x03: 1000.0V
0x04: DCmV	0x04: DC mV 0x16: AC+DC (mV)	0: Manual Range 1: Auto Range	0x00: 40.000mV 0x01: 400.00mV
0x05: Ohm	0x05: Ohm	0: Manual Range 1: Auto Range	0x00: 400.00Ω 0x01: 4.0000kΩ 0x02: 40.000kΩ 0x03: 400.00kΩ 0x04: 4.0000MΩ 0x05: 40.00MΩ
	0x06: Continuity	0: Manual Range	0x00: 400.00Ω
	0x07: Diode	0: Manual Range	0x00: 2.000V
	0x08: Cap	0: Manual Range 1: Auto Range	0x00: 40.00nF 0x01: 400.0nF 0x02: 4.000uF 0x03: 40.00uF 0x04: 400.0uF 0x05: 4.000mF 0x06: 40.00mF

● Table 7.2: Range code (506/506B)

Rotary	Function	Range	
		Bit 7	Bit 6...0
0x06: A	0x0B: AC mA 0x0C: DC mA 0x18: AC+DC (mA) 0x1C: LPF (mA) 0x2A: PeakHold (mA)	0: Manual Range 1: Auto Range	0x00: 40.000mA 0x01: 400.00mA
	0x09: AC A 0x0A: DC A 0x17: AC+DC (A) 0x1B: LPF (A) 0x29: PeakHold (A)	0: Manual Range 1: Auto Range	0x02: 4.0000A 0x03: 10.000A
	0x13: Hz (A) 0x14: Hz (mA)	0: Manual Range 1: Auto Range	0x00: 400.00Hz 0x01: 4.0000kHz 0x02: 40.000kHz 0x03: 100.00kHz
0x07: Temp	0x0D: °C	0: Manual Range	0x00: 1200.0°C
	0x0E: °F	0: Manual Range	0x00: 2192.0°F
0x08: LoZ	0x2B: LoZ AC V 0x2C: LoZ DC V	1: Auto Range	0x02: 400.00V 0x03: 1000.0V

● Table 8: Range code (208/208B)

The range code is roughly the same as 506/506B, but the rotary code is different. And the APPA 208/208B has an extra rotary switch that is frequency measuring. Refer the below table:

Rotary	Function	Range	
		Bit 7	Bit 6...0
0x08: Freq	0x0F: Frequency 0x10: Duty	0: Manual Range 1: Auto Range	0x00: 40.000Hz 0x01: 400.00Hz 0x02: 4.0000kHz 0x03: 40.000kHz 0x04: 400.00kHz 0x05: 4.0000MHz

● Table 9.1: Range code (150/150B)

Rotary	Function	Range	
		Bit 7	Bit 6...0
0x01: V	0x01: AC V 0x02: DC V 0x15: AC+DC (V) 0x19: LPF (V)	0: Manual Range 1: Auto Range	0x00: 100.00V 0x01: 1000.0V
	0x27: PeakHold (V)	0: Manual Range	0x00: 140.0V 0x01: 1400V
	0x11: Hz (V)	0: Manual Range 1: Auto Range	0x00: 100.00Hz 0x01: 1000.0Hz 0x02: 10.00kHz
	0x39: Vharm	0: Manual Range	0x00: 100.0%
0x02: A	0x09: AC A 0x0A: DC A 0x17: AC+DC (A) 0x1B: LPF (A)	0: Manual Range 1: Auto Range	0x00: 100.00V 0x01: 1000.0V
	0x3A: Inrush	0: Manual Range	0x00: 100.00V 0x01: 1000.0V
	0x29: PeakHold (A)	0: Manual Range	0x00: 140.0V 0x01: 1400V
	0x13: Hz (A)	0: Manual Range 1: Auto Range	0x00: 100.00Hz 0x01: 1000.0Hz 0x02: 10.00kHz
	0x3B: Aharm	0: Manual Range	0x00: 100.0%
0x03: Watt	0x32: AC W 0x33: DC W	0: Manual Range 1: Auto Range	0x00: 10.00kW 0x01: 100.0kW 0x02: 1000kW
	0x34: PF	0: Manual Range	0x00: 1.00
0x04: Ohm	0x05: Ohm	0: Manual Range 1: Auto Range	0x00: 1000.0Ω 0x01: 10.000kΩ 0x02: 100.00kΩ
	0x06: Continuity	0: Manual Range	0x00: 1000.0Ω
	0x07: Diode	0: Manual Range	0x00: 1.00V

● Table 9.2: Range code (150/150B)

Rotary	Function	Range	
		Bit 7	Bit 6...0
0x05: Cap	0x08: Cap	0: Manual Range 1: Auto Range	0x00: 4.000uF 0x01: 40.00uF 0x02: 400.0uF 0x03: 4000uF
0x06: Flex AC A	0x35: Flex AC A 0x36: Flex LPF (A)	0: Manual Range 1: Auto Range	0x00: 300.0A 0x01: 3000A
	0x3C: Flex Inrush	0: Manual Range	0x00: 300.0A 0x01: 3000A
	0x37: Flex PeakHold (A)	0: Manual Range	0x00: 420.0A 0x01: 4200A
	0x38: Flex Hz (A)	0: Manual Range 1: Auto Range	0x00: 100.00Hz 0x01: 1000.0Hz 0x02: 10.00kHz
	0x3D: Flex Aharm	0: Manual Range	0x00: 100.0%
0x07: Temp	0x0D: °C	1: Auto Range	0x00: 400.0°C 0x01: 1000°C
	0x0E: °F	1: Auto Range	0x00: 751.9°F 0x01: 1832°F

● **Table 10: EEPROM Map (506/506B/208/208B)**

EEPROM: 24LC512 x 4

Device Number: 0 to 3

EEPROM Address: 0x0000 to 0xFFFF

Page Size: 64 bytes

Function	Name	Device	Address	Length
System	Model Name	0	0x0010	16 byte
	Serial Number	0	0x0020	16 byte
Memory	Amount ^[3]	0	0x000E	2 byte
	Data ^[1] (no. 1 to 500)	0	0x0500	500 x 5 byte
	Data ^[1] (no. 501 to 1000)	1	0x0500	500 x 5 byte
Datalog	Rate ^{[2][3]}	0	0x000A	2 byte
	Amount ^[3]	0	0x000C	2 byte
	Data ^[1] (no. 1 to 10000)	0	0x1000	10000 x 5 byte
	Data ^[1] (no. 10001 to 20000)	1	0x1000	10000 x 5 byte
	Data ^[1] (no. 20001 to 30000)	2	0x1000	10000 x 5 byte
	Data ^[1] (no. 30001 to 40000)	3	0x1000	10000 x 5 byte
<p>[1] Data format refer to page 10: Display Data (Datalog, Memory)</p> <p>[2] 1 to 600 sec</p> <p>[3] 2 byte, MSB to LSB</p>				

● **Table 11: EEPROM Map (150/150B)**

EEPROM:

Device Number:

EEPROM Address:

Page Size:

Function	Name	Device	Address	Length
System	Model Name	0	0x0001	32 byte
	Serial Number	0	0x0021	16 byte
Memory	Amount	0	0x0031	2 byte
	Data ^[1] (no. 1 to 1000)	0	0x0040	1000 x 5 byte
Datalog	Rate ^[2]	0	0x0035	2 byte
	Amount	0	0x0033	2 byte
	Data ^[1] (no. 1 to 9999)	0	0x1400	9999 x 5 byte
[1] Refer to page 10: Display Data (Datalog, Memory)				
[2] 1 to 600 sec				

Version List

Version	Date	Content
1.0	2014/10/31	First version
1.1	2014/11/06	Modify the data format error
1.2	2014/11/12	Add function code (0x32 to 0x38) Add scope code (0x1A)
1.3	2014/12/09	Add rotary code (0x08) Add function code (0x39 to 0x3D) Add range code (for LoZ)
1.4	2014/12/23	Add function code (0x3E)
1.5	2015/01/14	Modify word code (0x2A) Add word code (0x30 to 0x36)
1.6	2015/04/30	Add memory space table Modify status 1 code (0x04 to 0x0C, 0x16)
1.7	2015/05/20	Add command code (0x1B: Read Harmonics) Add scope code (0x1B)
2.0	2015/06/26	Add rotary code (208/208B) Add range code (208/208B)
2.1	2015/09/23	Modify command code (0x00: Read information) Add EEPROM Map (506/506B/208/208B)
2.2	2015/11/11	Modify status 1 code (0x1B to 0x1D)
2.3	2015/12/23	Modify EEPROM Map (506/506B/208/208B)
2.4	2016/01/26	Modify command code (0x1B: Read Harmonics) Add rotary code (150/150B) Add range code (150/150B) Add EEPROM Map (150/150B) Modify EEPROM Map (506/506B/208/208B)
2.5	2016/02/16	Modify command code (0x1B: Read Harmonics) Modify range code (150/150B) Modify EEPROM Map (506/506B/208/208B)
2.6	2016/03/16	Add word code (0x37)