


Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475M000X
Title: PARK ASSIST / MONITORING: CLEARANCE SONAR MAIN SWITCH: COMPONENTS (2010 4Runner)		

COMPONENTS


ILLUSTRATION



Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475N000X
Title: PARK ASSIST / MONITORING: CLEARANCE SONAR MAIN SWITCH: REMOVAL (2010 4Runner)		

REMOVAL

1. REMOVE NO. 2 SWITCH HOLE BASE



2. REMOVE BACK SONAR OR CLEARANCE SONAR SWITCH ASSEMBLY

- (a) Detach the 2 claws and remove the back sonar or clearance sonar switch.

Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475P000X
Title: PARK ASSIST / MONITORING: CLEARANCE SONAR MAIN SWITCH: INSPECTION (2010 4Runner)		

INSPECTION


1. INSPECT BACK SONAR OR CLEARANCE SONAR SWITCH ASSEMBLY

- (a) Check the resistance.
- (1) Measure the resistance according to the value(s) in the table below.
- Standard Resistance:

TESTER CONNECTION	SWITCH CONDITION	SPECIFIED CONDITION
3 (ECU) - 6 (IG)	Sonar switch off	10 kΩ or higher
	Sonar switch on	Below 1 Ω

If the result is not as specified, replace the back sonar or clearance sonar switch assembly.

- (b) Apply battery voltage to the connector and check the LED illumination condition.
- OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive (+) → Terminal 3 (ECU) Battery negative (-) → Terminal 7 (E)	LED illuminates
Battery positive (+) → Terminal 5 (ILL+) Battery negative (-) → Terminal 4 (ILL-)	LED illuminates

If the result is not as specified, replace the back sonar or clearance sonar switch assembly.

Text in Illustration

*a	Component without harness connected
----	-------------------------------------

(Back Sonar or Clearance Sonar Switch Assembly)



Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475L000X
Title: PARK ASSIST / MONITORING: CLEARANCE SONAR MAIN SWITCH: INSTALLATION (2010 4Runner)		

INSTALLATION

1. INSTALL BACK SONAR OR CLEARANCE SONAR SWITCH ASSEMBLY

(a) Attach the 2 claws to install the back sonar or clearance sonar switch.


2. INSTALL NO. 2 SWITCH HOLE BASE



Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475C000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING BUZZER: COMPONENTS (2010 4Runner)		

COMPONENTS


ILLUSTRATION




Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475F000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING BUZZER: REMOVAL (2010 4Runner)		

REMOVAL

1. REMOVE INSTRUMENT PANEL SUB-ASSEMBLY

- (a) Remove the instrument panel sub-assembly  .



2. REMOVE NO. 1 CLEARANCE WARNING BUZZER

- (a) Disconnect the connector.
- (b) Detach the clamp and remove the No. 1 clearance warning buzzer.


Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475E000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING BUZZER: INSTALLATION (2010 4Runner)		

INSTALLATION

1. INSTALL NO. 1 CLEARANCE WARNING BUZZER

- (a) Attach the clamp to install the No. 1 clearance warning buzzer.
- (b) Connect the connector.

2. INSTALL INSTRUMENT PANEL SUB-ASSEMBLY


- (a) Install the instrument panel sub-assembly  .



Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475D000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING ECU: COMPONENTS (2010 4Runner)		

[COMPONENTS](#)

[ILLUSTRATION](#)



LOWER NO. 1 INSTRUMENT
PANEL AIRBAG ASSEMBLY

CLEARANCE WARNING
ECU ASSEMBLY



10 (102, 7)

x 4



COWL SIDE TRIM
BOARD LH




NO. 1 INSTRUMENT
CLUSTER FINISH
PANEL GARNISH



x 2

LOWER INSTRUMENT PANEL
FINISH PANEL SUB-ASSEMBLY



DOOR SCUFF PLATE ASSEMBLY LH

N*m (kgf*cm, ft.*lbf) : Specified torque

H



TOYOTA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000466X006X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING ECU: REMOVAL (2010 4Runner)		

REMOVAL

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

CAUTION:

Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to disable the SRS system.

NOTICE:

When disconnecting the cable, some systems need to be initialized after the cable is reconnected .


2. REMOVE DOOR SCUFF PLATE ASSEMBLY LH

3. REMOVE COWL SIDE TRIM BOARD LH

4. REMOVE NO. 1 INSTRUMENT CLUSTER FINISH PANEL GARNISH

5. REMOVE LOWER INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY

6. REMOVE LOWER NO. 1 INSTRUMENT PANEL AIRBAG ASSEMBLY



7. REMOVE CLEARANCE WARNING ECU ASSEMBLY

- (a) Disconnect the connector.
- (b) Remove the bolt and clearance warning ECU.

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000466V006X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING ECU: INSTALLATION (2010 4Runner)		

INSTALLATION

HINT:

A bolt without a torque specification is shown in the standard bolt chart  .

1. INSTALL CLEARANCE WARNING ECU ASSEMBLY

- (a) Install the clearance warning ECU with the bolt.
- (b) Connect the connector.

2. INSTALL LOWER NO. 1 INSTRUMENT PANEL AIRBAG ASSEMBLY

3. INSTALL LOWER INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY

4. INSTALL NO. 1 INSTRUMENT CLUSTER FINISH PANEL GARNISH

5. INSTALL COWL SIDE TRIM BOARD LH

6. INSTALL DOOR SCUFF PLATE ASSEMBLY LH

7. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

NOTICE:

When disconnecting the cable, some systems need to be initialized after the cable is reconnected  .


8. CHECK SRS WARNING LIGHT

- (a) Check the SRS warning light  .

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475I000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING INDICATOR: COMPONENTS (2010 4Runner)		

COMPONENTS

ILLUSTRATION



Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475H000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING INDICATOR: INSPECTION (2010 4Runner)		

INSPECTION

1. INSPECT SECURITY INDICATOR LIGHT ASSEMBLY (CLEARANCE WARNING INDICATOR)

(a) Apply battery voltage to the connector and check the LED illumination condition.

(1) for A :

OK:

MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive (+) → Terminal 7 (SK) Battery negative (-) → Terminal 3 (OP)	LED illuminates

(2) for B:

OK:

MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive (+) → Terminal 7 (SK) Battery negative (-) → Terminal 4 (BK)	LED illuminates


(3) for C:

OK:

MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive (+) → Terminal 7 (SK) Battery negative (-) → Terminal 6 (RL)	LED illuminates

(4) for D:

OK:



MEASUREMENT CONDITION	SPECIFIED CONDITION
Battery positive (+) → Terminal 7 (SK) Battery negative (-) → Terminal 5 (RR)	LED illuminates

If the result is not as specified, replace the security indicator light (clearance warning indicator).


Text in Illustration

*a	Component without harness connected Security Indicator Light (Clearance Warning Indicator)
----	-----------------------------------------------------------------------------------------------

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475J000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING INDICATOR: REMOVAL (2010 4Runner)		

REMOVAL

1. REMOVE NO. 1 INSTRUMENT CLUSTER FINISH PANEL GARNISH



2. REMOVE SECURITY INDICATOR LIGHT ASSEMBLY (CLEARANCE WARNING INDICATOR)

- (a) Disconnect the connector.
- (b) Detach the 4 claws and remove the security indicator light (clearance warning indicator).

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475G000X
Title: PARK ASSIST / MONITORING: CLEARANCE WARNING INDICATOR: INSTALLATION (2010 4Runner)		

INSTALLATION

1. INSTALL SECURITY INDICATOR LIGHT ASSEMBLY (CLEARANCE WARNING INDICATOR)

- (a) Attach the 4 claws to install the security indicator light (clearance warning indicator).
- (b) Connect the connector.


2. INSTALL NO. 1 INSTRUMENT CLUSTER FINISH PANEL GARNISH



Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000475K000X
Title: PARK ASSIST / MONITORING: TELEVISION CAMERA (for Rear): COMPONENTS (2010 4Runner)		

[COMPONENTS](#)


[ILLUSTRATION](#)



w/ Smart Key System:



w/o Smart Key System:



● Non-reusable part

H



TOYOTA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000470U001X
Title: PARK ASSIST / MONITORING: TELEVISION CAMERA (for Rear): REMOVAL (2010 4Runner)		

REMOVAL

1. REMOVE BACK DOOR TRIM PANEL ASSEMBLY



2. REMOVE MULTIPLEX NETWORK DOOR ECU



3. REMOVE NO. 2 BACK DOOR SERVICE HOLE COVER




4. REMOVE BACK DOOR LOCK CYLINDER (w/o Smart Key System)




5. REMOVE BACK DOOR OUTSIDE GARNISH



6. REMOVE REAR TELEVISION CAMERA ASSEMBLY



(a) Remove the 2 screws.




(b) Disconnect the connector.

(c) Detach the 2 claws and remove the rear television camera.

7. REMOVE NO. 4 BACK DOOR WIRE

(a) Disconnect the connector and remove the No. 4 back door wire.



Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000470S001X
Title: PARK ASSIST / MONITORING: TELEVISION CAMERA (for Rear): INSTALLATION (2010 4Runner)		

INSTALLATION

1. INSTALL NO. 4 BACK DOOR WIRE

(a) Connect the connector to install the No. 4 back door wire.

2. INSTALL REAR TELEVISION CAMERA ASSEMBLY

- (a) Attach the 2 claws to install the rear television camera.
- (b) Connect the connector.
- (c) Install the 2 screws.

3. INSTALL BACK DOOR OUTSIDE GARNISH

4. INSTALL BACK DOOR LOCK CYLINDER (w/o Smart Key System)

5. INSTALL NO. 2 BACK DOOR SERVICE HOLE COVER

6. INSTALL MULTIPLEX NETWORK DOOR ECU


7. INSTALL BACK DOOR TRIM PANEL ASSEMBLY

Last Modified: 5-10-2010	6.4 K	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM000004750000X
Title: PARK ASSIST / MONITORING: ULTRASONIC SENSOR (for Rear): COMPONENTS (2010 4Runner)		

COMPONENTS


ILLUSTRATION

except X-Runner:



ILLUSTRATION


for X-Runner:



P


ILLUSTRATION

except X-Runner:



ILLUSTRATION

for X-Runner:



P



TOYOTA

Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000470F002X
Title: PARK ASSIST / MONITORING: ULTRASONIC SENSOR (for Rear): REMOVAL (2010 4Runner)		

REMOVAL

1. REMOVE JACK BOX HOLE COVER



2. REMOVE REAR QUARTER PANEL MUDGUARD LH



3. REMOVE REAR QUARTER PANEL MUDGUARD RH

HINT:

Use the same procedure described for the LH side.

4. REMOVE REAR QUARTER PANEL MUDGUARD LH (for X-Runner)



5. REMOVE REAR QUARTER PANEL MUDGUARD RH (for X-Runner)

HINT:

Use the same procedure described for the LH side.

6. REMOVE REAR BUMPER COVER




7. REMOVE REAR BUMPER COVER (for X-Runner)



8. REMOVE NO. 3 FLOOR WIRE



9. REMOVE NO. 3 FLOOR WIRE (for X-Runner)



10. REMOVE NO. 1 ULTRASONIC SENSOR

HINT:


Use the same procedure to remove the No. 1 ultrasonic sensor on the other side.

- (a) Detach the 2 claws and remove the No. 1 ultrasonic sensor.


11. REMOVE ULTRASONIC SENSOR CLIP

HINT:

Use the same procedure to remove the No. 1 ultrasonic sensor clip on the other side.



- (a) Using a screwdriver, detach the claw and remove the ultrasonic sensor clip as shown in the illustration.




12. REMOVE NO. 2 ULTRASONIC SENSOR RETAINER

HINT:

Use the same procedure to remove the No. 2 ultrasonic sensor retainer on the other side.

- (a) Detach the 3 claws and remove the No. 2 ultrasonic sensor retainer.



13. REMOVE NO. 1 ULTRASONIC SENSOR RETAINER

HINT:

Use the same procedure to remove the No. 1 ultrasonic sensor retainer on the other side.

- (a) Detach the 4 claws and remove the No. 1 ultrasonic sensor retainer.




Last Modified: 5-10-2010	6.4 G	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000472K002X
Title: PARK ASSIST / MONITORING: ULTRASONIC SENSOR (for Rear): INSPECTION (2010 4Runner)		

INSPECTION

1. INSPECT NO. 1 ULTRASONIC SENSOR

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
1 (E) - 2 (S)	Always	20 to 40 kΩ

If the result is not as specified, replace the No. 1 ultrasonic sensor.


Last Modified: 5-10-2010	6.4 A	From: 200908
Model Year: 2010	Model: 4Runner	Doc ID: RM00000470D002X
Title: PARK ASSIST / MONITORING: ULTRASONIC SENSOR (for Rear): INSTALLATION (2010 4Runner)		

INSTALLATION

1. INSTALL NO. 1 ULTRASONIC SENSOR RETAINER

HINT:

Use the same procedure to install the No. 1 ultrasonic sensor retainer on the other side.



(a) Align the keyhole and protrusion as shown in the illustration.

Text in Illustration

* 1	Keyhole
-----	---------

(b) Attach the 4 claws to install the ultrasonic sensor retainer to the front bumper cover.


NOTICE:

Do not damage the bumper cover with the protrusion when installing the retainer.

2. INSTALL NO. 2 ULTRASONIC SENSOR RETAINER

HINT:

Use the same procedure to install the No. 2 ultrasonic sensor retainer on the other side.



(a) Align the keyhole and protrusion as shown in the illustration.

Text in Illustration

* 1	Keyhole
-----	---------

(b) Attach the 3 claws to install the ultrasonic sensor retainer to the front bumper cover.

NOTICE:

Do not damage the bumper cover with the protrusion when

installing the retainer.

3. INSTALL ULTRASONIC SENSOR CLIP

HINT:

Use the same procedure to install the No. 1 ultrasonic sensor clip on the other side.

- (a) Attach the claw to install the ultrasonic sensor clip.

4. INSTALL NO. 1 ULTRASONIC SENSOR

HINT:

Use the same procedure to install the No. 1 ultrasonic sensor retainer on the other side.

- (a) Attach the 2 claws to install the No. 1 ultrasonic sensor.

5. INSTALL NO. 3 FLOOR WIRE

6. INSTALL NO. 3 FLOOR WIRE (for X-Runner)

7. INSTALL REAR BUMPER COVER

8. INSTALL REAR BUMPER COVER (for X-Runner)

9. INSTALL REAR QUARTER PANEL MUDGUARD LH

10. INSTALL REAR QUARTER PANEL MUDGUARD RH

HINT:

Use the same procedure described for the LH side.

11. INSTALL REAR QUARTER PANEL MUDGUARD LH (for X-Runner)

12. INSTALL REAR QUARTER PANEL MUDGUARD RH (for X-Runner)

HINT:

Use the same procedure described for the LH side.

13. INSTALL JACK BOX HOLE COVER