

ESP8266 WiFi extension Design

Virgile Neu

June 3, 2017
version 1.0



ÉCOLE POLYTECHNIQUE
FÉDÉRALE DE LAUSANNE

Contents

| | | |
|----------|--------------------------------------|-----------|
| 1 | Introduction | 1 |
| 2 | Parameters | 2 |
| 2.1 | Default configuration | 2 |
| 2.2 | Serial Parameters | 2 |
| 2.2.1 | Data bits | 2 |
| 2.2.2 | Baud rates | 2 |
| 2.2.3 | Stop bit | 3 |
| 2.2.4 | Parity bit | 3 |
| 2.2.5 | Flow control | 3 |
| 2.3 | WiFi Parameters | 3 |
| 2.3.1 | Router connection | 3 |
| 2.3.2 | Connection mode | 4 |
| 3 | Design Choices | 4 |
| 3.1 | Registers | 5 |
| 3.2 | FIFO_out | 9 |
| 3.3 | FIFO_in | 11 |
| 3.4 | UART | 12 |
| 4 | Pinout | 14 |
| 5 | States Machines | 14 |
| 5.1 | UART | 14 |
| 5.1.1 | Transmitting State Machine | 14 |
| 5.1.2 | Receiving State Machine | 15 |
| 6 | Power consumption | 16 |
| 7 | Throughput | 17 |
| 8 | Other | 18 |
| | Appendices | 19 |
| | Appendix A Flashing the ROM | 19 |
| | Appendix B AT Commands | 19 |

1 Introduction

The ESP8266 chip is a WiFi module with a AT command mode. It can be used for single connection or multiple connections (server), either TCP or UDP.

It has 4 pins of interest plus VCC and GND : Chip Enable, RESET, Rx and Tx. The picture 1 below show the esp8266 board with it's connectivity.




Figure 1: The ESP8266 module

The goal is to make available this WiFi module to use on the FPGA and to make it easily usable.

2 Parameters

2.1 Default configuration

The default configuration depends on the firmware version and can be changed at any time by AT commands with the `_DEF` modifier (e.g. `AT+UART_DEF`). Most of the parameters can be set that way, or customise at run time without changing the stored settings with the `_CUR` command modifier.

2.2 Serial Parameters

The ESP8266 WiFi module uses UART communication to transmit information with the FPGA.

The UART works as described on figure 2. It starts with the start bit, always '0', then comes the data (here 8 bits), least significant bit first, then the parity bit (if set), and then 1 or 2 stop bit, always '1'.

The ESP8266 supports a lot of different settings :




Figure 2: UART data transfert.

2.2.1 Data bits

- 5 bits
- 6 bits
- 7 bits
- 8 bits

2.2.2 Baud rates

Unlike the HC05, it supports a continuous range of baud rates, between 300 to 115200*40 bits/s.

2.2.3 Stop bit

- 1 bit
- 1.5 bit
- 2 bit

2.2.4 Parity bit

- None
- Odd parity
- Even parity

2.2.5 Flow control

- No flow control
- enable Request To Send
- enable Clear To Send
- enable both RTS and CTS

The ESP8266 has on chip Tx/Rx FIFO of 128 Bytes.

2.3 WiFi Parameters

2.3.1 Router connection

It can connect to routers with several security :

- OPEN,
- WEP,
- WPA_PSK,
- WPA2_PSK,
- WPA_WPA2_PSK.

The connection to routers with the **WPA2_Enterprise** security is not available with the current version of the AT command set.

2.3.2 Connection mode

The ESP8266 has three WiFi connection modes :

- Station mode : Client only
- SoftAP mode : Server only
- SoftAP + Station mode

3 Design Choices

Here I will show how the extension will look like, see figure 3. It will consist of Four parts:

- Registers, to store configuration, status and other things,
- A FIFO_OUT to send data from the CPU to the UART custom interface,
- A FIFO_IN to receive data from the ESP8266,
- A custom UART interface to communicate to the ESP8266.




Figure 3: High level block diagram of the ESP8266 extension.

3.1 Registers

The registers will have height registers :

- A control register **CTRL**,
- A status register **STATUS**,
- A register for the **UART** waiting cycles (depends on the **UART rate**),

- The `FIFO_out_data` register,
- The `FIFO_out_free_space` register,
- The `FIFO_in_data` register,
- The `FIFO_in_pending_data` register.
- The `reset_FIFO` register.

Here is the register map in table 1 below.

Table 1: Register map of the Registers component.

| # | addr | 31..8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | R/W |
|---|------|----------------------|---------------|---|-----------|---|---|-----------|---|----------|-----|
| 0 | 0x00 | Unused | | | UART_CTRL | | | I_ENABLE | | UART_ON | R/W |
| 1 | 0x04 | Unused | | | | | | i_pending | | | R/W |
| 2 | 0x08 | UART_wait_cycles | | | | | | | | | R/W |
| 3 | 0x0C | ignored | FIFO_out_data | | | | | | | | W |
| 4 | 0x10 | FIFO_out_free_space | | | | | | | | | R |
| 5 | 0x14 | zeros | FIFO_in_data | | | | | | | | R |
| 6 | 0x18 | FIFO_in_pending_data | | | | | | | | | R |
| 7 | 0x1C | Unused | | | | | | Reset_out | | Reset_in | W |

| UART_CTRL | | | I_ENABLE | |
|------------|---|----------|-----------|------------|
| 5 | 4 | 3 | 2 | 1 |
| Parity_bit | | Stop_bit | i_dropped | i_received |

The role of each bit is described below :

- 0x00 :
 - `UART_ON` : Specifies if the UART will capture or send data or if it will stay off.
 - `i_reveived` : Specifies if the device can send interrupts request when receiving data from the ESP8266.
 - `i_dropped` : Specifies if the device can send interrupts request when some data is dropped.
 - `stop_bit` : Specifies the number of stop bit, '0' for 1, '1' for 2.
 - `parity_bit` : Specifies the parity bit, "00" for None, "10" for Even and "11" for Odd.
- 0x04 :

- `i_pending` : Tells if there is an interrupt waiting to be served by the CPU. The CPU must clear it by software when serving the interrupt. Bit 0 is for `i_received`, bit 1 is for `i_dropped`. Writing '1' to any of the two bits has no effect.
- `0x08 : UART_wait_cycles` : Specifies to the UART how many cycles it should wait before capturing the values during the transfer. The values to put are described in the table 2 below for a 50MHz clock.
- `0x0C : FIFO_out_data` : Address to write to send data to the ESP8266 through the `FIFO_out`. The write must has the `byte_enable` signal equal to "0001".
- `0x10 : FIFO_out_free_space` : Number of free words (10 bits) in the `FIFO_out`.
- `0x14 : FIFO_in_data` : Address to read to receive data from the ESP8266 through the `FIFO_in`.
- `0x18 : FIFO_out_free_space` : Number of waiting words (11 bits) in the `FIFO_in`.
- `0x1C` :
 - `Reset_in` : Write only bit to clear the `FIFO_in`.
 - `Reset_out` : Write only bit to clear the `FIFO_out`.

The value to put in the `UART_wait_cycles` registers depend on the desired `UART baud rate`, and is computed with the following formula.

$$\begin{aligned} wait_cycles &= \frac{time_per_bit}{time_per_cycles} \\ &= \frac{1}{\frac{baud_rate}{clk_period}} \\ &= \frac{clk_freq}{baud_rate} \end{aligned}$$

For 4800 bits/s of baud rate we have.

$$\begin{aligned} wait_cycles &= \frac{clk_freq}{baud_rate} \\ &= \frac{50 \cdot 10^6}{4800} = 10416.667 \quad clk_cycles \end{aligned}$$

The rounding doesn't matter.

Table 2: `UART_wait_cycles` values for a given `UART`.

| UART_Rate | wait_cycles value (decimal) |
|----------------|-----------------------------|
| 4800 bits/s | 10416 clk_cycles |
| 9600 bits/s | 5207 clk_cycles |
| 19200 bits/s | 2604 clk_cycles |
| 38400 bits/s | 1302 clk_cycles |
| 57600 bits/s | 868 clk_cycles |
| 115200 bits/s | 434 clk_cycles |
| 230400 bits/s | 217 clk_cycles |
| 460800 bits/s | 109 clk_cycles |
| 921600 bits/s | 54 clk_cycles |
| 1382400 bits/s | 36 clk_cycles |

The ports of the Registers component are described on figure 4 below.




Figure 4: Ports description of the Registers component.

3.2 FIFO_out

For the FIFO_out we will use the FIFO available in the IP catalogue of Quartus with the following configurations :

- Width = 8 bits,
- Depth = 1024 (biggest size with only one M10k element),
- control signals :
 - use_dw[] (10 bits),
 - empty,
 - asynchronous clear;
- Show ahead FIFO mode,
- Auto memory block type,

- No optimisation or circuitry protection.

The ports of the FIFO_out component are described on figure 5.




Figure 5: Ports description of the FIFO_out component.

3.3 FIFO_in

For the FIFO_in we will also use the FIFO available in the IP catalogue of Quartus with almost the same configurations :

- Width = 8 bits,
- Depth = 1024 (biggest size with only one M10k element),
- control signals :
 - use_dw[] (10 bits),
 - full,
 - asynchronous clear;
- Normal synchronous FIFO mode,
- Auto memory block type,
- No optimisation or circuitry protection.

The ports of the FIFO_in component are described on figure 6.




Figure 6: Ports description of the FIFO_in component.

3.4 UART

The UART will be the part communicating with the ESP8266 module. It will send whenever it can while the FIFO_out isn't empty, and whenever it receives information, it will recompose the words, perform the parity check (if set) and send the correct words to the FIFO_in.

The ports of the UART component are described on figure 7.




Figure 7: Ports description of the UART component.

4 Pinout

The external connectivity of the device is described on table 3.

Table 3: Pinout table of the device.

| signal name | connectivity |
|-------------|---------------------------|
| BLT_RxD | GPIO_0 23 -- FPGA PIN_T11 |
| BLT_TxD | GPIO_0 25 -- FPGA PIN_AF6 |
| BLT_State | PCA9673 via Avalon Bus |
| BLT_EN | |
| BLT_ATSel | |

5 States Machines

This section describes the several states machines used in the extension.

5.1 UART

5.1.1 Transmitting State Machine

The figure 8 below describe the state machine used for transmitting data. It consists of 5 states : WAITING, START, SENDING, PARITY and STOP states. It starts at the WAITING states, and wait for data to be available in the FIFO_out. Once data is available, it issue a read to the FIFO_out and go to the start states. During the start state, it outputs the '0' value, as specified in the UART protocol, and store the data from the FIFO_out_readdata during the first cycle in this state. Once it has waited enough, it goes to sending. During sending state, it will send bit after bit, every time waiting the good amount of time. Oncei all the 8 bit of data are sent, it will either go to STOP if the parity is disabled (Parity_bit = "00") or to PARITY if it is enable. In the PARITY state, it will output the parity value (odd or even) for the right amount of time, and then go to the STOP state. In the STOP state, it will output 1 or 2 bit at '1', depending on the settings of the Stop_bit, and then go to the WAITING state, ready to transfer again.




Figure 8: State machine used for sending one word (8 bits) to the ESP8266.

5.1.2 Receiving State Machine

The figure 9 below describe the state machine used for receiving data. It has 4 states : WAITING, START, RECEIVING and PARITY. It starts at the WAITING states, and wait until the BLT_Tx is '0' (start bit). Then we wait for half the cycles to wait in the START state in order to capture each bit in correctly and not just when they are supposed to go up (in order to avoid wrong bits), continuously checking that the start bit is still on (BLT.Tx = '0'). Then we go to the RECEIVING state, where we wait for a full wait before capturing each bit. There is a transition back to the WAITING state with a big condition, it is to catch an error in the start bit during the first half of the first wait round. Once we received all the bits, we either go to the parity check in the PARITY state if enable or directly to the WAITING state and writing the data to the FIFO_in if it is not full. If we go to the PARITY state, we check if the parity of the data we received is correct, and if it is we write it to the FIFO_in if it is not full, and else we discard it. Then we go back to WAITING.




Figure 9: State machine used for receiving one word (8 bits) from the ESP8266.

6 Power consumption

The ESP8266 module specification document has the following table regarding power consumption:

| Mode | Min | Typ | Max | Unit |
|--|-----|------|-----|------|
| Transmit 802.11b, CCK 1Mbps, P _{OUT} =+19.5dBm | | 215 | | mA |
| Transmit 802.11b, CCK 11Mbps, P _{OUT} =+18.5dBm | | 197 | | mA |
| Transmit 802.11g, OFDM 54Mbps, P _{OUT} =+16dBm | | 145 | | mA |
| Transmit 802.11n, MCS7, P _{OUT} =+14dBm | | 135 | | mA |
| Receive 802.11b, packet length=1024 byte, -80dBm | | 60 | | mA |
| Receive 802.11g, packet length=1024 byte, -70dBm | | 60 | | mA |
| Receive 802.11n, packet length=1024 byte, -65dBm | | 62 | | mA |
| Standby | | 0.9 | | mA |
| Deep sleep | | 10 | | uA |
| Power save mode DTIM 1 | | 1.2 | | mA |
| Power save mode DTIM 3 | | 0.86 | | mA |
| Total shutdown | | 0.5 | | uA |

Figure 10: Table with the power consumption of the module.

7 Throughput

For the ESP8266, I was not able to have some good measure for the throughput. The module can't connect to the WPA2 Enterprise network of EPFL, so I used my smartphone as a router, which can't be trusted regarding performance. More over, to make measurement, I needed to build a server on another machine also connected to my smartphone, which was too much work to do.

According to the Espressif team¹ (the ones who made the module), the maximum speed they measure was :

- TCP Throughput: AT TCP passthrough Tx 303 Kbps; Rx 302Kbps @ baudrate 420000
- UDP Throughput: AT UDP passthrough Tx 250 Kbps; Rx 250 Kbps @ baudrate 420000

¹<http://bbs.espressif.com/viewtopic.php?t=2187>

8 Other

The ESP8266 module has a lot more to offer, since there is a real ARM 32 bit CPU inside with some GPIOs and ADCs for instance. All of that is not accessible as he only use it by UART without any SDKs, only with the AT commands. That way to use the module is sufficient to do some inter FPGA communication, or to access a remote server, but if one wants to use the SPI, ADC or many other things, he will have to flash another firmware with an SDK.

A Flashing the ROM

In order to use the AT commands, you need to flash the ROM to update the software. This document was written for the version of the software given in archive with this file.

In order to correctly flash your module, please refer to the other pdf "`Flash.ESP8266.WiFi.module.pdf`".

B AT Commands

Below you can find the section from the `ESP8266` instruction manual regarding the AT commands.



1.

Overview

This document provides AT commands based on ESP8266_NONOS_SDK and explain how to use them. AT command set is divided into: Basic AT commands, Wi-Fi AT commands, and TCP/IP AT commands.

1.1. User-Defined AT Commands

Please use only English letters when naming user-defined AT commands. The AT command name must NOT contain characters or numbers.

AT firmware is based on ESP8266_NONOS_SDK. Espressif Systems' AT commands are provided in **libat.a**, which is included in the AT BIN firmware. Examples of customized, user-defined AT commands are provided in **ESP8266_NONOS_SDK/example/at**.

Examples of implementing user-defined AT commands are provided in **/ESP8266_NONOS_SDK/examples/at/user/user_main.c**. The structure, **at_funcationType**, is used to define four types of a command, for details of which please refer to the following table.

| Definition | Type | Description | |
|-------------|---------|---|--------------------------------------|
| at_testCmd | Test | AT Command | AT+TEST=? |
| | | Registered Callback In Example | at_testCmdTest |
| | | Function Design | Return the value range of parameters |
| | | If at_testCmd is registered as NULL, there will be no testing command. | |
| at_queryCmd | Query | AT Command | AT+TEST? |
| | | Registered Callback In Example | at_queryCmdTest |
| | | Function Design | Return the current value |
| | | If at_queryCmd is registered as NULL, there will be no Query Command. | |
| at_setupCmd | Set | AT Command | AT+TEST=parameter1, parameter2, ... |
| | | Registered Callback In Example | at_setupCmdTest |
| | | Function Design | Set configuration |
| | | If at_setupCmd is registered as NULL, there will be no setup command. | |
| at_exeCmd | Execute | AT Command | AT+TEST |
| | | Registered Callback In Example | at_exeCmdTest |
| | | Function Design | Execute an action |
| | | If at_exeCmd is registered as NULL, there will be no execution command. | |



All the files in folder **at** should be copied to the folder **app** in **ESP8266_NONOS_SDK** if users need to compile the AT firmware.



For details please refer to [ESP8266 Getting Started Guide](#).

1.2. Downloading AT Firmware into the Flash

Please refer to **ESP8266_NONOS_SDK/bin/at/readme.txt** for instructions on how to download AT firmware into flash. Please use Espressif's official Flash Download Tools to download the firmware. Make sure you select the corresponding flash size.

Espressif's official Flash Download Tools:

http://espressif.com/en/support/download/other-tools?keys=&field_type_tid%5B%5D=14.

1.2.1. 4 Mbit Flash

With the release of ESP8266_NONOS_SDK_V2.0.0, AT_V1.3, AT firmware can use 4-Mbit flash but does not supports FOTA (upgrade AT firmware through Wi-Fi) function.

| BIN | Address | Description |
|---------------------------|---------|---|
| blank.bin | 0x78000 | Initializes the RF_CAL parameter area. |
| esp_init_data_default.bin | 0x7C000 | Stores the default RF parameter values; the BIN has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this BIN has to be downloaded too. |
| blank.bin | 0x7A000 | Initializes the flash user parameter area; for more details please see Appendix . |
| blank.bin | 0x7E000 | Initializes Flash system parameter area; for more details please see Appendix . |
| eagle.flash.bin | 0x00000 | In /bin/at/noboot . |
| eagle.irom0text.bin | 0x10000 | In /bin/at/noboot . |

1.2.2. 8 Mbit Flash

If the flash size is 8 Mbit or larger, users can use boot mode which supports AT firmware upgrade feature through Wi-Fi by command **AT+CIUPDATE**. Use Espressif Flash download tool and select flash size: 8 Mbit.



| BIN | Address | Description |
|---------------------------|---------|---|
| blank.bin | 0xFB000 | Initializes the RF_CAL parameter area. |
| esp_init_data_default.bin | 0xFC000 | Initializes the RF_CAL parameter area. |
| blank.bin | 0x7E000 | Stores the default RF parameter values; the BIN has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this BIN has to be downloaded too. |
| blank.bin | 0xFE000 | Initializes the flash user parameter area; for more details please see Appendix . |
| boot.bin | 0x00000 | In /bin/at |
| user1.1024.new.2.bin | 0x01000 | In /bin/at/512+512 |

1.2.3. 16 Mbit Flash, Map: 512 KB + 512 KB

Use Espressif Flash download tool and select flash size: 16 Mbit.

| BIN | Address | Description |
|---------------------------|----------|---|
| blank.bin | 0x1FB000 | Initializes RF_CAL parameter area. |
| esp_init_data_default.bin | 0x1FC000 | Stores default RF parameter values, has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this bin has to be downloaded too. |
| blank.bin | 0x7E000 | Initializes Flash user parameter area, more details in Appendix . |
| blank.bin | 0x1FE000 | Initializes Flash system parameter area, more details in Appendix . |
| boot.bin | 0x00000 | In /bin/at . |
| user1.1024.new.2.bin | 0x01000 | In /bin/at/512+512 . |

1.2.4. 16 Mbit Flash, Map: 1024 KB + 1024 KB

Use Espressif Flash download tool and select flash size: 16 Mbit-C1.

| BIN | Address | Description |
|---------------------------|----------|---|
| blank.bin | 0x1FB000 | Initializes RF_CAL parameter area. |
| esp_init_data_default.bin | 0x1FC000 | Stores default RF parameter values, has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this bin has to be downloaded too. |
| blank.bin | 0xFE000 | Initializes Flash user parameter area, more details in Appendix . |



| BIN | Address | Description |
|----------------------|----------|--|
| blank.bin | 0x1FE000 | Initializes Flash system parameter area, more details in Appendix . |
| boot.bin | 0x00000 | In /bin/at . |
| user1.2048.new.5.bin | 0x01000 | In /bin/at/1024+1024 . |

1.2.5. 32 Mbit Flash, Map: 512 KB + 512 KB

Use Espressif Flash download tool and select flash size: 32 Mbit.

| BIN | Address | Description |
|---------------------------|----------|---|
| blank.bin | 0x3FB000 | Initializes RF_CAL parameter area. |
| esp_init_data_default.bin | 0x3FC000 | Stores default RF parameter values, has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this bin has to be downloaded too. |
| blank.bin | 0x7E000 | Initializes Flash user parameter area, more details in Appendix . |
| blank.bin | 0x3FE000 | Initializes Flash system parameter area, more details in Appendix . |
| boot.bin | 0x00000 | In /bin/at . |
| user1.1024.new.2.bin | 0x01000 | In /bin/at/512+512 . |

1.2.6. 32 Mbit Flash, Map: 1024 KB + 1024 KB

Use Espressif Flash download tool and select flash size: 32 Mbit-C1.

| BIN | Address | Description |
|---------------------------|----------|---|
| blank.bin | 0x3FB000 | Initializes RF_CAL parameter area |
| esp_init_data_default.bin | 0x3FC000 | Stores default RF parameter values, has to be downloaded into flash at least once. If the RF_CAL parameter area is initialized, this bin has to be downloaded too. |
| blank.bin | 0xFE000 | Initializes Flash user parameter area, more details in Appendix . |
| blank.bin | 0x3FE000 | Initializes Flash system parameter area, more details in Appendix . |
| boot.bin | 0x00000 | In /bin/at . |
| user1.2048.new.5.bin | 0x01000 | In /bin/at/1024+1024 . |



! Notes:

- Please make sure that correct BIN (*/ESP8266_NONOS_SDK/bin/at*) is already in the chip (ESP8266) before using the AT commands listed in this document.
- AT firmware uses priority levels 0 and 1 of `system_os_task`, so only one task of priority 2 is allowed to be set up by the user.
- AT returns messages below to show status of the ESP8266 Station's Wi-Fi connection.
 - ▶ Wi-Fi CONNECTED: Wi-Fi is connected.
 - ▶ Wi-Fi GOT IP: the ESP8266 Station has got the IP from the AP.
 - ▶ Wi-Fi DISCONNECT: Wi-Fi is disconnected.



2. Command Description

Each command set contains four types of AT commands.

| Type | Command Format | Description |
|-----------------|----------------|---|
| Test Command | AT+<x>=? | Queries the Set Commands' internal parameters and their range of values. |
| Query Command | AT+<x>? | Returns the current value of parameters. |
| Set Command | AT+<x>=<...> | Sets the value of user-defined parameters in commands, and runs these commands. |
| Execute Command | AT+<x> | Runs commands with no user-defined parameters. |

Notice:

- Not all AT commands support all four variations mentioned above.
- Square brackets [] designate the default value; it is either not required or may not appear.
- String values need to be included in double quotation marks, for example: AT+CWSAP="ESP756290", "21030826", 1, 4.
- The default baud rate is 115200. The configuration of serial options is shown in Figure 2-1.
- AT commands have to be capitalized, and must end with /r/n, as Figure 2-2 shows.




Figure 2-1. Configuration of Serial Options




Figure 2-2. New Line Mode



3. Basic AT Commands

3.1. Overview

| Commands | Description |
|-----------------|--|
| AT | Tests AT startup. |
| AT+RST | Restarts the module. |
| AT+GMR | Checks version information. |
| AT+GSLP | Enters Deep-sleep mode. |
| ATE | Configures echoing of AT commands. |
| AT+RESTORE | Restores the factory default settings of the module. |
| AT+UART | UART configuration. [@deprecated] |
| AT+UART_CUR | The current UART configuration. |
| AT+UART_DEF | The default UART configuration, saved in flash. |
| AT+SLEEP | Configures the sleep modes. |
| AT+WAKEUPGPIO | Configures a GPIO to wake ESP8266 up from Light-sleep mode. |
| AT+RFPOWER | Sets the maximum value of the RF TX Power. |
| AT+RFVDD | Sets the RF TX Power according to VDD33. |
| AT+RFAUTOTRACE | Sets RF frequency offset trace. |
| AT+SYSRAM | Checks the available RAM size. |
| AT+SYSADC | Checks the ADC value. |
| AT+SYSIOSETCFG | Sets configuration of IO pins. |
| AT+SYSIOGETCFG | Gets configuration of IO pins. |
| AT+SYSGPIODIR | Configures the direction of GPIO. |
| AT+SYSGPIOWRITE | Configures the GPIO output level |
| AT+SYSGPIOREAD | Checks the GPIO input level. |



3.2. Commands

3.2.1. AT—Tests AT Startup

| | |
|-----------------|----|
| Execute Command | AT |
| Response | OK |
| Parameters | - |

3.2.2. AT+RST—Restarts the Module

| | |
|-----------------|--------|
| Execute Command | AT+RST |
| Response | OK |
| Parameters | - |

3.2.3. AT+GMR—Checks Version Information

| | |
|-----------------|---|
| Execute Command | AT+GMR |
| Response | <AT version info> <SDK version info> <compile time> OK |
| Parameters | <ul style="list-style-type: none">• <AT version info>: information about the AT version.• <SDK version info>: information about the SDK version.• <compile time>: the duration of time for compiling the BIN. |

3.2.4. AT+GSLP—Enters Deep-sleep Mode

| | |
|-------------|--|
| Set Command | AT+GSLP=<time> |
| Response | <time> OK |
| Parameters | <time>: the duration of ESP8266's sleep. Unit: ms. ESP8266 will wake up after Deep-sleep for as many milliseconds (ms) as <time> indicates. |
| Note | A minor adjustment has to be made before the module enter the Deep-sleep mode, i.e., connecting XPD_DCDC to EXT_RSTB via a 0-ohm resistor. |



3.2.5. ATE—AT Commands Echoing

| | |
|-----------------|---|
| Execute Command | ATE |
| Response | OK |
| Parameters | <ul style="list-style-type: none">• ATE0: Switches echo off.• ATE1: Switches echo on. |
| Note | This command ATE is used to trigger command echo. It means that entered commands can be echoed back to the sender when ATE command is used. Two parameters are possible. The command returns OK in normal cases and ERROR when a parameter other than 0 or 1 was specified. |

3.2.6. AT+RESTORE—Restores the Factory Default Settings

| | |
|-----------------|---|
| Execute Command | AT+RESTORE |
| Response | OK |
| Note | The execution of this command will reset all parameters saved in flash, and restore the factory default settings of the module. The chip will be restarted when this command is executed. |

3.2.7. AT+UART—UART Configuration

[@deprecated] This command is deprecated. Please use AT+UART_CUR or AT+UART_DEF instead.

| | | |
|----------|--|--|
| Command | Query Command: AT+UART? | Set Command: AT+UART=<baudrate>,<databits>,<stopbits>,<parity>,<flow control> |
| Response | +UART:<baudrate>,<databits>,<stopbits>,<parity>,<flow control> OK | OK |
| Note | Command AT+UART? will return the actual value of UART configuration parameters, which may have allowable errors compared with the set value. For example, if the UART baud rate is set as 115200, the baud rate returned by using command AT+UART? could be 115273. | - |



| | |
|------------|---|
| Parameters | <ul style="list-style-type: none">• <baudrate>: UART baud rate• <databits>: data bits<ul style="list-style-type: none">▸ 5: 5-bit data▸ 6: 6-bit data▸ 7: 7-bit data▸ 8: 8-bit data• <stopbits>: stop bits<ul style="list-style-type: none">▸ 1: 1-bit stop bit▸ 2: 1.5-bit stop bit▸ 3: 2-bit stop bit• <parity>: parity bit<ul style="list-style-type: none">▸ 0: None▸ 1: Odd▸ 2: Even• <flow control>: flow control<ul style="list-style-type: none">▸ 0: flow control is not enabled▸ 1: enable RTS▸ 2: enable CTS▸ 3: enable both RTS and CTS |
| Notes | <ol style="list-style-type: none">1. The configuration changes will be saved in the user parameter area in the flash, and will still be valid when the chip is powered on again.2. The use of flow control requires the support of hardware:<ul style="list-style-type: none">▸ MTCK is UART0 CTS▸ MTDO is UART0 RTS3. The range of baud rates supported: 110~115200*40. |
| Example | AT+UART=115200,8,1,0,3 |



3.2.8. AT+UART_CUR—Current UART Configuration; Not Saved in the Flash

| | | |
|-------------------|---|--|
| Command | Query Command: AT+UART_CUR? | Set Command: AT+UART_CUR=<baudrate>,<databits>,<stopbits>,<parity>,<flow control> |
| Response | +UART_CUR:<baudrate>,<databits>,<stopbits>,<parity>,<flow control> OK | OK |
| Note | Command AT+UART_CUR? will return the actual value of UART configuration parameters, which may have allowable errors compared with the set value because of the clock division. For example, if the UART baud rate is set as 115200, the baud rate returned by using command AT+UART_CUR? could be 115273. | - |
| Parameters | <ul style="list-style-type: none">• <baudrate>: UART baud rate• <databits>: data bits<ul style="list-style-type: none">▸ 5: 5-bit data▸ 6: 6-bit data▸ 7: 7-bit data▸ 8: 8-bit data• <stopbits>: stop bits<ul style="list-style-type: none">▸ 1: 1-bit stop bit▸ 2: 1.5-bit stop bit▸ 3: 2-bit stop bit• <parity>: parity bit<ul style="list-style-type: none">▸ 0: None▸ 1: Odd▸ 2: Even• <flow control>: flow control<ul style="list-style-type: none">▸ 0: flow control is not enabled▸ 1: enable RTS▸ 2: enable CTS▸ 3: enable both RTS and CTS | |
| Notes | <ol style="list-style-type: none">1. The configuration changes will NOT be saved in the flash.2. The use of flow control requires the support of hardware:<ul style="list-style-type: none">▸ MTCK is UART0 CTS▸ MTDO is UART0 RTS3. The range of baud rates supported: 110~115200*40. | |
| Example | AT+UART_CUR=115200,8,1,0,3 | |



3.2.9. AT+UART_DEF—Default UART Configuration; Saved in the Flash

| | | |
|------------------|---|--|
| Command | Query Command: AT+UART_DEF? | Set Command: AT+UART_DEF=<baudrate>,<databits>,<stopbits> ,<parity>,<flow control> |
| Response | +UART_DEF:<baudrate>,<databits>,<stopbits>,< parity>,<flow control> OK | OK |
| Parameter | <ul style="list-style-type: none">• <baudrate>: UART baud rate• <databits>: data bits<ul style="list-style-type: none">▸ 5: 5-bit data▸ 6: 6-bit data▸ 7: 7-bit data▸ 8: 8-bit data• <stopbits>: stop bits<ul style="list-style-type: none">▸ 1: 1-bit stop bit▸ 2: 1.5-bit stop bit▸ 3: 2-bit stop bit• <parity>: parity bit<ul style="list-style-type: none">▸ 0: None▸ 1: Odd▸ 2: Even• <flow control>: flow control<ul style="list-style-type: none">▸ 0: flow control is not enabled▸ 1: enable RTS▸ 2: enable CTS▸ 3: enable both RTS and CTS | |
| Notes | <ol style="list-style-type: none">1. The configuration changes will be saved in the user parameter area in the flash, and will still be valid when the chip is powered on again.2. The use of flow control requires the support of hardware:<ul style="list-style-type: none">▸ MTCK is UART0 CTS▸ MTDO is UART0 RTS3. The range of baud rates supported: 110~115200*40. | |
| Example | AT+UART_DEF=115200,8,1,0,3 | |



3.2.10. AT+SLEEP—Configures the Sleep Modes

| | | |
|-----------|--|---------------------------------------|
| Command | Query Command: AT+SLEEP? | Set Command: AT+SLEEP=<sleep mode> |
| Response | +SLEEP:<sleep mode> OK | OK or ERROR |
| Parameter | <sleep mode>: <ul style="list-style-type: none">‣ 0: disables sleep mode‣ 1: Light-sleep mode‣ 2: Modem-sleep mode | |
| Notes | This command can only be used in Station mode. Modem-sleep is the default sleep mode. | |
| Example | AT+SLEEP=0 | |

3.2.11. AT+WAKEUPGPIO—Configures a GPIO to Wake ESP8266 up from Light-sleep Mode

| | |
|-----------|--|
| Command | AT+WAKEUPGPIO=<enable>,<trigger_GPIO>,<trigger_level>[,<awake_GPIO>,<awake_level>] |
| Response | OK |
| Parameter | <ul style="list-style-type: none">• <enable><ul style="list-style-type: none">‣ 0: ESP8266 can NOT be woken up from light-sleep by GPIO.‣ 1: ESP8266 can be woken up from light-sleep by GPIO.• <trigger_GPIO><ul style="list-style-type: none">‣ Sets the GPIO to wake ESP8266 up; range of value: [0, 15].• <trigger_level><ul style="list-style-type: none">‣ 0: The GPIO wakes up ESP8266 on low level.‣ 1: The GPIO wakes up ESP8266 on high level.• [<awake_GPIO>]<ul style="list-style-type: none">‣ Optional; this parameter is used to set a GPIO as a flag of ESP8266's being awoken from Light-sleep; range of value: [0, 15].• [<awake_level>]<ul style="list-style-type: none">‣ Optional;‣ 0: The GPIO is set to be low level after the wakeup process.‣ 1: The GPIO is set to be high level after the wakeup process. |
| Notes | <ul style="list-style-type: none">• The value of <trigger_GPIO> and <awake_GPIO> in the command should not be the same.• After being woken up by <trigger_GPIO> from Light-sleep, when the ESP8266 attempts to sleep again, it will check the status of the <trigger_GPIO>:<ul style="list-style-type: none">‣ if it is still in the wakeup status, the ESP8266 will enter Modem-sleep mode instead;‣ if it is NOT in the wakeup status, the ESP8266 will enter Light-sleep mode. |



| | |
|---------|--|
| Example | <ul style="list-style-type: none">Set ESP8266 to be woken from Light-sleep, when GPIO0 is on low level: <code>AT+WAKEUPGPIO=1,0,0</code>Set ESP8266 to be woken from Light-sleep, when GPIO0 is on high level. After the waking-up, GPIO13 is set to high level. <code>AT+WAKEUPGPIO=1,0,1,13,1</code>Disable the function that ESP8266 can be woken up from Light-sleep by a GPIO. <code>AT+WAKEUPGPIO=0</code> |
|---------|--|

3.2.12. AT+RFPOWER—Sets the Maximum Value of RF TX Power

| | |
|-------------|--|
| Set Command | AT+RFPOWER=<TX Power> |
| Response | OK |
| Parameter | <TX Power>: the maximum value of RF TX power; range: [0, 82]; unit: 0.25 dBm. |
| Note | This command sets the maximum value of ESP8266 RF TX power; it is not precise. The actual value could be smaller than the set value. |
| Example | AT+RFPOWER=50 |

3.2.13. AT+RFVDD—Sets RF TX Power According to VDD33

| | | | |
|-----------|---|--|---|
| Command | Query Command: AT+RFVDD? Function: Checks the value of ESP8266 VDD33. | Set Command: AT+RFVDD=<VDD33> Function: Sets the RF TX Power according to <VDD33>. | Execute Command: AT+RFVDD Function: Automatically sets the RF TX Power. |
| Response | +RFVDD: <VDD33> OK | OK | OK |
| Parameter | <VDD33>: power voltage of ESP8266 VDD33; unit: 1/1024 V. | <VDD33>: power voltage of ESP8266 VDD33 ; range: [1900, 3300]. | - |
| Note | The command should only be used when TOUT pin has to be suspended, or else the returned value would be invalid. | - | TOUT pin has to be suspended in order to measure VDD33. |
| Example | AT+RFVDD=2800 | | |



3.2.14. AT+RFAUTOTRACE—Sets RF Frequency Offset Trace

| | | |
|-----------|--|---|
| Command | Query Command: AT+RFAUTOTRACE? | Set Command: AT+RFAUTOTRACE=<enable> |
| Response | +RFAUTOTRACE:<enable> OK | OK |
| Parameter | <enable>: <ul style="list-style-type: none">▸ 0: disables RF frequency offset trace▸ 1: enables RF frequency offset trace | |
| Notes | <ul style="list-style-type: none">• The RF frequency offset trace function is enabled by default.• This configuration will be saved in the user parameter area in flash, and take effect after the chip restarts. | |
| Example | AT+RFAUTOTRACE=0 AT+RST | |

3.2.15. AT+SYSRAM—Checks the Remaining Space of RAM

| | |
|---------------|---|
| Query Command | AT+SYSRAM? |
| Response | +SYSRAM:<remaining RAM size> OK |
| Parameter | <remaining RAM size>: remaining space of RAM, unit: byte. |

3.2.16. AT+SYSADC—Checks the Value of ADC

| | |
|---------------|---|
| Query Command | AT+SYSADC? |
| Response | +SYSADC:<ADC> OK |
| Parameter | <ADC>: the value of ADC; unit: 1/1024V. |



| | |
|-----------|---|
| Parameter | <ul style="list-style-type: none">• <pin>: number of an IO pin• <mode>: the working mode of the IO pin• <pull-up><ul style="list-style-type: none">▸ 0: disable the pull-up▸ 1: enable the pull-up of the IO pin |
| Note | Please refer to ESP8266 Pin List for uses of AT+SYSIO-related commands. |
| Example | AT+SYSIOSETCFG=12,3,1 //Set GPIO12 to work as a GPIO |

3.2.18. AT+SYSIOGETCFG—Checks the Working Modes of IO Pins

| | |
|-------------|---|
| Set Command | AT+SYSIOGETCFG=<pin> |
| Response | +SYSIOGETCFG:<pin>,<mode>,<pull-up> OK |
| Parameter | <ul style="list-style-type: none">• <pin>: number of an IO pin• <mode>: the working mode of the IO pin• <pull-up><ul style="list-style-type: none">▸ 0: disable the pull-up▸ 1: enable the pull-up of the IO pin |
| Note | Please refer to ESP8266 Pin List for uses of AT+SYSIO-related commands. |

3.2.19. AT+SYSGPIODIR—Configures the Direction of a GPIO

| | |
|-------------|---|
| Set Command | AT+SYSGPIODIR=<pin>,<dir> |
| Response | <ul style="list-style-type: none">• If the configuration is successful, the command will return: OK• If the IO pin is not in GPIO mode, the command will return: NOT GPIO MODE! ERROR |
| Parameter | <ul style="list-style-type: none">• <pin>: GPIO pin number• <dir>:<ul style="list-style-type: none">▸ 0: sets the GPIO as an input▸ 1: sets the GPIO as an output |
| Note | Please refer to ESP8266 Pin List for uses of AT+SYSGPIO-related commands. |
| Example | AT+SYSIOSETCFG=12,3,1 //Set GPIO12 to work as a GPIO AT+SYSGPIODIR=12,0 //Set GPIO12 to work as an input |



3.2.20. AT+SYSGPIOWRITE—Configures the Output Level of a GPIO

| | |
|-------------|---|
| Set Command | AT+SYSGPIOWRITE=<pin>,<level> |
| Response | <ul style="list-style-type: none">If the configuration is successful, the command will return: OKIf the IO pin is not in output mode, the command will return: NOT OUTPUT! ERROR |
| Parameter | <ul style="list-style-type: none"><pin>: GPIO pin number<level>:<ul style="list-style-type: none">▸ 0: low level▸ 1: high level |
| Note | Please refer to ESP8266 Pin List for uses of AT+SYSGPIO-related commands. |
| Example | AT+SYSIOSETCFG=12,3,1 //Set GPIO12 to work as a GPIO AT+SYSGPIODIR=12,1 //Set GPIO12 to work as an output AT+SYSGPIOWRITE=12,1 //Set GPIO12 to output high level |

3.2.21. AT+SYSGPIOREAD—Reads the GPIO Input Level

| | |
|-------------|--|
| Set Command | AT+SYSGPIOREAD=<pin> |
| Response | <ul style="list-style-type: none">If the configuration is successful, the command returns: +SYSGPIOREAD:<pin>,<dir>,<level> OKIf the IO pin is not in GPIO mode, the command will return: NOT GPIO MODE! ERROR |
| Parameter | <ul style="list-style-type: none"><pin>: GPIO pin number<dir>:<ul style="list-style-type: none">▸ 0: sets the GPIO as an input▸ 1: sets the GPIO as an output<level>:<ul style="list-style-type: none">▸ 0: low level▸ 1: high level |
| Note | Please refer to ESP8266 Pin List for uses of AT+SYSGPIO-related commands. |



Example

```
AT+SYSIOSETCFG=12,3,1 //Set GPIO12 to work as a GPIO
AT+SYSGPIODIR=12,0 //Set GPIO12 to work as an input
AT+SYSGPIOREAD=12
```



4. Wi-Fi AT Commands

4.1. Overview

| Commands | Description |
|------------------|---|
| AT+CWMODE | Sets the Wi-Fi mode (Station/AP/Station+AP). @deprecated |
| AT+CWMODE_CUR | Sets the Wi-Fi mode (Station/AP/Station+AP); configuration not saved in the flash. |
| AT+CWMODE_DEF | Sets the default Wi-Fi mode (Station/AP/Station+AP); configuration saved in the flash. |
| AT+CWJAP | Connect to an AP. @deprecated |
| AT+CWJAP_CUR | Connects to an AP; configuration not saved in the flash. |
| AT+CWJAP_DEF | Connects to an AP; configuration saved in the flash. |
| AT+CWLAPOPT | Sets the configuration of command AT+CWLAP. |
| AT+CWLAP | Lists available APs. |
| AT+CWQAP | Disconnects from an AP. |
| AT+CWSAP | Sets the configuration of the ESP8266 SoftAP. @deprecated |
| AT+CWSAP_CUR | Sets the current configuration of the ESP8266 SoftAP; configuration not saved in the flash. |
| AT+CWSAP_DEF | Sets the configuration of the ESP8266 SoftAP; configuration saved in the flash. |
| AT+CWLIF | Gets the Station IP to which the ESP8266 SoftAP is connected. |
| AT+CWDHCP | Enables/Disables DHCP. @deprecated |
| AT+CWDHCP_CUR | Enables/Disables DHCP; configuration not saved in the flash. |
| AT+CWDHCP_DEF | Enable/Disable DHCP; configuration saved in the flash. |
| AT+CWDHCPS_CUR | Sets the IP range of the DHCP server; configuration not saved in the flash. |
| AT+CWDHCPS_DEF | Sets the IP range of the DHCP server; configuration saved in the flash. |
| AT+CWAUTOCONN | Connects to an AP automatically on power-up. |
| AT+CIPSTAMAC | Sets the MAC address of the ESP8266 Station. @deprecated |
| AT+CIPSTAMAC_CUR | Sets the MAC address of the ESP8266 Station; configuration not saved in the flash. |
| AT+CIPSTAMAC_DEF | Sets the MAC address of ESP8266 station; configuration saved in the flash. |



| | |
|--------------------|--|
| AT+CIPAPMAC | Sets the MAC address of the ESP8266 SoftAP. [@deprecated] |
| AT+CIPAPMAC_CUR | Sets the MAC address of the ESP8266 SoftAP; configuration not saved in the flash. |
| AT+CIPAPMAC_DEF | Sets the MAC address of the ESP8266 SoftAP; configuration saved in the flash. |
| AT+CIPSTA | Sets the IP address of the ESP8266 Station. [@deprecated] |
| AT+CIPSTA_CUR | Sets the IP address of the ESP8266 Station; configuration not saved in the flash. |
| AT+CIPSTA_DEF | Sets the IP address of the ESP8266 Station; configuration saved in the flash. |
| AT+CIPAP | Sets the IP address of ESP8266 SoftAP. [@deprecated] |
| AT+CIPAP_CUR | Sets the IP address of ESP8266 SoftAP; configuration not saved in the flash. |
| AT+CIPAP_DEF | Sets the IP address of ESP8266 SoftAP; configuration saved in the flash. |
| AT+CWSTARTSMART | Starts SmartConfig. |
| AT+CWSTOPSMART | Stops SmartConfig. |
| AT+CWSTARTDISCOVER | Enables the mode that ESP8266 can be found by WeChat. |
| AT+CWSTOPDISCOVER | Disables the mode that ESP8266 can be found by WeChat. |
| AT+WPS | Sets the WPS function. |
| AT+MDNS | Sets the MDNS function. |
| AT+CWHOSTNAME | Sets the host name of the ESP8266 Station. |



4.2. Commands

4.2.1. AT+CWMODE—Sets the Wi-Fi Mode (Station/SoftAP/Station+SoftAP)

[@deprecated] This command is deprecated. Please use AT+CWMODE_CUR or AT+CWMODE_DEF instead.

| | | | |
|-------------------|--|---|---|
| Commands | Test Command: AT+CWMODE=? | Query Command: AT+CWMODE? Function: to query the current Wi-Fi mode of ESP8266. | Set Command: AT+CWMODE=<mode> Function: to set the current Wi-Fi mode of ESP8266. |
| Response | +CWMODE:<mode> OK | +CWMODE:<mode> OK | OK |
| Parameters | <mode>: ▶ 1: Station mode ▶ 2: SoftAP mode ▶ 3: SoftAP+Station mode | | |
| Note | The configuration changes will be saved in the system parameter area in the flash. | | |
| Example | AT+CWMODE=3 | | |

4.2.2. AT+CWMODE_CUR—Sets the Current Wi-Fi mode; Configuration Not Saved in the Flash

| | | | |
|-------------------|--|---|---|
| Commands | Test Command: AT+CWMODE_CUR=? | Query Command: AT+CWMODE_CUR? Function: to query the current Wi-Fi mode of ESP8266. | Set Command: AT+CWMODE_CUR=<mode> Function: to set the current Wi-Fi mode of ESP8266. |
| Response | +CWMODE_CUR:<mode> OK | +CWMODE_CUR:<mode> OK | OK |
| Parameters | <mode>: ▶ 1: Station mode ▶ 2: SoftAP mode ▶ 3: SoftAP+Station mode | | |
| Note | The configuration changes will NOT be saved in the flash. | | |
| Example | AT+CWMODE_CUR=3 | | |

4.2.3. AT+CWMODE_DEF—Sets the Default Wi-Fi mode; Configuration Saved in the Flash

| | | | |
|-----------------|----------------------------------|---|---|
| Commands | Test Command: AT+CWMODE_DEF=? | Query Command: AT+CWMODE_DEF? Function: to query the current Wi-Fi mode of ESP8266. | Set Command: AT+CWMODE_DEF=<mode> Function: to set the current Wi-Fi mode of ESP8266. |
| Response | +CWMODE_DEF:<mode> OK | +CWMODE_DEF:<mode> OK | OK |



| | |
|------------|---|
| Parameters | <mode>: <ul style="list-style-type: none">▶ 1: Station mode▶ 2: SoftAP mode▶ 3: SoftAP+Station mode |
| | |
| Note | The configuration changes will be saved in the system parameter area in the flash. |
| Example | AT+CWMODE_DEF=3 |

4.2.4. AT+CWJAP—Connects to an AP

[@deprecated] This command is deprecated. Please use AT+CWJAP_CUR or AT+CWJAP_DEF instead.

| | | |
|------------|---|--|
| Commands | Query Command: AT+CWJAP? Function: to query the AP to which the ESP8266 Station is already connected. | Set Command: AT+CWJAP=<ssid>,<pwd>[,<bssid>] Function: to set the AP to which the ESP8266 Station needs to be connected. |
| | | |
| Response | +CWJAP:<ssid>,<bssid>,<channel>,<rssi> OK | OK or +CWJAP:<error code> ERROR |
| Parameters | <ssid>: a string parameter showing the SSID of the target AP. | <ul style="list-style-type: none">• <ssid>: the SSID of the target AP.• <pwd>: password, MAX: 64-byte ASCII.• [<bssid>]: the target AP's MAC address, used when multiple APs have the same SSID.• <error code>: (for reference only)<ul style="list-style-type: none">▶ 1: connection timeout.▶ 2: wrong password.▶ 3: cannot find the target AP.▶ 4: connection failed. <p>This command requires Station mode to be active. Escape character syntax is needed if SSID or password contains any special characters, such as , or " or \.</p> |
| Note | The configuration changes will be saved in the system parameter area in the flash. | |
| Examples | AT+CWJAP="abc", "0123456789" For example, if the target AP's SSID is "ab\,c" and the password is "0123456789\"", the command is as follows: AT+CWJAP="ab\\,c", "0123456789\"" If multiple APs have the same SSID as "abc", the target AP can be found by BSSID: AT+CWJAP="abc", "0123456789", "ca:d7:19:d8:a6:44" | |



4.2.5. AT+CWJAP_CUR—Connects to an AP; Configuration Not Saved in the Flash

| | | |
|----------|---|--|
| Commands | Query Command: AT+CWJAP_CUR? | Set Command: AT+CWJAP_CUR=<ssid>,<pwd>[,<bssid>] |
| | Function: to query the AP to which the ESP8266 Station is already connected. | Function: to set the AP to which the ESP8266 Station needs to be connected. |
| Response | +CWJAP_CUR:<ssid>,<bssid>,<channel>,<rssi> OK | OK or +CWJAP_CUR:<error code> ERROR |
| | | <ul style="list-style-type: none">• <ssid>: the SSID of the target AP.• <pwd>: password, MAX: 64-byte ASCII.• [<bssid>]: the target AP's MAC address, used when multiple APs have the same SSID.• <error code>: (for reference only)<ul style="list-style-type: none">▶ 1: connection timeout.▶ 2: wrong password.▶ 3: cannot find the target AP.▶ 4: connection failed. <p>This command requires Station mode to be active. Escape character syntax is needed if SSID or password contains any special characters, such as , or " or \.</p> |
| Note | The configuration changes will NOT be saved in the flash. | |
| Examples | AT+CWJAP_CUR="abc", "0123456789" For example, if the target AP's SSID is "ab\,c" and the password is "0123456789\"", the command is as follows: AT+CWJAP_CUR="ab\\,c", "0123456789\\\"\\\"" If multiple APs have the same SSID as "abc", the target AP can be found by BSSID: AT+CWJAP_CUR="abc", "0123456789", "ca:d7:19:d8:a6:44" | |

4.2.6. AT+CWJAP_DEF—Connects to an AP; Configuration Saved in the Flash

| | | |
|----------|--|---|
| Commands | Query Command: AT+CWJAP_DEF? | Set Command: AT+CWJAP_DEF=<ssid>,<pwd>[,<bssid>] |
| | Function: to query the AP to which the ESP8266 Station is already connected. | Function: to set the AP to which the ESP8266 Station needs to be connected. |
| Response | +CWJAP_DEF:<ssid>,<bssid>,<channel>,<rssi> OK | OK or +CWJAP_DEF:<error code> ERROR |
| | | |



| | | |
|------------|---|--|
| Parameters | <p><ssid>: a string parameter showing the SSID of the target AP.</p> | <ul style="list-style-type: none">• <ssid>: the SSID of the target AP.• <pwd>: password, MAX: 64-byte ASCII.• [<bssid>]: the target AP's MAC address, used when multiple APs have the same SSID.• <error code>: (for reference only)<ul style="list-style-type: none">▶ 1: connection timeout.▶ 2: wrong password.▶ 3: cannot find the target AP.▶ 4: connection failed. <p>This command requires Station mode to be active. Escape character syntax is needed if SSID or password contains any special characters, such as , or " or \.</p> |
| Note | The configuration changes will be saved in the system parameter area in the flash. | |
| Examples | <p>AT+CWJAP_DEF="abc", "0123456789"</p> <p>For example, if the target AP's SSID is "ab\,c" and the password is "0123456789\", the command is as follows:</p> <p>AT+CWJAP_DEF="ab\\,c", "0123456789\\\\"</p> <p>If multiple APs have the same SSID as "abc", the target AP can be found by BSSID:</p> <p>AT+CWJAP_DEF="abc", "0123456789", "ca:d7:19:d8:a6:44"</p> | |



4.2.7. AT+CWLAPOPT—Sets the Configuration for the Command AT+CWLAP

| | |
|-------------|--|
| Set Command | AT+CWLAPOPT=<sort_enable>,<mask> |
| Response | OK or ERROR |
| Parameters | <ul style="list-style-type: none">• <sort_enable>: determines whether the result of command AT+CWLAP will be listed according to RSSI:<ul style="list-style-type: none">▶ 0: the result is ordered according to RSSI.▶ 1: the result is not ordered according to RSSI.• <mask>: determines the parameters shown in the result of AT+CWLAP; 0 means not showing the parameter corresponding to the bit, and 1 means showing it.<ul style="list-style-type: none">▶ bit 0: determines whether <ecn> will be shown in the result of AT+CWLAP.▶ bit 1: determines whether <ssid> will be shown in the result of AT+CWLAP.▶ bit 2: determines whether <rssi> will be shown in the result of AT+CWLAP.▶ bit 3: determines whether <mac> will be shown in the result of AT+CWLAP.▶ bit 4: determines whether <ch> will be shown in the result of AT+CWLAP.▶ bit 5: determines whether <freq offset> will be shown in the result of AT+CWLAP.▶ bit 6: determines whether <freq calibration> will be shown in the result of AT+CWLAP. |
| Example | <p>AT+CWLAPOPT=1,127</p> <p>The first parameter is 1, meaning that the result of the command AT+CWLAP will be ordered according to RSSI;</p> <p>The second parameter is 127, namely 0x7F, meaning that the corresponding bits of <mask> are set to 1. All parameters will be shown in the result of AT+CWLAP.</p> |



4.2.8. AT+CWLAP—Lists Available APs

| | | |
|-------------------|---|---|
| Commands | Set Command: AT+CWLAP=<ssid>[,<mac>,<ch>] Function: to query the APs with specific SSID and MAC on a specific channel. | Execute Command: AT+CWLAP Function: to list all available APs. |
| Response | +CWLAP:<ecn>,<ssid>,<rssi>,<mac>,<ch>,<freq offset>,<freq calibration> OK or ERROR | +CWLAP: <ecn>,<ssid>,<rssi>,<mac>,<ch>,<freq offset>,<freq calibration> OK |
| Parameters | <ul style="list-style-type: none">• <ecn>: encryption method.<ul style="list-style-type: none">▸ 0: OPEN▸ 1: WEP▸ 2: WPA_PSK▸ 3: WPA2_PSK▸ 4: WPA_WPA2_PSK▸ 5: WPA2_Enterprise (AT can NOT connect to WPA2_Enterprise AP for now.)• <ssid>: string parameter, SSID of the AP.• <rssi>: signal strength.• <mac>: string parameter, MAC address of the AP.• <freq offset>: frequency offset of AP; unit: KHz. The value of ppm is <freq offset>/2.4.• <freq calibration>: calibration for frequency offset. | |
| Examples | AT+CWLAP="Wi-Fi", "ca:d7:19:d8:a6:44", 6 or search for APs with a designated SSID: AT+CWLAP="Wi-Fi" | |

4.2.9. AT+CWQAP—Disconnects from the AP

| | |
|------------------------|----------|
| Execute Command | AT+CWQAP |
| Response | OK |
| Parameters | - |



4.2.10. AT+CWSAP—Configures the ESP8266 SoftAP

[@deprecated] This command is deprecated. Please use AT+CWSAP_CUR or AT+CWSAP_DEF instead.

| | | |
|-------------------|---|--|
| Commands | Query Command: AT+CWSAP? Function: to obtain the configuration parameters of the ESP8266 SoftAP. | Set Command: AT+CWSAP=<ssid>,<pwd>,<chl>,<ecn>[,<max conn>][,<ssid hidden>] Function: to configure the ESP8266 SoftAP. |
| Response | +CWSAP:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden> | OK or ERROR |
| Parameters | <ul style="list-style-type: none">• <ssid>: string parameter, SSID of AP.• <pwd>: string parameter, length of password: 8 ~ 64 bytes ASCII.• <chl>: channel ID.• <ecn>: encryption method; WEP is not supported.<ul style="list-style-type: none">▸ 0: OPEN▸ 2: WPA_PSK▸ 3: WPA2_PSK▸ 4: WPA_WPA2_PSK• [<max conn>] (optional): maximum number of Stations to which ESP8266 SoftAP can be connected; within the range of [1, 10].• [<ssid hidden>] (optional):<ul style="list-style-type: none">▸ 0: SSID is broadcasted. (the default setting)▸ 1: SSID is not broadcasted. | The same as above. ⚠ Notice: This command is only available when SoftAP is active. |
| Note | The configuration changes will be saved in the system parameter area in the flash. | |
| Example | AT+CWSAP="ESP8266","1234567890",5,3 | |

4.2.11. AT+CWSAP_CUR—Configures the ESP8266 SoftAP; Configuration Not Saved in the Flash

| | | |
|-----------------|--|--|
| Commands | Query Command: AT+CWSAP_CUR? Function: to obtain the configuration parameters of the ESP8266 SoftAP. | Set Command: AT+CWSAP_CUR=<ssid>,<pwd>,<chl>,<ecn>[,<max conn>][,<ssid hidden>] Function: to configure the ESP8266 SoftAP. |
| Response | +CWSAP_CUR:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden> | OK or ERROR |



| | | |
|------------|---|---|
| Parameters | <ul style="list-style-type: none">• <ssid>: string parameter, SSID of AP.• <pwd>: string parameter, length of password: 8 ~ 64 bytes ASCII.• <chl>: channel ID.• <ecn>: encryption method; WEP is not supported.<ul style="list-style-type: none">▸ 0: OPEN▸ 2: WPA_PSK▸ 3: WPA2_PSK▸ 4: WPA_WPA2_PSK• [<max conn>] (optional): maximum number of Stations to which ESP8266 SoftAP can be connected; within the range of [1, 10].• [<ssid hidden>] (optional):<ul style="list-style-type: none">▸ 0: SSID is broadcasted. (the default setting)▸ 1: SSID is not broadcasted. | ⚠ Notice: This command is only available when SoftAP is active. |
| Note | The configuration changes will NOT be saved in the flash. | |
| Example | AT+CWSAP_CUR="ESP8266","1234567890",5,3 | |

4.2.12. AT+CWSAP_DEF—Configures the ESP8266 SoftAP; Configuration Saved in the Flash

| | | |
|------------|--|--|
| Commands | Query Command: AT+CWSAP_DEF? Function: to obtain the configuration parameters of the ESP8266 SoftAP. | Set Command: AT+CWSAP_DEF=<ssid>,<pwd>,<chl>,<ecn>[,<max conn>][,<ssid hidden>] Function: to list all available APs. |
| Response | +CWSAP_DEF:<ssid>,<pwd>,<chl>,<ecn>,<max conn>,<ssid hidden> | OK or ERROR |
| Parameters | <ul style="list-style-type: none">• <ssid>: string parameter, SSID of AP.• <pwd>: string parameter, length of password: 8 ~ 64 bytes ASCII.• <chl>: channel ID.• <ecn>: encryption method; WEP is not supported.<ul style="list-style-type: none">▸ 0: OPEN▸ 2: WPA_PSK▸ 3: WPA2_PSK▸ 4: WPA_WPA2_PSK• [<max conn>] (optional): maximum number of Stations to which ESP8266 SoftAP can be connected; within the range of [1, 4].• [<ssid hidden>] (optional):<ul style="list-style-type: none">▸ 0: SSID is broadcasted. (the default setting)▸ 1: SSID is not broadcasted. | The same as above. ⚠ Notice: This command is only available when SoftAP is active. |
| Note | The configuration changes will NOT be saved in the flash. | |
| Example | AT+CWSAP_DEF="ESP8266","1234567890",5,3 | |



4.2.13. AT+CWLIF—IP of Stations to Which the ESP8266 SoftAP is Connected

| | |
|-----------------|--|
| Execute Command | AT+CWLIF |
| Response | <ip addr>,<mac> OK |
| Parameters | <ul style="list-style-type: none">• <ip addr>: IP address of Stations to which ESP8266 SoftAP is connected.• <mac>: MAC address of Stations to which ESP8266 SoftAP is connected. |
| Note | This command cannot get a static IP. It only works when both DHCPs of the ESP8266 SoftAP, and of the Station to which ESP8266 is connected, are enabled. |

4.2.14. AT+CWDHCP—Enables/Disables DHCP

[@deprecated] This command is deprecated. Please use AT+CWDHCP_CUR or AT+CWDHCP_DEF instead.

| | | |
|------------|---|---|
| Commands | Query Command: AT+CWDHCP? | Set Command: AT+CWDHCP=<<mode>,<en> Function: to enable/disable DHCP. |
| Response | DHCP disabled or enabled now? | OK |
| Parameters | <ul style="list-style-type: none">• Bit0:<ul style="list-style-type: none">▸ 0: Station DHCP is disabled.▸ 1: Station DHCP is enabled.• Bit1:<ul style="list-style-type: none">▸ 0: SoftAP DHCP is disabled.▸ 1: SoftAP DHCP is enabled. | <ul style="list-style-type: none">• <mode>:<ul style="list-style-type: none">▸ 0: Sets ESP8266 SoftAP▸ 1: Sets ESP8266 Station▸ 2: Sets both SoftAP and Station• <en>:<ul style="list-style-type: none">▸ 0: Disables DHCP▸ 1: Enables DHCP |
| Notes | <ul style="list-style-type: none">• The configuration changes will be stored in the user parameter area in the flash.• This Set Command interacts with static-IP-related AT commands (AT+CIPSTA-related and AT+CIPA-related commands):<ul style="list-style-type: none">▸ If DHCP is enabled, static IP will be disabled;▸ If static IP is enabled, DHCP will be disabled;▸ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |

4.2.15. AT+CWDHCP_CUR—Enables/Disables DHCP; Configuration Not Saved in the Flash

| | | |
|----------|----------------------------------|---|
| Commands | Query Command: AT+CWDHCP_CUR? | Set Command: AT+CWDHCP_CUR=<<mode>,<en> Function: to enable/disable DHCP. |
| Response | DHCP disabled or enabled now? | OK |



| | | |
|------------|---|---|
| Parameters | <ul style="list-style-type: none">• Bit0:<ul style="list-style-type: none">▸ 0: Station DHCP is disabled.▸ 1: Station DHCP is enabled.• Bit1:<ul style="list-style-type: none">▸ 0: SoftAP DHCP is disabled.▸ 1: SoftAP DHCP is enabled. | <ul style="list-style-type: none">• <mode>:<ul style="list-style-type: none">▸ 0: Sets ESP8266 SoftAP▸ 1: Sets ESP8266 Station▸ 2: Sets both SoftAP and Station• <en>:<ul style="list-style-type: none">▸ 0: Disables DHCP▸ 1: Enables DHCP |
| Notes | <ul style="list-style-type: none">• The configuration changes will be stored in the user parameter area in the flash.• This Set Command interacts with static-IP-related AT commands (AT+CIPSTA-related and AT+CIPA-related commands):<ul style="list-style-type: none">▸ If DHCP is enabled, static IP will be disabled;▸ If static IP is enabled, DHCP will be disabled;▸ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CWDHCP_CUR=0,1 | |

4.2.16. AT+CWDHCP_DEF—Enables/Disables DHCP; Configuration Saved in the Flash

| | | |
|------------|---|---|
| Commands | Query Command: AT+CWDHCP_DEF? | Set Command: AT+CWDHCP_DEF=<mode>,<en> Function: to enable/disable DHCP. |
| Response | DHCP disabled or enabled now? | OK |
| Parameters | <ul style="list-style-type: none">• Bit0:<ul style="list-style-type: none">▸ 0: Station DHCP is disabled.▸ 1: Station DHCP is enabled.• Bit1:<ul style="list-style-type: none">▸ 0: SoftAP DHCP is disabled.▸ 1: SoftAP DHCP is enabled. | <ul style="list-style-type: none">• <mode>:<ul style="list-style-type: none">▸ 0: Sets ESP8266 SoftAP▸ 1: Sets ESP8266 Station▸ 2: Sets both SoftAP and Station• <en>:<ul style="list-style-type: none">▸ 0: Disables DHCP▸ 1: Enables DHCP |
| Notes | <ul style="list-style-type: none">• The configuration changes will be stored in the user parameter area in the flash.• This Set Command interacts with static-IP-related AT commands (AT+CIPSTA-related and AT+CIPA-related commands):<ul style="list-style-type: none">▸ If DHCP is enabled, static IP will be disabled;▸ If static IP is enabled, DHCP will be disabled;▸ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CWDHCP_DEF=0,1 | |



4.2.17. AT+CWDHCPS_CUR—Sets the IP Address Allocated by ESP8266 SoftAP DHCP; Configuration Not Saved in Flash

| | | |
|------------|--|--|
| Commands | Query Command: AT+CWDHCPS_CUR? | Set Command: AT+CWDHCPS_CUR=<enable>,<lease time>,<start IP>,<end IP> Function: sets the IP address range of the ESP8266 SoftAP DHCP server. |
| Response | +CWDHCPS_CUR=<lease time>,<start IP>,<end IP> | OK |
| Parameters | <ul style="list-style-type: none">• <enable>:<ul style="list-style-type: none">▸ 0: Disable the settings and use the default IP range.▸ 1: Enable setting the IP range, and the parameters below have to be set.• <lease time>: lease time; unit: minute; range [1, 2880].• <start IP>: start IP of the IP range that can be obtained from ESP8266 SoftAP DHCP server.• <end IP>: end IP of the IP range that can be obtained from ESP8266 SoftAP DHCP server. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will NOT be saved in the flash.• This AT command is enabled when ESP8266 runs as SoftAP, and when DHCP is enabled. The IP address should be in the same network segment as the IP address of ESP8266 SoftAP. | |
| Examples | AT+CWDHCPS_CUR=1,3,"192.168.4.10","192.168.4.15" or AT+CWDHCPS_CUR=0 //Disable the settings and use the default IP range. | |

4.2.18. AT+CWDHCPS_DEF—Sets the IP Address Allocated by ESP8266 SoftAP DHCP; Configuration Saved in Flash

| | | |
|------------|--|--|
| Commands | Query Command: AT+CWDHCPS_DEF? | Set Command: AT+CWDHCPS_DEF=<enable>,<lease time>,<start IP>,<end IP> Function: sets the IP address range of the ESP8266 SoftAP DHCP server. |
| Response | +CWDHCPS_DEF=<lease time>,<start IP>,<end IP> | OK |
| Parameters | <ul style="list-style-type: none">• <enable>:<ul style="list-style-type: none">▸ 0: Disable the settings and use the default IP range.▸ 1: Enable setting the IP range, and the parameters below have to be set.• <lease time>: lease time; unit: minute; range [1, 2880].• <start IP>: start IP of the IP range that can be obtained from ESP8266 SoftAP DHCP server.• <end IP>: end IP of the IP range that can be obtained from ESP8266 SoftAP DHCP server. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will be stored in the user parameter area in the flash.• This AT command is enabled when ESP8266 runs as SoftAP, and when DHCP is enabled. The IP address should be in the same network segment as the IP address of ESP8266 SoftAP. | |



| | |
|----------|---|
| Examples | AT+CWDHCPS_DEF=1,3,"192.168.4.10","192.168.4.15" |
| | or |
| | AT+CWDHCPS_DEF=0 //Disable the settings and use the default IP range. |

4.2.19. AT+CWAUTOCONN—Auto-Connects to the AP or Not

| | |
|-------------|---|
| Set Command | AT+CWAUTOCONN=<enable> |
| Response | OK |
| Parameters | <enable>: <ul style="list-style-type: none">▸ 0: does NOT auto-connect to AP on power-up.▸ 1: connects to AP automatically on power-up. The ESP8266 Station connects to the AP automatically on power-up by default. |
| Note | The configuration changes will be saved in the system parameter area in the flash. |
| Example | AT+CWAUTOCONN=1 |

4.2.20. AT+CIPSTAMAC—Sets the MAC Address of the ESP8266 Station

[@deprecated] This command is deprecated. Please use AT+CIPSTAMAC_CUR or AT+CIPSTAMAC_DEF instead.

| | | |
|------------|--|--|
| Commands | Query Command: AT+CIPSTAMAC? | Set Command: AT+CIPSTAMAC=<mac> Function: to set the MAC address of the ESP8266 Station. |
| | +CIPSTAMAC: <mac> OK | OK |
| Parameters | <mac>: string parameter, MAC address of the ESP8266 Station. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure that you do not set the same MAC address for both of them.• Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:...". | |
| Example | AT+CIPSTAMAC="18:fe:35:98:d3:7b" | |

4.2.21. AT+CIPSTAMAC_CUR—Sets the MAC Address of the ESP8266 Station; Configuration Not Saved in the Flash

| | | |
|----------|-------------------------------------|--|
| Commands | Query Command: AT+CIPSTAMAC_CUR? | Set Command: AT+CIPSTAMAC_CUR=<mac> Function: to set the MAC address of the ESP8266 Station. |
| | | |



| | | | |
|------------|--|----|--|
| Response | +CIPSTAMAC_CUR: <mac> OK | OK | |
| Parameters | <mac>: string parameter, MAC address of the ESP8266 Station. | | |
| Notes | <ul style="list-style-type: none">• The configuration changes will NOT be saved in the flash.• The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure that you do not set the same MAC address for both of them.• Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:..." | | |
| Example | AT+CIPSTAMAC_CUR="18:fe:35:98:d3:7b" | | |

4.2.22. AT+CIPSTAMAC_DEF—Sets the MAC Address of the ESP8266 Station; Configuration Saved in the Flash

| | | |
|------------|---|--|
| Commands | Query Command: AT+CIPSTAMAC_DEF? | Set Command: AT+CIPSTAMAC_DEF=<mac> Function: to set the MAC address of the ESP8266 Station. |
| | | |
| Response | +CIPSTAMAC_DEF: <mac> OK | OK |
| Parameters | <mac>: string parameter, MAC address of the ESP8266 Station. | |
| Notes | <ul style="list-style-type: none">The configuration changes will be saved in the user parameter area in the flash.The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure that you do not set the same MAC address for both of them.Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:..." | |
| Example | AT+CIPSTAMAC_DEF="18:fe:35:98:d3:7b" | |

4.2.23. AT+CIPAPMAC—Sets the MAC Address of the ESP8266 SoftAP

[@deprecated] This command is deprecated. Please use AT+CIPAPMAC_CUR or AT+CIPAPMAC_DEF instead.

| | | |
|------------|--|--|
| Commands | Query Command: AT+CIPAPMAC? Function: to obtain the MAC address of the ESP8266 SoftAP. | Set Command: AT+CIPAPMAC=<mac> Function: to set the MAC address of the ESP8266 SoftAP. |
| | | |
| Response | +CIPAPMAC: <mac> OK | OK |
| Parameters | <mac>: string parameter, MAC address of ESP8266 SoftAP. | |



| | |
|---------|---|
| Notes | <ul style="list-style-type: none">The configuration changes will be saved in the user parameter area in the flash.The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure you do not set the same MAC address for both of them.Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:...". |
| Example | AT+CIPAPMAC="1a:fe:36:97:d5:7b" |

4.2.24. AT+CIPAPMAC_CUR—Sets the MAC Address of the ESP8266 SoftAP; Configuration Not Saved in the Flash

| | | |
|------------|---|--|
| Commands | Query Command: AT+CIPAPMAC_CUR? Function: to obtain the MAC address of the ESP8266 SoftAP. | Set Command: AT+CIPAPMAC_CUR=<mac> Function: to set the MAC address of the ESP8266 SoftAP. |
| Response | +CIPAPMAC_CUR:<mac> OK | OK |
| Parameters | <mac>: string parameter, MAC address of ESP8266 SoftAP. | |
| Notes | <ul style="list-style-type: none">The configuration changes will NOT be saved the flash.The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure you do not set the same MAC address for both of them.Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:...". | |
| Example | AT+CIPAPMAC_CUR="1a:fe:36:97:d5:7b" | |

4.2.25. AT+CIPAPMAC_DEF—Sets the MAC Address of the ESP8266 SoftAP; Configuration Saved in Flash

| | | |
|------------|---|--|
| Commands | Query Command: AT+CIPAPMAC_DEF? Function: to obtain the MAC address of the ESP8266 SoftAP. | Set Command: AT+CIPAPMAC_DEF=<mac> Function: to set the MAC address of the ESP8266 SoftAP. |
| Response | +CIPAPMAC_DEF:<mac> OK | OK |
| Parameters | <mac>: string parameter, MAC address of ESP8266 SoftAP. | |
| Notes | <ul style="list-style-type: none">The configuration changes will be saved in the user parameter area in the flash.The MAC address of ESP8266 SoftAP is different from that of the ESP8266 Station. Please make sure you do not set the same MAC address for both of them.Bit 0 of the ESP8266 MAC address CANNOT be 1. For example, a MAC address can be "18:..." but not "15:...". | |
| Example | AT+CIPAPMAC_DEF="1a:fe:36:97:d5:7b" | |



4.2.26. AT+CIPSTA—Sets the IP Address of the ESP8266 Station

[@deprecated] This command is deprecated. Please use AT+CIPSTA_CUR or AT+CIPSTA_DEF instead.

| | | |
|------------|--|--|
| Commands | Query Command: AT+CIPSTA? | Set Command: AT+CIPSTA=<ip>[, <gateway>, <netmask>] |
| | Function: to obtain the IP address of the ESP8266 Station. | Function: to set the IP address of the ESP8266 Station. |
| Response | +CIPSTA: <ip> OK | OK |
| Parameters | ⚠ Notice: Only when the ESP8266 Station is connected to an AP can its IP address be queried. | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 Station.• [<gateway>]: gateway.• [<netmask>]: netmask. |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▶ If static IP is enabled, DHCP will be disabled;▶ If DHCP is enabled, static IP will be disabled;▶ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPSTA="192.168.6.100", "192.168.6.1", "255.255.255.0" | |

4.2.27. AT+CIPSTA_CUR—Sets the IP Address of the ESP8266 Station; Configuration Not Saved in the Flash

| | | |
|------------|---|--|
| Commands | Query Command: AT+CIPSTA_CUR? | Set Command: AT+CIPSTA_CUR=<ip>[, <gateway>, <netmask>] |
| | Function: to obtain the IP address of the ESP8266 Station. | Function: to set the IP address of the ESP8266 Station. |
| Response | +CIPSTA_CUR: <ip> OK | OK |
| Parameters | ⚠ Notice: Only when the ESP8266 Station is connected to an AP can its IP address be queried. | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 Station.• [<gateway>]: gateway.• [<netmask>]: netmask. |
| Notes | <ul style="list-style-type: none">• The configuration changes will NOT be saved in the flash.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▶ If static IP is enabled, DHCP will be disabled;▶ If DHCP is enabled, static IP will be disabled;▶ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPSTA_CUR="192.168.6.100", "192.168.6.1", "255.255.255.0" | |



4.2.28. AT+CIPSTA_DEF—Sets the IP Address of the ESP8266 Station; Configuration Saved in the Flash

| | | |
|------------|--|--|
| Commands | Query Command: AT+CIPSTA_DEF? | Set Command: AT+CIPSTA_DEF=<ip>[, <gateway>, <netmask>] |
| | Function: to obtain the IP address of the ESP8266 Station. | Function: to set the IP address of the ESP8266 Station. |
| Response | +CIPSTA_DEF:<ip> OK | OK |
| Parameters | ⚠ Notice: Only when the ESP8266 Station is connected to an AP can its IP address be queried. | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 Station.• [<gateway>]: gateway.• [<netmask>]: netmask. |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▶ If static IP is enabled, DHCP will be disabled;▶ If DHCP is enabled, static IP will be disabled;▶ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPSTA_DEF="192.168.6.100", "192.168.6.1", "255.255.255.0" | |

4.2.29. AT+CIPAP—Sets the IP Address of the ESP8266 SoftAP

[@deprecated] This command is deprecated. Please use AT+CIPAP_CUR or AT+CIPAP_DEF instead.

| | | |
|------------|---|--|
| Commands | Query Command: AT+CIPAP? | Set Command: AT+CIPAP=<ip>[, <gateway>, <netmask>] |
| | Function: to obtain the IP address of the ESP8266 SoftAP. | Function: to set the IP address of the ESP8266 SoftAP. |
| Response | +CIPAP:<ip>,<gateway>,<netmask> OK | OK |
| Parameters | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 SoftAP.• [<gateway>]: gateway.• [<netmask>]: netmask. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• Currently, ESP8266 only supports class C IP addresses.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▶ If static IP is enabled, DHCP will be disabled;▶ If DHCP is enabled, static IP will be disabled;▶ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPAP="192.168.5.1", "192.168.5.1", "255.255.255.0" | |



4.2.30. AT+CIPAP_CUR—Sets the IP Address of the ESP8266 SoftAP; Configuration Not Saved in the Flash

| | | |
|------------|---|---|
| Commands | Query Command: AT+CIPAP_CUR? | Set Command: AT+CIPAP_CUR=<ip>[,<gateway>,<netmask>] |
| | Function: to obtain the IP address of the ESP8266 SoftAP. | Function: to set the IP address of the ESP8266 SoftAP. |
| Response | +CIPAP_CUR:<ip>,<gateway>,<netmask> OK | OK |
| Parameters | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 SoftAP.• [<gateway>]: gateway.• [<netmask>]: netmask. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• Currently, ESP8266 only supports class C IP addresses.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▸ If static IP is enabled, DHCP will be disabled;▸ If DHCP is enabled, static IP will be disabled;▸ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPAP_CUR="192.168.5.1","192.168.5.1","255.255.255.0" | |

4.2.31. AT+CIPAP_DEF—Sets the IP Address of the ESP8266 SoftAP; Configuration Saved in the Flash

| | | |
|------------|---|---|
| Commands | Query Command: AT+CIPAP_DEF? | Set Command: AT+CIPAP_DEF=<ip>[,<gateway>,<netmask>] |
| | Function: to obtain the IP address of the ESP8266 SoftAP. | Function: to set the IP address of the ESP8266 SoftAP. |
| Response | +CIPAP_DEF:<ip>,<gateway>,<netmask> OK | OK |
| Parameters | <ul style="list-style-type: none">• <ip>: string parameter, the IP address of the ESP8266 SoftAP.• [<gateway>]: gateway.• [<netmask>]: netmask. | |
| Notes | <ul style="list-style-type: none">• The configuration changes will be saved in the user parameter area in the flash.• Currently, ESP8266 only supports class C IP addresses.• The Set Command interacts with DHCP-related AT commands (AT+CWDHCP-related commands):<ul style="list-style-type: none">▸ If static IP is enabled, DHCP will be disabled;▸ If DHCP is enabled, static IP will be disabled;▸ Whether it is DHCP or static IP that is enabled depends on the last configuration. | |
| Example | AT+CIPAP_DEF="192.168.5.1","192.168.5.1","255.255.255.0" | |



4.2.32. AT+CWSTARTSMART – Starts SmartConfig

| | | |
|------------|--|--|
| Commands | Execute Command: AT+CWSTARTSMART Function: to start SmartConfig. (The type of SmartConfig is ESP-TOUCH + AirKiss.) | Set Command: AT+CWSTARTSMART=<type> Function: to start SmartConfig of a designated type. |
| | Response OK | |
| Parameters | <type>: ‣ 1: ESP-TOUCH ‣ 2: AirKiss ‣ 3: ESP-TOUCH+AirKiss | |
| Notes | <ul style="list-style-type: none">For details on SmartConfig please see ESP-TOUCH User Guide.SmartConfig is only available in the ESP8266 Station mode.The message <code>Smart get Wi-Fi info</code> means that SmartConfig has successfully acquired the AP information. ESP8266 will try to connect to the target AP.Message <code>Smartconfig connected Wi-Fi</code> is printed if the connection is successful. Use command <code>AT+CWSTOPSMART</code> to stop SmartConfig before running other commands. Please make sure that you do not execute other commands during SmartConfig.Starting from AT_v1.0, SmartConfig can get protocol type (AirKiss or ESP-TOUCH) automatically by command <code>AT+CWSTARTSMART</code>. | |
| Example | AT+CWMODE=1 AT+CWSTARTSMART | |

4.2.33. AT+CWSTOPSMART – Stops SmartConfig

| | |
|-----------------|---|
| Execute Command | AT+CWSTOPSMART |
| Response | OK |
| Parameters | - |
| Note | Irrespective of whether SmartConfig succeeds or not, before executing any other AT commands, please always call <code>AT+CWSTOPSMART</code> to release the internal memory taken up by SmartConfig. |
| Example | AT+CWSTOPSMART |



4.2.34. AT+CWSTARTDISCOVER—Enables the Mode that ESP8266 can be Found by WeChat

| | |
|-------------|---|
| Set Command | AT+CWSTARTDISCOVER=<WeChat number>,<dev_type>,<time> |
| Response | OK |
| Parameters | <ul style="list-style-type: none">• <WeChat number>: WeChat official account, which is to be obtained from WeChat.• <dev_type>: the device type, which is to be obtained from WeChat.• <time>: the interval of time for ESP8266 to send packets; range: 0 ~ 24x3600; unit: second.<ul style="list-style-type: none">▸ 0: ESP8266 will not take the initiative to send packets; it only makes response to queries from WeChat.▸ Otherwise: the time interval for ESP8266 to send packets regularly in order to be detected by WeChat on the same LAN. |
| Note | <ul style="list-style-type: none">• For details on detection function of WeChat, please refer to http://iot.weixin.qq.com.• ESP8266 Station should connect to an AP and obtain an IP address first before this command is used. |
| Example | AT+CWSTARTDISCOVER="gh_9e2cff3dfa51","122475",10 |

4.2.35. AT+CWSTOPDISCOVER—Disables the Mode that ESP8266 can be Found by WeChat

| | |
|-----------------|-------------------|
| Execute Command | AT+CWSTOPDISCOVER |
| Response | OK or ERROR |
| Example | AT+CWSTOPDISCOVER |

4.2.36. AT+WPS—Enables the WPS Function

| | |
|-------------|---|
| Set Command | AT+WPS=<enable> |
| Response | OK or ERROR |
| Parameters | <enable>: <ul style="list-style-type: none">▸ 1: enables WPS/Wi-Fi Protected Setup▸ 0: disables WPS |
| Notes | <ul style="list-style-type: none">• WPS must be used when the ESP8266 Station is enabled.• WPS does not support WEP/Wired-Equivalent Privacy encryption. |
| Example | AT+CWMODE=1 AT+WPS=1 |



4.2.37. AT+MDNS—Configures the MDNS Function

| | |
|-------------|--|
| Set Command | AT+MDNS=<enable>,<hostname>,<server_name>,<server_port> |
| Response | OK or ERROR |
| Parameters | <ul style="list-style-type: none">• <enable>:<ul style="list-style-type: none">▸ 1: enables the MDNS function; the following three parameters need to be set.▸ 0: disables the MDNS function; the following three parameters need not to be set.• <hostname>: MDNS host name• <server_name>: MDNS server name• <server_port>: MDNS server port |
| Notes | <ul style="list-style-type: none">• Please do not use special characters (such as .) or a protocol name (for example, http) for <hostname> and <server_name>.• ESP8266 SoftAP mode does not support the MDNS function for now. |
| Example | AT+MDNS=1,"espressif","iot",8080 |

4.2.38. AT+CWHOSTNAME—Configures the Name of ESP8266 Station

| | | |
|------------|--|--|
| Commands | Query Command: AT+CWHOSTNAME? Function: Checks the host name of ESP8266 Station. | Set Command: AT+CWHOSTNAME=<hostname> Function: Sets the host name of ESP8266 Station. |
| Response | +CWHOSTNAME:<host name> OK If the station mode is not enabled, the command will return: +CWHOSTNAME:<null> OK | OK If the Station mode is not enabled, the command will return: ERROR |
| Parameters | <hostname>: the host name of the ESP8266 Station. | |
| Notes | <ul style="list-style-type: none">• The configuration changes are not saved in the flash.• The default host name of the ESP8266 Station is ESP_XXXXXX; XXXXXX is the lower 3 bytes of the MAC address, for example, +CWHOSTNAME:<ESP_A378DA>. | |
| Example | AT+CWMODE=3 AT+CWHOSTNAME="my_test" | |



5. TCP/IP-Related AT Commands

5.1. Overview

| Command | Description |
|------------------|--|
| AT+CIPSTATUS | Gets the connection status |
| AT+CIPDOMAIN | DNS function |
| AT+CIPSTART | Establishes TCP connection, UDP transmission or SSL connection |
| AT+CIPSSLIZE | Sets the size of SSL buffer |
| AT+CIPSEND | Sends data |
| AT+CIPSENDEX | Sends data when length of data is <Length>, or when \0 appears in the data |
| AT+CIPSENDERBUF | Writes data into TCP-send-buffer |
| AT+CIPBUFRESET | Resets the segment ID count |
| AT+CIPBUFSTATUS | Checks the status of TCP-send-buffer |
| AT+CIPCHECKSEQ | Checks if a specific segment is sent or not |
| AT+CIPCLOSE | Closes TCP/UDP/SSL connection |
| AT+CIFSR | Gets the local IP address |
| AT+CIPMUX | Configures the multiple connections mode |
| AT+CIPSERVER | Deletes/Creates a TCP server |
| AT+CIPMODE | Configures the transmission mode |
| AT+SAVETRANSLINK | Saves the transparent transmission link in the flash |
| AT+CIPSTO | Sets timeout when ESP8266 runs as TCP server |
| AT+PING | Ping packets |
| AT+CIUPDATE | Upgrades the software through network |
| AT+CIPDINFO | Shows remote IP and remote port with +IPD |
| AT+CIPSNTPCFG | Configures the time domain and SNTP server. |
| AT+CIPSNTPTIME | Queries the SNTP time. |
| AT+CIPDNS_CUR | Sets user-defined DNS servers; configuration not saved in the flash |
| AT+CIPDNS_DEF | Sets user-defined DNS servers; configuration saved in the flash |



5.2. Commands

5.2.1. AT+CIPSTATUS—Gets the Connection Status

| | |
|-----------------|--|
| Execute Command | AT+CIPSTATUS |
| Response | STATUS:<stat> +CIPSTATUS:<link ID>,<type>,<remote IP>,<remote port>,<local port>,<tetype> |
| Parameters | <ul style="list-style-type: none">• <stat>: status of the ESP8266 Station interface.<ul style="list-style-type: none">▶ 2: The ESP8266 Station is connected to an AP and its IP is obtained.▶ 3: The ESP8266 Station has created a TCP or UDP transmission.▶ 4: The TCP or UDP transmission of ESP8266 Station is disconnected.▶ 5: The ESP8266 Station does NOT connect to an AP.• <link ID>: ID of the connection (0~4), used for multiple connections.• <type>: string parameter, "TCP" or "UDP".• <remote IP>: string parameter indicating the remote IP address.• <remote port>: the remote port number.• <local port>: ESP8266 local port number.• <tetype>:<ul style="list-style-type: none">▶ 0: ESP8266 runs as a client.▶ 1: ESP8266 runs as a server. |

5.2.2. AT+CIPDOMAIN—DNS Function

| | |
|-----------------|--|
| Execute Command | AT+CIPDOMAIN=<domain name> |
| Response | +CIPDOMAIN:<IP address> |
| Parameter | <domain name>: the domain name. |
| Example | AT+CHMODE=1 // set Station mode AT+CWJAP="SSID","password" // access to the internet AT+CIPDOMAIN="iot.espressif.cn" // DNS function |



5.2.3. AT+CIPSTART—Establishes TCP Connection, UDP Transmission or SSL Connection

Establish TCP Connection

| Set Command | Single TCP connection (AT+CIPMUX=0): AT+CIPSTART=<type>,<remote IP>,<remote port>[,<TCP keep alive>] | Multiple TCP Connections (AT+CIPMUX=1): AT+CIPSTART=<link ID>,<type>,<remote IP>,<remote port>[,<TCP keep alive>] |
|-------------|---|--|
| Response | OK or ERROR If TCP is already connected, the response is: ALREADY CONNECT | |
| Parameters | <ul style="list-style-type: none">• <link ID>: ID of network connection (0~4), used for multiple connections.• <type>: string parameter indicating the connection type: "TCP", "UDP" or "SSL".• <remote IP>: string parameter indicating the remote IP address.• <remote port>: the remote port number.• [<TCP keep alive>]: detection time interval when TCP is kept alive; this function is disabled by default.<ul style="list-style-type: none">▶ 0: disable TCP keep-alive.▶ 1 ~ 7200: detection time interval; unit: second (s). | |
| Examples | AT+CIPSTART="TCP","iot.espressif.cn",8000 AT+CIPSTART="TCP","192.168.101.110",1000 For more information please see: ESP8266 AT Command Examples . | |

Establish UDP Transmission

| Set Command | Single connection (AT+CIPMUX=0): AT+CIPSTART=<type>,<remote IP>,<remote port>[,<UDP local port>],[<UDP mode>] | Multiple connections (AT+CIPMUX=1): AT+CIPSTART=<link ID>,<type>,<remote IP>,<remote port>[,<UDP local port>],[<UDP mode>] |
|-------------|--|---|
| Response | OK or ERROR If UDP is already connected, the response is: ALREADY CONNECT | |



| | |
|------------|--|
| Parameters | <ul style="list-style-type: none">• <link ID>: ID of network connection (0~4), used for multiple connections.• <type>: string parameter indicating the connection type: "TCP", "UDP" or "SSL".• <remote IP>: string parameter indicating the remote IP address.• <remote port>: remote port number.• [<UDP local port>]: optional; UDP port of ESP8266.• [<UDP mode>]: optional. In the UDP transparent transmission, the value of this parameter has to be 0.<ul style="list-style-type: none">▶ 0: the destination peer entity of UDP will not change; this is the default setting.▶ 1: the destination peer entity of UDP can change once.▶ 2: the destination peer entity of UDP is allowed to change. <p>⚠ Notice:</p> <p>To use <UDP mode> , <UDP local port> must be set first.</p> |
| Example | <pre>AT+CIPSTART="UDP", "192.168.101.110", 1000, 1002, 2</pre> <p>For more information please see: ESP8266 AT Command Examples.</p> |

Establish SSL Connection

| | |
|-------------|--|
| Set Command | <pre>AT+CIPSTART=[<link ID>,<type>,<remote IP>,<remote port>[,<TCP keep alive>]</pre> |
| Response | <pre>OK or ERROR</pre> <p>If TCP is already connected, the response is:</p> <pre>ALREADY CONNECT</pre> |
| Parameters | <ul style="list-style-type: none">• <link ID>: ID of network connection (0~4), used for multiple connections.• <type>: string parameter indicating the connection type: "TCP", "UDP" or "SSL".• <remote IP>: string parameter indicating the remote IP address.• <remote port>: the remote port number.• [<TCP keep alive>]: detection time interval when TCP is kept alive; this function is disabled by default.<ul style="list-style-type: none">▶ 0: disable the TCP keep-alive function.▶ 1 ~ 7200: detection time interval, unit: second (s). |
| Notes | <ul style="list-style-type: none">• ESP8266 can only set one SSL connection at most.• SSL connection does not support UART-Wi-Fi passthrough mode (transparent transmission).• SSL connection needs a large amount of memory; otherwise, it may cause system reboot. The command <code>AT+CIPSSLSIZE=<size></code> can be used to enlarge the SSL buffer size. |
| Example | <pre>AT+CIPSTART="SSL", "iot.espressif.cn", 8443</pre> |



5.2.4. AT+CIPSSLSIZE—Sets the Size of SSL Buffer

| | |
|-------------|---|
| Set Command | AT+CIPSSLSIZE=<size> |
| Response | OK or ERROR |
| Parameters | <size>: the size of the SSL buffer; range of value: [2048, 4096]. |
| Example | AT+CIPSSLSIZE=4096 |

5.2.5. AT+CIPSEND—Sends Data

| | | |
|------------|--|--|
| Commands | <p>Set Command:</p> <ol style="list-style-type: none">Single connection: (+CIPMUX=0) AT+CIPSEND=<length>Multiple connections: (+CIPMUX=1) AT+CIPSEND=<link ID>,<length>Remote IP and ports can be set in UDP transmission: AT+CIPSEND=[<link ID>,<length> [<remote IP>,<remote port>] <p>Function: to configure the data length in normal transmission mode.</p> | <p>Execute Command:</p> <p>AT+CIPSEND</p> <p>Function: to start sending data in transparent transmission mode.</p> |
| Response | <p>Send data of designated length.</p> <p>Wrap return > after the Set Command. Begin receiving serial data. When data length defined by <length> is met, the transmission of data starts.</p> <p>If the connection cannot be established or gets disrupted during data transmission, the system returns:</p> <p>ERROR</p> <p>If data is transmitted successfully, the system returns:</p> <p>SEND OK</p> | <p>Wrap return > after executing this command.</p> <p>Enter transparent transmission, with a 20-ms interval between each packet, and a maximum of 2048 bytes per packet.</p> <p>When a single packet containing +++ is received, ESP8266 returns to normal command mode. Please wait for at least one second before sending the next AT command.</p> <p>This command can only be used in transparent transmission mode which requires single connection.</p> <p>For UDP transparent transmission, the value of <UDP mode> has to be 0 when using AT+CIPSTART.</p> |
| Parameters | <ul style="list-style-type: none"><link ID>: ID of the connection (0~4), for multiple connections.<length>: data length, MAX: 2048 bytes.[<remote IP>]: remote IP can be set in UDP transmission.[<remote port>]: remote port can be set in UDP transmission. | - |
| Example | For more information please see: ESP8266 AT Command Examples . | |



5.2.6. AT+CIPSENDEX—Sends Data

| | |
|-------------|--|
| Set Command | <ol style="list-style-type: none">1. Single connection: (+CIPMUX=0) AT+CIPSENDEX=<length>2. Multiple connections: (+CIPMUX=1) AT+CIPSENDEX=<link ID>,<length>3. Remote IP and ports can be set in UDP transmission: AT+CIPSENDEX=[<link ID>,<length>,<remote IP>,<remote port>] Function: to configure the data length in normal transmission mode. |
| Response | <p>Send data of designated length.</p> <p>Wrap return > after the Set Command. Begin receiving serial data. When the requirement of data length, determined by <length>, is met, or when \0 appears in the data, the transmission starts.</p> <p>If connection cannot be established or gets disconnected during transmission, the system returns:</p> <p>ERROR</p> <p>If data are successfully transmitted, the system returns:</p> <p>SEND OK</p> |
| Parameters | <ul style="list-style-type: none">• <link ID>: ID of the connection (0~4), for multiple connections.• <length>: data length, MAX: 2048 bytes.• When the requirement of data length, determined by <length>, is met, or when \0 appears, the transmission of data starts. Go back to the normal command mode and wait for the next AT command.• When sending \0, please send it as \\0. |

5.2.7. AT+CIPSENDERBUF—Writes Data into the TCP-Send-Buffer

| | |
|-------------|--|
| Set Command | <ol style="list-style-type: none">1. Single connection: (+CIPMUX=0) AT+CIPSENDERBUF=<length>2. Multiple connections: (+CIPMUX=1) AT+CIPSENDERBUF=<link ID>,<length> |
|-------------|--|



| | |
|------------|--|
| Response | <p><current segment ID>,<segment ID of which sent successfully></p> <p>OK</p> <p>></p> <ul style="list-style-type: none">Wrap return > begins receiving serial data; when the length of data defined by the parameter <length> is met, the data is sent; if the data length over the value of <length>, the data will be discarded, and the command returns busy.If the connection cannot be established, or if it is not a TCP connection, or if the buffer is full, or some other error occurs, the command returns ERROR <p>ERROR</p> <ul style="list-style-type: none">If data is transmitted successfully,<ul style="list-style-type: none">for single connection, the response is: <segment ID>,SEND OKfor multiple connections, the response is: <link ID>,<segment ID>,SEND OK |
| Parameters | <ul style="list-style-type: none"><link ID>: ID of the connection (0~4), for multiple connections.<segment ID>: uint32; the ID assigned to each data packet, starting from 1; the ID number increases by 1 every time a data packet is written into the buffer.<length>: data length; MAX: 2048 bytes. |
| Notes | <ul style="list-style-type: none">This command only writes data into the TCP-send-buffer, so it can be called continually, and the user need not wait for SEND OK; if a TCP segment is sent successfully, it will return <segment ID>,SEND OK.Before data length reaches the value defined by <length>, input +++ can switch back from data mode to command mode, and discard the data received before.This command can NOT be used for SSL connections. |

5.2.8. AT+CIPBUFRESET – Resets the Segment ID Count

| | |
|-------------|--|
| Set Command | <ol style="list-style-type: none">Single connection: (+CIPMUX=0) AT+CIPBUFRESETMultiple connections: (+CIPMUX=1) AT+CIPBUFRESET=<link ID> |
| Response | <p>OK</p> <p>If the connection is not established or there is still TCP data waiting to be sent, the response will be:</p> <p>ERROR</p> |
| Parameter | <link ID>: ID of the connection (0~4), for multiple connections. |
| Note | This command can only be used when AT+CIPSENDER is used. |



5.2.9. AT+CIPBUFSTATUS—Checks the Status of the TCP-Send-Buffer

| | |
|-------------|---|
| Set Command | 1. Single connection: (+CIPMUX=0) AT+CIPBUFSTATUS 2. Multiple connections: (+CIPMUX=1) AT+CIPBUFSTATUS=<link ID> |
| Response | <next segment ID>,<segment ID sent >,<segment ID successfully sent>,<remain buffer size>,<queue number> OK |
| Parameters | <ul style="list-style-type: none">• <next segment ID>: the next segment ID obtained by AT+CIPSENDERBUF;• <segment ID sent>: the ID of the TCP segment last sent;• Only when <next segment ID> - <segment ID sent> = 1, can AT+CIPBUFRESET be called to reset the counting.• <segment ID successfully sent>: the ID of the last successfully sent TCP segment;• <remain buffer size>: the remaining size of the TCP-send-buffer;• <queue number>: available TCP queue number; it's not reliable and should be used as a reference only. |
| Notes | This command can not be used for SSL connection. |
| Example | For example, in single connection, the command AT+CIPBUFSTATUS returns: 20,15,10,200,7 Description: <ul style="list-style-type: none">• 20: means that the latest segment ID is 19; so when calling AT+CIPSENDERBUF the next time, the segment ID returned is 20;• 15: means that the TCP segment with the ID 15 is the last segment sent, but the segment may not be successfully sent;• 10: means that the TCP segment with the ID 10 was sent successfully;• 200: means that the remaining size of the TCP-send-buffer is 200 bytes;• 7: the available TCP queue number; it is not reliable and should be used as a reference only; when the queue number is 0, no TCP data can be sent. |

5.2.10. AT+CIPCHECKSEQ—Checks If a Specific Segment Was Successfully Sent

| | |
|-------------|---|
| Set Command | 1. Single connection: (+CIPMUX=0) AT+CIPCHECKSEQ=<segment ID> 2. multiple connections: (+CIPMUX=1) AT+CIPCHECKSEQ=<link ID>,<segment ID> |
| Response | [<link ID>,<segment ID>,<status> OK |



| | |
|------------|--|
| Parameters | <ul style="list-style-type: none">• The command can only be used to record the status of the last 32 segments at most.• [<link ID>]: ID of the connection (0~4), for multiple connection;• <segment ID>: the segment ID obtained by calling AT+CIPSEND;BUF;• <status>:<ul style="list-style-type: none">▶ FALSE: the segment-sending failed;▶ TRUE: the segment was sent successfully. |
| Notes | This command can only be used when AT+CIPSEND;BUF is used. |

5.2.11. AT+CIPCLOSE—Closes the TCP/UDP/SSL Connection

| | | |
|------------|--|--|
| Commands | Set Command (used in multiple connections): AT+CIPCLOSE=<link ID> Function: closes the TCP/UDP Connection. | Execute Command (used in multiple connections): AT+CIPCLOSE |
| Response | OK | |
| Parameters | <link ID>: ID of the connection to be closed. When ID is 5, all connection will be closed. (In server mode, the ID 5 has no effect.) | - |

5.2.12. AT+CIFSR—Gets the Local IP Address

| | | |
|-----------------|--|--|
| Execute Command | AT+CIFSR | |
| Response | +CIFSR:<SoftAP IP address> +CIFSR:<Station IP address> OK | |
| Parameters | <IP address>: IP address of the ESP8266 SoftAP; IP address of the ESP8266 Station. | |
| Notes | Only when the ESP8266 Station is connected to an AP can the Station IP can be queried. | |

5.2.13. AT+CIPMUX—Enable or Disable Multiple Connections

| | | |
|------------|--|---|
| Commands | Query Command: AT+CIPMUX? | Set Command: AT+CIPMUX=<mode> Function: to set the connection type. |
| Response | +CIPMUX: <mode> OK | OK |
| Parameters | <mode>: <ul style="list-style-type: none">▶ 0: single connection▶ 1: multiple connections | |



| | |
|---------|--|
| Notes | <ul style="list-style-type: none">The default mode is single connection mode.Multiple connections can only be set when transparent transmission is disabled (<code>AT+CIPMODE=0</code>).This mode can only be changed after all connections are disconnected.If the TCP server is running, it must be deleted (<code>AT+CIPSERVER=0</code>) before the single connection mode is activated. |
| Example | <code>AT+CIPMUX=1</code> |

5.2.14. AT+CIPSERVER—Deletes/Creates TCP Server

| | |
|-------------|---|
| Set Command | <code>AT+CIPSERVER=<mode>[, <port>]</code> |
| Response | OK |
| Parameters | <ul style="list-style-type: none"><code><mode></code>:<ul style="list-style-type: none">0: deletes server.1: creates server.<code><port></code>: port number; 333 by default. |
| Notes | <ul style="list-style-type: none">A TCP server can only be created when multiple connections are activated (<code>AT+CIPMUX=1</code>).A server monitor will automatically be created when the TCP server is created.When a client is connected to the server, it will take up one connection and be assigned an ID. |
| Example | <code>AT+CIPMUX=1</code> <code>AT+CIPSERVER=1,1001</code> |

5.2.15. AT+CIPMODE—Sets Transmission Mode

| | | |
|------------|--|---|
| Commands | Query Command: <code>AT+CIPMODE?</code> Function: to obtain information about transmission mode. | Set Command: <code>AT+CIPMODE=<mode></code> Function: to set the transmission mode. |
| Response | <code>+CIPMODE: <mode></code> OK | OK |
| Parameters | <code><mode></code> : <ul style="list-style-type: none">0: normal transmission mode.1: UART-Wi-Fi passthrough mode (transparent transmission), which can only be enabled in TCP single connection mode or in UDP mode when the remote IP and port do not change. | |
| Notes | <ul style="list-style-type: none">The configuration changes will NOT be saved in flash.During the UART-Wi-Fi passthrough transmission, if the TCP connection breaks, ESP8266 will keep trying to reconnect until +++ is input to exit the transmission. If it is a normal TCP transmission and the TCP connection breaks, ESP8266 will give a prompt and will not attempt to reconnect. | |
| Example | <code>AT+CIPMODE=1</code> | |