

1. Don't connect SD card to SD card connector of the BBB
2. The board preferably powered using power adapter (recommended, watch next video to understand why)
3. Use USB to TTL Serial converter hardware to connect BBB's UART0 serial pins to PC.