

Device Information

- **Get Device Info:** `/ISAPI/System/deviceInfo`
 - Retrieves information about the device, such as model, serial number, firmware version, etc.

Network Configuration

- **Get Network Interfaces:** `/ISAPI/System/Network/interfaces`
 - Retrieves network interface information.
- **Set Network Interfaces:** `/ISAPI/System/Network/interfaces/{id}`
 - Configures network interface settings.

User Management

- **Get Users:** `/ISAPI/Security/users`
 - Retrieves a list of users.
- **Add User:** `/ISAPI/Security/users`
 - Adds a new user.
- **Modify User:** `/ISAPI/Security/users/{id}`
 - Modifies an existing user.
- **Delete User:** `/ISAPI/Security/users/{id}`
 - Deletes a user.

Video and Image

- **Get Video Channels:** `/ISAPI/System/Video/inputs/channels`
 - Retrieves information about video channels.
- **Get Video Stream:** `/ISAPI/Streaming/channels`
 - Retrieves video stream settings.
- **Set Video Stream:** `/ISAPI/Streaming/channels/{id}`
 - Configures video stream settings.

PTZ Control

- **PTZ Control:** `/ISAPI/PTZCtrl/channels/{channelId}/pos`
 - Controls PTZ functions such as pan, tilt, and zoom.

Event Management

- **Get Event Types:** `/ISAPI/Event/triggers`
 - Retrieves a list of event types.
- **Set Event Trigger:** `/ISAPI/Event/triggers/{id}`
 - Configures an event trigger.

Alarm Management

- **Get Alarm Inputs:** `/ISAPI/System/IO/inputs`
 - Retrieves information about alarm inputs.

- **Set Alarm Input:** /ISAPI/System/IO/inputs/{id}
 - Configures an alarm input.

Storage Management

- **Get Storage Status:** /ISAPI/ContentMgmt/Storage/status
 - Retrieves storage status.
- **Get Storage Info:** /ISAPI/ContentMgmt/Storage
 - Retrieves storage information.

Time and Date

- **Get Device Time:** /ISAPI/System/time
 - Retrieves the current device time.
- **Set Device Time:** /ISAPI/System/time
 - Sets the current device time.
- **Get NTP Server:** /ISAPI/System/time/ntpServers
 - Retrieves NTP server settings.
- **Set NTP Server:** /ISAPI/System/time/ntpServers/{id}
 - Configures NTP server settings.

System Control

- **Reboot Device:** /ISAPI/System/reboot
 - Reboots the device.
- **Restore Device:** /ISAPI/System/restore
 - Restores the device to factory settings.

Log Management

- **Get Logs:** /ISAPI/System/operationLog
 - Retrieves operation logs.
- **Clear Logs:** /ISAPI/System/operationLog/clear
 - Clears operation logs.