



1) Left output: 1/4" jack, unbalanced signal output, instrument or line level.

2) Right output: 1/4" jack, unbalanced signal output, instrument or line level. Echo send in "mono with external loop" echo style.

3) Left input: 1/4" jack, unbalanced signal input, instrument or line level

4) Right input: 1/4" jack, unbalanced signal input, instrument or line level. Normalled to left input. Echo return in "mono with external loop" echo style.

5) Power input: 9VDC center negative, 200mA

6) Tone control: EQ in feedback path of echo, turn clockwise for brighter repeats and counter clockwise for darker

7) Repeats control: Feedback amount for delay lines, from 0% for a single repeat up to 110% for self oscillation and distortion.

8) Depth control: Depth of pitch modulation on echo signal. At 12 o'clock, there is no pitch modulation. Counter clockwise for sine wave modulation and clockwise for random modulation.

9) Rate control: Speed of pitch modulation on echo signal

10) Mix control: Balance of dry and wet signal.

11) Midi input: Type B, 3.5mm TRS input jack

12) Time control: 9 discrete max echo times ranging from 85 ms to 22 sec. No pitch modulation artifacts when adjusted.

13) ECHO STYLE modes: Reroutes the echo feedback paths.

Dual Stereo: two independent echos that can be used in stereo or stacked in mono.

Ping Pong: Echo's feedback into each other

Mono: Mono echo with feedback path routed to Right input and output jacks for external processing.

14) TRIG footswitch: footswitch for tap tempo or toggle's infinite mode (repeats = 100%), depending on "TRIG FUNCTION" selection.

15) Left and Right sliders: time control for delays that scale the delay time selected on the **time** knob. Press "SYNC" to lock both delay to the left slider.