

1. The yacht controller must only be used on calm water and light winds. It must not be used unless:
 - a manned motorised boat to follow the yacht while on the water to provide assistance if required;
 - another person on the yacht to provide assistance if required.
2. When servicing the unit's chain loops, motors, pulleys or ropes ensure the unit is powered off using switch S1 and the battery is disconnected by unplugging connector C1.
3. Only charge the battery when the unit is powered off using switch S1 and the battery is disconnected by unplugging connector C1.
4. Do not change the CT UNO microprocessor for a standard Arduino UNO microprocessor as they have different input voltage ranges:
 - CT UNO DC 7 15V
 - Arduino UNO DC 7 12V

This manual has been read and understood and the yacht controller will only be used in accordance with these instructions.

.....
Date