

# AVR GCC

Avr gcc is one of the most popular compilers for compiling c code for avr microcontrollers. Arduino IDE and platfromIO both use avr-gcc as a compiler.

It is free open source compiler and can be installed on Linux by using the following command:

```
sudo apt-get install gcc-avr
```

It is also recommended to have avr-gcc alongside the gcc, which is a C library for atmel and avr microcontrollers to be used with avr-gcc.

It can be installed through the following command on ubuntu:

```
sudo apt-get install avr-libc
```

The typical command to run to compile a code that works for most is:

```
avr-gcc -mmcu=<microcontroller> Os <sourcefile.c> -o <outputfile>
```

Where <microcontroller> is the name or architecture of the used microcontroller, for example atmega2560 or avr5.

Os is for compiling optimization

<sourcefile.c> is the main or source code file that the main code lives in

<outputfile> is an optional argument. You can specify the name of the output file with this option, otherwise the default is a.out

<https://www.nongnu.org/avrdude/>

## Avr-gcc flags and commands

### -mmcu=mcu:

- Specify Architecture or MCU type. Default is avr2. Following devices are supported:
  - avr2: 8KiB memory devices:
    - attiny22, attiny26, at90s2313, at90s2323, at90s2333, at90s2343, at90s4414, at90s4433, at90s4434, at90c8534, at90s8515, at90s8535.
  - avr25: 8KiB memory and MOVW instruction devices:
    - attiny13, attiny13a, attiny24, attiny24a, attiny25, attiny261, attiny261a, attiny2313, attiny2313a, attiny43u, attiny44, attiny44a, attiny45, attiny48, attiny441, attiny461, attiny461a, attiny4313, attiny84, attiny84a, attiny85, attiny87, attiny88, attiny828, attiny841, attiny861, attiny861a, ata5272, ata6616c, at86rf401.
  - avr3: 16KiB up to 64KiB memory devices:
    - at76c711, at43usb355.
  - avr31: 128KiB memory devices:
    - atmega103, at43usb320.
  - avr35: 16KiB up to 64KiB memory with MOVW instruction devices:
    - attiny167, attiny1634, atmega8u2, atmega16u2, atmega32u2, ata5505, ata6617c, ata664251, at90usb82, at90usb162.
  - avr4: 8KiB memory “enhanced” devices:
    - atmega48, atmega48a, atmega48p, atmega48pa, atmega48pb, atmega8, atmega8a, atmega8hva, atmega88, atmega88a, atmega88p, atmega88pa, atmega88pb, atmega8515, atmega8535, ata6285, ata6286, ata6289, ata6612c, at90pwm1, at90pwm2, at90pwm2b, at90pwm3, at90pwm3b, at90pwm81
  - avr5: 16KiB up to 64KiB memory “enhanced” devices:
    - atmega16, atmega16a, atmega16hva, atmega16hva2, atmega16hvb, atmega16hvbrevb, atmega16m1, atmega16u4, atmega161, atmega162, atmega163, atmega164a, atmega164p, atmega164pa, atmega165, atmega165a, atmega165p, atmega165pa, atmega168, atmega168a, atmega168p, atmega168pa, atmega168pb, atmega169, atmega169a, atmega169p, atmega169pa, atmega32, atmega32a, atmega32c1, atmega32hvb, atmega32hvbrevb, atmega32m1, atmega32u4, atmega32u6, atmega323, atmega324a, atmega324p, atmega324pa, atmega324pb, atmega325, atmega325a, atmega325p,

<https://www.nongnu.org/avrduide/>

atmega325pa, atmega328, atmega328p, atmega328pb, atmega329, atmega329a, atmega329p, atmega329pa, atmega3250, atmega3250a, atmega3250p, atmega3250pa, atmega3290, atmega3290a, atmega3290p, atmega3290pa, atmega406, atmega64, atmega64a, atmega64c1, atmega64hve, atmega64hve2, atmega64m1, atmega64rfr2, atmega640, atmega644, atmega644a, atmega644p, atmega644pa, atmega644rfr2, atmega645, atmega645a, atmega645p, atmega649, atmega649a, atmega649p, atmega6450, atmega6450a, atmega6450p, atmega6490, atmega6490a, atmega6490p, ata5795, ata5790, ata5790n, ata5791, ata6613c, ata6614q, ata5782, ata5831, ata8210, ata8510, ata5702m322, at90pwm161, at90pwm216, at90pwm316, at90can32, at90can64, at90scr100, at90usb646, at90usb647, at94k, m3000.

- avr51: 128KiB memory “enhanced” devices:
  - atmega128, atmega128a, atmega128rfa1, atmega128rfr2, atmega1280, atmega1281, atmega1284, atmega1284p, atmega1284rfr2, at90can128, at90usb1286, at90usb1287.
- avr6: 3-byte pc, more than 128KiB memory devices
  - atmega256rfr2, atmega2560, atmega2561, atmega2564rfr2.
- avrxmega2: 8KiB up to 64KiB memory XMEGA devices
  - atxmega8e5, atxmega16a4, atxmega16a4u, atxmega16c4, atxmega16d4, atxmega16e5, atxmega32a4, atxmega32a4u, atxmega32c3, atxmega32c4, atxmega32d3, atxmega32d4, atxmega32e5, avr64da28, avr64da32, avr64da48, avr64da64, avr64db28, avr64db32, avr64db48, avr64db64, avr64dd14, avr64dd20, avr64dd28, avr64dd32, avr64ea28, avr64ea32, avr64ea48.
- avrxmega3: 64KiB memory & ram XMEGA devices
  - attiny202, attiny204, attiny212, attiny214, attiny402, attiny404, attiny406, attiny412, attiny414, attiny416, attiny417, attiny424, attiny426, attiny427, attiny804, attiny806, attiny807, attiny814, attiny816, attiny817, attiny824, attiny826, attiny827, attiny1604, attiny1606, attiny1607, attiny1614, attiny1616, attiny1617, attiny1624, attiny1626, attiny1627, attiny3214, attiny3216, attiny3217, attiny3224, attiny3226, attiny3227, atmega808, atmega809, atmega1608, atmega1609, atmega3208, atmega3209, atmega4808, atmega4809, avr16dd14, avr16dd20, avr16dd28,

avr16dd32, avr16ea28, avr16ea32, avr16ea48, avr16eb14, avr16eb20, avr16eb28, avr16eb32, avr32da28, avr32da32, avr32da48, avr32db28, avr32db32, avr32db48, avr32dd14, avr32dd20, avr32dd28, avr32dd32, avr32ea28, avr32ea32, avr32ea48.

- avrxmega4: 64KiB up to 128KiB memory XMEGA devices:
  - atxmega64a3, atxmega64a3u, atxmega64a4u, atxmega64b1, atxmega64b3, atxmega64c3, atxmega64d3, atxmega64d4, avr128da28, avr128da32, avr128da48, avr128da64, avr128db28, avr128db32, avr128db48, avr128db64.
- avrxmega5: 64KiB up to 128KiB memory and more than 64KiB ram XMEGA devices:
  - atxmega64a1, atxmega64a1u.
- avrxmega6: more than 128KiB memory XMEGA devices:
  - atxmega128a3, atxmega128a3u, atxmega128b1, atxmega128b3, atxmega128c3, atxmega128d3, atxmega128d4, atxmega192a3, atxmega192a3u, atxmega192c3, atxmega192d3, atxmega256a3, atxmega256a3b, atxmega256a3bu, atxmega256a3u, atxmega256c3, atxmega256d3, atxmega384c3, atxmega384d3.
- avrxmega7: more than 128KiB memory and more than 64KiB ram XMEGA devices:
  - atxmega128a1, atxmega128a1u, atxmega128a4u.
- avrtiny:
  - attiny4, attiny5, attiny9, attiny10, attiny102, attiny104, attiny20, attiny40.
- avr1:
  - attiny11, attiny12, attiny15, attiny28, at90s1200.

#### -mabsdata:

- This option has only an effect on reduced Tiny devices like ATtiny40
- Assumes that all data in static storage can be accessed by LDS/STS instructions

#### -maccumulate-args:

- Accumulate outgoing function arguments and acquire/release the needed stack space for outgoing function arguments once in function prologue/epilogue
- Without this option, outgoing arguments are pushed before calling a function and popped afterwards

<https://www.nongnu.org/avrdude/>

- Popping arguments after the function call can be expensive on AVR so that accumulating the stack space might lead to smaller executables
- Can lead to reduced code size for functions that perform several calls to functions that get their arguments on the stack like calls to printf-like functions

#### -mbranch-cost=cost:

- Set branch costs for conditional branch instructions to cost.
- Values for cost are small, non-negative integers
- Default branch cost is 0

#### -mcall-prologues:

- Functions prologues/epilogues are expanded as calls to appropriate subroutines
- Code size is smaller

#### -mdouble=bits, -mlong-double=bits:

- Set the size of the double or long double type.
- Possible values for bits are 32 and 64
- Depends on the `-with-double=` and `-with-long-double=` configure options

#### -mgas-isr-prologues=

- Interrupt Service Routine may use the `__gcc_isr` pseudo instruction
- Activated per default if optimization is on (but not with `-Og`)

#### -mint8:

- Assumes int to be 8-bit integer
- Affects the sizes of all types:
  - Char : 1 byte
  - Int : 1 byte
  - Long : 2 bytes
  - Long long : 4 bytes
- This option does not conform to the C standards but results in smaller code size

#### -mmain-is-OS\_task:

- Do not save registers in main
- Effect is the same like attaching attribute `OS_task` to main.
- Activated per default if optimization is on

### -mno-interrupt:

- Generated code is not compatible with hardware interrupts
- Makes code smaller

### -mrelax:

- Try to replace CALL resp. JMP instruction by the shorter RCALL resp. RJMP instruction if applicable
- Adds the -mlink-relax option to the assembler's command line and the -relax option to the linker's command line
- Must be turned on if linker stubs are needed

### -mrodata-in-ram, -mno-rodata-in-ram:

- Locate the .rodata sections for read-only data in RAM resp. in program memory.
- For most devices, there is no choice and this option acts like an assertion
- For the AVR64\* and AVR128\* devices, .rodata is located in flash memory per default provided the required GNU binutils support is available.
- In that case, this can be used to return to the old layout with .rodata in RAM

### -mstrict-X:

- Use address register x in a way proposed by the hardware.
- Means that x is only used in indirect, post-increment or pre-decrement addressing
- Without this option, the x register may be used in the same way as Y or Z which then is emulated by additional instructions.

### -mtiny-stack:

- Only change the lower 8 bits of the stack pointer

### -mfract-convert-truncate:

- Allow to use truncation instead of rounding towards zero for fractional fixed-point types

### -nodevicelib:

- Don't link against AVR-LibC's device specific library lib<mcu>.a.

### -nodevicespecs:

- Don't add -specs=device-specs/specs-mcu to the compiler driver's command line

<https://www.nongnu.org/avrdude/>

- User takes responsibility for supplying the sub-processes like compiler proper, assembler, and linker with appropriate command line options
- User has to supply their private device specs file by means of `-specs=path-to-specs-fil` thus no need for option `-mmcu=mcu`

#### `-Waddr-space-convert:`

- Warn about conversions between address spaces in the case where the resulting address space is not contained in the incoming address space

#### `-Wmisspelled-isr:`

- Warn if the ISR is misspelled, i.e without `__vector` prefix.
- Enabled by default

# AVR-OBJCOPY

A software that comes along automatically when installing avr-gcc. This software copies and translate object files, the a.out gotten by avr-gcc, into hex files that can be directly uploaded into the microcontroller.

Typing `avr-objcopy` in the command line will show the flags and commands that can be used alongside some explanation to what they do.

```
light-llvm5-avr-objcopy
Usage: avr-objcopy [options] in-file [out-file]
Copies a binary file, possibly transforming it in the process

The options are:
-I --input-target <format>      Assume input file is in format <format>
-O --output-target <format>     Create an output file in format <format>
-m --binary-architecture <arch> Set output arch, when input is arch-less
-t --target <format>            Set both input and output format to <format>
-d --debugging                  Convert debugging information, if possible
-p --preserve-dates             Copy modified/access timestamps to the output
-D --enable-deterministic-archives
                                Produce deterministic output when stripping archives
-W --disable-deterministic-archives
                                Disable -D behavior (default)
-o --only-section <name>       Only copy section <name> into the output
-a --add-gnu-debuglink=<file>   Add section .gnu_debuglink linking to <file>
-r --remove-section <name>     Remove section <name> from the output
-s --strip-all                 Remove all symbol and relocation information
-g --strip-debug                Remove all debugging symbols & sections
-G --strip-dwo                  Remove all DWARF sections
-S --strip-unneeded             Remove all symbols not needed by relocations
-s --strip-symbol <name>       Do not copy symbol <name>
-S --strip-unneeded-symbol <name>
                                Do not copy symbol <name> unless needed by
                                relocations
-m --only-keep-debug            Strip everything but the debug information
-e --extract-dwo                Copy only dwo sections
-r --retract-symbol <name>     Remove section contents but keep symbols
-k --keep-symbol <name>        Do not strip symbol <name>
-K --keep-file-symbols          Do not strip file symbol(s)
-L --localize-hidden            Turn all h: hidden symbols into locals
-l --localize-symbol <name>    Force symbol <name> to be marked as a local
-L --globalize-symbol <name>  Force symbol <name> to be marked as a global
-G --keep-global-symbol <name>
                                Localize all symbols except <name>
-g --remove-symbol <name>      Force symbol <name> to be marked as a weak
-w --weaken                     Force all global symbols to be marked as weak
-W --discard                    Permit wildcard in section comparison
-a --discard-all              Remove all non-global symbols
-A --discard-locals             Remove any compiler-generated symbols
-i --interleave[<number>]      Only copy <number> of every <number> bytes
-I --interleave-width <number>
                                Set <number> for interleaving
-b --byte-size <number>        Select byte size in every interleaved block
-g --gap-fill <val>            Fill gaps between sections with <val>
-a --reloc-addr <addr>         Pad the last section up to <reloc-addr>
-s --start-addr <addr>         Set the start address to <addr>
[-change-start|--adjust-start] <addr>
                                Add <addr> to the start address
[-change-addresses|--adjust-vm] <addr>
                                Add <addr> to LMA, VMA and start addresses
[-change-section-address|--adjust-section-vm] <name>[=] <val>
                                Change LMA and VMA of section <name> by <val>
-change-section-lma <name>[=] <val>
                                Change the LMA of section <name> by <val>
-change-section-vm <name>[=] <val>
                                Change the VMA of section <name> by <val>
[-no[-change-warnings]] [-no[-reloc-warnings]]
                                Warn if a named section does not exist

light-llvm5-avr-objcopy
Usage: avr-objcopy [options]
Options:
  -h, --help                Display this program's version number
  -V, --version              Display this output
  -b, --help                 List object formats & architectures supported
avr-objcopy: supported targets: elf32-avr elf32-little elf32-big plugin brcr symbolsrc verilog tekhex binary hex
```

The typical command to run that would work most of the time:

```
avr-obicopy -O ihex -i .data -i .text a.out a.hex
```

Where: -O ihex is the file format, -j .data and -j .text so that only necessary code is uploaded, thus smaller code size, a.out name of object file, and a.hex name of hex file

<https://www.nongnu.org/avrdude/>



# AVRDUDE

## AVRDUDE commands

### -p partno:

- mandatory option. Tells what type of MCU is connected.
- partno is the id listed in the configuration file.
- -p ? Lists all parts in the configuration file.
- If a part is not there, it needs to be added to the configuration file by entering the programming specifications found on the Atmel datasheet.

### -b baudrate:

- Overrides the RS-232 connection baudrate specified in the respective programmers entry of the configuration file

### -B bitlock:

- Specify the bit lock period for the JTAG interface (JTAG ICE only)
- The value is a floating-point number in microseconds
- The default value of the HTAG ICE results in about 1microsecond bit clock period. Suitable for targets running at 4MHz and above

### -c programmer-id:

- Specify the programmer to be used
- -c ? Lists all programmer's id listed in the configuration file
- A new, unknown/undefined programmer can be added by copying an existing entry in the configuration file and changing the pin definitions to match that of the unknown programmer.

### -C config-file:

- Use the specified config file for configuration data for the programmers.
- If not specified, AVRDUDE reads the configuration file from /usr/local/etc/avrdude.conf (FreeBSD and Linux)

### -D:

- Disable auto erase for flash, which is the default:

<https://www.nongnu.org/avrdude/>

- When `-U` option with flash memory is specified, avrdude will perform a chip erase before starting any of the programming operations.
- To remain backward compatible, the `-i` and `-m` options automatically disable the auto erase feature.

#### `-e:`

- Causes a chip erase to be executed.
- Restes the contents of the flash ROM and EEPROM to the value 0xff.
- Technically a prerequisite command before the flash ROM can reprogrammed again. Only exception would be if the new contents would exclusively cause bits to be programmed from the value 1 to 0.
- Does not have to be called before programming as the MCU provides an auto-erase cycle before programming the cell

#### `-E exitspec[,...]:`

- By defaults AVRDUDE leaves the parallel port in the same state at exit as it has been found at startup. This option modifies the state of the /RESET and Vcc lines the parallel port is left at, according to the exitspec arguments provided:
  - `reset`: The /RESET signal will be left activated at program exit, will be held low, in order to keep the MCU in reset state afterward.
  - `noreset`: the /RESET line will be deactivated at program exit.
  - `vcc`: will leave those parallel port pins active, high, that can be used to supply Vcc power to the MCU
  - `novcc`: pull the Vcc pins of the parallel port down at program exit
- Multiple exitspec arguments can be seperated with commas

#### `-F:`

- Normally, AVRDUDE tries to verify that the device signature read from the part is reasonable before continuing
- This option is provided to override the check

#### `-n:`

- No-write – disables actually writing data to the MCU (useful for debugging AVRDUDE)

#### `-P port:`

- Use port to identify the device to which the programmer is attached

<https://www.nongnu.org/avrdude/>

- Normally the default parallel port is used.
- If you need to use a different parallel or serial port, use this option to specify the alternate port name.

#### -q:

- Disable (quell) output of the progress bar while reading or writing to the device.
- Specify it a second time for even quieter operation

#### -U:

- Disables the default behaviour of reading out the fuses three times before programming, then verifying at the end of programming that the fuses have not changed.
- If you want to change fuses, specify this option, as AVRDUDE will change the fuses back for you “safety”
- Designed to prevent cases of fuse bits magically changing (safemore)

#### -t:

- Enter the interactive “terminal” mode instead of up- or downloading files.
- See next chapter

#### -U memtype:op:filename[:format]:

- Perform a memory operation equivalent to specifying the -m, -i, or -o and -f options, except that multiple -U options can be specified in order to operate on multiple memories on
- The memtype field specifies the memory type to operate on.
- Use the -v option on the command line or the part command from terminal mode to display all the memory types supported by a particular device.
- Typically, a device’s memory configuration at least contains t
- Memory types currently known are:
  - calibration : one or more bytes of RC oscillator calibration data
  - eeprom : The EEPROM of the device
  - fuse : the fuse byte in devices that have only a single fuse byte
  - efuse : the extended fuse byte
  - hfuse : the high fuse byte
  - lfuse : the low fuse byte
  - lock : the lock byte
  - signature : the three device signature bytes (device ID)

<https://www.nongnu.org/avrdude/>

- Flash : typical for avr
- The op field specification:
  - r : read the specified device memory and write to the specified file
  - w : read the specified file and write it to the specified device memory
  - v : read the specified device memory and the specified file and perform a verify operation
- The filename field indicates the name of the file to read or write.
- The format field is optional and contains the format of the file to read or write.

Possible values are:

- i : Intel
- s : Motorola S-record
- r : raw binary; little-endian byte order, in the case of the flash ROM data
- m : immediate mode; actual byte values specified on the command line, separated by commas or spaces in places of the filename field of the -i, -o, or -U options. Useful for programming fuse bytes without having to create a single-byte file or enter terminal mode. If the number specified begins with 0x, it is treated as a hex value. If the number otherwise begins with a leading zero it is treated as octal. Otherwise the value is treated as decimal
- a : auto detect; valid for input only, and only if the input is not provided at stdin.
- The default is to use auto detection for input files, and raw binary format for output files.
- If filename contains a colon, the format field is no longer optional since the filename part following the colon would otherwise be misinterpreted as format

-v:

- Enable ver

-V:

- Disable automatic verify check when upload

-y:

- Tells AVRDUDE to use the last four bytes of the connected parts' EEPROM memory to track the number of times the device has been erased

<https://www.nongnu.org/avrdude/>

- When this option is used and the `-e` flag is specified to generate a chip erase, the previous counter will be saved before the chip erase, which will be incremented, and written back after the erase cycle completes.
- Typically to track how many erase-rewrite cycles the part has undergone since the FLASH memory can only endure a finite number of erase-rewrite cycles.
- Typical limit for Atmel AVR FLASH is 1000 cycles.
- If the application needs the last four bytes of EEPROM memory, this option should not be used.
- No longer supported

#### `-Y` cycles:

- Instructs AVRDUDE to initialize the erase-rewrite cycle counter residing at the last four bytes of EEPROM memory to be the specified value.
- No longer supported

## Terminal Mode Operation

Enabled by the `-t` option. Allows to enter interactive commands to display and modify the various device memories, perform a chip erase, display the device signature bytes and part parameters, and to send raw programming commands.

<https://www.nongnu.org/avrdude/>

Commands and parameters may be abbreviated to their shortest unambiguous form.

Supports a command history so that previously entered commands can be recalled and edited.

## Terminal Mode Commands

### dump memtype addr nbytes:

- Read nbytes from the specified memory area, and display them in hexadecimal and ASCII form

### dump :

- Continue dumping the memory contents for another nbytes where the previous dump command left off

### write memtype addr byte1 ... byteN

- Manually program the respective memory cells starting at address addr using the values byte1 through byteN.
- Not implemented for bank-addressed memories such as the flash memory of ATmega devices.

### erase :

- Perform a chip erase

### send b1 b2 b3 b4:

- Send raw instruction codes to the AVR devices.
- If you need access to a feature of an AVR part that is not directly supported by AVRDUDE, this command allows you to use it.

### sig :

- Display the device signature bytes.

### part :

- Display the current part settings and parameters. Includes chip specific information including all memory types supported by the device, read/write timing, etc.

<https://www.nongnu.org/avrdude/>

?:

- Give a short on-line summary of the available commands

quit :

- Leave the terminal mode and thus AVRDUDE

## Other Commands for STK500 and JTAG ICE

vtarg voltage

- Set the target's supply voltage to voltage Volts.

varef voltage

- Set the adjustable voltage source to voltage Volts. This voltage is normally used to drive the target's Aref input on the STK500

fosc freq [M/k] :

- Set the master oscillator to freq Hz. An optional trailing letter M multiplies by 1E6, a trailing letter k by 1E3

fosc o

- Turn the master oscillator off

sck period :

- STK500 only : Set the sck clock period to period microseconds
- JTAG ICE only : Set the JTAG ICE bit clock period to period microseconds. Will be reverted to its default value when the programming software signs off from the JTAG ICE.

parm :

- STK500 only; Display the current voltage and master oscillator parameters
- JTAG ICE only: Display the current target supply voltage and JTAG bit clock rate/period

## Configuration File

AVRDUDE reads a configuration file upon startup. Any chip or programmer not supported by AVRDUDE can be added to the configuration file.

AVRDUDE first looks for a system wide config file in “/usr/local/etc/avrdude.conf” on linux. The name of the file can be changed using the -C command line option.

After the system wide configuration file is parsed, AVRDUDE looks for a per-user configuration file to augment or override the system wide defaults.

The per-user file is .avrduderc within the user’s home directory.

## Programmer Definitions

The format of the programmer definition is as follows:

```
programmer
  id      = <id1> [, <id2> [, <id3>] ...] ; # <idN> are quoted strings
  desc    = <description> ;                  # quoted string
  type    = par | stk500 ;                   # programmer type
  baudrate = <num> ;                         # baudrate for serial ports
  vcc     = <num1> [, <num2> ... ] ;         # pin number(s)
  reset   = <num> ;                          # pin number
  sck     = <num> ;                          # pin number
  mosi    = <num> ;                          # pin number
  miso    = <num> ;                          # pin number
  errled   = <num> ;                         # pin number
  rdyled   = <num> ;                         # pin number
  pgmled   = <num> ;                         # pin number
  vfyld    = <num> ;                         # pin number
;
```

## Part Definitions

part

JTAG ICE: contains on-board logic to control the programming of the target device. Uses serial communication protocol. Allows both memory programming and on-chip debugging. The JTAG ICE mkII protocol can also be run on top of USB.

To access the full manual on Linux use command: man avrdude

<https://www.nongnu.org/avrdude/>



