

Raw Table		
Columns	Typeof	Details
SrNo	System.String	
LTCableFeature	System.String	Type of Feature
LTCableFeatureOID	System.String	ObjectID of the LTFeature
End1OID	System.String	Connected Object OID (Fuse/BusDropper)
End1Type	System.String	Type: Fuse/BusDropper
End1No	System.String	Fuse No
End1Position	System.String	Fuse: Normal Position (On/Off)
End1FacilityOID	System.String	ObjectID of the Pillar
End1FacilityType	System.String	Type of Pillar
End1FacilityName	System.String	Pillar No
End1BusBarLV	System.String	BusBar - LV
End1FacilityContainsBusCoupler	System.String	Y/N
End1BC1OID	System.String	ObjectID of the First Connected BC to BusBar - LV (from Left)
End1BC1Position	System.String	Normal Position (On/Off)
End1BC2OID	System.String	ObjectID of the Second Connected BC to BusBar - LV (from Left)
End1BC2Position	System.String	Normal Position (On/Off)
Remarks1	System.String	Partial Pillar / MiniPillar / FUMP
End2OID	System.String	Connected Object OID (Fuse/BusDropper)
End2Type	System.String	Type: Fuse/BusDropper
End2No	System.String	Fuse No
End2Position	System.String	Fuse: Normal Position (On/Off)
End2FacilityOID	System.String	ObjectID of the Pillar
End2FacilityType	System.String	Type of Pillar
End2FacilityName	System.String	Pillar No
End2BusBarLV	System.String	BusBar - LV
End2FacilityContainsBusCoupler	System.String	Y/N
End2BC1OID	System.String	ObjectID of the First Connected BC to BusBar - LV (from Left)
End2BC1Position	System.String	Normal Position (On/Off)
End2BC2OID	System.String	ObjectID of the Second Connected BC to BusBar - LV (from Left)
End2BC2Position	System.String	Normal Position (On/Off)
Remarks2	System.String	Partial Pillar / MiniPillar / FUMP
COID	System.String	COID connected to given SP
UnitConsumption	System.String	UnitConsumption consumed by given COID

TableName: LTCableTraceDetails

TappedLTCable details		
Columns	Typeof	Details
SrNo	System.String	
End1OID	System.String	ObjectID of the LTFeature to which the current LTCable is connected
CurrentFeatureOID	System.String	ObjectID of the current LTCable
COID	System.String	COID of the connected Service Point
UnitConsumption	System.String	Total Unit Consumption consumed per month by the COID

TableName: TappedLTCable

ErrorTable		
Columns	Typeof	Details
SrNo	System.String	
LTCableFeatureOID	System.String	ObjectID of the LTFeature
LayerName	System.String	Layer to which the connectivity failed
ErrorType	System.String	Type of Error: Snapping Error / No object Found etc
OID	System.String	Feature at which intersection is taking place

TableName: ErrorList