

CONNECTIVITY RULES FOR LT FEATURES								
	DT	LT CABLE	BUSBAR	DROPPER	SWITCH LINK	FUSE	SERVICE POINT	TERMINATION POINT
DT	X	√	X	X	X	X	X	X
LT CABLE	√	√	√	√	X	X	√	√
BUSBAR	X	√	√ (FUMP)	√	√	√ (FUMP)	X	X
DROPPER	X	√	√	X	X	√	X	√
SWITCH LINK	X	X	√	X	X	X	X	X
FUSE	X	X	√ (FUMP)	√	X	X	X	X
SERVICE POINT	X	√	X	X	X	X	X	X
TERMINATION POINT	X	√	X	√	X	X	X	X