

GM8136

H264 ENCODER

User Guide

Rev.: 1.0

Issue Date: October 2014



REVISION HISTORY

GM8136 H264 Encoder User Guide

Date	Rev.	From	To
Oct. 2014	1.0	-	Original

Copyright © 2014 Grain Media, Inc.

All Rights Reserved.

Printed in Taiwan 2014

Grain Media and the Grain Media Logo are trademarks of Grain Media, Inc. in Taiwan and/or other countries. Other company, product and service names may be trademarks or service marks of others.

All information contained in this document is subject to change without notice. The products described in this document are NOT intended for use in implantation or other life support application where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Grain Media's product specification or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Grain Media or third parties. All information contained in this document was obtained in specific environments, and is presented as an illustration. The results obtained in other operating environments may vary.

THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROVIDED ON AN "AS IS" BASIS. In no event will Grain Media be liable for damages arising directly or indirectly from any use of the information contained in this document.

Grain Media, Inc.
5F, No. 5, Li-Hsin Road III, Hsinchu Science Park, Hsinchu City, Taiwan 300, R.O.C.

Grain Media's home page can be found at:
<http://www.grain-media.com>

TABLE OF CONTENTS

Chapter 1	Introduction.....	1
	1.1 Overview.....	2
	1.2 Related Document.....	2
Chapter 2	Driver Module of H264 Encoder.....	3
	2.1 Driver Module	4
	2.2 Module Parameter	4
Chapter 3	H264 Encoder Proc Node	7
	3.1 /proc/videograph/h264e/info.....	8
	3.2 /proc/videograph/h264e/chn_info.....	8
	3.3 /proc/videograph/h264e/utilization	9
	3.4 /proc/videograph/h264e/callback_period	9
	3.5 /proc/videograph/h264e/level	10
	3.6 /proc/videograph/h264e/property	10
	3.7 /proc/videograph/h264e/job.....	11
	3.8 /proc/videograph/h264e/param	12
	3.9 /proc/videograph/h264e/didn.....	15
	3.10 /proc/videograph/h264e/ref_info	15
	3.11 /proc/videograph/h264e/q_matrix.....	16
	3.12 /proc/videograph/h264e/mcnr	17

Chapter 1

Introduction

This chapter contains the following sections:

- 1.1 Overview
- 1.2 Related Document

1.1 Overview

The H264 high-profile encoder is a high-performance hardware video encoder based on the MPEG4 AVC/JVT/H.264 video coding standard. The encoder is designed to compress a sequence of YcbCr 4:2:2 pictures into a compressed video bitstream. The supported resolutions are up to 4096x4096. The features of H264 encoder include the following MPEG4 AVC/JVT/H.264 (ISO/IEC 14496-10) video coding standard:

- High profile level 4.1
- Supports I, B, and P frame encodings
- Supports CAVLC and CABAC entropy coding
- Includes de-interlace and de-noise preprocessor
- Configures horizontal and vertical search ranges as 16pixels ~ 256pixels with configuration steps of 8pixels
- CBR and VBR (Rate control by firmware)
- Supports user-defined quantization matrix
- Supports mono (4:0:0) encoding
- Supports 4x4 and 8x8 transform coding
- Supports 4x4 and 8x8 intra predictions

1.2 Related Document

The reference document includes:

- H264_Rate_Control_User_Guide_xxx.pdf

Chapter 2

Driver Module of H264 Encoder

This chapter contains the following sections:

- 2.1 Driver Module
- 2.2 Module Parameter

2.1 Driver Module

The H264 encoder module contains the following part:

- favc_enc.ko

This is the H264 encoder core. It includes the H264 encoder hardware control layer and middle ware (GM_graph) communication layer.

The following example shows the operation procedure:

```
/ # insmod favc_enc.ko h264e_max_b_frame=0 h264e_max_width=1920 h264e_max_height=1088  
FAVC Encoder v0.1.105, built @ Sep 30 2014 17:39:25 (GM8136)
```

2.2 Module Parameter

Table 2-1 lists and describes the module parameters when inserting the H264 encoder driver.

Table 2-1. Module Parameters

Name	Default Value	Description
h264e_max_width	0	Maximal width of the encoded frame
h264e_max_height	0	Maximal height of the encoded frame
h264e_max_chn	128	Maximal number of the channel ID
h264e_snapshot_chn	0	Number of the snapshot channels
h264e_max_b_frame	0	Maximal number of b frame in gop 0: Not support b frame
h264e_yuv_swap	0	Input YUV422 format 0: CbYCrY 1: YCbYCr
use_ioremap_wc	0	Register of mcp280 remap type 0: ncnb 1: ncb
config_path	"/mnt/mtd"	Specify the configure path
h264e_slice_offset	0	Output slice offset 0: Not output the position of echo slice on the bitstream 1: Output the position of echo slice on the bitstream (At most, first four slices)
h264e_tight_buf	0	Allocate exact number of the reference buffers

Name	Default Value	Description
h264e_one_ref_buf	0	Reduce number of the reference buffers 0: Reference buffer and reconstructed buffer are different buffers. 1: Reference buffer and reconstructed buffer are the same buffers.
h264e_user_config	0	Using "favce_param.cfg" to be the encode setting for each channel
pwm	0	Control clock ratio

Chapter 3

H264 Encoder Proc Node

This chapter contains the following sections:

- 3.1 /proc/videograph/h264e/info
- 3.2 /proc/videograph/h264e/chn_info
- 3.3 /proc/videograph/h264e/utilization
- 3.4 /proc/videograph/h264e/callback_period
- 3.5 /proc/videograph/h264e/level
- 3.6 /proc/videograph/h264e/property
- 3.7 /proc/videograph/h264e/job
- 3.8 /proc/videograph/h264e/param
- 3.9 /proc/videograph/h264e/didn
- 3.10 /proc/videograph/h264e/ref_info
- 3.11 /proc/videograph/h264e/q_matrix
- 3.12 /proc/videograph/h264e/mcnr

The H264 encoder module provides several proc nodes. Users can read the information of the H264 encoder or setup the configuration through the nodes.

3.1 /proc/videograph/h264e/info

Users can use /proc/videograph/h264e/info to get the driver information, including the versions of the drivers and the values of the module parameters.

Usage:

- Get the version of the driver and value of the module parameters
cat /proc/videograph/h264e/info

```
FAVC Encoder v0.1.105, built @ Oct 13 2014 15:04:11 (GM8136)
module parameter
=====
h264e_max_width          1920
h264e_max_height         1088
h264e_max_b_frame        0
h264e_max_chn            128
h264e_snapshot_chn       0
h264e_yuv_swap           0
pwm                      0
config_path               "/mnt/mtd"
use_ioremap_wc            0
h264e_slice_offset       1
h264e_one_ref_buf        1
h264e_tight_buf          1
h264e_user_config        0
```

3.2 /proc/videograph/h264e/chn_info

Users can use /proc/videograph/h264e/chn_info to get the settings of each encoded channel, including the resolution, frame rate, gop, bitrate, mode of the rate control, and current quant value.

Usage:

- Get the settings of each channel
cat /proc/videograph/h264e/chn_info

chn	resolution	buf.type	gop	mode	fps	bitrate	max.br	init.q	min.q	max.q	qp
===	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====
0	704x480	D1	60	CB	900/3	1024	0	30	15	51	29
				R	0						

1	352x244	cif	60	CB	900/3	512	0	30	15	51	32
			R	0							

3.3 /proc/videograph/h264e/utilization

Users can use /proc/videograph/h264e/utilization to get the percentage of the hardware utilization and set the time period of the measured utilization.

Usage:

- Get the hardware utilization
cat /proc/videograph/h264e/utilization

HW Utilization Period=5(sec) Utilization=78
- Set the period of the hardware utilization measurement
echo [sec] > /proc/videograph/h264e/utilization

3.4 /proc/videograph/h264e/callback_period

Users can use /proc/videograph/h264e/callback_period to get and set the callback period.

Usage:

- Get the callback period
cat /proc/videograph/h264e/callback_period

Callback Period = 3 (msecs)
- Set the callback period
echo [msec] > /proc/videograph/h264e/callback_period

3.5 /proc/videograph/h264e/level

Users can use /proc/videograph/h264e/level to set the debug level. Higher debug level will dump more information to the background log.

Usage:

- Get the debug level

```
cat /proc/videograph/h264e/level
```

```
Log level = 2 (0: emergy, 1: error, 2: warning, 3: debug, 4: info)
```

- Set the debug level

```
Echo [level] /proc/videograph/h264e/level
```

```
[level]:
```

```
0: Emergency message
```

```
1: Error message
```

```
2: Warning message
```

```
3: Debug message
```

```
4: Information
```

For example, if the current debug level is 2, the driver will dump the emergency message, error message, and warning message.

3.6 /proc/videograph/h264e/property

Users can use /proc/videograph/h264e/property to get the input property of the specified channel.

Usage:

- Get the input property of the specified channel

```
cat /proc/videograph/h264e/property
```

```
usage: echo [chn] > /proc/videograph/h264e/property
```

```
FAVCE favce ch0 job 14257793
```

```
=====
```

ID	Name (string)	Value (hex)	Readme
----	---------------	-------------	--------

2	src_xy	00240050	roi xy
4	src_dim	00900060	encode resolution
47	init_quant	0000001e	initial quant
41	bitrate	000000e6	target bitrate (Kb)
43	idr_interval	00000036	I frame interval
38	didn_mode	00000000	didn mode
...			

- Set the specified channel ID to get property
echo [chn] > /proc/videograph/h264e/property

3.7 /proc/videograph/h264e/job

Users can use /proc/videograph/h264e/job to get the information of job in the encoder job list.

Usage:

- Get the information of the job list
cat /proc/videograph/h264e/job

```
usage: echo [chn] > /proc/videograph/h264e/job ([chn] = 999: means dump all job)
current [chn] = 999
Engine      Minor      Job_ID      Status      Puttime
=====
0           41         15838469    STANDBY     0xb3f1
0           35         15841020    ONGOING     0x8e75
```

- Set the specified channel to get the job information
echo [chn] > /proc/videograph/h264e/job
[chn]: 999 means to get job information in job list

3.8 /proc/videograph/h264e/param

Users can use /proc/videograph/h264e/param to get and set the encode parameters.

Usage:

- Get the encode parameters

```
cat /proc/videograph/h264e/param
```

Parameter name	Value	Note
DefaultCfg	1	0: Light quality (Between performance and quality) 1: Performance 2: Quality 3: User definition
SymbolMode	0	0: CAVLC 1: CABAC
ROIQPType	1	0: Disable ROI QP 1: Delta QP 2: Fixed QP
ROIDeltaQP	-4	ROI QP = Frame QP - Delta QP
ROIFixedQP	20	ROI QP = Fixed QP
ResendSPSPPS	1	0: Packing sps and pps (Only the first IDR frame) 1: Packing sps and pps (Each I frame_ 2: Packing sps and pps (Each frame)
CbQPOffset	6	Cb QP offset
CrQPOffset	6	Cr QP offset
DFDisableIdc	0	Deblock idc 0: Strong 1: Disable 2: Weak
DFAAlpha	6	H264 deblock coefficient
DFBeta	6	H264 deblock coefficient

Parameter name	Value	Note
DiDnMode	0	DiDn enable -1: Using property input Bit0: Spatial de-interlace Bit1: Temporal de-interlace Bit2: Spatial denoise Bit3: Temporal denoise
PRef0SearchRangeX	32	Search range of X
PRef0SearchRangeY	16	Search range of Y
DisableCoeff	0	Threshold residual coefficient 0: Enable coefficient threshold 1: Disable coefficient threshold
LumaCoeffThd	4	Threshold coefficient of luma
ChromaCoeffThd	4	Threshold coefficient of chroma
DeltaQPWeight	5	Delta QP of each MB 5: Disable Delta QP 4: Enable Delta QP by image variance
DeltaQPStrength	19	Coefficient of Delta QP
DeltaQPThd	231	Coefficient of Delta QP
MaxDeltaQP	5	Max. Delta QP of MB
Transform8x8	0	0: Disable 8x8 transform 1: Enable 8x8 transform
InterDefaultTransformSize	0	Inter hardware transform size 0: 4x4 1: 8x8
DisablePInterPartition	6	Disable inter prediction mode of P frame Bit 0: 8x8 Bit 1: 8x16 Bit 2: 16x8 Bit 3: 16x16
DisableBInterPartition	14	Disable inter prediction mode of B frame Bit 0: 8x8 Bit 1: 8x16 Bit 2: 16x8 Bit 3: 16x16

Parameter name	Value	Note
DisableIntra8x8	1	Disable intra 8x8 prediction mode
IntraMode	0	Intra 4x4 prediction mode 0: 5 modes 1: 9 modes
FastIntra4x4	1	Fast algorithm of intra prediction
DisableIntra16x16Plane	1	Disable intra 16x16 plane prediction
DisableIntraIntra	0	Disable intra prediction of P/B frame
DisableIntra4x4	0	Disable intra 4x4 prediction mode of I frame
DisableIntra16x16	0	Disable intra 16x16 prediction mode of I frame
IPOffset	2	QP offset of I/P frame
PBOffset	2	QP offset of P/B frame
QPStep	1	QP step
MinQuant	1	Minimal QP
MaxQuant	51	Maximal QP
IntraCostRatio	0	Intra cost weight
ForceMV0Thd	0	Force MV to be zero by image variance
CABACInitMode	0	CABAC init idc
CostEarlyTerminate	0	Early termination by cost 0: Disable
PCycleEarlyTerminate	4095	Early termination by cycle of P frame: 4095 disable
BCycleEarlyTerminate	4095	Early termination by cycle of B frame: 4095 disable
ScalingListEnable	0	Scaling matrix 0: Disable 1: Enable
MCNREnable	0	MCNR 0: Disable 1: Enable
MCNRShift	2	MCNR parameter
MCNRMVThd	4	MCNR parameter
Profile	100	Default profile 66: Baseline profile 77: Main profile 100: High profile

Parameter name	Value	Note
LevelIdc	0	Level idc 0: Using the default setting Others: level_idc = LevelIdc/10

- Set the encode parameters
echo [parameter name] [value(dec)] > /proc/videograph/h264e/param

3.9 /proc/videograph/h264e/didn

Users can use /proc/videograph/h264e/didn to get and set the didn parameters.

Usage:

- Get the didn parameters
cat /proc/videograph/h264e/didn
- Set the didn parameters
echo [parameters name] [value(dec)] > /proc/videograph/h264e/didn

3.10 /proc/videograph/h264e/ref_info

Users can use /proc/videograph/h264e/ref_info to get the number of the allocated buffers and usage of buffer.

Usage:

- Get the number of the allocated buffers
echo 0 > /proc/videograph/h264e/ref_info
cat /proc/videograph/h264e/ref_info

```
dump ref buffer flag = 0 (0: dump pool number, 1: dump ref pool, 2: dump chn pool)
allocate reference buffer va0xbb000000/pa0x20000000, size 27800064
    D1: unit 622080, num 36, size 22394880
    CIF: unit 158976, num 34, size 5405184
    sys info size 11520, mvinfo size 130560, 11col size 261120
        total size 28203264 byte (26.896M)
```

- Get the number of the allocated buffer
`echo 1 > /proc/videograph/h264e/ref_info`
`cat /proc/videograph/h264e/ref_info`

```
Reference Pool
Avail:
id  addr_virt      addr_phy      size
0   0xbb686a00     0x20686a00   622080
1   0xbc8b1600     0x218b1600   158976
Allocated:
id  addr_virt      addr_phy      size
2   0xbb556e00     0x20556e00   622080
3   0xbbaadc00     0x20aadc00   622080
4   0xbc94ca00     0x2194ca00   158976
5   0xbc99a400     0x2199a400   158976
```

- Get the used buffer of each channel
`echo 2 > /proc/videograph/h264e/ref_info`
`cat /proc/videograph/h264e/ref_info`

```
Channel used pool
chn  res      s.res      addr_virt      addr_phy      size
===  ===      ===      =====      =====      =====
0    CIF      CIF      0xbc5f6c00     0x215f6c00    158976
1    D1       D1       0xbc09c800     0x2109c800    622080
2    CIF      CIF      0xbc692000     0x21692000    158976
3    D1       D1       0xbb12fc00     0x2012fc00    622080
```

3.11 /proc/videograph/h264e/q_matrix

Users can use /proc/videograph/h264e/q_matrix to get and set the scaling matrix.

- Get the scaling matrix
`cat /proc/videograph/h264e/q_matrix`
- Set the scaling matrix
`echo [matrix idx] [idx] [value] > /proc/videograph/h264e/q_matrix`

3.12 /proc/videograph/h264e/mcnr

Users can use /proc/videograph/h264e/mcnr to get and set the mcnr matrix

- Get the mcnr matrix
cat /proc/videograph/h264e/mcnr
- Set the mcnr matrix
echo [H/L] [idx] [value] > /proc/videograph/h264e/mcnr