

GM8136

3DNR

User Guide

Rev.: 1.1

Issue Date: October 2014



REVISION HISTORY

GM8136 3DNR User Guide

Date	Rev.	From	To
Aug. 2014	1.0	-	Original
Oct. 2014	1.1	-	<ul style="list-style-type: none">• Updated Chapter 3• Added Chapter 4

Copyright © 2014 Grain Media, Inc.

All Rights Reserved.

Printed in Taiwan 2014

Grain Media and the Grain Media Logo are trademarks of Grain Media, Inc. in Taiwan and/or other countries. Other company, product and service names may be trademarks or service marks of others.

All information contained in this document is subject to change without notice. The products described in this document are NOT intended for use in implantation or other support application where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Grain Media's product specification or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Grain Media or third parties. All information contained in this document was obtained in specific environments, and is presented as an illustration. The results obtained in other operating environments may vary.

THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROVIDED ON AN "AS IS" BASIS. In no event will Grain Media be liable for damages arising directly or indirectly from any use of the information contained in this document.

Grain Media, Inc.
5F, No. 5, Li-Hsin Road III, Hsinchu Science Park, Hsinchu City, Taiwan 300, R.O.C.

Grain Media's home page can be found at:
<http://www.grain-media.com>

TABLE OF CONTENTS

Chapter 1	Introduction.....	1
	1.1 Overview.....	2
	1.2 Features	2
Chapter 2	3DNR Driver Module	3
Chapter 3	3DNR Proc Node	5
	3.1 /proc/thdnr200/dma Proc Node	6
Chapter 4	3DNR Module Parameter	9
	4.1 max_minors Module Parameter	10
	4.2 res_cfg Module Parameter	10
	4.3 Other Module Parameters	10

LIST OF TABLES

Table 3-1.	Proc Node Component of 3DNR Driver Module	6
------------	---	---

LIST OF FIGURES

Figure 3-1. Proc Node of 3DNR Driver Module 6

Chapter 1

Introduction

This chapter contains the following sections:

- 1.1 Overview
- 1.2 Features

1.1 Overview

3DNR in GM8136 is used to de-noise the frames. The de-noise process is critical for enhancing the scene quality and reducing the encoded bitrate for network transmission. In a real-time IP camera system, the de-noise function is considerably useful in eliminating the Gauss-distribution noise. With this function, the encoder only needs to make little effort to encode the source scene. On the other hand, the encoded files will be smaller and thus reduce the bitrate transferred in the network.

1.2 Features

3DNR contains the following features:

- Supports spatial noise reduction
- Supports temporal noise reduction
- Supports temporal edge enhancement
- Supports temporal strength learning
- Supports source and destination YCbCr swap

Chapter 2

3DNR Driver Module

In the GM8136 SDK release package, users can find the source code and kernel module of 3DNR from “/module/ft3dnr200”.

The 3DNR driver module contains the following part:

- ft3dnr200.ko
This is the 3DNR core. It includes the 3DNR hardware control layer, middleware (GM_Graph), communication layer, and export library layer.

Chapter 3

3DNR Proc Node

This chapter contains the following section:

- 3.1 /proc/thdnr200/dma Proc Node

The 3DNR driver module provides the proc node. Users can read the information of 3DNR or setup the configuration through the node. The current useful node is listed below.

```
/ # ls /proc/thdnr200/  
dma
```

Figure 3-1. Proc Node of 3DNR Driver Module

Table 3-1 shows the proc node component of the 3DNR driver module.

Table 3-1. Proc Node Component of 3DNR Driver Module

/proc/thdnr200	dma	param
----------------	-----	-------

3.1 /proc/thdnr200/dma Proc Node

The 3DNR hardware supports the setting for the wait intervals of the DMA read and write channels. Users can use the proc node to set the wait intervals of the DMA read and write channels.

3.1.1 param

Users can use the /proc/thdnr200/dma/param node to get and set the parameter for wait intervals of the DMA read and write channels

Usage:

- Get all current values

cat /proc/thdnr200/dma/param

```
/# cat /proc/thdnr200/dma/param  
  
=== DMA Parameter ===  
[00]WC_WAIT_VALUE (0x0~0xffff) : 0x0  
[01]RC_WAIT_VALUE (0x0~0xffff) : 0x0
```



Usage:

- Set the param_id value to change the parameter value of DMA

echo [param_id] [value] > /proc/thdnr200/dma/param

param_id:

0: WC_WAIT_VALUE is the wait interval of the DMA write channel for each DMA write burst.

1: RC_WAIT_VALUE is the wait interval of the DMA read channel for each DMA read burst.

Chapter 4

3DNR Module Parameter

This chapter contains the following sections:

- 4.1 max_minors Module Parameter
- 4.2 res_cfg Module Parameter
- 4.3 Other Module Parameters

When loading the driver module, users can specify the module parameter of the module name to set the special value used in the driver. Currently, the useful module parameters are described below.

4.1 max_minors Module Parameter

Users can specify the maximum number of the channels used by the middleware. The usage is:

```
# insmod ft3dnr200.ko max_minors=16
```

If this parameter is not specified, the default value will be used.

4.2 res_cfg Module Parameter

The 3DNR hardware needs the memory space to store the output data depending on the specification of the product. Users can specify various resolutions as the module parameter. The format of the parameter is "resolution_keywords/channels"; if many resolutions are specified, they should be separated by a comma.

For example, users need the driver to provide one channel of 2M resolution, one channel of VGA resolution, and one channel of CIF resolution:

```
# insmod ft3dnr200.ko res_cfg="2M/1,VGA/1,CIF/1"
```

If this parameter is not specified, the default value will be extracted from the middleware configuration file, "gmlib.cfg", under the [ENCODE_DIDN] section.

4.3 Other Module Parameters

For other module parameters that are not described above, it is not allowed to be modified by users; it is only used by the factory configuration.