

# Beldray BEL0197 12 Stitch Sewing Machine Specification

The Beldray BEL0197 12 Stitch Sewing Machine is designed for both novice and experienced users seeking versatility and ease of use. It features a robust build with a compact, portable design, making it ideal for sewing enthusiasts with limited space. The machine offers 12 distinct stitch patterns, enabling users to perform a range of sewing tasks, from basic stitching to decorative designs. It is equipped with an easy-to-use dial for selecting stitch patterns, allowing for quick adjustments to suit various fabric types and sewing requirements.

The BEL0197 includes a four-step buttonhole function, simplifying the process of creating neat and consistent buttonholes. Its adjustable stitch length and zigzag width provide greater control over stitch customization. The machine is fitted with a powerful motor that ensures steady performance, even when working with thicker fabrics. A built-in LED light illuminates the sewing area, enhancing visibility and precision during sewing tasks.

Additional features include a thread cutter for convenience, a reverse sewing lever for reinforcing stitches, and a free arm for sewing cylindrical items like sleeves and cuffs. The Beldray BEL0197 also offers easy bobbin winding and a drop-in bobbin system for straightforward threading. Accessories such as extra bobbins, needles, and a foot pedal are included, providing users with everything needed to start sewing immediately. With its user-friendly operation and comprehensive features, the Beldray BEL0197 is an excellent choice for anyone looking to explore sewing projects with ease and efficiency.

## Beldray BEL0197 12 Stitch Sewing Machine F.A.Q.

### **Q. How do I thread the Beldray BEL0197 sewing machine?**

To thread the machine, first raise the needle to its highest position. Place the spool of thread on the spool pin and guide the thread through the thread guide, down the tension dial, and into the needle. Ensure the thread is properly secured in the take-up lever.

### **Q. What should I do if the stitches are skipping?**

Skipped stitches can be due to a dull or bent needle. Replace the needle with a new one, ensuring it is the correct type for your fabric. Also, check that the machine is threaded correctly.

### **Q. How can I adjust the tension on my sewing machine?**

To adjust the tension, use the tension dial located on the front of the machine. For tighter tension, turn the dial to a higher number. For looser tension, turn it to a lower number. Always test on a scrap piece of fabric first.

**Q. Why is the sewing machine making a loud noise?**

A loud noise may indicate that the machine needs cleaning or oiling. Check for any lint or thread caught in the bobbin area. If necessary, refer to the manual for instructions on how to lubricate the machine.

**Q. How do I change the presser foot on the BEL0197?**

To change the presser foot, raise the needle and presser foot lever. Release the current foot by pressing the lever at the back of the foot holder. Position the new foot under the holder and lower the presser foot lever to snap it into place.

**Q. What steps should I follow to clean the sewing machine?**

Turn off the machine and unplug it. Remove the needle, presser foot, and bobbin. Using a small brush, gently clean out any lint or dust from the bobbin area and feed dogs. Wipe the exterior with a soft cloth.

**Q. How can I fix the bobbin winding issue?**

Ensure the bobbin is placed correctly on the winder spindle and that the thread is wrapped around the bobbin tension guide. Start the machine and make sure the bobbin is winding evenly. If not, check for any tangles or misalignment.

**Q. Why does the fabric bunch up under the needle?**

Fabric bunching can result from incorrect tension settings or improper threading. Re-thread the machine and check the tension dial settings. Also, ensure the needle is suitable for the fabric type.

**Q. What causes the needle to break frequently?**

Frequent needle breaks can be caused by pulling the fabric too hard, using the wrong needle size, or hitting a pin. Use the correct needle for your fabric and avoid sewing over pins.

**Q. How do I select different stitch patterns on the BEL0197?**

To select a stitch pattern, turn the stitch selector dial on the front of the machine. Align the desired stitch number with the indicator. Adjust the stitch length and width as needed for your project.

## Questions to Ask

1. “Can you show me how to thread my BEL0197 sewing machine?”
2. “My machine is skipping stitches — how can I fix this?”
3. “How do I adjust the thread tension for better stitching?”
4. “Why is my BEL0197 making a strange or loud noise?”
5. “How can I change or replace the presser foot on my machine?”
6. “What’s the correct way to clean and maintain my sewing machine?”
7. “The bobbin isn’t winding properly — what should I check?”
8. “Why is my fabric bunching up while I sew?”
9. “My needle keeps breaking — what might be causing that?”
10. “How do I switch between stitch patterns on the BEL0197?”