




Installation manual

R32 Split series



2MXM40A2V1B
2MXM50A2V1B

Installation manual
R32 Split series

English

CE - DECLARATION OF CONFORMITY
CE - KONFORMITÄTSEKLERUNG
CE - DECLARATION DE CONFORMITE
CE - KONFORMITEITSEKLERING

01 continuation of previous page
02 Fortsetzung der vorherigen Seite:
03 suite de la page précédente:
04 vervolg van vorige pagina:

CE - DECLARACIÓN DE CONFORMIDAD
CE - DICHLARAZIONE DI CONFORMITA
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

05 continuation of the página anterior:
06 continua della pagina precedente:
07 συνέχεια της προηγούμενης σελίδας:

01 Construction des Modèles to which this declaration relates:

02 Specifications of conception des modèles auxquels se rapporte cette déclaration:

03 Ontwerpspecificaties van de modellen waarop deze verklaring betrekking heeft:

04 Especificaciones de diseño de los modelos a los cuales hace referencia esta declaración:

05 Specifiche di progetto dei modelli cui fa riferimento la presente dichiarazione:

01 Maximum allowable pressure (PS): <P> (bar)
Maximum maximum allowable pressure (TS):
Tmin: Minimum temperature at low pressure side <L> (°C)
Tmax: Saturated temperature corresponding with the maximum allowable pressure (PS): <P> (°C)
Refrigerant: <R>

Setting of pressure safety device: <P> (bar)

Manufacturing number and manufacturing year: refer to model nameplate

Minimale zulassige Druck (PS): <P> (bar)

Minimale maximale zulässige Temperatur (TS):

Tmin: Mindesttemperatur auf der Niederdruckseite <L> (°C)

Tmax: Sättigungstemperatur auf der dem maximal zulässigen Druck (PS) entspricht: <P> (°C)

Kältemittel: <R>

Einstellung der Druck-Schutzvorrichtung: <P> (bar)

Herstellungsnr. und Herstellungsjahr: siehe Typenschild des Modells

Pressure maxima admissible (PS): <P> (bar)

Température minimum admissible (TS):

Tmin: Température minimum admissible (TS):

Tmax: Température saturée correspondant à la pression maximale admissible (PS): <P> (°C)

Refrigerant: <R>

Installation of safety device: <P> (bar)

Production number and production year: refer to the nameplate of the model

Minimale toelaten druk (PS): <P> (bar)

Tmin: Minimale toelaten druk (PS): <P> (bar)

Tmax: Verzekigde temperatuur die overeenkomstig met de maximale toelaten druk (PS): <P> (°C)

Koelmiddel: <R>

Instelling van drukschutvoorz. <P> (bar)

Fabricagejaar en fabricagejaar: zie naamplaat model

Pressure maxima admissible (PS): <P> (bar)

Temperatura minima admissible (TS):

Tmin: Temperatura minima en el lado de baja presión <L> (°C)

Tmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <P> (°C)

Refrigerante: <R>

Ajuste del dispositivo de seguridad: <P> (bar)

Número de fabricación y año de fabricación: consulte la placa de especificaciones técnicas de modelo

CE - ERKLÄRUNG ÜBER SÄMERSVAR
CE - LÄMÖTUS, YHTEENLÄISKUOZAT
CE - PROHLÁŠENÍ O SHODĚ

12 continuation of the page anterior:
13 jatka edellisellä sivulla:
14 pokračování z předchozí strany:
15 fortløstelse fra brige side:

07 Προδιαγραφές των μοντέλων με το οποίο συγγίττει η δήλωση:

08 Especificaciones de proyecto des modelos a los que se aplica esta declaración:

09 Поопные характеристики моделей, к которым относится настоящее заявление:

10 Typespecificaties van de modellen, som deze eklarung vderen:

11 Desingspecificationer for de modeller som denne deklaration gælder:

12 Konstruktionsspecificationer for de modeller som bærer av denne deklarasjonen:

06 Pressione massima consentita (PS): <P> (bar)

Temperatura minima massima consentita (TS):

Tmin: Temperatura minima nel lato di bassa pressione: <L> (°C)

Tmax: Saturata temperatura sul lato di massima pressione

Refrigerante: <R>

Impostazione dei dispositivi di controllo della pressione: <P> (bar)

Numero di serie e anno di produzione: fare riferimento alla targhetta del modello

Minimale tilatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tilatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

CE - IZJAVA O SKLADENOSTI
CE - VASTANUSKELARATISIOON
CE - DEKLARACIJA ZGODNOSTI
CE - DECLARAȚIE DE CONFORMITATE

15 continuation of the previous page:
16 jatka edellisellä sivulla:
17 pokračování z předchozí strany:
18 fortløstelse fra tidligere side:

13 Specificații de proiectare ale modelelor la care se referă această declarație:

14 Specificaciones de diseño de los modelos a los cuales se refiere esta declaración:

15 Ontwerpspecificaties van de modellen waarop deze verklaring betrekking heeft:

16 Especificaciones de diseño de los modelos a los cuales se refiere esta declaración:

17 Specifiche di progetto dei modelli cui fa riferimento la presente dichiarazione:

06 Pressione massima consentita (PS): <P> (bar)

Temperatura minima massima consentita (TS):

Tmin: Temperatura minima nel lato di bassa pressione: <L> (°C)

Tmax: Saturata temperatura sul lato di massima pressione

Refrigerante: <R>

Impostazione dei dispositivi di controllo della pressione: <P> (bar)

Numero di serie e anno di produzione: fare riferimento alla targhetta del modello

Minimale tilatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tilatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

Produktionsnummer og produktionsår: se modellens fabriksskilt

Maximal tillatet tryk (PS): <P> (bar)

Minimale maximale tilatet tryk (PS): <P> (bar)

Tmin: Minstemperatur på trykssiden: <L> (°C)

Tmax: Maksimaltemperatur som motsvarar maximalt tillatet tryk (PS): <P> (°C)

Kølemiddel: <R>

Indstilling af trykssikringsudrust: <P> (bar)

CE - ATTIKTESDEKLARACIJA
CE - ATTIKTESDEKLARACIJA
CE - ATTIKTESDEKLARACIJA
CE - ATTIKTESDEKLARACIJA

19 continuation of the previous page:
20 jatka edellisellä sivulla:
21 pokračování z předchozí strany:
22 fortløstelse fra tidligere side:

20 Deklaratsiooni alla kuuluvate mudelite disainispetsifikatsioonid:

21 Specificaciones de diseño de los modelos a los cuales se refiere esta declaración:

22 Ontwerpspecificaties van de modellen waarop deze verklaring betrekking heeft:

23 Especificaciones de diseño de los modelos a los cuales se refiere esta declaración:

24 Specifiche di progetto dei modelli cui fa riferimento la presente dichiarazione:

24 Maximum allowable pressure (PS): <P> (bar)

Maximum maximum allowable pressure (TS):

Tmin: Minimum temperature at low pressure side <L> (°C)

Tmax: Saturated temperature corresponding with the maximum allowable pressure (PS): <P> (°C)

Refrigerant: <R>

Setting of pressure safety device: <P> (bar)

Manufacturing number and manufacturing year: refer to model nameplate

Minimale zulassige Druck (PS): <P> (bar)

Minimale maximale zulässige Temperatur (TS):

Tmin: Mindesttemperatur auf der Niederdruckseite <L> (°C)

Tmax: Sättigungstemperatur auf der dem maximal zulässigen Druck (PS) entspricht: <P> (°C)

Kältemittel: <R>

Einstellung der Druck-Schutzvorrichtung: <P> (bar)

Herstellungsnr. und Herstellungsjahr: siehe Typenschild des Modells

Pressure maxima admissible (PS): <P> (bar)

Température minimum admissible (TS):

Tmin: Température minimum admissible (TS):

Tmax: Température saturée correspondant à la pression maximale admissible (PS): <P> (°C)

Refrigerant: <R>

Installation of safety device: <P> (bar)

Production number and production year: refer to the nameplate of the model

Minimale toelaten druk (PS): <P> (bar)

Tmin: Minimale toelaten druk (PS): <P> (bar)

Tmax: Verzekigde temperatuur die overeenkomstig met de maximale toelaten druk (PS): <P> (°C)

Koelmiddel: <R>

Instelling van drukschutvoorz. <P> (bar)

Fabricagejaar en fabricagejaar: zie naamplaat model

Pressure maxima admissible (PS): <P> (bar)

Temperatura minima admissible (TS):

Tmin: Temperatura minima en el lado de baja presión <L> (°C)

Tmax: Temperatura saturada correspondiente a la presión máxima admisible (PS): <P> (°C)

Refrigerante: <R>

Ajuste del dispositivo de seguridad: <P> (bar)

Número de fabricación y año de fabricación: consulte la placa de especificaciones técnicas de modelo

CE - IZJAVA O SKLADENOSTI
CE - VASTANUSKELARATISIOON
CE - DEKLARACIJA ZGODNOSTI
CE - DECLARAȚIE DE CONFORMITATE

19 continuation of the previous page:
20 jatka edellisellä sivulla:
21 pokračování z předchozí strany:
22 fortløstelse fra tidligere side:

20 Deklaratsiooni alla kuuluvate mudelite disainispetsifikatsioonid:

21 Specificaciones de diseño de los modelos a los cuales se refiere esta declaración:

22 Ontwerpspecificaties van de modellen waarop deze verklaring betrekking heeft:

Table of contents

1	About the documentation	5
1.1	About this document.....	5
2	Specific installer safety instructions	6
3	About the box	7
3.1	Outdoor unit.....	7
3.1.1	To remove the accessories from the outdoor unit.....	7
4	Unit installation	7
4.1	Preparing the installation site	7
4.1.1	Installation site requirements of the outdoor unit	7
4.1.2	Additional installation site requirements of the outdoor unit in cold climates	8
4.2	Mounting the outdoor unit.....	8
4.2.1	To provide the installation structure	8
4.2.2	To install the outdoor unit.....	9
4.2.3	To provide drainage	9
5	Piping installation	9
5.1	Preparing refrigerant piping	9
5.1.1	Refrigerant piping requirements.....	9
5.1.2	Refrigerant piping insulation	9
5.1.3	Refrigerant piping length and height difference	10
5.2	Connecting the refrigerant piping	10
5.2.1	Connections between outdoor and indoor unit using reducers	10
5.2.2	To connect the refrigerant piping to the outdoor unit ..	10
5.3	Checking the refrigerant piping	11
5.3.1	To check for leaks.....	11
5.3.2	To perform vacuum drying	11
6	Charging refrigerant	11
6.1	About the refrigerant.....	11
6.2	To determine the additional refrigerant amount	12
6.3	To determine the complete recharge amount	12
6.4	To charge additional refrigerant	12
6.5	To fix the fluorinated greenhouse gases label.....	12
7	Electrical installation	12
7.1	Specifications of standard wiring components	13
7.2	To connect the electrical wiring to the outdoor unit	13
8	Finishing the outdoor unit installation	14
8.1	To finish the outdoor unit installation.....	14
9	Configuration	14
9.1	About ECONO mode prohibition setting.....	14
9.1.1	To turn ON ECONO mode prohibition setting.....	14
9.2	About night quiet mode	14
9.2.1	To turn ON the night quiet mode.....	14
9.3	About heat mode lock.....	14
9.3.1	To turn ON heat mode lock.....	15
9.4	About standby electricity saving function	15
9.4.1	To turn ON standby electricity saving function.....	15
10	Commissioning	15
10.1	Checklist before commissioning	15
10.2	Checklist during commissioning	16
10.3	Trial operation and testing	16
10.3.1	To perform a test run	16
11	Maintenance and service	16
12	Disposal	16
13	Technical data	16
13.1	Wiring diagram	16
13.1.1	Unified wiring diagram legend.....	16

13.2	Piping diagram: Outdoor unit.....	17
------	-----------------------------------	----

1 About the documentation

1.1 About this document



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

Target audience

Authorised installers



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from Daikin and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.



INFORMATION

This document only describes installation instructions specific to the outdoor unit. For installation of the indoor unit (mounting the indoor unit, connecting the refrigerant piping to the indoor unit, connecting the electrical wiring to the indoor unit ...), see the installation manual of the indoor unit.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you **MUST** read before installing
 - Format: Paper (in the box of the outdoor unit)
- **Outdoor unit installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the outdoor unit)
- **Installer reference guide:**
 - Preparation of the installation, reference data,...
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

2 Specific installer safety instructions

2 Specific installer safety instructions

Always observe the following safety instructions and regulations.

Unit installation (see "[4 Unit installation](#)" ▶ 7))



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.

Installation site (see "[4.1 Preparing the installation site](#)" ▶ 7))



CAUTION

- Check if the installation location can support the unit's weight. Poor installation is hazardous. It can also cause vibrations or unusual operating noise.
- Provide sufficient service space.
- Do NOT install the unit so that it is in contact with a ceiling or a wall, as this may cause vibrations.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.

Piping installation (see "[5 Piping installation](#)" ▶ 9))



CAUTION

Piping and joints of a split system shall be made with permanent joints when inside an occupied space except joints directly connecting the piping to the indoor units.



CAUTION

- No brazing or welding on site for units with R32 refrigerant charge during shipment.
- During installation of the refrigeration system, joining of parts with at least one part charged shall be performed taking into account the following requirements: inside occupied spaces non-permanent joints are NOT allowed for R32 refrigerant except for site made joints directly connecting the indoor unit to piping. Site made joints directly connecting piping to indoor units shall be of non-permanent type.



CAUTION

Do NOT connect the embedded branch piping and the outdoor unit when only carrying out piping work without connecting the indoor unit in order to add another indoor unit later.



WARNING

Connect the refrigerant piping securely before running the compressor. If the refrigerant piping is NOT connected and the stop valve is open when the compressor is run, air will be sucked in. This will cause abnormal pressure in the refrigeration cycle, which may result in equipment damage and even injury.



CAUTION

Do NOT open the valves before flaring is complete. This would cause refrigerant gas leakage.



DANGER: RISK OF EXPLOSION

Do NOT start the unit if it is vacuumed.

Charging refrigerant (see "[6 Charging refrigerant](#)" ▶ 11))



WARNING

- The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.
- Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.



WARNING

- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.



WARNING

NEVER directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.

Electrical installation (see "[7 Electrical installation](#)" ▶ 12))



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.



WARNING

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



WARNING

Do NOT connect the power supply to the indoor unit. This could result in electrical shock or fire.



WARNING

- Do NOT use locally purchased electrical parts inside the product.
- Do NOT branch the power supply for the drain pump, etc. from the terminal block. This could result in electrical shock or fire.



WARNING

Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.



DANGER: RISK OF ELECTROCUTION

All electrical parts (including thermistors) are powered by the power supply. Do NOT touch them with bare hands.



DANGER: RISK OF ELECTROCUTION

Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage MUST be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.

Finishing the outdoor unit installation (see "8 Finishing the outdoor unit installation" [p 14])



DANGER: RISK OF ELECTROCUTION

- Make sure that the system is earthed properly.
- Turn OFF the power supply before servicing.
- Install the switch box cover before turning ON the power supply.

Commissioning (see "10 Commissioning" [p 15])



CAUTION

Do NOT perform the test operation while working on the indoor units.

When performing the test operation, NOT ONLY the outdoor unit, but the connected indoor unit will operate as well. Working on an indoor unit while performing a test operation is dangerous.



CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. Do NOT remove the fan guard. When the fan is rotating at high speed, it will cause injury.

Maintenance and service (see "11 Maintenance and service" [p 16])



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING



WARNING

- Before carrying out any maintenance or repair activity, ALWAYS switch off the circuit breaker on the supply panel, remove the fuses or open the protection devices of the unit.
- Do NOT touch live parts for 10 minutes after the power supply is turned off because of high voltage risk.
- Please note that some sections of the electric component box are hot.
- Make sure you do NOT touch a conductive section.
- Do NOT rinse the unit. This may cause electric shocks or fire.



DANGER: RISK OF ELECTROCUTION

- Use this compressor on a grounded system only.
- Turn the power off before servicing the compressor.
- Reattach the switch box cover and service lid after servicing.



CAUTION

ALWAYS wear safety glasses and protective gloves.



DANGER: RISK OF EXPLOSION

- Use a pipe cutter to remove the compressor.
- Do NOT use the brazing torch.
- Use approved refrigerants and lubricants only.



DANGER: RISK OF BURNING/SCALDING


Do NOT touch the compressor with bare hands.

3 About the box

3.1 Outdoor unit

3.1.1 To remove the accessories from the outdoor unit

- Lift the outdoor unit.
- Remove the accessories at the bottom of the package.



- a Outdoor unit installation manual
- b General safety precautions
- c Fluorinated greenhouse gases label
- d Multilingual fluorinated greenhouse gases label
- e Drain socket
- f Screw bag (for fixing wire retainer)
- g Reducer assembly
- h Energy label

4 Unit installation



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.

4.1 Preparing the installation site





WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.

4.1.1 Installation site requirements of the outdoor unit


Mind the following spacing guidelines:

- Wall facing 1 side:




- Wall facing 2 sides:

4 Unit installation




- Wall facing 3 sides:



- a Air outlet
- b Air inlet

Allow 300 mm of work space below the ceiling surface and 250 mm for piping and electrical servicing.



- a Baffle plate
- b Prevailing wind direction
- c Air outlet

Do NOT install the unit in sound sensitive areas (e.g. near a bedroom), so that the operation noise will cause no trouble.

Note: If the sound is measured under actual installation conditions, the measured value might be higher than the sound pressure level mentioned in "Sound spectrum" in the data book due to environmental noise and sound reflections.



INFORMATION


The sound pressure level is less than 70 dBA.

The outdoor unit is designed for outdoor installation only, and for ambient temperatures within the following ranges (unless otherwise specified in the operation manual of the connected indoor unit):

Cooling mode	Heating mode
-10~46°C DB	-15~24°C DB

4.1.2 Additional installation site requirements of the outdoor unit in cold climates

Protect the outdoor unit against direct snowfall and take care that the outdoor unit is NEVER snowed up.



- a Snow cover or shed
- b Pedestal
- c Prevailing wind direction
- d Air outlet

It is recommended to provide at least 150 mm of free space below the unit (300 mm for heavy snowfall areas). Additionally, make sure the unit is positioned at least 100 mm above the maximum expected level of snow. If necessary, construct a pedestal. See "4.2 Mounting the outdoor unit" [p. 8] for more details.

In heavy snowfall areas it is very important to select an installation site where the snow will NOT affect the unit. If lateral snowfall is possible, make sure that the heat exchanger coil is NOT affected by the snow. If necessary, install a snow cover or shed and a pedestal.


4.2 Mounting the outdoor unit


4.2.1 To provide the installation structure

Use a vibration-proof rubber (field supply) in cases where vibrations may be transmitted to the building.

The unit may be installed directly on a concrete veranda or another solid surface as long as it provides proper drainage.


Prepare 4 sets of M8 or M10 anchor bolts, nuts and washers (field supply).





a 100 mm above expected level of snow

4.2.2 To install the outdoor unit



4.2.3 To provide drainage



NOTICE

If the unit is installed in a cold climate, take adequate measures so that the evacuated condensate CANNOT freeze.



NOTICE


If the drain holes of the outdoor unit are blocked up by a mounting base or floor surface, place additional foot bases ≤30 mm under the outdoor unit's feet.



INFORMATION

For information on the available options, contact your dealer.

- 1 Use a drain plug for drainage.
- 2 Use a Ø16 mm hose (field supply).



- a Drain port
- b Bottom frame
- c Drain plug
- d Hose (field supply)

5 Piping installation

5.1 Preparing refrigerant piping

5.1.1 Refrigerant piping requirements



CAUTION

Piping and joints of a split system shall be made with permanent joints when inside an occupied space except joints directly connecting the piping to the indoor units.



NOTICE

The piping and other pressure-containing parts shall be suitable for refrigerant. Use phosphoric acid deoxidised seamless copper for refrigerant.

- Foreign materials inside pipes (including oils for fabrication) must be ≤30 mg/10 m.

Refrigerant piping diameter

Class 40	
Liquid piping	2× Ø6.4 mm (1/4")
Gas piping	2× Ø9.5 mm (3/8")
Class 50	
Liquid piping	2× Ø6.4 mm (1/4")
Gas piping	1× Ø9.5 mm (3/8") 1× Ø12.7 mm (1/2")



INFORMATION

Usage of reducers might be required based on the indoor unit. See "5.2.1 Connections between outdoor and indoor unit using reducers" [p 10] for more information.

Refrigerant piping material

- Piping material:** Phosphoric acid deoxidised seamless copper.
- Flare connections:** Only use annealed material.
- Piping temper grade and thickness:**

Outer diameter (Ø)	Temper grade	Thickness (t) ^(a)	
6.4 mm (1/4")	Annealed (O)	≥0.8 mm	
9.5 mm (3/8")			
12.7 mm (1/2")			

^(a) Depending on the applicable legislation and the maximum working pressure of the unit (see "PS High" on the unit name plate), larger piping thickness might be required.


5.1.2 Refrigerant piping insulation

- Use polyethylene foam as insulation material:
 - with a heat transfer rate between 0.041 and 0.052 W/mK (0.035 and 0.045 kcal/mh°C)
 - with a heat resistance of at least 120°C
- Insulation thickness

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
6.4 mm (1/4")	8~10 mm	≥10 mm

5 Piping installation

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
9.5 mm (3/8")	12~15 mm	≥13 mm
12.7 mm (1/2")	14~16 mm	≥13 mm



If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

Use separate thermal insulation pipes for the gas and liquid refrigerant piping.

5.1.3 Refrigerant piping length and height difference

The shorter the refrigerant piping, the better the performance of the system.

The piping length and height differences must comply with the following requirements.

Shortest allowable length per room is 3 m.

Refrigerant piping length to each indoor unit	≤20 m
Refrigerant piping total length	≤30 m

	Height difference outdoor-indoor	Height difference indoor-indoor
Outdoor unit installed higher than indoor unit	≤15 m	≤7.5 m
Outdoor unit installed lower than at least 1 indoor unit	≤7.5 m	≤15 m

5.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING/SCALDING



CAUTION

- No brazing or welding on site for units with R32 refrigerant charge during shipment.
- During installation of the refrigeration system, joining of parts with at least one part charged shall be performed taking into account the following requirements: inside occupied spaces non-permanent joints are NOT allowed for R32 refrigerant except for site made joints directly connecting the indoor unit to piping. Site made joints directly connecting piping to indoor units shall be of non-permanent type.



CAUTION

Do NOT connect the embedded branch piping and the outdoor unit when only carrying out piping work without connecting the indoor unit in order to add another indoor unit later.

5.2.1 Connections between outdoor and indoor unit using reducers

Total indoor unit capacity class that can be connected to this outdoor unit:

Outdoor unit	Total indoor unit capacity class
2MXM40	≤6.0 kW
2MXM50	≤8.5 kW


Port	Class	Reducer
2MXM40		
A	15, 20, 25, 35	—
B	15, 20, 25, 35	—
2MXM50		
A	15, 20, 25, 35, 42 ^(a)	—
B	15, 20, 25, 35	1+2
	42, 50	—

^(a) Use optional accessory.

Reducer type	Connection
1	 Ø12.7 mm → Ø9.5 mm
2	 Ø12.7 mm → Ø9.5 mm

Connection example:

- Connecting a Ø9.5 mm pipe to a Ø12.7 mm gas pipe connection port



Coat the threaded connection port of the outdoor unit where the flare nut comes in with refrigeration oil.

Flare nut for (mm)	Tightening torque (N·m)
Ø12.7	50~60



NOTICE

Use an appropriate wrench to avoid damaging the connection thread by overtightening the flare nut. Be careful NOT to overtighten the nut, or the smaller pipe may be damaged (about 2/3-1× the normal torque).

5.2.2 To connect the refrigerant piping to the outdoor unit


- Piping length.** Keep field piping as short as possible.
- Piping protection.** Protect the field piping against physical damage.



WARNING

Connect the refrigerant piping securely before running the compressor. If the refrigerant piping is NOT connected and the stop valve is open when the compressor is run, air will be sucked in. This will cause abnormal pressure in the refrigeration cycle, which may result in equipment damage and even injury.

- 1 Connect the liquid refrigerant connection from the indoor unit to the liquid stop valve of the outdoor unit.



- a Liquid stop valve
- b Gas stop valve
- c Service port

- 2 Connect the gas refrigerant connection from the indoor unit to the gas stop valve of the outdoor unit.



NOTICE

It is recommended that the refrigerant piping between indoor and outdoor unit is installed in a ducting or the refrigerant piping is wrapped with finishing tape.



NOTICE

Connect the vacuum pump to **both** the service ports of the gas stop valves.

- 1 Vacuum the system until the pressure on the manifold indicates -0.1 MPa (-1 bar).
- 2 Leave as is for 4-5 minutes and check the pressure:

If the pressure...	Then...
Does not change	There is no moisture in the system. This procedure is finished.
Increases	There is moisture in the system. Go to the next step.

- 3 Vacuum the system for at least 2 hours to a manifold pressure of -0.1 MPa (-1 bar).
- 4 After turning the pump OFF, check the pressure for at least 1 hour.
- 5 If you do NOT reach the target vacuum or CANNOT maintain the vacuum for 1 hour, do the following:
 - Check for leaks again.
 - Perform vacuum drying again.



NOTICE

Make sure to open the stop valves after installing the refrigerant piping and performing vacuum drying. Running the system with the stop valves closed may break the compressor.

5.3 Checking the refrigerant piping

5.3.1 To check for leaks



NOTICE

Do NOT exceed the unit's maximum working pressure (see "PS High" on the unit name plate).



NOTICE

ALWAYS use a recommended bubble test solution from your wholesaler.

NEVER use soap water:

- Soap water may cause cracking of components, such as flare nuts or stop valve caps.
- Soap water may contain salt, which absorbs moisture that will freeze when the piping gets cold.
- Soap water contains ammonia which may lead to corrosion of flared joints (between the brass flare nut and the copper flare).

- 1 Charge the system with nitrogen gas up to a gauge pressure of at least 200 kPa (2 bar). It is recommended to pressurize to 3000 kPa (30 bar) in order to detect small leaks.
- 2 Check for leaks by applying the bubble test solution to all connections.
- 3 Discharge all nitrogen gas.

5.3.2 To perform vacuum drying



DANGER: RISK OF EXPLOSION

Do NOT start the unit if it is vacuumed.

6 Charging refrigerant

6.1 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Please contact your installer for more information.



WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (e.g. open flames, an operating gas appliance, or an operating electric heater). The room size shall be as specified in the General safety precaution.

7 Electrical installation



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

- The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.
- Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.



WARNING

NEVER directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.

6.2 To determine the additional refrigerant amount

If the total liquid piping length is...	Then...
≤20 m	Do NOT add additional refrigerant.
>20 m	$R = (\text{total length (m) of liquid piping} - 20 \text{ m}) \times 0.020$ $R = \text{Additional charge (kg) (rounded in units of 0.1 kg)}$



INFORMATION

Piping length is the one-way length of liquid piping.

6.3 To determine the complete recharge amount



INFORMATION

If a complete recharge is necessary, the total refrigerant charge is: the factory refrigerant charge (see unit name plate) + the determined additional amount.

6.4 To charge additional refrigerant



WARNING


- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.

Prerequisite: Before charging refrigerant, make sure the refrigerant piping is connected and checked (leak test and vacuum drying).

- Connect the refrigerant cylinder to the service port.
- Charge the additional refrigerant amount.
- Open the gas stop valve.

6.5 To fix the fluorinated greenhouse gases label

- Fill in the label as follows:



- If a multilingual fluorinated greenhouse gases label is delivered with the unit (see accessories), peel off the applicable language and stick it on top of a.
- Factory refrigerant charge: see unit name plate
- Additional refrigerant amount charged
- Total refrigerant charge
- Quantity of fluorinated greenhouse gases** of the total refrigerant charge expressed as tonnes CO₂ equivalent.
- GWP = Global warming potential



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Use the GWP value mentioned on the refrigerant charge label.

- Fix the label on the inside of the outdoor unit near the gas and liquid stop valves.

7 Electrical installation



DANGER: RISK OF ELECTROCUTION



WARNING

- All wiring **MUST** be performed by an authorised electrician and **MUST** comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction **MUST** comply with the applicable legislation.



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.



WARNING

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



WARNING

Do NOT connect the power supply to the indoor unit. This could result in electrical shock or fire.


WARNING

- Do NOT use locally purchased electrical parts inside the product.
- Do NOT branch the power supply for the drain pump, etc. from the terminal block. This could result in electrical shock or fire.


WARNING


Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.


DANGER: RISK OF ELECTROCUTION

All electrical parts (including thermistors) are powered by the power supply. Do NOT touch them with bare hands.


DANGER: RISK OF ELECTROCUTION

Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage MUST be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.



- a DB1 diode bridge
- b S90 thermistor lead wire
- c LED A
- d S40 thermal overload relay lead wire
- e S20 (white) room A electronic expansion valve coil
- f S21 (red) room B electronic expansion valve coil
- g S80 (white) 4-way valve lead wire connector
- h S70 fan motor lead wire
- i S99 heating lock
- j S91 (red) liquid thermistor lead wire
- k S92 (white) gas thermistor lead wire
- l Multimeter (DC voltage range)

7.1 Specifications of standard wiring components

Component		
Power supply cable	Voltage	220~240 V
	Phase	1~
	Frequency	50 Hz
	Wire type	3-core cable 2.5 mm ² H05RN-F (60245 IEC 57) H07RN-F (60245 IEC 66)
Interconnection cable (indoor↔outdoor)	3-core cable 4.0 mm ² H07RN-F (60245 IEC 66)	
	4-core cable 1.5 mm ² or 2.5 mm ² and applicable for 220~240 V H05RN-F (60245 IEC 57)	
Recommended circuit breaker	16 A	


Component

Residual current device


MUST comply with applicable legislation

7.2 To connect the electrical wiring to the outdoor unit

- Remove the switch box cover (2 screws).




- Connect the wires between the indoor and outdoor units so that the terminal numbers match. Make sure to match the symbols for piping and wiring.
- Make sure to connect correct wiring to correct room (A to A, B to B).



- a Terminal for room (A, B)
- b Circuit breaker
- c Residual current device
- d Power supply wire
- e Interconnection wire for room (A, B)
- f Wire retainer

- Tighten the terminal screws securely using a Phillips screwdriver.
- Check that the wires do not disconnect by pulling them lightly.
- Firmly secure the wire retainer to avoid external stress on wire terminations.
- Pass the wiring through the cutout on the bottom of the protection plate.
- Make sure the electrical wiring does not contact with the gas piping.



8 Finishing the outdoor unit installation

- 9 Reattach the switch box cover and the service cover.

8 Finishing the outdoor unit installation


8.1 To finish the outdoor unit installation




DANGER: RISK OF ELECTROCUTION

- Make sure that the system is earthed properly.
- Turn OFF the power supply before servicing.
- Install the switch box cover before turning ON the power supply.

- 1 Insulate and fix the refrigerant piping and cables as follows:



- 2 Install the service cover.



- 4 Reinstall the electric box cover and the top plate in reverse order and turn on the main power supply.

9 Configuration

9.1 About ECONO mode prohibition setting

This setting disables the input control signal from the user interface. Use this setting when you wish to block reception of input controls (cooling/heating) from indoor unit user interfaces.

9.1.1 To turn ON ECONO mode prohibition setting

Prerequisite: The main power supply MUST be turned off.

- 1 Remove the top plate of the outdoor unit (2 screws on sides)
- 2 Remove the electric box cover by sliding it. Be careful not to bend the electric box hook.
- 3 Cut the jumper (J23).


9.2 About night quiet mode

The night quiet mode function makes the outdoor unit run more quietly at nighttime. This will reduce the cooling capacity of the unit. Explain Night quiet mode to the customer and confirm if customer wants to use this mode.

9.2.1 To turn ON the night quiet mode

Prerequisite: The main power supply MUST be turned off.

- 1 Remove the top plate and the electric box cover of the outdoor unit (see "9.1.1 To turn ON ECONO mode prohibition setting" ▶ 14)
- 2 Cut the jumper J6.



- 3 Reinstall the top plate and the electric box cover.



CAUTION


When reinstalling the electric box cover, be careful not to pinch the fan motor lead wire.

9.3 About heat mode lock

Heat mode lock limits the unit to heat operation.

9.3.1 To turn ON heat mode lock

- 1 Remove the top plate (2 screws) and the front plate (8 screws).
- 2 To set heat mode lock remove the S99 connector.
- 3 To reset the heat pump mode (cooling/heating), plug the connector back.



- a Front plate
b Top plate
c S99 connector

Mode	S99 connector
Heat pump (cooling, heating)	Connected
Heating only	Disconnected

- 4 Reinstall the top plate and the front plate.



INFORMATION

Forced operation is also available in heating mode.

9.4 About standby electricity saving function

The standby electricity saving function:

- turns OFF the power supply to the outdoor unit and,
- turns ON the standby electricity saving mode on the indoor unit.

The standby electricity saving function works with following units:

FTXM, FTXP, FTXJ, FVXM, ATXF


If another indoor unit is used, the connector for standby electric saving **MUST** be plugged in.

The standby electricity saving function is turned OFF before shipping.

9.4.1 To turn ON standby electricity saving function

Prerequisite: The main power supply **MUST** be turned OFF.

- 1 Remove the service cover.
- 2 Disconnect the selective standby electricity saving connector.



- 3 Turn ON the main power supply.

10 Commissioning



NOTICE

General commissioning checklist. Next to the commissioning instructions in this chapter, a general commissioning checklist is also available on the Daikin Business Portal (authentication required).

The general commissioning checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during the commissioning and hand-over to the user.



NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If **NOT**, burning of the compressor might be the result.

10.1 Checklist before commissioning

- 1 After the installation of the unit, check the items listed below.
- 2 Close the unit.
- 3 Power up the unit.

<input type="checkbox"/>	The indoor unit is properly mounted.
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	The refrigerant pipes (gas and liquid) are thermally insulated.
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.
<input type="checkbox"/>	Drainage Make sure drainage flows smoothly. Possible consequence: Condensate water might drip.
<input type="checkbox"/>	The indoor unit receives the signals of the user interface .
<input type="checkbox"/>	The specified wires are used for the interconnection cable .

11 Maintenance and service

<input type="checkbox"/>	The fuses, circuit breakers , or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	Check if marks (room A and B) on the wiring and piping match for each indoor unit.
<input type="checkbox"/>	Check if the priority room setting is set for 2 or more rooms. Keep in mind that the DHW generator for Multi or the Hybrid for Multi shall not be selected as the priority room.

10.2 Checklist during commissioning

<input type="checkbox"/>	To perform a wiring check .
<input type="checkbox"/>	To perform an air purge .
<input type="checkbox"/>	To perform a test run .

10.3 Trial operation and testing

<input type="checkbox"/>	Before starting the test run, measure the voltage at the primary side of the safety breaker .
<input type="checkbox"/>	The piping and wiring work match.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.

Initialization of the Multi system can take several minutes depending on the number of indoor units and options used.

10.3.1 To perform a test run



INFORMATION

If the unit runs into an error during commissioning, see the service manual for the detailed troubleshooting guidelines.

Prerequisite: Power supply MUST be in the specified range.

Prerequisite: Test run operation may be done in cooling or heating mode.

Prerequisite: Test run should be done in accordance with the operation manual of the indoor unit to make sure that all functions and parts are working properly.

- 1 In cooling mode, select the lowest programmable temperature. In heating mode, select the highest programmable temperature.
- 2 Measure the temperature at the indoor unit inlet and outlet after running the unit for about 20 minutes. The difference should be more than 8°C (cooling) or 15°C (heating).
- 3 First check operation of each unit individually, then check simultaneous operation of all indoor units. Check both heating and cooling operation.
- 4 When test run is finished, set the temperature to a normal level. In cooling mode: 26~28°C, in heating mode: 20~24°C.



INFORMATION

- Test run can be disabled if necessary.
- After the unit is turned OFF, it cannot be started again for 3 minutes.
- During cooling operation, frost may form on the gas stop valve or other parts. This is normal.



INFORMATION

- Even if the unit is turned OFF, it consumes electricity.
- When the power turns back on after a power break, the previously selected mode will be resumed.

11 Maintenance and service



NOTICE

General maintenance/inspection checklist. Next to the maintenance instructions in this chapter, a general maintenance/inspection checklist is also available on the Daikin Business Portal (authentication required).

The general maintenance/inspection checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during maintenance.



NOTICE

Maintenance MUST be done by an authorised installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

12 Disposal



NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.



INFORMATION

To protect the environment, make sure to perform an automatic pump down operation when relocating or dismantling the unit. For the pump down procedure, refer to the service manual or the installer reference guide.

13 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

13.1 Wiring diagram

The wiring diagram is delivered with the unit, located inside of the outdoor unit (bottom side of the top plate).

13.1.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.

Symbol	Meaning	Symbol	Meaning
	Circuit breaker		Protective earth
	Connection		Protective earth (screw)
	Connector		Rectifier
	Earth		Relay connector
	Field wiring		Short-circuit connector
	Fuse		Terminal
	Indoor unit		Terminal strip
	Outdoor unit		Wire clamp
	Residual current device		

Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
SKY BLU	Sky blue	YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*O	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*, NE	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor

Symbol	Meaning
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*C	Circuit breaker
Q*DI, KLM	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
Q*R	Residual current device
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NG	Refrigerant leak detector
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor
V*R	Diode bridge, Insulated-gate bipolar transistor (IGBT) power module
WRC	Wireless remote controller
X*	Terminal
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter


13.2 Piping diagram: Outdoor unit

Component PED category classification:

- High pressure switches: category IV
- Compressor: category II
- Other components: refer to PED article 4, paragraph 3



13 Technical data

2MXM50



- A Room A
- B Room B
- a 4-way valve ON: heating
- b High pressure switch with automatic reset
- c Muffler
- d Discharge pipe thermistor
- e Compressor
- f Accumulator
- g Branch pipe
- h Thermistor (gas)
- i Gas stop valve
- j Field piping (gas)

- k Field piping (liquid)
- l Liquid stop valve
- m Thermistor (liquid)
- n Filter
- o Motor-operated valve
- p Muffler
- q Outdoor air temperature thermistor
- r Heat exchanger
- M Fan motor
- Refrigerant flow: cooling
- - - Refrigerant flow: heating





DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium