



A circular inset showing a hand holding a credit card, symbolizing financial transactions or credit.

Operating System

Features



§ Commercial Tools

- Microsoft Visual Studio v6.0
- ARM Compiler

§ Native Code

- Applications run faster as compared to interpreted code
- Object code requires more space

§ Large Applications

- May extend well-beyond the 64K limit
- R-modules no longer needed

§ Shared Libraries

- Build libraries that can be shared between applications
- Reduces library duplication amongst applications
- Changes to a library requires recompile & download

Features



§ Dynamic Memory Allocation

§ Downloadable OS

§ Flash File System

- Application / Shared Libraries / Static Files
- Append vs. Overwrite
- Occasionally may want to defrag or coalesce

§ Events

- No interrupts, traps/guards

Features



§ Console Interface

- Keyboard
- Display

§ Device Ownership

- Only one task can own a device at any time
- Can pass console ownership across tasks

§ Extension Areas

- Declare maximum file size (in bytes)
- Eliminates writing blank records and then overwriting

Features



§ Multiple Applications

§ Waterproofing

- Segregate applications into partitions
- Firmware and software partitioning via the MMU
- Eliminates the re-certification process

System Mode



- § A system application that comes with the OS
- § Responsible for administrative tasks, such as:
 - Starting the initial application
 - Receiving downloads
 - Setting config.sys variables
 - Setting the clock
 - Setting display contrast
 - Starting the debug monitor
 - Device diagnostics
 - Clearing memory
- § Enter System Mode by:
 - Pressing [F2]/[F4]
 - Entering a password (1Z66831 or 1)

Check the OS version



Vx510

Firmware/
OS version

VERI FONE 05150
Q50014A0
09/22/2001 VERI X V

COPYRI GHT 1997- 2001
VERI FONE
ALL RI GHTS RESERVED

F₁

F₂

F₃

F₄

ALPHA

System Mode Menus



§ SYS MODE MENU 1

CONTRAST

CLOCK

RESTART

§ SYS MODE MENU 2

DOWNLOAD

RAM FILES

FLASH FILES

§ SYS MODE MENU 3

SYSTEM INFO

EDIT

PASSWORDS

System Mode Menus



§ SYS MODE MENU 4

- REMOTE DIAGS
- ERROR LOG
- DEBUGGER

§ SYS MODE MENU 5

- SCREEN DIAG
- KEYBOARD DIAG
- MAG CARD DIAG

§ SYS MODE MENU 6

- IPP DIAG
- IPP KEY LOAD
- PRINTER DIAG

System Mode Menus



§ SYS MODE MENU 7

RAM DIRECTORY

FLASH DIRECTORY

§ SYS MODE MENU 8

ICC DIAGS

System Mode Menu - Navigation



- § Use ↑ [purple 1] and ↓ [purple 2] to scroll through menus
- § To select a menu option, press the [Fx] key associated with the menu item
- § Generally, press [X] or CANCEL to exit a menu item or Menu and return to the Menu or Previous Menu
- § Press RESTART [F4] from SYS MODE MENU 1 to run the application or exit from System Mode

File Groups



§ Logical partitions of memory

§ There are 16 groups (0-15)


- GID 0 Operating System only
- GID 1 Supervisory Application / Sponsor Application (VMAC)
 - » Can open files in GID 1-15
- GID 2-14 Can open file in their group
 - » Can open files in GID 15
- GID 15 Common Area
 - » Shared common data space
 - » Limited to GID 15

§ Groups span both Flash & RAM

File Groups



Across Ram & Flash
No fixed size per group
Limited by memory available
in the terminal



File Authentication and Compression



§ File Authentication

- Verify or prove the authenticity of a file before it can be executed in the terminal
- Uses VeriShield to generate an application signature

§ File Compression

- For download files
- Can be used only with VeriCentre
- Zip files do not get authenticated, however, individual files in the zip file are
- Requires config.sys variable in GID 1
 - e.g. *UNZIP=MYAPP.ZIP

Memory Layouts



Group	Ram (I:)	Flash (F:)
GID0	For system use	For system use
GID1 (main)	Main CONFIG.SYS	
GID2	CONFIG.SYS	
.		
.		
GID14	CONFIG.SYS	
GID15 (shared)	CONFIG.SYS	

System / Group Passwords



Group	Passwords	Where it is?
GID0	N/A	N/A
GID1	Group 1 password	Inside CONFIG.SYS *SMPW ← *PW
GID2	Group 2 password	Inside CONFIG.SYS *PW
.		
GID14	Group 14 password	Inside CONFIG.SYS *PW
GID15	Group 15 password	Inside CONFIG.SYS *PW

**System mode
Password**

System / Group Passwords



When you need to have a password?

- Enter into system menu (need the system mode password)
- Edit the CONFIG.SYS
- Clear the RAM/FLASH
- Download application into the GID
- Change password
- List out the files in a GID

What if the passwords are not known?

- Change the passwords if system password is known
- Download the passwords if *SMDL=1
- Bootloading the OS

Download



Download cable : 26264-01 (RJ45 to DB9)

Download method:

- Direct download using DDL.EXE
- Direct download using VeriCentre
- Modem download (terminal initiated) using VeriCentre
- Modem download (VC initiated, need TMA) using VeriCentre
- Terminal to terminal download

PC Requirement (for the case of using DDL.EXE)

- DOS – capable PC
- A free COM port (be careful when in a Windows environment)

Download – DDL.EXE



DDL - Direct Download (Version 1.2, Build 45)

Usage:

DDL -p port -b baud -t timeout -d file -e file -i file
-c [offset] -x password -f file file... key=value...

Arguments:

file File to download. Equivalent to "-i" file.

key=value Set configuration variable.

Options:

- p port Set host communication port. Default = 1 (COM1).
- b baud Set baud rate. Values: 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200. Default = 19200.
- t time Set communication timeout, in seconds. Default = 1.
- d file Download file as a data file.
- e file Download file as a code file.
- i file Download file as code if it has a .OUT or .LIB extension, otherwise as data.
- c [off] Set terminal clock to host time plus optional offset of -23 to +23 hours.
- x psswd Set terminal password.
- f file Read more arguments from file.

Download - Example



File d.bat:

```
ddl -b115200 -p1 -fdl.lst
```

File dl.lst:

```
-isetgroup.1      // set to GID1
-isetdrive.f      // set to flash
-iapp.out         // download this file into GID1,flash
-isetdrive.I      // set to ram
-iapp.p7s         // download this file into GID1,ram
*PW=1            // set GID1 password to 1
*SMPW=1          // set system mode password to 1
*SMDL=1          // allow download when startup
*GO=f:app.out    // the starting program
*PHONE=102       // other parameters
```

System Menu – Ram/Flash files



For RAM Files:

- Clear Group _X
- Clear all files

**Good practice before you
do any downloading**

For Flash Files

- Clear Group _X
- Clear all files
- Defrag Y

**Can help to defragment the
fragmented memory blocks**

System Menu – EDIT config.sys



Keys

EDIT CONFIG.SYS

Values

*MC = 74
*GO = F:MYAPP.OUT
#HOSTIP=1.2.3.4
*ZT=1
*ZA=EPS010
*ZP=23820224
MYPARAM=234

***GO = start up program**

**Keys start with * or # are system parameters
Other key values are application parameters**

System parameters



Table 23 CONFIG.SYS Environment Variables (continued)

Variable	Description
*FA	When this variable is set to 1, all signature files are retained in terminal memory; default is 1.
*FILE	Maximum number of files that can be open simultaneously. Minimum is 10; maximum is 96; default is 30.
*GO	File Group 1 application filename to execute.
*MC	Modem country code setting.
*PIPE	Controls the number of pipe handles available. Minimum is 0; maximum is 256 (default).
*POW	(Omni 3600 only) Indicates the amount of time (msecs) that Verix waits before attempting to place the unit in sleep mode.
*PW	Group access system mode password; password for the current group.
*SMDL	Enables poll-for-direct download during the start-up sequence before displaying the copyright screen.
*SMPW	System mode entry password.
*TIME	Number of system timers; default 10; used with set_timer () .
*UNZIP	Group 1 CONFIG.SYS file. Automatic decompression of only one archive. If *UNZIP is set, the .ZIP archive automatically decompresses at startup.
*VALID	List of groups searched during file authentication using

Reference : Verix Programmer Manual (VDN:19733)

Download – Change Password



Lab Exercise : Fix a terminal with unknown password.

Create download files to change the

-System password = Z66831

-GID1 password = PASS1

-GID2 password = PASS2


-..

-GID15 password = PASS15

!!! Remember don't set anything on *SMDL !!!

Lab exercise : reset password

Download - Authentication




Download - Authentication




- *.P7S – Signature file (download to RAM initially, after successful check, it will move to FLASH area. If you want to enable terminal to terminal download, these files not should not be deleted. *FA=0)**
- *.OUT – Application file (can be downloaded but it allow execute only after authentication OK. The authentication status can be checked in system menu)**
- *.CRT – Certification file (use default certificate most of the case. If you have VeriShield purchased, you can restrict the application allowed in your terminals)**


Authentication – Default Certification Tree




Authentication – Default Signing Process



Authentication – Sponsor Certification



Authentication – Sponsor File Signing



Download – Terminal to terminal



Need cable 05651-02

Two terminals - one as copy source and the other as copy destination

Source terminal should have the *.P7S file retained. (I.e. *FA cannot be equal to 0)

Steps:

- 1. Enter system mode**
- 2. Press * for sender, press # for receiver**
- 3. Enter password.**
- 4. Download initiated...**
- 5. File authentication**

Lab exercise : Back to Back download

OS reload – By Download



- Required when
 - OS upgrade/downgrade
 - Unexpected corruption of OS

!!!! Warning !!!!

1. Please don't interrupt during downloading/updating
2. Please don't inject the incorrect type of OS

QA00XXX – Vx510/Vx610

Q500XXXX – Omni37xx

Lab exercise : OS download

OS reload – Bootloading



- Required when
 - Unable to access the system menu
 - OS failed to start up correctly
 - Incorrect manufacture program block are programmed
 - Any other unexpected errors / lockup

!!!! Security Warning !!!!

Due to the secure nature of the terminal. Bootloading should be restricted for use by the authorized personnel only. Strict security policy should be used to safeguard the process from being misuse.

LAB Exercise



LAB1:

1. Set system mode download enable
2. Chang system password and all group's password as “1”