


ROPER WHITNEY


ORION CONTROL SYSTEM

Appendix B Creating Angle Compensation Tables



ROPER WHITNEY
OF ROCKFORD, INC.

2833 HUFFMAN BLVD
ROCKFORD, ILLINOIS 61103
815/962-3011
815/962-2227 FAX
Website: www.roperwhitney.com



MAINSR

Angle
Compensation
Tables
Touchbutton

Figure B-1. Orion Control System Mainscreen

TABLE OF CONTENTS

Getting Started	3
Angle Compensation Tables Screen	5
Creating and Angle Compensation Table	7
Entering Angle Compensation Data	9
Deleting an Angle Comensation Table	13

APPENDIX B

ANGLE COMPENSATION TABLES

GETTING STARTED

Angle Compensation Tables take the place of general angle compensation values. Like the general angle compensation values, they are added to the programmed value of the specific bend. They are developed by testing various materials, taking into account width and thickness being bent.

Because so many combinations of size and material exist, it is not possible for Roper Whitney to provide Angle Compensation Tables suitable for use by all customers. Therefore, no Angle Compensation Tables are supplied with the machine; it is left to the owner of the equipment to develop these tables.

When Angle Compensation Tables are created, they are stored on the system hard drive. Any number of tables may be stored, thus enabling the machine owner to develop a complete set of tables specifically designed to support the manufacturing processes he uses.

Angle Compensation Tables may also be deleted from the hard drive when they are no longer needed.

To create or remove an Angle Compensation Table, touch the Angle Compensation Tables Touchbutton on the Orion system Main Screen. This will bring up the Angle Compensation Tables Screen shown in Figure B-2.




Figure B-2. Angle Compensation Tables Screen

**ANGLE
COMPENSATION
TABLES
SCREEN**

The Angle Compensation Screen is shown in Figure B-2. Elements comprising the screen are described below.

**COMPENSATION
TABLE
LISTING
DISPLAY**

The Compensation Table Listing Display lists all the angle compensation tables contained on the system hard drive. Compensation table files are designated by the **.mtr** extension.

**COMPENSATION
TABLE
SELECTION
DISPLAY**

The Compensation Table Selection Display will show the name of a compensation table being prepared, or the name of a compensation table selected for deletion.

SCROLL BARS

The Scroll Bars enable the operator to scroll backward and forward through the list of compensation tables shown in the Compensation Table Listing Display when the number of tables contained on the hard drive is too large to fit entirely in the display.

**COMPENSATION
VALUE
DISPLAYS**

The Compensation Value Displays contain the compensation values entered for the designated angles. The values are effective over a range of +/- 4 degrees from the designated angle, except for the value entered for 10 degrees, which is effective from 1 degree through 14 degrees.

**CREATE
TABLE
TOUCHBUTTON**

The Create Table Touchbutton initiates table creation. See the instructions beginning with Figure B-3.

**SAVE TABLE
TOUCHBUTTON**

The Save Table Touchbutton saves a newly created table. See the instructions beginning with Figure B-5.

**DELETE
TABLE
TOUCHBUTTON**

The Delete Table Touchbutton initiates the deletion of a table. See the instructions beginning with Figure B-6.

**RETURN TO
MAIN SCREEN
TOUCHBUTTON**

The Return To Main Screen Touchbutton returns you to the Main Screen.




Figure B-3. The Alpha-Numeric Pop-Up Keypad

**CREATING AND
ANGLE
COMPENSATION
TABLE**

To create an Angle Compensation Table, press the Create Table Touchbutton on the Angle Compensation Table Screen shown in Figure B-2.

The Alpha/Numeric Pop-Up Keypad, shown in Figure B-3, will appear. This keypad is used to enter a file name for the Angle Compensation Table. The file name must be entered before the table can be created.

**ENTERING THE
TABLE NAME**

As the table name is entered, it appears in the Compensation Table Selection Display. shown in Figure B-2.

Textual data is entered by using the Alpha Touchbuttons. Numbers are entered by using the Numeric Touchbuttons. The Period Touchbutton is used to enter a period in the text. Spaces between words are added by using the Spacebar Touchbutton. Use the Upper/Lower Case Toggle Touchbutton to change from upper to lower case and back again. When this toggle is used, it automatically changes the Alpha-Touchbuttons from one case to the other. As the data is entered, it appears in the Program Title Area of the Program Selection display.

A character or space can be removed by touching the Delete Letter Touchbutton. When this touchbutton is used, it removes one character at a time, starting from the right.

The entry can be cleared completely by touching the Cancel Touchbutton.

When the entry shown is that desired, touch the Enter Touchbutton on the Alpha/Numeric Pop-Up Keypad. The keypad will disappear, and the name shown in the Compensation Table Selection Display will be followed by the **.mtr** extension. Compensation values may now be entered in the Compensation Value Displays.

**ENTERING
COMPENSATION
VALUES**

Touch the first Compensation Table Selection Display for which a value is to be entered. The Numeric Keypad shown in Figure B-4 will appear.




Figure B-4. The Numeric Pop-Up Keypad

**ENTERING
ANGLE
COMPENSATION
DATA**

Angle compensation data is entered by using the Numeric Touchbuttons. As the data is entered, it appears in the New Value Display at the top of the keypad. A decimal point is entered by using the Decimal Point Touchbutton.

Numeric values can be made positive or negative by using the Plus/Minus Touchbutton, which can be used at the beginning of an entry, or at any point after numeric data is entered.

A numeral can be removed from the New Value Display by touching the Clear Touchbutton. When this touchbutton is used, it removes one number at a time, starting from the right.

The New Value Display can be cleared completely by touching the Cancel Touchbutton.

The values are effective over a range of ± 4 degrees from the designated angle, except for the value entered for 10 degrees, which is effective from 1 degree through 14 degrees.

When the value shown in the New Value Display is the value desired, touch the Enter Touchbutton to enter the number into the Compensation Value Display. The Numeric Pop-Up Keypad disappears from the screen.

Material Setup

060 ALUMINUM.mtr

10 ° :	2.0°	50 ° :	0.0°	90 ° :	0.0°	130 ° :	0.0°
20 ° :	3.0°	60 ° :	0.0°	100 ° :	0.0°	140 ° :	0.0°
30 ° :	4.0°	70 ° :	0.0°	110 ° :	0.0°		
40 ° :	0.0°	80 ° :	0.0°	120 ° :	0.0°		

COMPTAB2

Save Table Touchbutton

Figure B-5. A Completed Angle Compensation Table

The process is repeated for each compensation value to be entered. Values need not be entered in all the Compensation Value Displays.

When all desired values have been entered, touch the Save Table Touchbutton, the Table name shown in the Compensation Table Selection Display will move to the Compensation Table Listing Display, and the Compensation Table will be saved to the system hard drive.




Figure B-6. Selecting a Compensation Table to be Deleted




Figure B-7. Delete Table Confirmation Display

**DELETING AN
ANGLE
COMENSATION
TABLE**

If it is desired to delete an Angle Compensation Table, use the following procedure.

Bring up the Angle Compensation Table Screen shown in Figure B-6. The list of Angle Compensation Tables will appear in the Compensation Table Listing Display.

Touch the file name of the Compensation Table to be removed. The file name will appear in the Compensation Table Selection Display. Touch the Delete Table Touchbutton and the Delete Table Confirmation Display shown in Figure B-7 will appear.

At this point, the delete operation can be halted by touching the Cancel Touchbutton in the Delete Table Confirmation Display.

If the correct table to be removed appears in the Compensation Table Selection Display, touch the Enter Touchbutton in the Delete Table Confirmation Display. The Confirmation display will disappear and the Compensation Table will be removed from the system hard drive.

Touch the Enter Touchbutton in the Angle Compensation Table Screen shown in Figure C-6 to return to the system Main Screen.

ROPER WHITNEY
ORION CONTROL SYSTEM

**ROPER WHITNEY
OF ROCKFORD, INC.**

2833 HUFFMAN BLVD
ROCKFORD, ILLINOIS 61103
815/962-3011
815/962-2227 FAX
Website: www.roperwhitney.com