

GL14 Selfdiag-Redesign Migration Guide

GL14 Selfdiag- Redesign Migration Guide
Revision 1.0

Linkwell Telesystems Pvt. Ltd.
Gowra Klassic 1-11-252/1/B, Begumpet, Hyderabad - 500016. Andhra Pradesh, INDIA.
Ph: +91-40-66388000, Fax: +91-40-66388006 Email: info@visiontek.co.in
www.visiontek.co.in

This Document provides clarification on existing APIs and new APIs of GL14 POS terminals.

IO Module	Existing API's GL14-UB-2009.08-795-K-3.0.bin GL14-KR-2.6.31-796-3-0.IMG GL14-RD-JFFS2-797-3-0.IMG	Default State	New API's in re-design analog board GL14-UB-2009.08-1094-1.2.bin GL14-KR-2.6.31-1095-1-0.IMG GL14-RD-JFFS2-1096-2.0.IMG	Default State	Purpose
RFID	Not applicable	ON	tama_rffieldon (void)	ON	Power ON RF field
	Not applicable		tama_rffieldoff (void)		power OFF RF field
USB-Host	Not applicable	ON	usb_pwr_enable(void)	ON	Power ON usb-host
	Not applicable		usb_pwr_disable(void)		power OFF usb-host
Audio	Not applicable	ON	audio_pwr_enable (void)	ON	Power ON audio device
	Not applicable		audio_pwr_disable (void)		Power OFF audio device
Magswipe	Not applicable	ON	mscr_pwr_enable (void)	ON	Power ON magswipe device
	Not applicable		mscr_pwr_disable (void)		Power OFF magswipe device
WIFI	Not applicable	ON	wifi_enable(void)	OFF	Enable wifi functionality
	Not applicable		wifi_disable(void)		Disable wifi functionality
	Not applicable		wifi_rfpower_on(void)		Power on the RF section of wifi
	Not applicable		wifi_rfpower_off(void)		Power OFF the RF section of

	wlan0		ra0		wifi
			All other APIs are same		Wifi instance

Note for re-design analog board:

1.

Wi-fi and USB-B are multiplexed in hardware.
When wi-fi is disabled then only USB-B functionality will work.

2.

If existing terminal is not using wi-fi feature then there is NO need to modify application image.

3.

When wi-fi is enabled, 20 mA more power will draw from the battery irrespective of data communication



subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by Linkwell Telesystems Pvt. Ltd. in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded. This document is intended only to assist the reader in the use of the product. Linkwell Telesystems Pvt. Ltd. shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or the use or inability to use the product.