


TEVO Little Monster – Simplify3D



Configuration data

Bed Radius = 175mm

Build Volume :

X-axis
 $= 2 * 175 * \cos(45^\circ)$
 $= 350 * 0.707$
 $= 247.48$
 $\approx 246 \text{ mm}$

Y-axis
 $= 2 * 175 * \sin(45^\circ)$
 $= 350 * 0.707$
 $= 247.48$
 $\approx 246 \text{ mm}$

Z-axis
 $= 510 \text{ mm}$

Origin Offsets :

X-axis = 123 mm

Y-axis = 123 mm

Z-axis = 0 mm

Little Monster Auto-configuration Procedure

Auto-calibration procedure is already implemented in the motherboard and available via the TFT screen. However, here's the GCODE sequence behind that feature.

M280 PS3 ; Set BLTouch to probing position (light on, pin out)

M190 S80 ; Wait until Bed temperature to 80°C

G32 ; Z-Plane probing and calculation

G31 ; Dock Z Probe sled


M374 ; Save Calibration Grid

M500 ; Save firmware

M280 PS7 ; Set BLTouch to idle position (light off, pin in)

G28 ; Homing

M140 S0 ; Set Bed temperature to 0 (actually turn it off)



Little Monster Starting script for Simplify3D

M280 PS3 ; Set BLTouch to probing position (light on, pin out)

G28 ; Homing

G1 Z50 F25000 ;

G30 Z2.0 ; Define offset between nozzle and BLTouch (*)

M280 PS7 ; Set BLTouch to idle position (light off, pin in)

G1 X0 Y0 Z100 ;

M140 S0 ; Set Bed temperature to 0 (actually turn it off)

(*) G30 Z2.0 indicate BLTouch trigger point is 2mm below nozzle tip. Please adjust this value according to the first layer print result :

- Increase this value will lower nozzle closer to bed. (Example: G30 Z2.0 to G30 Z2.2)

- Decrease this value will lift nozzle away from bed. (Example: G30 Z2.0 to G30 Z1.8)

Little Monster Stopping script for Simplify3D

G92 E0 ; Reset Extruder

G1 E-8.0 F9000 ; Retract filament

M104 F0 ; Set Extruder temperature to 0

G28 ; Home axis (hopefully on top for Delta printer)

M84 ; Disable motors (**)

(**) Ensure all your carriages are tightened enough so the print-head does not fall down once stepper motors are off. Otherwise you will see that head crashing on your prints.


Little Monster - BLTouch commands

Here are simple tests using GCODE commands to diagnose your BLTouch sensor is working properly.

M280 PS3

Set BLTouch to probing position : light on, pin out (1).


Send that command and use your finger to retract the pin. The sensor should trigger (2). It must come back to its « probing » position at end (3).



M280 PS10.6


Reset the BLTouch

When your BLTouch is blinking (error detected), you can reset it with 'M280 PS10.6' command. The sensor should then reset with light on and pin out.



M280 PS7

Set BLTouch to idle position : light off, pin retracted.



M280 PS8

SELF TEST.

In self test mode, the sensor launches an endless cycle pin-in pin-out. If you block the pin with your fingers, the BLTouch must pass in Error mode (blinking). You need then to reset it with PS10.6 command.

