

## **GREE SPLIT SYSTEMS COMPATIBILITY LIST**



**Document Version** : 1.1

**Last Revision** : 21.01.2026

**Product Code** : CR-CG-GRE-KNX-02

## 1. PRESENTATION

In this document, compatible Gree AC indoor unit models with Core Gree Split Systems Gateway (CR-CG-GRE-KNX-02) are specified.



Core GREE Split KNX Gateway is applicable for several kinds of units. Some functions of the gateway are not available for certain kinds of units, more details please refer to the owner's manual of unit.



Any AC indoor unit not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



Any remote controller not specified in the list may not be compatible with Core AC Gateway. Therefore compatibility list must be checked before installation.



We highly recommend to pay attention to the possible updates of this document in case of any misprint, typing error and equivalent problems.



Core Smart Home undertakes maximum effort to avoid any error in the content of this document but cannot be responsible for the consequences that could arise because of any mistake in the document

## 2. COMPATIBLE AC INDOOR UNITS

FLOOR MOUNT TYPE	<b>GEH09AA-K6DNA1E/I</b> <b>GEH12AA-K6DNA1E/I</b> <b>GEH18AA-K6DNA1E/I</b>
DUCT TYPE	<b>GFH(09)CA-K6DNA1C/I</b> <b>GFH(12)CA-K6DNA1C/I</b> <b>GFH(18)CB-K6DNA1C/I</b> <b>GFH(24)CC-K6DNA1C/I</b>
4-WAY CASSETTE TYPE	<b>GKH(12)BB-K6DNA3A/I</b> <b>GKH(18)BB-K6DNA3A/I</b> <b>GKH(24)BC-K6DNA4A/I</b>
1-WAY CASSETTE TYPE	<b>GKH09DA-K6DNA1A/I</b> <b>GKH12DA-K6DNA1A/I</b> <b>GKH18DA-K6DNA1A/I</b> <b>GKH20DA-K6DNA1A/I</b> <b>GKH24DA-K6DNA1A/I</b>

WALL MOUNT TYPE	GWH09QB-K6DNB8E/I
	GWH12QC-K6DNB8D/I
	GWH18QD-K6DNE8D/I
	GWH24QE-K6DNE8E/I
	GWH09YC-K6DNA2A/I
	GWH12YC-K6DNA2A/I
	GWH18YD-K6DNA2A/I
	GWH24YE-K6DNA2A/I
	GWH07AGA-K6DNA1A/I
	GWH09AGAXB-K6DNA1C/I
	GWH12AGBXB-K6DNA1F/I
	GWH18AGD-K6DNA1D/I
	GWH24AGDXE-K6DNA1A/I
	GWH09ACC-K6DNA1F/I
	GWH12ACC-K6DNA1F/I
	GWH18ACD-K6DNA1I/I
	GWH24ACE-K6DNA1I/I
	GWH09AVCXB-K6DNA1B/I
	GWH12AVCXD-K6DNA1A/I
	GWH18AVDXE-K6DNA1A/I

### 3. INSTALLATION SCENARIOS

Connect Core AC Gateway directly to the **COM-Manual** terminal of the Gree AC indoor unit.



**Core AC Gateway can only work without Gree AC wired remote controller.** Don't use Gree AC wired remote controller if Core AC Gateway is connected to Gree AC indoor unit.



Disconnect the main power from the AC unit before connecting Core AC gateway to knx bus line.