


ADAPTING THE INTERNALLY REGULATED AUTOMOTIVE ALTERNATOR TO AIRCRAFT

AEROELECTRIC CONNECTION
6936 BAINBRIDGE ROAD
WICHITA, KS 67226
AEROELECTRIC.COM

TITLE	PAGE
COVER	0.0

INTERIM



NOTE:
SOME ALTERNATORS DO NOT
TOLERATE BEING "SHUT OFF" WHILE
UNDER LOAD. IF THIS OVERVOLTAGE
CONTROL SYSTEM IS INCORPORATED,
IT'S IMPORANT NOT TO SHUT THE ALTERNATOR
"OFF" ANY TIME THE ENGINE IS RUNNING
EXCEPT EMERGENCIES.

THE PROPOSED SYSTEM DESCRIBED ON THE NEXT PAGE WILL EASILY REPLACE THE INTERIM SYSTEM AND HAS NO PROHIBITIONS AS TO WHEN AND HOW THE ALTERNATOR IS SWITCHED ON OR OFF.

INTERIM

TITLE	PAGE
TEMPORARY ALTERNATOR CONTROL	1.0

