

SECTION

SBC

SEAT BELT CONTROL SYSTEM

A
B
C

CONTENTS

E

PRECAUTION	2	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	14	F
PRECAUTIONS	2	Description	14	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Diagnosis Procedure	14	G
Precautions Necessary for Steering Wheel Rotation After Battery Disconnection	2	Component Inspection	14	
Precautions for Removing Battery Terminal	3	SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)	15	SBC
SYSTEM DESCRIPTION	4	Description	15	
COMPONENT PARTS	4	Diagnosis Procedure	15	I
Component Parts Location	4	Component Inspection	16	
Seat Belt Buckle Switch	5	REAR SEAT BELT BUCKLE SWITCH	17	J
SYSTEM	6	Description	17	
SEAT BELT WARNING LAMP CONTROL SYSTEM	6	Diagnosis Procedure	17	
SEAT BELT WARNING LAMP CONTROL SYSTEM : System Description	6	Component Inspection	17	
WIRING DIAGRAM	7	SYMPTOM DIAGNOSIS	18	K
SEAT BELT WARNING LAMP CONTROL SYSTEM	7	SEAT BELT WARNING LAMP DOES NOT TURN ON	18	L
Wiring Diagram	7	Diagnosis Procedure	18	
BASIC INSPECTION	11	SEAT BELT WARNING LAMP DOES NOT TURN OFF	20	M
DIAGNOSIS AND REPAIR WORK FLOW	11	Diagnosis Procedure	20	
Work Flow	11	REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE	22	N
DTC/CIRCUIT DIAGNOSIS	14	Diagnosis Procedure	22	
		REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF	24	O
		Diagnosis Procedure	24	P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010323912

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation After Battery Disconnection

INFOID:0000000010323913

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Before removing and installing any control units, first turn the ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the ignition switch to ACC position.
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT.


Precautions for Removing Battery Terminal

INFOID:0000000010323915

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	ZD30DDTi	: 60 seconds
HRA2DDT	: 12 minutes	ZD30DDTT	: 60 seconds
K9K engine	: 4 minutes		
M9R engine	: 4 minutes		
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000010323897



JMHIA2901ZZ

No.	Component	Function
①	Rear seat belt buckle switch (Center and RH)	Refer to SBC-5, "Seat Belt Buckle Switch" .
②	Seat belt buckle switch (Driver side)	Refer to SBC-5, "Seat Belt Buckle Switch" .
③	Combination meter	<ul style="list-style-type: none">Receives seat belt buckle switch signal from seat belt buckle switch (driver side) and air bag diagnosis sensor unit.Turns the seat belt warning lamp ON when the seat belt is unfastened.
④	Air bag diagnosis sensor unit	Transmits seat belt buckle switch signal to Combination meter. Refer to SRC-6, "Component Parts Location" for detailed installation location.
⑤	Seat belt buckle switch (Passenger side)	Refer to SBC-5, "Seat Belt Buckle Switch" .
⑥	Rear seat belt buckle switch (LH)	Refer to SBC-5, "Seat Belt Buckle Switch" .


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Seat Belt Buckle Switch

INFOID:0000000010323899

- Detects seat belt status and transmits seat belt buckle switch (driver side) signal to combination meter.
- Detects seat belt status and transmits seat belt buckle switch (passenger side and rear) signal to air bag diagnosis sensor unit.



A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

SEAT BELT WARNING LAMP CONTROL SYSTEM

SEAT BELT WARNING LAMP CONTROL SYSTEM : System Description INFOID:0000000010323900

SYSTEM DIAGRAM



SEAT BELT WARNING LAMP OPERATION

Seat belt warning lamp on combination meter turns ON during a period when ignition switch is turns ON until front seat belts are fastened. Seat belt warning lamp turns OFF when front seat belt is fastened. Seat belt warning lamp turns ON again when front seat belt is unfastened.

REAR SEAT BELT WARNING LAMP OPEATION

Seat belt warning is displayed on information display for approximately 35 seconds when the following conditions.

- Ignition switch is ON and engine starts running.
- Rear seat belt buckle switch is turned ON (rear seat belt is not fastened) and vehicle speed is 15km/h (9.3 MPH) or more.

Seat belt warning is canceled when the following conditions.

- Ignition switch is turned OFF.
- Approximately 35 seconds are passed since rear seat belt warning is displayed.

SEAT BELT WARNING CHIME OPERATION

Front seat belt warning chime sounds for approximately 90 seconds when the vehicle speed is approximately 15 km/h (9.3 MPH) or more while front seat belts are not fastened. Front seat belt warning chime stops when front seat belt is fastened.

Rear seat belt warning chime sounds for approximately 50ms after rear seat belt warning is displayed.

SEAT BELT WARNING LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

SEAT BELT WARNING LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:0000000010323904



SBC

SEAT BELT WARNING LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

SEAT BELT WARNING SYSTEM

Connector No.	B11
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	—
2	B	—
2	LG	—

Connector No.	B12
Connector Name	REAR SEAT BELT BUCKLE SWITCH (LH)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	—
2	B	—

Connector No.	B19
Connector Name	WIRE TO WIRE
Connector Type	TH132MW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	—
2	V	—
4	GR	—
5	Y	—
6	W	—
10	W	—
11	Y	—
13	G	—
15	V	—
20	LG	—
21	G	—
22	V	—
23	BR	—
24	P	—
25	L	—
26	G	—
28	SHIELD	—
30	W	—
31	B	—
32	R	—

Connector No.	B20
Connector Name	OCCUPANT SENSOR
Connector Type	NS02FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	—

Connector No.	B31
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH22FY-2V-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
51	BR	ELR LH2+
52	L	ELR LH2-
53	V	SIDE INF LH+
54	SB	SIDE INF LH-
55	BR	INF CURTAIN RR LH+
56	Y	INF CURTAIN RR LH-
59	SB	REAR SEAT BELT BUCKLE SWITCH (CENTER AND LH)
60	BR	ELR LH+
61	L	ELR LH-
62	V	—
63	G	SIDE SEN LH+
64	R	SIDE SEN LH-
70	SHIELD	GND

Connector No.	B69
Connector Name	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	—
2	B	—
2	LG	—

Connector No.	B70
Connector Name	REAR SEAT BELT BUCKLE SWITCH (CENTER)
Connector Type	TH04MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	B	—
4	P	—


JRHWC3185GB

SEAT BELT WARNING LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

SEAT BELT WARNING SYSTEM

Connector No.	B74
Connector Name	WIRE TO WIRE
Connector Type	TH80MFC-CSI2-TM4




Connector No.	B81
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NK22FY-1V-EX



Connector No.	B81
Connector Name	OCCUPANT SENSOR
Connector Type	NS02FW-CS




Connector No.	M/5
Connector Name	WIRE TO WIRE
Connector Type	TH02FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	ELR RH2+
2	L	ELR RH-
3	LG	ELR LH2+
4	P	ELR LH-
5	SB	INF CURTAIN RR RH+
6	Y	INF CURTAIN RR RH-
7	P	REAR SEAT BELT BUCKLE SWITCH (CENTER)
10	GR	REAR SEAT BELT BUCKLE SWITCH (RH)
17	SHIELD	GND
18	R	SIDE SEN RH+
19	G	SIDE SEN RH-
20	SB	INF CURTAIN RR RH+
20	W	INF CURTAIN RR RH-
21	L	ELR RH+
21	L	ELR RH-
22	BR	ELR RH+
22	BR	ELR RH-
89	EG	ECZS- (With gasoline engine)
89	W	ECZS- (With diesel engine)
90	ER	ECZS- (With MR16 engine)
93	Y	ECZS- (With gasoline engine)
93	Y	ECZS- (With diesel engine)
94	P	ECZS- (With MR16 engine)
98	L	ECZS- (With gasoline engine)
98	L	ECZS- (With diesel engine)
99	LG	ECZS- (With MR16 engine)
100	GR	ECZS- (With gasoline engine)
100	GR	ECZS- (With diesel engine)
100	R	ECZS- (With MR16 engine)
100	W	ECZS- (With gasoline engine)
100	W	ECZS- (With diesel engine)
100	W	ECZS- (With MR16 engine)

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	ELR RH2+
2	L	ELR RH-
3	L	ELR LH2+
4	P	ELR LH-
5	BR	INF CURTAIN RR RH+
6	Y	INF CURTAIN RR RH-
7	P	REAR SEAT BELT BUCKLE SWITCH (CENTER)
10	GR	REAR SEAT BELT BUCKLE SWITCH (RH)
17	SHIELD	GND
18	R	SIDE SEN RH+
19	G	SIDE SEN RH-
20	SB	INF CURTAIN RR RH+
20	W	INF CURTAIN RR RH-
21	L	ELR RH+
21	L	ELR RH-
22	BR	ELR RH+
22	BR	ELR RH-

Connector No.	M5
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH28FY-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	ELR RH2+
3	L	ELR RH-
4	L	ELR LH2+
5	GR	ELR LH-
5	BR	INF CURTAIN RR RH+
6	W	INF CURTAIN RR RH-
10	R	SIDE SEN RH+
11	L	SIDE SEN RH-
13	LG	ECZS-
15	V	ECZS-
20	BG	ECZS-
21	BG	ECZS-
22	GR	ECZS-
23	GR	ECZS-
24	P	ECZS-
25	L	ECZS-
26	L	ECZS-
29	SHIELD	GND
30	W	ECZS-
31	B	ECZS-
32	R	ECZS-

Terminal No.	Color Of Wire	Signal Name [Specification]
25	SB	INFLATOR AS+
26	V	INFLATOR AS+
27	B	GND
29	G	INFLATOR DR+
30	Y	INFLATOR DR+
31	P	ECZS-
38	BG	OUT OFF SWDEACT
37	R	OUT OFF SWDEACT
39	SHIELD	GND
41	L	ECZS-
42	P	ECZS-
43	L	ECZS-
44	P	ECZS-
45	L	ECZS-
46	L	ECZS-
47	GR	TELLTALE OFF
48	W	TELLTALE ON
49	BG	AGS (For vehicles with ABS module and ABS system without CVT)
49	BR	AGS (For vehicles with ABS module and ABS system without CVT)
50	R	ICN

Connector No.	B08
Connector Name	REAR SEAT BELT BUCKLE SWITCH (RH)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	B	-

JRHWC3186GB

SEAT BELT WARNING LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

SEAT BELT WARNING SYSTEM

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Type	TH480FW-CS16-TM4




Terminal No.	Color	Wire	Signal Name [Specification]
1	GR	W	-
2	GR	W	-
3	SB	B	-
4	P	-	-
9	SB	G	-
20	G	-	-
21	B	-	-
24	G	-	- [Without MR16 engine]
24	R	-	- [With MR16 engine]
25	BR	-	-
55	LG	-	-
66	GR	-	-
74	R	-	-
79	V	-	-
80	L	-	-
85	W	-	-
89	GR	-	-
90	BR	-	-
93	Y	-	-
94	P	-	-
98	L	-	-
99	LG	-	-
100	R	-	-

Connector No.	M21
Connector Name	DATA LINK CONNECTOR
Connector Type	SD16FW




Terminal No.	Color	Wire	Signal Name [Specification]
1	LG	W	-
2	B	-	-
5	B	-	-
6	L	-	-
8	Y	-	-
11	SB	-	-
14	P	-	-
15	BR	-	-
16	W	-	-

Connector No.	M51
Connector Name	COMBINATION METER
Connector Type	TH460FW-NH




Terminal No.	Color	Wire	Signal Name [Specification]
1	B	-	-
7	L	-	-
8	P	-	-
9	GR	-	-
13	RG	-	-
18	SB	-	-
20	R	-	-
21	L	-	-
22	LG	-	-
23	GR	-	-
25	Y	-	-

27	W	LDW OFF SW
28	W	DP BELT SW
30	Y	M RANGE
31	G	NOT M RANGE
32	R	AT SHIFT UP
33	W	AT SHIFT DOWN
36	BR	ILL UP SW
37	V	ILL DOWN SW
38	P	BP R/OUT



Connector No.	M7B
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS

Connector No.	M52
Connector Name	COMBINATION METER
Connector Type	TH12FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
41	L	-	-
42	P	-	-
43	R	-	-
44	W	-	-
45	W	-	-
46	RG	-	-
47	SB	-	-
48	LG	-	-
49	V	-	-
50	P	-	-
51	G	-	-
52	B	-	-

Terminal No.	Color	Wire	Signal Name [Specification]
13B	W	-	-
14B	GR	-	-
16B	L	-	-
1B	R	-	-
2B	G	-	-
3B	LG	-	-
4B	LG	-	-
5B	LG	-	-
6B	SB	-	-
7B	Y	-	-
8B	BG	-	-
8B	GR	-	-

JRHWC3187GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010323905

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Description

INFOID:0000000010500922

- Detects whether or not the seat belt is fastened when the ignition switch turns ON. If the seat belt is not fastened, illuminates the seat belt warning lamp on the combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

Diagnosis Procedure

INFOID:0000000010500924

1.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side).

Refer to [SBC-14, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace seat belt buckle (driver side). Refer to [SB-8, "FRONT SEAT BELT BUCKLE : Removal and Installation"](#).

2.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

1. Disconnect seat belt buckle switch (driver side) connector.
2. Check continuity between seat belt buckle switch (driver side) and ground.

LHD models

Seat belt buckle switch (driver side)		Ground	Continuity
Connector	Terminal		
B11	2		Existed

RHD models

Seat belt buckle switch (driver side)		Ground	Continuity
Connector	Terminal		
B69	2		Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

Component Inspection

INFOID:0000000010500925

1.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity of seat belt buckle (driver side).

Seat belt buckle switch (driver side)		Condition	Continuity
Terminal			
1	2	When driver side seat belt is not fastened	Existed
		When driver side seat belt is fastened	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (driver side). Refer to [SB-8, "FRONT SEAT BELT BUCKLE : Removal and Installation"](#).

SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Description

INFOID:0000000010500926

- Detects whether or not the seat belt is fastened when the ignition switch turns ON. If the seat belt switch is not fastened, illuminates the seat belt warning lamp on the combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

Diagnosis Procedure

INFOID:0000000010500928

1.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side).

Refer to [SBC-16, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace seat belt buckle (passenger side). Refer to [SB-8, "FRONT SEAT BELT BUCKLE : Removal and Installation"](#).

2.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT1

1. Disconnect seat belt buckle switch (passenger side) connector and occupant sensor connector.
2. Check continuity between seat belt buckle switch (passenger side) and occupant sensor.

LHD models

Seat belt buckle switch (passenger side)		Occupant sensor		Continuity
Connector	Terminal	Connector	Terminal	
B69	2	B91	1	Existed

RHD models

Seat belt buckle switch (passenger side)		Occupant sensor		Continuity
Connector	Terminal	Connector	Terminal	
B11	2	B20	1	Existed

3. Check continuity between seat belt buckle switch (passenger side) and ground.

LHD models

Seat belt buckle switch (passenger side)		Ground	Continuity
Connector	Terminal		
B69	2		Not existed

RHD models

Seat belt buckle switch (passenger side)		Ground	Continuity
Connector	Terminal		
B11	2		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT2

Check continuity between occupant sensor and ground.

LHD models

Occupant sensor		Ground	Continuity
Connector	Terminal		
B91	2		Existed

RHD models

Occupant sensor		Ground	Continuity
Connector	Terminal		
B20	2		Existed

SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-28, "Removal and Installation"](#).
NO >> Repair or replace harness.

Component Inspection

INFOID:0000000010500929

1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity of seat belt buckle (passenger side).

Seat belt buckle switch (passenger side)		Condition	Continuity
Terminal			
1	2	When driver side seat belt is not fastened	Existed
		When driver side seat belt is fastened	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace seat belt buckle (passenger side). Refer to [SB-8, "FRONT SEAT BELT BUCKLE : Removal and Installation"](#).

REAR SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR SEAT BELT BUCKLE SWITCH

Description

INFOID:0000000010500930

- Detects if the seat belt is fastened or unfastened.
- Warning lamp turns OFF if the seat belt is fastened.

Diagnosis Procedure

INFOID:0000000010500931

1.CHECK REAR SEAT BELT BUCKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-17. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace rear seat belt buckle. Refer to [SB-12. "SEAT BELT BUCKLE : Removal and Installation"](#).

2.CHECK REAR SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

1. Disconnect rear seat belt buckle switch connector.
2. Check the continuity between rear seat belt buckle switch harness connector and ground.

Rear seat belt buckle switch			Ground	Continuity
Connector		Terminal		
LH	B12	2	Ground	Existed
Center	B70	3		
RH	B88	2		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

Component Inspection

INFOID:0000000010500932

1.CHECK REAR SEAT BELT BUCKLE SWITCH

Check continuity between rear seat belt buckle switch connector.

Rear seat belt buckle switch				Condition	Continuity
Connector		Terminal			
LH	B12	1	2	Rear seat belt (LH) is unfas- tened	Existed
				Rear seat belt (LH) is fastened	Not existed
Center	B70	3	4	Rear seat belt (center) is unfas- tened	Existed
				Rear seat belt (center) is fas- tened	Not existed
RH	B88	1	2	Rear seat belt (RH) is unfas- tened	Existed
				Rear seat belt (RH) is fastened	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear seat belt buckle. Refer to [SB-12. "SEAT BELT BUCKLE : Removal and Installation"](#).

SEAT BELT WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SEAT BELT WARNING LAMP DOES NOT TURN ON

Diagnosis Procedure

INFOID:0000000010431554

1. CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-19, "DTC Index"](#).
- NO >> GO TO 2

2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-40, "DTC Index"](#).
- NO >> GO TO 3

3. CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUIT

Check combination meter power supply and ground circuit. Refer to [MWI-66, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4
- NO >> Repair or replace the malfunctioning parts.

4. CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 5
- NO-1 >> damage: Replace malfunctioning parts.
- NO-2 >> disconnection or looseness: Securely lock the connector.

5. CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

- YES-1 >> GO TO 6. (driver side)
- YES-2 >> GO TO 7. (passenger side)
- NO >> Replace malfunctioning parts.

6. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check the seat belt buckle switch. Refer to [SBC-14, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 8
- NO >> Repair or replace the malfunctioning parts.

7. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check the seat belt buckle switch. Refer to [SBC-15, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 8
- NO >> Repair or replace the malfunctioning parts.

8. REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace air bag diagnosis sensor unit.
2. Check air bag warning lamp operation.

Is the inspection result normal?

- YES >> INSPECTION END

SEAT BELT WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

NO >> GO TO 9

9.REPLACE COMBINATION METER

1. Replace combination meter. Refer to [MWI-86, "Removal and Installation"](#).
2. Check air bag warning lamp operation.

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 10

10.CHECK INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

SEAT BELT WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000010431555

1.CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-19, "DTC Index"](#).
- NO >> GO TO 2.

2.CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-40, "DTC Index"](#).
- NO >> GO TO 3

3.CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 4.
- NO-1 >> damage: Replace malfunctioning parts.
- NO-2 >> disconnection or looseness: Securely lock the connector.

4.CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

- YES-1 >> GO TO 5. (driver side)
- YES-2 >> GO TO 6. (passenger side)
- NO >> Replace malfunctioning parts.

5.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check the seat belt buckle switch. Refer to [SBC-14, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 7
- NO >> Repair or replace the malfunctioning parts.

6.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check the seat belt buckle switch. Refer to [SBC-15, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 7
- NO >> Repair or replace the malfunctioning parts.

7.REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 8.

8.REPLACE COMBINATION METER

1. Replace combination meter. Refer to [MWI-86, "Removal and Installation"](#).
2. Check air bag warning lamp operation.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 9.

9.INTERMITTENT INCIDENT

SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

Refer to [GI-44. "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000010431972

1.CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-19, "DTC Index"](#).
- NO >> GO TO 2.

2.CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-40, "DTC Index"](#).
- NO >> GO TO 3

3.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUIT

Check combination meter power supply and ground circuit. Refer to [MWI-66, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4.CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 5.
- NO-1 >> damage: Replace malfunctioning parts.
- NO-2 >> disconnection or looseness: Securely lock the connector.

5.CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Replace malfunctioning parts.

6.CHECK REAR SEAT BELT BUCKLE SWITCH

Check the applicable rear seat belt buckle switch. Refer to [SBC-17, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace the applicable rear seat belt buckle.

7.REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

1. Replace air bag diagnosis sensor unit.
2. Check air bag warning lamp operation.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 8.

8.REPLACE COMBINATION METER

1. Replace combination meter. Refer to [MWI-86, "Removal and Installation"](#).
2. Check air bag warning lamp operation.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 9.

REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

9.CHECK INTERMITTENT INCIDENT

Refer to [GI-44. "Intermittent Incident"](#).

>> INSPECTION END

- A
- B
- C
- D
- E
- F
- G
- SBC
- I
- J
- K
- L
- M
- N
- O
- P

REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000010431974

1.CHECK DTC OF "AIR BAG DIAGNOSIS SENSOR UNIT"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [SRC-19, "DTC Index"](#).
- NO >> GO TO 2.

2.CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnosis Result" "Air bag diagnosis sensor unit" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-40, "DTC Index"](#).
- NO >> GO TO 3

3.CHECK HARNESS CONNECTOR

Check the harness connector for disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 4.
- NO-1 >> damage: Replace malfunctioning parts.
- NO-2 >> disconnection or looseness: Securely lock the connector.

4.CHECK WIRING HARNESS

Check the wiring harness externals.

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace malfunctioning parts.

5.CHECK REAR SEAT BELT BUCKLE SWITCH

Check the applicable rear seat belt buckle switch. Refer to [SBC-17, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Replace the applicable rear seat belt buckle.

6.REPLACE AIR BAG DIAGNOSIS SENSOR UNIT

Replace air bag diagnosis sensor unit.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 7.

7.REPLACE COMBINATION METER

1. Replace combination meter. Refer to [MWI-86, "Removal and Installation"](#).
2. Check air bag warning lamp operation.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 8.

8.INTERMITTENT INCIDENT

Refer to [GI-44, "Intermittent Incident"](#).

>> INSPECTION END