




ECE3186 Embedded IoT Systems and Applications

DR. TAN WOOL HAW

Install Arduino IDE

- Download the Arduino IDE 2.0 from the Arduino Software page:
<https://www.arduino.cc/en/software>
- Next, run the downloaded installer file.
- Follow the instructions in the installation guide to complete the installation.
- When the installer asks for permission to install some drivers, please click “Install” to install drivers.





Install ESP32 Add-on

- After installing Arduino IDE 2.0, launch it and go to **File → Preferences**.
- Copy and paste the following line to the Additional Boards Manager URLs field:

https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package_esp32_index.json

- Open the Boards Manager by going to **Tools → Board → Boards Manager** or simply click the Boards Manager icon near the top left corner.
- Search for ESP32 and press the install button for esp32 by Espressif Systems.



Install Driver for DOIT ESP32 Devkit V1

- Browse to the following link:

<https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers?tab=downloads>

- Download and install CP210x Windows Driver.

The screenshot shows the Silicon Labs website's 'USB to UART Bridge VCP Drivers' page. The page has a navigation bar with links for Products, Applications, Ecosystems, Resources, and Company. Below the navigation bar, there's a breadcrumb trail: // Developers // USB to UART Bridge VCP Drivers. The main heading is 'Download and Install VCP Drivers'. Below this, it says 'Downloads for Windows, Macintosh, Linux and Android below.' and includes a note about the Linux version being maintained in the current Linux tree at www.kernel.org. On the right side, there are links for 'Legacy OS Software Versions' and 'Serial Enumeration Driver'. The 'Software Downloads' section is highlighted, showing a list of software items. The 'CP210x Windows Drivers' item is highlighted with a red dashed box.

SILICON LABS Products ▾ Applications ▾ Ecosystems ▾ Resources ▾ Company ▾ English ▾

// Developers // USB to UART Bridge VCP Drivers

Download and Install VCP Drivers

Downloads for Windows, Macintosh, Linux and Android below.

*Note: The Linux 3.x.x and 4.x.x version of the driver is maintained in the current Linux 3.x.x and 4.x.x tree at www.kernel.org.

Software Downloads

[Software](#) (10)

Software	10
CP210x Universal Windows Driver	v11.2.0 10/21/2022
CP210x VCP Mac OSX Driver	v6.0.2 10/27/2021
CP210x Windows Drivers	v6.7.6 9/4/2020
CP210x Windows Drivers with Serial Enumerator	v6.7.6 9/4/2020
CP210x_5x_AppNote_Archive	9/4/2020

Legacy OS Software Versions

Driver Package download links and support information

Serial Enumeration Driver

What is the serial enumeration driver and why would I need it?