

# 017921w14 Pattern Manager 6.0

## User Guide

---

**Author's name**  
Lambley, Jason

**Sub-business unit**  
Service Outage Management

**Issue number**  
6

**Business unit**  
Customer Service Delivery

**Issue date**  
21 July 2017

**Telstra ID**  
AAV-3348

**Implementation Approval**  
Craig Goodwin  
Network & Service Incident  
Manager  
SOM Incident Management  
Customer Service Delivery

**Process Owner**  
Jason Lambley  
SOM Skills Specialist

---

### Summary

The purpose of this work instruction is to provide a user operating guide to the Pattern Manager application used by Customer Service Delivery Service Outage Management (SOM) to identify potential outages from related fault patterns.

---

## Contents

1.	Purpose	5
2.	Scope	5
3.	Overview of Pattern Manager 6.0	5
4.	Overview of major upgrade 2016	6
5.	User Profiles	7
6.	Get Access to Pattern Manager	8
7.	Login & Navigation	9
	7.1. Log in to NODS-PM	9
	7.2. Home Menu Screen	9
	7.3. Basic Navigation	10
	7.4. Log into Pattern Manager	10
	7.5. Pattern Manager Home Menu screen	11
	7.6. Pattern Manager Navigation	12
8.	CAN Patterner Version 6.0	13
	8.1. Select Region	13
	8.2. Select Exchange	14
	8.3. CAN Exchange screen	14
	8.4. CAN Fault Patterning Rules	16
	8.4.1. Form CAN fault pattern	16
	8.4.2. Display CAN fault pattern	17
	8.4.3. Special CAN patterning and display rules	17
	8.5. Analyse CAN Fault Pattern	19
	8.6. Create NODS from CAN Patterner	20
	8.7. Check off CAN Fault Pattern	21
9.	PGS Patterner Version 6.0	23
	9.1. Select Region	23
	9.2. Select Exchange	24
	9.3. PGS Exchange screen	24
	9.4. PGS Fault Patterning Rules	26
	9.4.1. Form PGS fault pattern	26
	9.4.2. Display PGS fault pattern	27
	9.4.3. CMUX patterning & display rules	27
	9.4.4. PGS in secondary exchange	30
	9.4.5. Special PGS patterning and display rules	31
	9.5. Analyse PGS Fault Pattern	32
	9.6. Create NODS from PGS Patterner	32

	<b>9.7. Check off PGS Fault Pattern</b>	<b>33</b>
<b>10.</b>	<b>Switch Patterner Version 6.0</b>	<b>35</b>
	10.1. Select Region	35
	10.2. Select Node	36
	10.3. Switch Node screen	37
	10.4. Switch Fault Patterning Rules	38
	10.4.1. Form Switch fault pattern	39
	10.4.2. Display Switch fault pattern	39
	10.5. Analyse Switch Fault Pattern	40
	10.6. Create NODS from Switch Patterner	40
	10.7. Check off Switch Fault Pattern	41
<b>11.</b>	<b>Broadband Patterner Version 2.0</b>	<b>43</b>
	11.1. Select Region	43
	11.2. Select Exchange	44
	11.3. BB CAN Exchange screen	44
	11.4. BB CAN Fault Patterning Rules	46
	11.4.1. Form BB CAN fault pattern	46
	11.4.2. Display BB CAN fault pattern	47
	11.4.3. CMUX display rules in BB CAN Patterner	47
	11.4.4. Special patterning & display rules	48
	11.5. Analyse BB CAN Fault Pattern	48
	11.6. Create NODS	49
	11.7. Check off BB CAN Fault Pattern	49
	11.7.1. BVH Check off code	50
<b>12.</b>	<b>Priority Outage Dashboard</b>	<b>51</b>
	12.1. Priority Outage Display	52
	12.2. Priority Patterning Rules - Unchecked	53
	12.3. Priority Patterning Rules - Fast	54
	12.3.1. Patterner Hierarchy rule	54
	12.3.2. Network Element rules	55
	12.3.2.1. PGS Patterner	55
	12.3.2.2. Switch Patterner	55
	12.3.2.3. BB CAN Patterner	56
	12.3.2.4. CAN Patterner	56
	12.4. Priority Pattern Auto NODS	59
	12.5. Investigate Priority Pattern	60
	12.6. Action Priority Pattern	61
<b>13.</b>	<b>Pattern Manager Admin Version 2.0</b>	<b>63</b>

13.1. Guidelines for Pattern Manager Admin changes	65
13.2. Update Priority Thresholds	65
13.3. Update Patternner Thresholds	67
13.4. Update Age of Patterning Data	68
13.5. Update Checklist Code	69
13.6. Update Symptom Code	69
13.7. Update PGS Type	70
13.8. Update Exchange	71
13.9. Update Auto Outage Exchange	72
13.10. Audit Trail Report	73
13.11. Pattern Manager Admin Messages	75
14. Functionality common to all Patterns	76
14.1. Plain Text View	76
14.2. Hyperlinks to Other Patterns	77
14.3. Table of PSTN Symptom Codes	78
14.4. Table of ADSL Symptom Codes	79
14.5. Create NODS from Patternner	80
14.6. Service Types	82
14.7. Check off Codes	82
14.8. Table Check Off Codes	84
14.9. Patternner Refresh Rates and Timings	85
15. References	86
16. Attachments	87
17. Definitions	87
18. Document Control Sheet	88

## 1. Purpose

The purpose of this work instruction is to provide a user operating guide to the Pattern Manager application used by Customer Service Delivery Service Outage Management (SOM) to identify potential outages from related customer fault patterns.

## 2. Scope

This document is a system user guide for Pattern Manager 6.0.

It describes and explains the features, screen elements, field values, and patterning and display rules and provides instructions on login, navigation, support and using the various functions.

This document does not directly cover the business processes used by SOM consultants to monitor, analyse or action related fault patterns as part of outage management.

For details of these procedures refer to work instructions [017921w06](#) Outage Identification & Setup and [017921w07](#) Pattern Manager – Identification & Actioning of Related Fault Patterns.

## 3. Overview of Pattern Manager 6.0

Pattern Manager 6.0 is a web based application which interfaces with SIIAM.

Pattern Manager (PM) is used to identify related fault patterns with a common network element which may indicate an outage.

An outage is any significant disruption to the network affecting multiple services and with a single or related technical cause.

PM gathers SIIAM data for customer fault reports which meet certain criteria – e.g. specific FNN types, symptom codes and plant types and which are within a 72 hour reporting window - and then applies patterning rules to identify common network elements e.g. customer faults having the same Pillar or same Pair Gain System.

Patterned faults are stored until certain display criteria are met and then are displayed in a Graphical User Interface (GUI) screen as colour-differentiated groups along with key information to facilitate pattern analysis by SOM consultants. (*Refer Figure 1*)

Faults (new and existing) are re-analysed every 10 minutes.

A Check code field allows the user to mark off patterns with the determination made/action taken.

A SOM Administrator option allows SOM managers and complex consultants to adjust fault pattern display thresholds and to make some other basic changes (e.g. to add or remove symptom and/or check-off codes) in response to operational requirements.

There are 4 different fault Patterners within the Pattern Manager application:

- **CAN Patterner 6.0**



- 
- Implement automatic NODS creation from Priority Patterns
  - Implement manual creation of NODS direct from within Pattern Manager
  - Improve fault patterning and display by adding additional functions:
  - Gateway in all Patterners
  - Exchange in Switch Patterner
  - Full network address for AXE and System 12 Switches
  - 'Update All' capability
  - Update User Management to align with current business roles and security requirements.

In parallel with the NODS/Pattern Manager Enhancement, the newly developed Mozart CONEN to NODS solution on the PUMA platform developed by Telstra Service Ops (TSO) Network Automations enables NODS to be created automatically from CONEN notifications raised by Service Assurance Ops (SAO) for network incidents (i.e. unplanned outages affecting core network).

## 5. User Profiles

There are 5 User Profiles or Access Levels available in the combined NODS-Pattern Manager web application:

- **Level 3 NODS-PM**

- System developers and IT support only
- Access to all functions

- **Level 2 NODS-PM**

- Systems Security and Access only
- Access to user management functions only

- **Super User NODS-PM**

- Typically SOM Complex Consultants
- Able to create NODS; able to update, cease user & interface created NODS
- Able to view and update Pattern Manager
- Able to access and change Pattern Manager Configuration settings

- **Read/Write NODS-PM**

- 
- Typically SOM Simplex Consultants & CNSC Data and Afterhours Testers
  - Able to create NODS; able to update, cease user & interface created NODS
  - Able to view and update Pattern Manager

- **Read/Write NODS**

- Typically SOM Partner agents
- Able to create NODS; able to update, cease user & interface created NODS
- NOTE: This profile does NOT include access to Pattern Manager

- **Read-only PM**

- Typically GOC consultants
- Able to view Pattern Manager only (i.e. Read-only)

**NOTE:** This profile does NOT include access to NODS

## 6. Get Access to Pattern Manager

Pattern Manager is now bundled with NODS. New Access or changes to existing access level to NODS-Pattern Manager web-application is by online request via the Telstra Intranet.

The stand-alone Read-Only Pattern Manager access level must also be requested via the NODS New access form.

- MyIT website
- Log an IT fault or service request
- Service Desk Online
- Software Applications
- NODS – National Outage Database System
- Then select either:
  - NODS New Access
    - To apply for new access to NODS-Pattern Manager application
  - NODS/Modify/Delete
    - To modify access level or delete access to NODS-Pattern Manager application
  - NODS Password Reset



- 
- For NODS-Pattern Manager application password reset
  - NODS Fault
    - For faults with the NODS-Pattern Manager application (e.g. unable to log in, slow response, etc.)

New or changed access requests will need to specify the required access level according to the user's business role (refer section 7) and will require the approval of the user's one up manager.

**NOTE:** The previous generic logins for Read-only access to Pattern Manager are no longer available. Users requiring Read-only access to Pattern Manager must apply for an individual Account-01 login and password via MyIT as above.

## 7. Login & Navigation


The following sections describe how to login and navigate to the main NODS-Pattern Manager UI and in the dedicated Pattern Manager application.

### 7.1. Log in to NODS-PM

Pattern Manager is bundled with NODS in the NODS-Pattern Manager Web UI.

To Log into NODS-Pattern Manager web application follow these steps:

1. Click on the URL <https://nods:8443/NODS/login>
2. At the Log In screen enter your Telstra account-01 User ID & password ('LAN Log in')
3. Click Submit button
4. The Welcome to NODS Home Menu screen displays




### 7.2. Home Menu Screen

Depending on user Access level, the following menu items may be available as hyperlinks to access required NODS and Pattern Manager functions:

- Active Outage Search
- Archive Outage Search
- Create Outage

- Admin Menu
- Pattern Manager



**NOTE:** User Admin option is only visible to and accessible by L2 Access and L3 System Admin. Other users will see a blank space.

**NOTE:** Read-only users of Pattern Manager will only see and only have access to the Pattern Manager option on the Home Screen. All other options will be blanked out.


### 7.3. Basic Navigation

Navigation within web NODS-PM is very simple:


- Click the required menu hyperlink to access that option
- Click Home hyperlink at top left at any time to return to the Home menu
- Click Logout in top right corner to log out of NODS Pattern Manager web application
- Click the browser back arrow to view the previous screen

### 7.4. Log into Pattern Manager

At the NODS-PM Home menu, click Pattern Manager link.




Pattern Manager Home menu screen will display which provides access to the 4 Patterners and to other Pattern Manager functions. Refer Section 6.5 for more detail.



## 7.5. Pattern Manager Home Menu screen

The Pattern Manager Home screen contains a menu of 6 hyperlinked options used to access all the functions of Pattern Manager:

- **CAN Patterner Version 6.0**
  - Click to view & analyse related fault patterns on CAN cables
- **PGS Patterner Version 6.0**
  - Click to view & analyse related fault patterns on PGS
- **Switch Patterner Version 6.0**
  - Click to view & analyse related fault patterns on Exchange Switches
- **Broadband CAN Patterner Version 2.0**
  - Click to view & analyse related broadband fault patterns on CAN cables
- **Priority Outage Dashboard**
  - Click to view & analyse Priority fault patterns & auto-created NODS
- **Pattern Manager Admin Version 2.0**
  - Click to view & modify fault patterner configuration settings




## 7.6. Pattern Manager Navigation

Basic navigation methods within Pattern Manager are the same as those for the NODS-Pattern manager application in general. Refer section 6.3 above.

Some specific navigation options within various Pattern Manager screens will be described within the each relevant section later on in this document.

When users are on any Pattern Manager screen a '**Pattern Manager Home**' link will always be available at the top centre of the screen to enable quick navigation back to the main Pattern Manager Home menu.

Users can also click the **Home** link to go right back to the main NODS-PM menu screen.



**National Outage Database System**

[Home](#) [Pattern Manager Home](#)

### CAN PATTERNER 6.0

Albany Creek (ABCK) [UPDATE](#) [Create NODS](#)

exch	tot	new	HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1
ABCK	14	8						Select ▼		Select ▼				Select ▼			
ARUN	10	6	P	S	B	0733252830	28/11/16	08:03	NTN	40	42						
BUDE	32	2	P	S	B	0733251428	29/11/16	08:54	NTN	40	70						
CPBA	60	8															

BRIS | [printable](#)  
as at 30-11-2016 21:38  
75% checked

exch	tot	new
ABCK	14	8
ARUN	10	6
BUDE	32	2
CPBA	60	8

## 8. CAN Patterner Version 6.0

CAN Patterner 6.0 forms and displays fault patterns related by a common CAN copper cable network element e.g. main cable, cabinet, gateway, pillar or control joint.

Click the CAN Patterner Version 6.0 link from the Pattern Manager home screen to access CAN Patterner.

### 8.1. Select Region

When the CAN Patterner Version 6.0 link is clicked, the CAN Patterner Region Dashboard will open displaying the various geographical regions of the PSTN network and the number of patterned faults in each.

The Region Dashboard allows a user to:

- **Quickly assess the relative volumes of patterned faults per region**
  - MO = Mode of Operations – the number of faults which must meet patterning criteria before a fault pattern will display in that region
  - TOT = total number of patterned faults per region
  - NEW = number of patterned faults in region not yet analysed and actioned
  - % = percentage of patterned faults in region not yet analysed and actioned
- **Determine the region requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required region by clicking the Region name link**
  - Regions are state-based with metro and country areas of the same state grouped together
  - Regions are listed geographically North to South; East to West

[Home](#)
[Pattern Manager Home](#)
[Logout](#)

# CAN PATTERNER 6.0

Welcome c687775  
please click here for [HELP](#)

MO	REGION	TOT	NEW	%
5	<a href="#">Melbourne</a>	183	61	66
5	<a href="#">New South Wales North</a>	235	2	99
5	<a href="#">New South Wales South</a>	40	32	20
5	<a href="#">Queensland Country</a>	50	14	72
5	<a href="#">Brisbane</a>	293	101	65
5	<a href="#">South Australia and Northern Territory</a>	79	41	48
5	<a href="#">Sydney North</a>	62	34	45
5	<a href="#">Sydney South</a>	28	8	71
5	<a href="#">Victoria and Tasmania</a>	39	38	2
5	<a href="#">Western Australia</a>	36	29	19

[HELP](#)

[HELP](#)

## 8.2. Select Exchange

When a Region link is clicked, the CAN Patternner Exchange List will open displaying the various exchanges which contain fault patterns and the number of patterned faults in each.

To the right of the Exchange List a version history gives details of the changes introduced in each successive version of Pattern Manager.

The Exchange List allows a user to:

- **Quickly assess the relative volumes of patterned faults per exchange**
  - tot = total number of patterned faults per exchange
  - new = number of patterned faults in exchange not yet analysed and actioned
  - Above the exchange list are displayed:
    - Region name
    - 'Printable' link providing plain text view of region
    - Last refresh date
    - % faults unchecked in region
  - Below the exchange list are displayed:
    - Total faults in region
    - Number unchecked faults in region
- **Determine the exchange requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required exchange by clicking the Region name link**
  - Regions are listed alphabetically

[Home](#)
[Pattern Manager Home](#)
[Logout](#)

### CAN PATTERNER 6.0

[WA](#) | [printable](#)  
as at 05-12-2016 13:34  
**19% checked**

exch	tot	new
<a href="#">MOLD</a>	9	5
<a href="#">MDNA</a>	12	11
<a href="#">TUTU</a>	10	8
<a href="#">YANP</a>	5	5

36 faults, 29 unchecked

**CAN Pattern Manager Version 6.0**

**CAN Patternner Version 6.0 (Fri 18-Nov-16)**

The following changes have been made:

1. Pattern Manager has been moved onto the new NODS platform Web GUI to enable automated NODS creation
2. Pattern Manager will automatically create a NODS outage notification whenever a CAN fault pattern meets Priority Patternner criteria as configured by SOM
3. A 'Create NODS' push-button and network element and pair range selection fields have been added to enable the user creation of NODS direct from CAN patternner
4. When a NODS has been auto-created or push-created, the NODS ID will now display in a new NODS ID column. The NODS ID acts as a hyperlink to the NODS record.
5. New columns have been added to display 'Gateway' and Gateway 'o pair'.
6. Patterns will form on Gateways according to the standard CAN patterning rules.
7. A new Check-off code 'AVH' ('Automatic Volume Hold') has been added for when a pattern has been identified as a priority pattern and a NODS has been auto-created
8. A single check-off code selection drop down list has been added to enable rapid checking-off of multiple faults.
9. Individual checkboxes have been added against all rows to enable rapid selection of faults for checking off or de-checking.
10. An Update All checkbox has been added to enable rapid checking off of all faults on the patternner screen

**No Other Changes are made to the CAN Patterning rules**

## 8.3. CAN Exchange screen

When an Exchange is clicked, the Exchange screen will present, displaying any related fault patterns present in the exchange along with key information to assist with initial analysis.

---

Exchange List remains visible at left to allow quick selection of the next exchange.

The main section of the screen displays basic details of customer faults reports which meet CAN patterning criteria (see next section 8.4).

The following details are displayed from left to right in the middle section of the screen

- HP Hyperlinks – if the fault also appears in a fault pattern in another Patternner (e.g. PGS) the hyperlink letter will be bold and underlined:
  - P (PGS) – S (Switch) – B (BB CAN)
- Faulty FNN (Full National Number)
- Date & Time of fault report
- Fault Symptom code (e.g. NTN – No Tone)
- CAN Network Elements
  - Main cable/mpair – Cabinet/bpair – Gateway/opair – Pillar/opair – Control Joints/opair
  - Only the first 2 Control Joints from the exchange end are displayed
  - If a Network Element column is blank, that type of network element is not present in that FNN's service

NOTE: to simplify the display and make analysis easier, only CAN network elements are displayed in CAN Patternner. To see Pair Gain Systems or Switch devices present in a service or pattern it is necessary to use the hyperlinks (if active) or consult Shazbot or NPAMS.

- 'X' – Service Type as recorded in NPAMS e.g. XR = ADSL service – SS = PSTN service (see table section 14.6)
- NODS ID
  - If a NODS has been created automatically by Priority Patternner or manually from within CAN Patternner, the NODS ID will display here
  - NODS manually created in native NODS will NOT display
  - NODS auto-created by Mozart or other external interfaces will NOT display
- User ID of the user who has Checked off the fault pattern
- Check List ('Chk\_1st') indicating determination made/action taken on fault pattern e.g. CVH – Confirmed Volume Hold – NYV – Not Yet Volume Hold (refer table section 14.8)

National Outage Database System

Home

Pattern Manager Home

Logout

WA | printable  
as of 05-12-2016 13:34  
19% checked

exch

MDLD

MDNA

TUIT

YANP

36 faults,  
29  
unchecked

tot

9

12

10

5

new

5

11

8

5

Yanchep (YANP)

UPDATE

Create NODS

No Selection

UPDATE ALL

CAN PATTERNER 6.0

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_lst	
					<div>Select</div>	<div></div>					<div>Select</div>	<div></div>	<div>Select</div>	<div></div>							
P S B	0895611276	02/12/16	14:46	NTN	1	1422					20	407	CJ24	145	CJ2	39	LB			Test-Pending	
P S B	0895611274	02/12/16	15:20	NTN	2	400					20	431	CJ24	142	CJ2	35	LA			Test-Pending	
P S B	0895611277	02/12/16	15:22	NTN	2	395					20	425	CJ24	149	CJ2	36	LA			Test-Pending	
P S B	0895612231	03/12/16	08:41	NTN	1	1467					20	430	CJ24	148	CJ2	30	XR			Test-Pending	
P S B	0895612411	04/12/16	16:48	NTN	1	1414					20	409	CJ24	147	CJ2	7	SS			Field-Open	

end YANP as c637775 5 frm(s)

last refresh: Sun Dec 4 21:34:52 2016 EST

## 8.4. CAN Fault Patterning Rules

In CAN Patterner there are separate rules for:

- Forming a pattern of faults
- Displaying a pattern of faults
- Special CAN Patterning & Display Rules

### 8.4.1. Form CAN fault pattern

A related fault pattern will form **in the background** in CAN Patterner whenever:

- 2 or more SIIAM customer trouble reports meet the following criteria:
  - Symptom code is one of: CBO, CTK, EXO, ICP, NSF, NSY, NTN, NWO, OGP, PLR, SSI, SSS, TSM, UCC, ULI, ULL, VMT, CCO, COS, DTP, DTI, DTG, DTD, DTH, and...
  - Faults are in the same Exchange Service Area (ESA) and...
  - Faults are in the same Pillar or...
  - Where there is no pillar, in the same Control Joint (closest to the exchange) or...
  - Where there is no Pillar or Control Joint, in the same Gateway
  - Where there is no Gateway, in the same Cabinet or...
  - Where there is no Pillar, Control joint, Gateway or Cabinet, in the same Main Cable and...
  - The O, branch or main pair is within 30 pairs of the lowest pair in the pattern
- Fault pattern will be retained for 72 hours from fault report date or for the timeframe configured by SOM in the 'Update Age of Pattern Data' table of Pattern Manager Admin 2.0
- Only the valid Symptom Code and Age of Pattern Data timeframe rules can be changed by SOM. Changes can only be made by a user with NODS-PM Super User Access Level via the Pattern Manager Admin function. All other rules are hard coded into Pattern Manager.

**NOTE:** ADSL Symptom codes for connectivity issues most indicative of exchange line problems have been added to the normal exchange line symptom code list.



### 8.4.2. Display CAN fault pattern

While a basic CAN fault pattern will ALWAYS form in the background of CAN Patterner, fault patterns will only become visible in an Exchange screen in CAN Patterner when the following criteria are met:

- The above patterning rules have been met and patterns have formed in the background
- The number of patterned faults is equal to or greater than the patterning threshold configured by SOM in the Update Patterning Threshold' table of Pattern Manager Admin 2.0

For example, when the Threshold Setting is set to '5' a fault pattern will only display when there are 5 patterned faults in the same exchange and the same pillar, etc.

- Faults so displayed can be in the one 30 pair grouping or in a combination of 30 pair patterns

e.g. If the Threshold was set to 5 then the rule would be met if there were:

- 5 faults in one 30 pair group
  - E.g. P5 – pairs 3 + 9 +10 +18 +25
- 2 faults in one 30 pair group plus 3 faults in another 30 pair group or "2+3":
  - E.g. P5 – pairs 3 + 9 plus 74 + 87 + 91
- 2 faults in one 30 pair group plus 2 faults in another plus 2 faults in another or "2+2+2":
  - E.g. P5 – pairs 3 + 9 plus 51 + 56 plus 89+ 97
- Each 30 pair grouping is distinguished by a band of different background colour
- Only the 2 Control Joints (CJ) closest to the exchange are displayed
- CJ faults are only patterned on the CJ closest to the exchange. CJ 2 is display only

### 8.4.3. Special CAN patterning and display rules

In addition to the above basic CAN patterning and display rules there are some special rules:

- **Pair Gain Systems**
  - To simplify the display, PGS will not appear in CAN patterner network elements even when present in the service
  - If the FNN is also in a PGS pattern, the P (PGS) hyperlink will be active
  - The presence of PGS can also be suspected by the following evidence:
    - Access Large PGS = absence of main cable (although services fed by 'secondary' or 'out of area' PGS may have main cables and pairs)
    - CAN Electronic Small PGS = presence of CJ (although straight lines can also run through CJs)

- ADSL DSLAM = 'x' service type is XR or XS

- **Control Joints**

- Only the first CJ closest to the exchange will be used for patterning
- Only the first 2 CJs closest to the exchange will be visible
- Any subsequent CJs in the cable route will be ignored for patterning and will not be visible on the screen

- **Faults with no cable details**

- CAN Patterner will also display any faults which have no cable details whenever the exchange in which the fault occurs also has a valid displayed fault pattern

E.g. a case with no cable details is reported in an exchange but the current threshold for displaying fault patterns (5) has not yet been met – the no cable details case does not display. However, when a fault pattern meets the display criteria and appears in the exchange, so too will case with no cable details

- Faults with no cable details may have ANY Symptom code.
- Faults with no cable details generally occur for one of 5 main reasons:
  - A fault has been created for a service which is working over copper network which has now been asset transferred to Nbnco (known as 'Continuity' or CSLL services)
  - A fault has been created for a data line where the cable details have not been available from NPAMS to populate the Cable Details tab
  - A fault has been created for the exchange or auxiliary line of an ISDN service
  - A fault has been created to log a fault on multiple services for a business
  - An error has occurred during case creation
- The details of DummyFNN faults must be investigated in SIIAM to determine whether or not they are related to the fault pattern in the exchange.

### CAN PATTERNER 6.0

Dromana\_ (DROM)

UPDATE

Create NODS

No Selection

UPDATE

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_ist
					Select						Select									
P S B	0359818898	04/12/16	08:52	NTN	4	481					603	481						XR		Test-Pending
P S B	1614902024	04/12/16	15:36	ULL	4	465					603	465						UL		Field-Open
P S B	0359870930	02/12/16	21:19	DTG	4	505					603	505						XR		Test-ADSL
P S B	1615527435	05/12/16	13:55	ULL	4	528					603	528						UL		Test-Pending
P S B	0359819499	03/12/16	08:58	NTN	4	572					603	572						XR		Test-Pending
P S B	0359818930	04/12/16	17:02	NTN	4	565					603	565						XR		Test-Accepted
P S B	0359819499	05/12/16	10:08	NTN	4	572					603	572						XR		Test-Pending
P S B	0359810326	05/12/16	19:48	NTN	4	573					603	573						XR		Test-Pending
P S B	0359810972	05/12/16	19:42	DTH																Field-Open
P S B	0359847300	28/11/16	14:44	NSF																Field-Open

end DROM as c687775 10 fnn(s)

last refresh: Mon Dec 5 05:06:33 2016 EST

## • DummyFNN cases

- CAN Patterner will also display any Plant & Equipment cases with a symptom code of UCC (Underground Cable Cut) whenever the exchange in which the fault occurs also has a valid displayed fault pattern
- Plant & Equipment cases with a Symptom code of UCC are created whenever a damage is reported to an underground cable.

E.g. a UCC damage case is reported in an exchange but the current threshold for displaying fault patterns (5) has not yet been met – the DummyFNN case does not display. However, when a fault pattern meets the display criteria and appears in the exchange, so too will the UCC DummyFNN case

- Damage related P&E cases have an FNN formed from the text 'DummyFNN' and the Case number e.g. 'DummyFNN131234567'. In CAN Patterner this FNN will appear shortened by replacing the 'DummyFNN' with an asterisk e.g. '\*131234567'
- The details of DummyFNN faults must be investigated in SIIAM to determine whether or not they are related to the fault pattern in the exchange.

### CAN PATTERNER 6.0

Print

PDF

Greenvale (GRLE)

UPDATE

Create NODS

No Selection

UPDATE

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_lst
					Select						Select									
P S B	0393333515	02/12/16	22:20	NTN	1	2205					3	385					XR	d270503	CVH	
P S B	0393334104	03/12/16	14:33	DTH	1	2249					3	374					XR	d270503	CVH	
P S B	0393331700	03/12/16	16:57	NSF	1	2129					3	379					XR	d270503	CVH	
P S B	0393336018	03/12/16	18:35	NTN	1	2124					3	383					XS	d270503	CVH	
P S B	0393333830	05/12/16	20:09	NTN	1	2128					3	378					XR	d270503	Outage-Child	
P S B	*162324533	30/11/16	08:50	UCC														d270503	NYV	

end GRLE as c687775 6 fnn(s)

last refresh: Mon Dec 5 05:06:53 2016 EST

end GRLE as c687775 6 fnn(s)

last refresh: Mon Dec 5 05:06:53 2016 EST

## 8.5. Analyse CAN Fault Pattern

A related fault pattern in CAN Patterner is only an indication of a potential outage. To confirm the presence of an outage to a single network element having caused all the faults in the pattern, further detailed investigation and analysis must be conducted by SOM Complex Consultants using both the information in Pattern Manager itself and in external systems.

The below sequence describes the basic general approach:

1. Investigate fault and network detail within the CAN pattern e.g. fault report times, symptom codes and contiguity of affected pairs
2. Use hyperlinks to compare fault and network detail in other Patterners e.g. which fault pattern gives the clearer and more compelling evidence
3. Investigate individual customer and fault details of each FNN in pattern, e.g. SIIAM case details, history and notes
4. Run a SIIAM query to identify any related faults which did not meet patterning display criteria

- 
5. Investigate customer type and address patterns and pair occupancy of range in CASINO (Clarification of Affected Services in Network Outage) tool or NPAMS
  6. Check cable location and route and relative location of faults using GDD (Graphical Data Display) network maps
  7. Test services in SULTAN particularly when there is an apparent gap in the affected range ("testing within the range")
  8. Ring CT's or Team leaders for more information

### 8.6. Create NODS from CAN Patternner

If an outage has been confirmed on a CAN network element included in the fault pattern, create a NODS notification directly from within CAN Patternner using the 'Create NODS' button.

This provides the quickest response to the outage and ensures that FOH consultants and customers will be advised of the outage at the earliest opportunity.

Follow these basic steps:

1. Select the affected network element e.g. Main Cable or Pillar ID using the Network Element selection field
2. Enter the affected pair range in the Pair Selection field e.g. 1-50
3. Click the 'Create NODS' button
4. After a brief pause the NODS ID that has been created will display in the NODs ID column
5. The NODS can be opened directly using this link, allowing changes to be made (e.g. adding Parent case and CONEN IDs)

NOTE: Round out to the actual pair range of the affected cable as determined by investigation of CASINO, NPAMS and/or GDD e.g. a pattern in comprising related faults on a common Pillar P5 between 7 and 46 would typically be rounded out to the standard size of a 50 pair cable (pairs 1-50) once further investigation (e.g. in SIIAM and SULTAN) had confirmed that there were no faults beyond pair 50.

Refer also Section 14.5

CAN PATTERNER 6.0

Carmilla (CARM) UPDATE

Create NODS

No Selection UPDATE ALL

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_1st		
P	<a href="#">S</a>	B	0749502356	29/11/16	17:33	UCC					1	98									Field-Open	<input type="checkbox"/>
P	<a href="#">S</a>	B	0749502284	29/11/16	19:01	NTN					1	96									Field-Open	<input type="checkbox"/>
P	<a href="#">S</a>	B	0749502254	29/11/16	19:06	NTN					1	100									Field-Open	<input type="checkbox"/>
P	<a href="#">S</a>	B	0749502236	29/11/16	19:08	NTN					1	93									Field-Open	<input type="checkbox"/>
P	<a href="#">S</a>	B	0749502274	30/11/16	09:28	NTN					1	83									Field-Open	<input type="checkbox"/>
P	<a href="#">S</a>	B	QCARME5002	30/11/16	13:46	NSF															Field-Open	<input type="checkbox"/>

end CARM as c587775 6 fnn(s)

last refresh: Wed Nov 30 19:04:44 2016 EST

### 8.7. Check off CAN Fault Pattern

Once the pattern has been analysed and a determination made as to the findings and the action to be taken, each fault in the pattern must be 'checked off' to indicate this finding/action e.g. CVH = Confirmed Volume Hold or NYV = Not Yet Volume Hold.

Initially, when first appearing, faults in a pattern will display the SIIAM case status of the fault when it first met Pattern Manager criteria e.g. Test-Pending or Field-Open.

There are 3 methods of applying a check-off code:

1. Apply a common code to all faults in the Exchange using the Update All function
2. Apply a common code to selected faults in the Exchange using the selection boxes
3. Apply a single code to each individual fault using the individual drop down lists

To apply a check off action code to each fault in the pattern follow these basic steps:

1. Choose the most appropriate Check off method from the above e.g. if all faults in the exchange are part of the one outage use Method 1
2. Apply the correct code
3. Click the Update or Update All buttons to save the code and update the exchange display and the totals in the Exchange list and Region Dashboard

**NOTE:** Users with a PM Read-only Access Level can view the Check off code that has been applied by SOM but are unable to add or change Check off codes.

For detailed instructions on the above, refer section 14.7

For a table of valid check off codes and their meanings refer to section 14.8

Carmilla (CARM) UPDATE Create NODS

No Selection UPDATE ALL

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS	ID	CHK	Ist		
<a href="#">P</a>	<a href="#">S</a>	B	0749502356	29/11/16	17:33	UCC					1	98											
<a href="#">P</a>	<a href="#">S</a>	B	0749502284	29/11/16	19:01	NTN					1	96											
<a href="#">P</a>	<a href="#">S</a>	B	0749502254	29/11/16	19:06	NTN					1	100											
<a href="#">P</a>	<a href="#">S</a>	B	0749502236	29/11/16	19:08	NTN					1	93											
<a href="#">P</a>	<a href="#">S</a>	B	0749502274	30/11/16	09:28	NTN					1	83											
<a href="#">P</a>	<a href="#">S</a>	B	0749502027	01/12/16	10:46	NTN					1	94											
<a href="#">P</a>	<a href="#">S</a>	B	QCARME5002	30/11/16	13:46	NSF																	

end CARM as c687775 7 fnn(s)

## 9. PGS Patterner Version 6.0

PGS Patterner 6.0 forms and displays fault patterns related by a common Pair Gain System network element e.g. Access Core Large PGS or CAN Electronic Small PGS.

Click the PGS Patterner Version 6.0 link from the Pattern Manager home screen to access PGS Patterner.

### 9.1. Select Region

When the PGS Patterner Version 6.0 link is clicked, the PGS Patterner Region Dashboard will open displaying the various geographical regions of the PSTN network and the number of patterned faults in each.

The Region Dashboard allows a user to:

- **Quickly assess the relative volumes of patterned faults per region**
  - MO = Mode of Operations – the number of faults which must meet patterning criteria before a fault pattern will display in that region
  - TOT = total number of patterned faults per region
  - NEW = number of patterned faults in region not yet analysed and actioned
  - % = percentage of patterned faults in region not yet analysed and actioned
- **Determine the region requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required region by clicking the Region name link**
  - Regions are state-based with metro and country areas of the same state grouped together
  - Regions are listed geographically North to South; East to West

[Home](#)
[Pattern Manager Home](#)
[Logout](#)

PGS PATTERNER 6.0

Welcome c687775

please click here for [HELP](#)

MO	REGION	TOT	NEW	%
4	<a href="#">Melbourne</a>	10	10	0
4	<a href="#">New South Wales North</a>	126	71	43
4	<a href="#">New South Wales South</a>	47	41	12
4	<a href="#">Queensland Country</a>	42	28	33
4	<a href="#">Brisbane</a>	236	175	25
4	<a href="#">South Australia and Northern Territory</a>	0	0	0
4	<a href="#">Sydney North</a>	29	29	0
4	<a href="#">Sydney South</a>	4	4	0
4	<a href="#">Victoria and Tasmania</a>	11	11	0
4	<a href="#">Western Australia</a>	63	62	1

HELP

[HELP](#)

## 9.2. Select Exchange

When a Region link is clicked, the PGS Patterner Exchange List will open displaying the various exchanges which contain fault patterns and the number of patterned faults in each.

To the right of the Exchange List a version history gives details of the changes introduced in each successive version of Pattern Manager.

The Exchange List allows a user to:

- **Quickly assess the relative volumes of patterned faults per exchange**

- tot = total number of patterned faults per exchange
- new = number of patterned faults in exchange not yet analysed and actioned
- Above the exchange list are displayed:
  - Region name
  - 'Printable' link providing plain text view of region
  - Last refresh date
  - % faults unchecked in region
- Below the exchange list are displayed:
  - Total faults in region
  - Number unchecked faults in region

- **Determine the exchange requiring the greatest focus**

- with the highest percentage of unchecked faults
- with the largest volume of unchecked faults

- **Access the required exchange by clicking the Region name link**

- Regions are listed alphabetically

[Home](#)
[Pattern Manager Home](#)
[Logout](#)

**QLDC** [\[printable\]](#)  
as at 05-12-2016 10:31  
30% checked

exch	tot	new
<a href="#">BTPE</a>	4	4
<a href="#">KROY</a>	7	7
<a href="#">MOTH</a>	11	7
<a href="#">MTME</a>	4	5
<a href="#">TBAY</a>	11	2
<a href="#">WALV</a>	4	4

42 faults, 29 unchecked

Pattern Manager PGS Version 6.0

---

**PGS Patterner Version 6.0 (Fri 18-Nov-16)**

**The following changes have been made:**

1. Pattern Manager has been moved onto the new NODS platform Web GUI to enable automated NODS creation
2. Pattern Manager will automatically create a NODS outage notification whenever a PGS fault pattern meets Priority Pattern criteria as configured by SOM
3. A 'Create NODS' push-button and network element and panel & slot selection fields have been added to also enable the user creation of NODS direct from PGS pattern.
4. When a NODS has been auto-created or push-created, the NODS ID will now display in a new NODS ID column. The NODS ID acts as a hyperlink to the NODS record.
5. New columns have been added to display 'Gateway' and Gateway 'o pair'.
6. A new Check-off code 'AVH' ('Automatic Volume Hold') has been added for when a pattern has been identified as a priority pattern and a NODS has been auto-created
7. A single check-off code selection drop down list has been added to enable rapid checking-off of multiple faults.
8. Individual checkboxes have been added against all rows to enable rapid selection of faults for checking off or de-checking.
9. An Update All checkbox has been added to enable rapid checking off of all faults on the pattern screen

**No Other Changes have been made to the PGS Patterning display or rules**

**PGS Patterner Version 5.5 (Fri 08-Oct-2010)**

## 9.3. PGS Exchange screen

When an Exchange is clicked, the Exchange screen will present, displaying any related fault patterns present in the exchange along with key information to assist with initial analysis.



---

Exchange List remains visible at left to allow quick section of the next exchange.

The main section of the screen displays basic details of customer faults reports which meet PGS patterning criteria (see next section 9.4).

The following details are displayed from left to right in the middle section of the screen

- HP Hyperlinks – if the fault also appears in a fault pattern in another Patterner (e.g. PGS) the hyperlink letter will be bold and underlined:
  - C (CAN) – S (Switch) – B (BB CAN)
- Faulty FNN (Full National Number)
- Date & Time of fault report
- Fault Symptom code (e.g. NTN – No Tone)
  - PGS & basic CAN Network Elements
  - Access Core large PGS ID – Type – P/S/C (Panel/Slot/Channel) e.g. CMUX or RIM
  - Main cable/mpair – Cabinet/bpair – Gateway/opair – Pillar/opair
  - CAN Electronic small PGS ID – Type – P/S/C e.g. 6/16 or RAM 8
  - If a Network Element column is blank, that type of network element is not present in that FNNs service

NOTE: to simplify the display and make analysis easier, only Access and CAN Electronic PGS and basic CAN network elements are displayed in PGS Patterner. To see other CAN or Switch devices present in a service or pattern it is necessary to use the hyperlinks (if active) or consult Shazbot or NPAMS.

- 'X' – Service Type as recorded in NPAMS e.g. XR = ADSL service – SS = PSTN service (see table section 14.6)
- NODS ID
  - If a NODS has been created automatically by Priority Patterner or manually from within CAN Patterner, the NODS ID will display here
  - NODS manually created in native NODS will NOT display
  - NODS auto-created by Mozart or other external interfaces will NOT display
- User ID of the user who has Checked off the fault pattern
- Check List ('Chk\_Lst') indicating determination made/action taken on fault pattern e.g. CVH – Confirmed Volume Hold – NYV – Not Yet Volume Hold (refer table section 14.8)

**NOTE:**

The left hand PGS columns display details for Access Core Large PGS e.g. CMUX, RIM, RCM, DCS20 and SSNMUX

The right hand PGS columns display details for CAN Electronic Small PGS e.g. 2/4 DPGS, RAM 8, 6/15-16, 16/96, SCaDS

ADSL DSLAM PGS do not display in PGS patterner – they display in BB CAN Patterner.

Home

Pattern Manager Home

Logout

Pattern Manager PGS Version 6.0

Shelford (SHEF)

UPDATE

Create NODS

No Selection

UPDATE ALL

VICT printable

as at 05-12-2016

13:07

0% checked

exch tot new

SHEE 8 8

YAHA 7 7

15 faults, 15 unchecked

12345678910111213141516171819202122232425262728293031323334353637383940414243444546474849505152535455565758596061626364656667686970717273747576777879808182838485868788899091929394959697989910010110210310410510610710810911011111211311411511611711811912012112212312412512612712812913013113213313413513613713813914014114214314414514614714814915015115215315415515615715815916016116216316416516616716816917017117217317417517617717817918018118218318418518618718818919019119219319419519619719819920020120220320420520620720820921021121221321421521621721821922022122222322422522622722822923023123223323423523623723823924024124224324424524624724824925025125225325425525625725825926026126226326426526626726826927027127227327427527627727827928028128228328428528628728828929029129229329429529629729829930030130230330430530630730830931031131231331431531631731831932032132232332432532632732832933033133233333433533633733833934034134234334434534634734834935035135235335435535635735835936036136236336436536636736836937037137237337437537637737837938038138238338438538638738838939039139239339439539639739839940040140240340440540640740840941041141241341441541641741841942042142242342442542642742842943043143243343443543643743843944044144244344444544644744844945045145245345445545645745845946046146246346446546646746846947047147247347447547647747847948048148248348448548648748848949049149249349449549649749849950050150250350450550650750850951051151251351451551651751851952052152252352452552652752852953053153253353453553653753853954054154254354454554654754854955055155255355455555655755855956056156256356456556656756856957057157257357457557657757857958058158258358458558658758858959059159259359459559659759859960060160260360460560660760860961061161261361461561661761861962062162262362462562662762862963063163263363463563663763863964064164264364464564664764864965065165265365465565665765865966066166266366466566666766866967067167267367467567667767867968068168268368468568668768868969069169269369469569669769869970070170270370470570670770870971071171271371471571671771871972072172272372472572672772872973073173273373473573673773873974074174274374474574674774874975075175275375475575675775875976076176276376476576676776876977077177277377477577677777877978078178278378478578678778878979079179279379479579679779879980080180280380480580680780880981081181281381481581681781881982082182282382482582682782882983083183283383483583683783883984084184284384484584684784884985085185285385485585685785885986086186286386486586686786886987087187287387487587687787887988088188288388488588688788888989089189289389489589689789889990090190290390490590690790890991091191291391491591691791891992092192292392492592692792892993093193293393493593693793893994094194294394494594694794894995095195295395495595695795895996096196296396496596696796896997097197297397497597697797897998098198298398498598698798898999099199299399499599699799899910001001100210031004100510061007100810091010101110121013101410151016101710181019102010211022102310241025102610271028102910301031103210331034103510361037103810391040104110421043104410451046104710481049105010511052105310541055105610571058105910601061106210631064106510661067106810691070107110721073107410751076107710781079108010811082108310841085108610871088108910901091109210931094109510961097109810991100110111021103110411051106110711081109111011111112111311141115111611171118111911201121112211231124112511261127112811291130113111321133113411351136113711381139114011411142114311441145114611471148114911501151115211531154115511561157115811591160116111621163116411651166116711681169117011711172117311741175117611771178117911801181118211831184118511861187118811891190119111921193119411951196119711981199120012011202120312041205120612071208120912101211121212131214121512161217121812191220122112221223122412251226122712281229123012311232123312341235123612371238123912401241124212431244124512461247124812491250125112521253125412551256125712581259126012611262126312641265126612671268126912701271127212731274127512761277127812791280128112821283128412851286128712881289129012911292129312941295129612971298129913001301130213031304130513061307130813091310131113121313131413151316131713181319132013211322132313241325132613271328132913301331133213331334133513361337133813391340134113421343134413451346134713481349135013511352135313541355135613571358135913601361136213631364136513661367136813691370137113721373137413751376137713781379138013811382138313841385138613871388138913901391139213931394139513961397139813991400140114021403140414051406140714081409141014111412141314141415141614171418141914201421142214231424142514261427142814291430143114321433143414351436143714381439144014411442144314441445144614471448144914501451145214531454145514561457145814591460146114621463146414651466146714681469147014711472147314741475147614771478147914801481148214831484148514861487148814891490149114921493149414951496149714981499150015011502150315041505150615071508150915101511151215131514151515161517151815191520152115221523152415251526152715281529153015311532153315341535153615371538153915401541154215431544154515461547154815491550155115521553155415551556155715581559156015611562156315641565156615671568156915701571157215731574157515761577157815791580158115821583158415851586158715881589159015911592159315941595159615971598159916001601160216031604160516061607160816091610161116121613161416151616161716181619162016211622162316241625162616271628162916301631163216331634163516361637163816391640164116421643164416451646164716481649165016511652165316541655165616571658165916601661166216631664166516661667166816691670167116721673167416751676167716781679168016811682168316841685168616871688168916901691169216931694169516961697169816991700170117021703170417051706170717081709171017111712171317141715171617171718171917201721172217231724172517261727172817291730173117321733173417351736173717381739174017411742174317441745174617471748174917501751175217531754175517561757175817591760176117621763176417651766176717681769177017711772177317741775177617771778177917801781178217831784178517861787178817891790179117921793179417951796179717981799180018011802180318041805180618071808180918101811181218131814181518161817181818191820182118221823182418251826182718281829183018311832183318341835183618371838183918401841184218431844184518461847184818491850185118521853185418551856185718581859186018611862186318641865186618671868186918701871187218731874187518761877187818791880188118821883188418851886188718881889189018911892189318941895189618971898189919001901190219031904190519061907190819091910191119121913191419151916191719181919192019211922192319241925192619271928192919301931193219331934193519361937193819391940194119421943194419451946194719481949195019511952195319541955195619571958195919601961196219631964196519661967196819691970197119721973197419751976197719781979198019811982198319841985198619871988198919901991199219931994199519961997199819992000200120022003200420052006200720082009201020112012201320142015201620172018201920202021202220232024202520262027202820292030203120322033203420352036203720382039204020412042204320442045204620472048204920502051205220532054205520562057205820592060206120622063206420652066206720682069207020712072207320742075207620772078207920802081208220832084208520862087208820892090209120922093209420952096209720982099210021012102210321042105210621072108210921102111211221132114211521162117211821192120212121222123212421252126212721282129213021312132213321342135213621372138213921402141214221432144214521462147214821492150215121522153215421552156215721582159216021612162216321642165216621672168216921702171217221732174217521762177217821792180218121822183218421852186218721882189219021912192219321942195219621972198219922002201220222032204220522062207220822092210221122122213221422152216221722182219222022212222222322242225222622272228222922302231223222332234223522362237223822392240224122422243224422452246224722482249225022512252225322542255225622572258225922602261226222632264226522662267226822692270227122722273227422752276227722782279228022812282228322842285228622872288228922902291229222932294229522962297229822992300230123022303230423052306230723082309231023112312231323142315231623172318231923202321232223232324232523262327232823292330233123322333233423352336233723382339234023412342234323442345234623472348234923502351235223532354235523562357235823592360236123622363236423652366236723682369237023712372237323742375237623772378237923802381238223832384238523862387238823892390239123922393239423952396239723982399240024012402240324042405240624072408240924102411241224132414241524162417241824192420242124222423242424252426242724282429243024312432243324342435243624372438243924402441244224432444244524462447244824492450245124522453245424552456245724582459246024612462246324642465246624672468246924702471247224732474247524762477247824792480248124822483248424852486248724882489249024912492249324942495249624972498249925002501250225032504250525062507250825092510251125122513251425152516251725182519252025212522252325242525252625272528252925302531253225332534253525362537253825392540254125422543254425452546254725482549255025512552255325542555255625572558255925602561256225632564256525662567256825692570257125722573257425752576257725782579258025812582258325842585258625872588258925902591259225932594259525962597259825992600260126022603260426052606260726082609261026112612261326142615261626172618261926202621262226232624262526262627262826292630263126322633263426352636263726382639264026412642264326442645264626472648264926502651265226532654265526562657265826592660266126622663266426652666266726682669267026712672267326742675267626772678267926802681268226832684268526862687268826892690269126922693269426952696269726982699270027012702270327042705270627072708270927102711271227132714271527162717271827192720272127222723272427252726272727282729273027312732273327342735273627372738273927402741274227432744274527462747274827492750275127522753275427552756275727582759276027612762276327642765276627672768276927702771277227732774277527762777277827792780278127822783278427852786278727882789279027912792279327942795279627972798279928002801280228032804280528062807280828092810281128122813281428152816281728182819282028212822282328242825282628272828282928302831283228332834283528362837283828392840284128422843284428452846284728482849285028512852285328542855285628572858285928602861286228632864286528662867286828692870287128722873287428752876287728782879288028812882288328842885288628872888288928902891289228932894289528962897289828992900290129022903290429052906290729082909291029112912291329142915291629172918291929202921292229232924292529262927292829292930293129322933293429352936293729382939294029412942294329442945294629472948294929502951295229532954295529562957295829592960296129622963296429652966296729682969297029712972297329742975297629772978297929802981298229832984298529862987298829892990299129922993299429952996299729982999300030013002300330043005300630073008300930103011301230133014301530163017301830193020302130223023302430253026302730283029303030313032303330343035303630373038303930403041304230433044304530463047304830493050305130523053305430553056305730583059306030613062306330643065306630673068306930703071307230733074307530763077307830793080308130823083308430853086308730883089309030913092309330943095309630973098309931003101310231033104310531063107310831093110311131123113311431153116311731183119312031213122312331243125312631273128312931303131313231333134313531363137313831393140314131423143314431453146314731483149315031513152315331543155315631573158315931603161316231633164316531663167316831693170317131723173317431753176317731783179318031813182318331843185318631873188318931903191319231933194319531963197319831993200320132023203320432053206320732083209321032113212321332143215321632173218321932203221322232233223432253226322732283229323032313232323332343235323632373238323932403241324232433244324532463247324832493250325132523253325432553256325732583259326032613262326332643265326632673268326932703271327232733274327532763277327832793280328132823283328432853286328732883289329032913292329332943295329632973298329933003301330233033304330533063307330833093310331133123313331433153316331733183319332033213322332333243

## 9.4. PGS Fault Patterning Rules

In PGS Patterner there are separate rules for:

- Forming a pattern of faults
- Displaying a pattern of faults
- Special PGS Rules

### 9.4.1. Form PGS fault pattern

A related fault pattern will form **in the background** in PGS Patterner whenever:

- 2 or more SIIAM customer trouble reports meet the following criteria:
  - Symptom code is one of: CBL, CBO, CCO, CEF, COS, CTK, EXO, ICP, NSF, NSY, NTN, NWO, OGP, TSM, UCC, VMT, DTP, DTD, DTG, DTI, and...
  - Faults have a PGS type of:
    - Access Core (CMUX, SSNMUX, RIM, RCM or DCS20) and/or...
    - CAN Electronic (1+4W, 2DPGS, 4DPGS, RAM8 Ph1, RAM8 Ph2, RAM8V90, MLC 6/15, 6/16, 16/96 or SCADS) and...
  - Faults are in the same ESA and...
  - Faults are in the same PGS Id
- When faults contain both Access Core and CAN Electronic PGS the pattern will be formed on the PGS Id with the greatest number of faults
- Where there are equal numbers of faults with the same two PGS Id (i.e. Access Core and CAN Electronic), the pattern will be formed on the Access Core PGS
- Faults are retained in a pattern for 72 hours from report date.
- Fault pattern will be retained for 72 hours from fault report date or for the timeframe configured by SOM in the 'Update Age of Pattern Data' table of Pattern Manager Admin 2.0

- Only the valid Symptom Code and Age of Pattern Data timeframe rules can be changed by SOM. Changes can only be made by a user with NODS-PM Super User Access Level via the Pattern Manager Admin function. All other rules are hard coded into Pattern Manager.

**NOTE:** Fault patterns are NOT formed on other PGS types (e.g. DSLAM or CAN Radio)

**NOTE:** ADSL Symptom codes for connectivity issues most indicative of exchange line problems have been added to the normal exchange line symptom code list.

#### 9.4.2. Display PGS fault pattern

While a basic PGS fault pattern will ALWAYS form in the background of PGS Patterner, fault patterns will only become visible in an Exchange screen in PGS Patterner when the following criteria are met:

- The above patterning rules have been met and patterns have formed in the background
- The number of patterned faults is equal to or greater than the patterning threshold configured by SOM in the Update Patterning Threshold' table of Pattern Manager Admin 2.0 for PGS

For example, when the Threshold Setting is set to '4' a fault pattern will only display when there are 4 patterned faults in the same exchange and the same PGS ID, etc.

#### 9.4.3. CMUX patterning & display rules

Due the ability of CMUX (Customer Multiplexer) PGS to perform various network roles for a service according to the card and port type installed, PGS patterner uses some additional rules for CMUX patterning and display:

#### CMUX Master and Slave types

- CMUX are complex Pair Gain Systems which can function in a variety of ways and configurations to deliver a combination of telephony ('POTS' – Plain Old Telephone Service), broadband (ADSL), ISDN and/or narrowband special services (data lines).
- CMUX have 2 main physical configurations:
  - **Master**
    - An exchange based Network Unit (NU) feeding a remote based Access Unit (AU) either in the street or in a multi-storey building. Called a 'master' unit in common terminology.
    - Appear in Pattern Manager with a PGS ID like "E04003"
  - **Slave Unit**
    - An exchange based Network Unit (NU) feeding a series of remote Slave Units each with its own remote unit (AU). Each Slave Unit supplies services to a different geographical locality.
    - Slave Units appear separately in Pattern Manager with PGS ID like 'E04003/2, E04003/3, etc.'
- PGS Patterner 6.0 forms and displays patterns by treating Slave Units as a separate PGS Id:

- 4 faults each on a different Slave of the one PGS Id e.g. E7/2, E7/3, E7/5 and E7/7 will NOT form a valid pattern
- 4 faults on the same slave unit e.g. E7/6, E7/6, E7/6 and E7/6 will form a valid pattern
- Outages affecting multiple Slave Units will not appear until the threshold is reached for one of the affected Slave Units. As the threshold is reached for other Slave Units they too will appear – as separate colour-differentiated patterns – providing a clue to the widespread nature of the outage

Pattern Manager PGS Version 6.0

Sydenham (SHAM)

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR
					Select										
C	S	B	0393902444	02/12/16	14:23	DTD	E00058	CMUX	2/10/15	1	248	7	393	80	214

Pattern Manager PGS Version 6.0

Banora Point (BRPT)

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR
					Select										
C	S	B	0755130325	02/12/16	16:11	NTN	E00004/5	CMUX	1/14/17			1	35	22	152

### CMUX Network Role

- CMUX may function in a customer's service as either Access Core to provide exchange service (i.e. dial tone) in lieu of copper main cable or as DSLAM to provide ADSL internet service or both depending on the type of card or port used.
- In PGS Patterner 6.0 CMUX faults pattern and display according to the role the CMUX plays in providing customer service as indicated by the NPAMS Port type (refer Table 4):
  - Access Core (PSTN or ISDN)
  - DSLAM (ADSL)
  - Combination (Access Core and ADSL)

**Table CMUX network role and Port/card types**

Role	Port (card) Type
Access Core (PSTN) only	POTS*
Access Core (ISDN) only	2B1Q
DSLAM (ADSL) only	ADSL*
Combination (Access Core + DSL)	ADSP*, ADSLP*

- PGS Patterner will form a fault pattern on a CMUX whenever the card/port type is POTS, 2B1Q, ADSP or ADSLP i.e. Access Core or combination Access Core/DSL.
- PGS Patterner will NOT form fault patterns on a CMUX where the card/port type is ADSL (i.e. functioning as DSLAM in service only) although these faults may be included in otherwise valid patterns in which case the CMUX ADSL component will be "hidden" in the right hand PGS columns (as with other types of DSLAM) but will be indicated by the presence of an 'XR' or 'XS' ADSL 'X' code. These faults may also appear in other Patterners e.g. BB CAN Patterner
- Sometimes 2 different CMUX will be deployed to provide service to a customer FNN – one to provide telephony ('POTS') and another to provide Broadband ('ADSL') e.g. CMUX E7 (using 'POTS' card) and CMUX E2 (using 'ADSL2' card)
  - In these instances PGS Patterner will pattern on the Access Core CMUX and display it in the left hand PGS columns
- Sometimes different cards within the same CMUX will be used to provide service to a customer e.g. CMUX E7 ('POTS' card) and CMUX E7 (separate 'ADSL2' card)
  - In these instances PGS Patterner will pattern on and display the POTS component (Panel/Slot/Channel of 'POTS' card) of the CMUX in the left hand PGS columns

```

F 0755130325
L BRPT BZNR00 LIG 1708
CMUX C4 VUT
S BRPT E4 S27647 POTS [1/14/17]
UNIT ID: ISAM TOP HAT-BRPT E4022
C BRPT E4/5 C1047
ISAM 7330-240 I4 VUT
X BRPT E4022 X1047
T BRPT E4022 M123 DSL48P [1/4/27]
S BRPT E4022 S123 DSL48P [1/4/27]
C BRPT E4022 C93
D BRPT G1 O 35
D BRPT P22 O 152
  
```

Pattern Manager PGS Version 6.0

Banora Point (BRPT)

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	F
<u>C</u>	S	B	0755130325	02/12/16	16:11	NTN	E00004/5	CMUX								

## CMUX DSLAM catastrophic failure

Catastrophic failure of a CMUX which is only providing ADSL broadband service can **in rare circumstances** result in a loss of telephony service along with internet.

As PGS Patterner does not form or display patterns on faults where the CMUX is only providing ADSL (i.e. via an ADSL\* card/port) such an outage may not be immediately

obvious as a PSTN outage on that CMUX, although it is highly likely that in the event of an extensive failure the following patterns would be visible:


- **PGS Patterner** – a pattern BOTH PSTN ('NTN') and ADSL ('DT\*') on the CMUX POTS, RIM or other Access PGS which is providing the Exchange Access component of the customers' services
- **CAN Patterner** – pattern(s) BOTH PSTN ('NTN') and ADSL ('DT\*') on common Pillar, Cabinet or Main Cable
- **BB CAN Patterner** – pattern of ADSL faults on common Pillar, Cabinet or Main Cable displaying the failed CMUX in the right hand DSLAM column
- **Switch Patterner** – pattern of BOTH PSTN ('NTN') and ADSL ('DT\*') faults formed on common Switch Id with Device type 'LIG' or 'xxV' e.g. '30V'

SOM staff should contact SAO to confirm PSTN impact if in doubt.

#### 9.4.4. PGS in secondary exchange

Sometimes services are delivered by employing an Access PGS in a larger 'secondary' exchange to provide exchange access to a smaller sub-exchange. This is most commonly used in rural and remote areas. Typically the Remote Unit (RU) of the PGS will be co-located with exchange MDF in the sub-exchange building where the local main pairs will connect to the PGS C pairs. The RU then links back to the larger secondary exchange via its fibre link to the Exchange Unit (EU) of the PGS.

Fnn: 0248362161



This arrangement will result in the customer and their copper cable pairs (e.g. main cable and pillar) belonging to one exchange (e.g. LOST Lost River) and the Access PGS 'feeding' their service being in another exchange (e.g. GLBN Goulburn)

Pattern Manager will display this like:

- **In PGS Patterner:**
  - Pattern will form in exchange to which the customer and main cable belongs
  - PGS will display in this pattern without any indication of belonging to another exchange
  - The usual clue though is the presence of BOTH Access PGS AND Main Cable (normally an Access PGS REPLACES main cable)
- **In CAN Patterner:**
  - Pattern will form in exchange to which the customer and main cable belongs

- A clue may be the presence of BOTH a Main Cable AND an active hyperlink to PGS Patterner (providing a pattern has formed in PGS Patterner as well)

Home Pattern Manager Home

Pattern Manager PGS Version 6.0

NSWS | Printable as at 07-12-2016 08:57 | 16% checked

exch	tot	new	HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	PGS_Id	PGS_Type	P/S/C	X	NODS_ID
CANL	5	5																					
CRCE	9	9																					
KGLN	7	7																					
KNGA	7	1																					
LOST	5	5																					
MBTN	6	6																					
MDAL	4	4																					

SOM Complex Consultants will need to be alert to these clues and to confirm the presence of a 'secondary exchange' PGS by checking cable details in Shazbot.

```

F 0248362161
L GLBY GLBY00 LI3 1292
ALCATEL RCM A1 LUL
X GLBN E76 X15
T GLBN E76 M15 POTS [1/5/3]
S GLBN E76 S15 POTS [1/5/3]
C GLBN E76 C15
M LOST01 2 9
  
```

A native NODS will need to be loaded on BOTH the PGS 'secondary' exchange and the customer exchange.

Priority Patterner (and Mozart CONEN to NODS automation) will automatically load NODS in this way for these scenarios.

#### 9.4.5. Special PGS patterning and display rules

In addition to the above basic PGS patterning and display rules there are some special rules:

- **Display of PGS types**

- Only Access Core or CAN Electronic PGS types are displayed in PGS Patterner.
- If a FNN in a PGS pattern contains another type of PGS e.g. FFTP, DSLAM or CAN Radio these PGS will not be displayed.
- The presence of other types of PGS can be only identified by the following clues:
  - The right hand PGS column is blank AND...
  - An ADSL 'X' code such as 'XR' or 'XS' will indicate the presence of a DSLAM
  - A remote or island exchange (e.g. THUT Thursday Island) may include a CAN Radio PGS

- **Limitation on number of PGS displayed**



- 
- PGS Patterner 6.0 screen has only 2 sets of PGS display columns – one on the left coded to display Access Core PGS and another on the right to display CAN Electronic PGS.
  - This means that (comparatively rare) instances of where there are 2 Access Core PGS + 1 Small PGS or where there is one Access PGS and 2 Small PGS, one of the PGS will NOT be displayed. In these cases PGS Patterner will pattern and display the PGS closest to the exchange.

### 9.5. Analyse PGS Fault Pattern

A related fault pattern in PGS Patterner is only an indication of a potential outage. To confirm the presence of an outage to a single network element having caused all the faults in the pattern, further detailed investigation and analysis must be conducted by SOM Complex Consultants using both the information in Pattern Manager itself and in external systems.

The below sequence describes the basic general approach:

1. Check CONEN for an Network Incident on the affected Access Large PGS
2. Check 'SOM Production' mailbox for an email advice of Small PGS outage
3. Investigate fault and network detail within the PGS pattern e.g. fault report times, symptom codes and common Panel and Slot
4. Use hyperlinks to compare fault and network detail in other Patterners e.g. which fault pattern gives the clearer and more compelling evidence
5. Investigate individual customer and fault details of each FNN in pattern, e.g. SIIAM case details, history and notes
6. Run a SIIAM query to identify any related faults which did not meet patterning display criteria
7. Investigate customer type and address patterns in CASINO (Clarification of Affected Services in Network Outage) tool
8. Check relative location of faults using GDD (Graphical Data Display) network maps
9. Ring CT's or GOC for more information

### 9.6. Create NODS from PGS Patterner

If an outage has been confirmed on a PGS network element included in the fault pattern, create a NODS notification directly from within PGS Patterner using the 'Create NODS' button.

This provides the quickest response to the outage and ensures that FOH consultants and customers will be advised of the outage at the earliest opportunity.

Follow these basic steps:



1. Select the affected network element e.g. large or Small PGS ID using the Network Element selection field
2. Enter the affected Panel and or Panel and Slot range in the Panel & Slot Selection fields e.g. Panel 3 Slots 1-3
3. Click the 'Create NODS' button
4. After a brief pause the NODS ID that has been created will display in the NODs ID column
5. The NODS can be opened directly using this link, allowing changes to be made (e.g. adding Parent case and CONEN IDs)

Refer also Section: 14.5

Pattern Manager PGS Version 6.0

Yanachie (YAHIA) UPDATE **Create NODS**

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	PGS_Id	PGS_Type	P/S/C	X
<a href="#">C</a>	<a href="#">S</a>	B	0356871105	05/12/16	09:59	NTN	E09811	RIM	2/4/6							505	107		SS
<a href="#">C</a>	<a href="#">S</a>	B	0356871135	05/12/16	11:20	NTN	E09811	RIM	2/7/8							505	103		SS
<a href="#">C</a>	<a href="#">S</a>	B	0356871209	05/12/16	12:13	NTN	E09811	RIM	1/9/2							505	5		MA
<a href="#">C</a>	<a href="#">S</a>	B	0356871248	05/12/16	10:18	NTN	E09811	RIM	2/7/6							505	137		SS
<a href="#">C</a>	<a href="#">S</a>	B	0356871249	05/12/16	12:14	NTN	E09811	RIM	2/9/4							505	112		SS
<a href="#">C</a>	<a href="#">S</a>	B	0356871295	05/12/16	09:51	NTN	E09811	RIM	2/4/2							505	119		SS
<a href="#">C</a>	<a href="#">S</a>	B	0356871488	05/12/16	09:26	NTN	E09811	RIM	2/4/10							505	87		SS

end as c687775 7 fnn(s)

last refresh: Mon Dec 05 13:10:57 EST 2016

## 9.7. Check off PGS Fault Pattern

Once the pattern has been analysed and a determination made as to the findings and the action to be taken, each fault in the pattern must be 'checked off' to indicate this finding/action e.g. CVH = Confirmed Volume Hold or NYV = Not Yet Volume Hold.

Initially, when first appearing, faults in a pattern will display the SIAM case status of the fault when it first met Pattern Manager criteria e.g. Test-Pending or Field-Open.

There are 3 methods of applying a check-off code:

1. Apply a common code to all faults in the Exchange using the Update All function
2. Apply a common code to selected faults in the Exchange using the selection boxes
3. Apply a single code to each individual fault using the individual drop down lists

To apply a check off action code to each fault in the pattern follow these basic steps:

1. Choose the most appropriate Check off method from the above e.g. if all faults in the exchange are part of the one outage use Method 1

2. Apply the correct code
3. Click the Update or Update All buttons to save the code and update the exchange display and the totals in the Exchange list and Region Dashboard

**NOTE:** Users with a PM Read-only Access Level can view the Check off code that has been applied by SOM but are unable to add or change Check off codes.

For detailed instructions on the above, refer section 14.7

For a table of valid check off codes and their meanings refer to section 14.8

Pattern Manager PGS Version 6.0

Yanakie (YAHA)

SYM	PGS_ID	PGS_Type	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	PGS_Id	PGS_Type	P/S/C	X	NODS_ID	Check_Lst
VTN	E09811	RIM	2/4/6							505	107					SS	Pending
VTN	E09811	RIM	2/7/8							505	103					SS	ie-Child
VTN	E09811	RIM	1/9/2							505	5					MA	ie-Child
VTN	E09811	RIM	2/7/6							505	137					SS	Outage-Child
VTN	E09811	RIM	2/9/4							505	112					SS	Outage-Child
VTN	E09811	RIM	2/4/2							505	119					SS	Test-Pending
VTN	E09811	RIM	2/4/10							505	87					SS	Test-Accepted

end as c687775 7 fnn(s)

last refresh: Mon Dec 05 13:10:57 EST 2016

## 10. Switch Patterner Version 6.0

Switch Patterner 6.0 forms and displays fault patterns related by a common Exchange Switching network element e.g. AXE or System 12 switching technology.

Click the Switch Patterner Version 6.0 link from the Pattern Manager Home screen to access Switch Patterner.

### 10.1. Select Region

When the Switch Patterner Version 6.0 link is clicked, the Switch Patterner Region Dashboard will open displaying the various geographical regions of the PSTN network and the number of patterned faults in each.

The Region Dashboard allows a user to:

- **Quickly assess the relative volumes of patterned faults per region**
  - MO = Mode of Operations – the number of faults which must meet patterning criteria before a fault pattern will display in that region
  - TOT = total number of patterned faults per region
  - NEW = number of patterned faults in region not yet analysed and actioned
  - % = percentage of patterned faults in region not yet analysed and actioned
- **Determine the region requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required region by clicking the Region name link**
  - Regions are state-based with metro and country areas of the same state grouped together
  - Regions are listed geographically North to South; East to West

Home

Pattern Manager Home

Logout

SWITCH PATTERNER 6.0

Welcome c687775  
please click here for [HELP](#)

MO	REGION	TOT	NEW	%
5	<a href="#">Melbourne</a>	11	11	0
5	<a href="#">New South Wales North</a>	66	24	63
5	<a href="#">New South Wales South</a>	17	17	0
5	<a href="#">Queensland Country</a>	33	15	54
5	<a href="#">Brisbane</a>	47	23	51
5	<a href="#">South Australia and Northern Territory</a>	9	6	33
5	<a href="#">Sydney North</a>	11	5	54
5	<a href="#">Sydney South</a>	7	7	0
5	<a href="#">Victoria and Tasmania</a>	10	10	0
5	<a href="#">Western Australia</a>	24	22	8

HELP

## 10.2. Select Node

When a Region link is clicked, the Switch Patternner Node List will open displaying the various AXE or S12 Exchange Nodes which contain fault patterns and the number of patterned faults in each.

**NOTE:** Unlike the other Patternners, Switch patternner organises related fault patterns by AXE or S12 Node. A Node is a 'master' exchange which controls the operation of several smaller local exchanges.

The actual exchange to which a Switch Pattern belongs can be seen within the Node pattern screen (see section 10.3 below)

To the right of the Node List a version history gives details of the changes introduced in each successive version of Pattern Manager.

The Node List allows a user to:

- **Quickly assess the relative volumes of patterned faults per Node**

- tot = total number of patterned faults per node
- new = number of patterned faults in node not yet analysed and actioned
- Above the node list are displayed:
  - Region name
  - 'Printable' link providing plain text view of region
  - Last refresh date
  - % faults unchecked in region
- Below the exchange list are displayed:
  - Total faults in region
  - Number unchecked faults in region

- **Determine the Node requiring the greatest focus**

- with the highest percentage of unchecked faults
- with the largest volume of unchecked faults

- **Access the required Node by clicking the Node link**

- Regions are listed alphabetically

[Home](#)
[Pattern Manager Home](#)
[Logout](#)

### Switch PATTERNER 6.0

[QLDC printable](#)  
as at 05-12-2016 13:16  
54% checked

node	tot	new
<a href="#">MGAU</a>	9	9
<a href="#">MYDO</a>	13	5
<a href="#">TOBK</a>	11	1

33 faults, 15 unchecked

#### Pattern Manager Switch Version 6.0

**Switch Patternner Version 6.0 (Fri 18-Nov-16)**

The following changes have been made:

1. Pattern Manager has been moved onto the new NODS platform Web GUI to enable automated NODS creation
2. A 'Create NODS' push-button and network element and LI/EN selection fields have been added to enable the user creation of NODS direct from Switch patternner
3. When a NODS has been push-created, the NODS ID and Category will display in the NODS ID column. The NODS ID acts as a hyperlink to the NODS record
4. NICAD Exchange Alarm function has been ceased and these NODS (EC, EF, FH) will no longer display in Switch Patternner.
5. A new column has been added to display the Exchange code to which the Switch belongs.
6. A single check-off code selection drop down list has been added to enable rapid checking-off of multiple faults.
7. Individual checkboxes have been added against all rows to enable rapid selection of faults for checking off or de-checking.
8. An Update All checkbox has been added to enable rapid checking off of all faults on the patternner screen

• No Other Changes have been made to the Switch Patternner display or rules

### 10.3. Switch Node screen

When a Node is clicked, the Node screen will present, displaying any related fault patterns present in the node along with key information to assist with initial analysis.

Node List remains visible at left to allow quick selection of the next node.

The main section of the screen displays basic details of customer faults reports which meet Switch patterning criteria (see next section 10.4).

The following details are displayed from left to right in the middle section of the screen

- HP Hyperlinks – if the fault also appears in a fault pattern in another Pattern (e.g. PGS) the hyperlink letter will be bold and underlined:
  - C (CAN) - P (PGS) – B (BB CAN)
- Faulty FNN (Full National Number)
- Date & Time of fault report
- Fault Symptom code (e.g. NTN – No Tone)
- Exchange to which Switch belongs
- Primary CAN Network Elements
  - Main Cable ID – if any
  - CAN Distribution element closest to the exchange e.g. Cabinet ('C'), Gateway ('G'), Pillar ('P') or Control Joint ('CJ')

**NOTE:** to simplify the display and make analysis easier, only Switch network elements are displayed in Switch Pattern plus the exchange and the primary CAN elements. To see Pair Gain Systems or other CAN elements present in a service or pattern it is necessary to use the hyperlinks (if active) or consult Shazbot or NPAMS.

- Switch Elements:
  - **AXE Switch**
    - RSS (Remote Switching Stage) Switch ID
    - LI (line Interface) AXE Device Type
    - LI number
    - NPAMS 128 pair grouping
  - **System 12 Switch**
    - RSA (Remote Subscriber Access) Switch ID
    - Network Address
    - EN number
    - Network Address group



- 
- Displaying a pattern of faults
  - Special patterning & display rules

#### 10.4.1. Form Switch fault pattern

A related fault pattern will form **in the background** in Switch Patternner whenever:

- 2 or more SIIAM customer trouble reports meet the following criteria:
  - Any Symptom code (either PSTN or ADSL) and...
  - Faults are in the same Node and...
  - Faults are in the same Switch ID and...
  - Faults are in the same Group (AXE 128 LI grouping or S12 Network address) and...
  - Faults have been reported within 24 hours of earliest fault in group
- Fault pattern will be retained for 72 hours from fault report date or for the timeframe configured by SOM in the 'Update Age of Pattern Data' table of Pattern Manager Admin 2.0
- Only the valid Age of Pattern Data timeframe rules can be changed by SOM. Changes can only be made by a user with NODS-PM Super User Access Level via the Pattern Manager Admin function. All other rules are hard coded into Pattern Manager.

#### 10.4.2. Display Switch fault pattern

While a basic CAN fault pattern will ALWAYS form in the background of Switch Patternner, fault patterns will only become visible in a Node screen in Switch Patternner when the following criteria are met:

- The above patterning rules have been met and patterns have formed in the background
- The number of patterned faults is equal to or greater than the patterning threshold configured by SOM in the 'Update Patterning Threshold' table of Pattern Manager Admin 2.0

For example, when the Threshold Setting is set to '5' a fault pattern will only display when there are 5 patterned faults in the same Switch ID and same Group, etc.

- Each different Switch and Magazine Group pattern will be distinguished by a different band of background colour

## Switch PATTERN 6.0

in table

12-2016 13:20

ked

Switch

Maroochydhore Axe No3 AXE (MYDO)

UPDATE

Create NODS

No Selection

UPDATE ALL

tot

new

9

9

13

5

11

1

Select

Select

Select

C

P

B

0754350041

041216

0933

NTN

CONO

1

P2

CONE00

L13

59481

464

d292370

CVH

C

P

B

0754350440

041216

1038

NTN

CONO

1

P2

CONE00

L13

59463

464

d292370

CVH

C

P

B

0754944503

041216

0857

NSY

CONO

1

P2

CONE00

L13

59429

464

Outage-Child

C

P

B

0754944619

041216

0945

NTN

CONO

1

P2

CONE00

L13

59431

464

d292370

CVH

C

P

B

0754944628

041216

1322

NTN

CONO

1

P2

CONE00

L13

59479

464

d292370

CVH

C

P

B

0754944525

041216

0825

NTN

CONO

J2

CONE00

L13

59460

464

Outage-Child

C

P

B

0754944643

041216

0959

NTN

CONO

J2

CONE00

L13

59497

464

Outage-Child

C

P

B

0754835019

031216

1011

NTN

MOTH

P3

MOTL00

LIV

199

1

Test-Accepted

C

P

B

0754835098

021216

1655

NTN

MOTH

P3

MOTL00

LIV

175

1

48153745

OC

C

CVH

C

P

B

0754835205

021216

1723

NTN

MOTH

P3

MOTL00

LIV

235

1

48153745

OC

C

CVH

C

P

B

0754835269

031216

1117

NTN

MOTH

P3

MOTL00

LIV

132

1

Outage-Child

C

P

B

0754835396

021216

1630

NTN

MOTH

P3

MOTL00

LIV

153

1

48153745

OC

C

CVH

C

P

B

0754835520

031216

0927

NTN

MOTH

P3

MOTL00

LIV

246

1

48153745

OC

C

CVH

## 10.5. Analyse Switch Fault Pattern

A related fault pattern in Switch Paterner is only an indication of a potential outage. To confirm the presence of an outage to a single network element having caused all the faults in the pattern, further detailed investigation and analysis must be conducted by SOM Complex Consultants using both the information in Pattern Manager itself and in external systems.

The below sequence describes the basic general approach:

1. Check CONEN for an network Incident on the affected Access Large PGS
2. Investigate fault and network detail within the PGS pattern e.g. fault report times, symptom codes and common Panel and Slot
3. Use hyperlinks to compare fault and network detail in other Patterners e.g. which fault pattern gives the clearer and more compelling evidence
4. Investigate individual customer and fault details of each FNN in pattern, e.g. SIIAM case details, history and notes
5. Run a SIIAM query to identify any related faults which did not meet patterning display criteria
6. Investigate customer type and address patterns in CASINO (Clarification of Affected Services in Network Outage) tool
7. Ring GOC or CT's for more information

## 10.6. Create NODS from Switch Patterner

If an outage has been confirmed by GOC on a Switch network element included in the fault pattern, create a NODS notification directly from within Switch Patternner using the 'Create NODS' button.



This provides the quickest response to the outage and ensures that FOH consultants and customers will be advised of the outage at the earliest opportunity.

Follow these basic steps:

1. Select the affected network element i.e. Switch ID and Switch Type using the Network Element selection fields
2. Enter the affected LI/EN range in the LI/EN Selection field e.g. 1-256
3. Click the 'Create NODS' button
4. After a brief pause the NODS ID that has been created will display in the NODs ID column
5. The NODS can be opened directly using this link, allowing changes to be made (e.g. adding Parent case and CONEN IDs)

NOTE: The exact LI or EN range of an affected AXE or S12 Switch ID and/or magazine can be determined by using the JC08 'Display FF/LI (Digital)' query in NPAMS.

Refer also Section: 14.5

### Switch PATTERNER 6.0



end as c687775 7 fnn(s)

### 10.7. Check off Switch Fault Pattern

Once the pattern has been analysed and a determination made as to the findings and the action to be taken, each fault in the pattern must be 'checked off' to indicate this finding/action e.g. CVH = Confirmed Volume Hold or NYV = Not Yet Volume Hold.

Initially, when first appearing, faults in a pattern will display the SIIAM case status of the fault when it first met Pattern Manager criteria e.g. Test-Pending or Field-Open.

There are 3 methods of applying a check-off code:

1. Apply a common code to all faults in the Exchange using the Update All function
2. Apply a common code to selected faults in the Exchange using the selection boxes
3. Apply a single code to each individual fault using the individual drop down lists


To apply a check off action code to each fault in the pattern follow these basic steps:

1. Choose the most appropriate Check off method from the above e.g. if all faults in the exchange are part of the one outage use Method 1
2. Apply the correct code
3. Click the Update or Update All buttons to save the code and update the exchange display and the totals in the Exchange list and Region Dashboard

For detailed instructions on the above, refer section 14.7

For a table of valid check off codes and their meanings refer to section 14.8

### Switch PATTERNER 6.0



The screenshot shows the 'Switch' interface for 'Frankston A AXE (FRTX)'. It includes a table of faults with columns: HP, FNN, DATE, TIME, SYM, EXCH, MAIN, PIR, SWid, Swtype, Swnum, Grp, NODS\_ID, OutCat, OutSta, and a 'List' column. A dropdown menu is open for the 'List' column, showing options: No Selection, BVH, PVH, CVH, CLR, CAN, LGT, LNK, NYV, WCH, NBN, DIS, TCT, and AVH. The 'UPDATE ALL' button is circled in red. The 'List' column for the first row is also circled in red.

HP	FNN	DATE	TIME	SYM	EXCH	MAIN	PIR	SWid	Swtype	Swnum	Grp	NODS_ID	OutCat	OutSta	List
C	P	B	0359776951	051216	1615	NTN	SOME	1	A4	SOMV02	LI3	76560	598		
C	P	B	0359776661	041216	1809	NTN	SOME	1	A5	SOMV02	LI3	76573	598		
C	P	B	0359776970	041216	1923	NTN	SOME	1	14	SOMV02	LI3	76647	598		
C	P	B	0359776890	051216	1619	NTN	SOME	2	16	SOMV02	LI3	76612	598		
C	P	B	0359777821	041216	1649	NTN	SOME	2	16	SOMV02	LI3	76588	598		
C	P	B	0359778874	041216	1731	NTN	SOME	3	12	SOMV02	LI3	76655	598		
C	P	B	0359775818	051216	1629	NTN	SOME	3	21	SOMV02	LI3	76654	598		

end as c687775 7 fnn(s)

## 11. Broadband Patterner Version 2.0

Broadband (BB) CAN Patterner 2.0 forms and displays broadband fault patterns related by a common CAN copper cable network element e.g. main cable, cabinet, gateway, or pillar.

Click the BB CAN Patterner Version 2.0 link from the Pattern Manager home screen to access BB CAN Patterner.

### 11.1. Select Region

When the BB CAN Patterner Version 2.0 link is clicked, the BB CAN Patterner Region Dashboard will open displaying the various geographical regions of the PSTN network and the number of patterned faults in each.

The Region Dashboard allows a user to:

- **Quickly assess the relative volumes of patterned faults per region**
  - MO = Mode of Operations – the number of faults which must meet patterning criteria before a fault pattern will display in that region
  - TOT = total number of patterned faults per region
  - NEW = number of patterned faults in region not yet analysed and actioned
  - % = percentage of patterned faults in region not yet analysed and actioned
- **Determine the region requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required region by clicking the Region name link**
  - Regions are state-based with metro and country areas of the same state grouped together
  - Regions are listed geographically North to South; East to West

[Home](#)[Pattern Manager Home](#)[Logout](#)

# BROADBAND CAN PATTERNER 2.0

Welcome c687775  
please click here for [HELP](#)

MO	REGION	TOT	NEW	%
5	<a href="#">Queensland Country</a>	0	0	0
5	<a href="#">Brisbane</a>	14	6	57
5	<a href="#">New South Wales North</a>	27	2	92
5	<a href="#">New South Wales South</a>	0	0	0
5	<a href="#">Sydney North</a>	23	2	91
5	<a href="#">Sydney South</a>	0	0	0
5	<a href="#">Melbourne</a>	33	0	100
5	<a href="#">Victoria and Tasmania</a>	0	0	0
5	<a href="#">South Australia and Northern Territory</a>	6	2	66
5	<a href="#">Western Australia</a>	8	8	0

[HELP](#)


## 11.2. Select Exchange

When a Region link is clicked, the BB CAN Patternner Exchange List will open displaying the various exchanges which contain fault patterns and the number of patterned faults in each.

To the right of the Exchange List a version history gives details of the changes introduced in each successive version of Pattern Manager.

The Exchange List allows a user to:

- **Quickly assess the relative volumes of patterned faults per exchange**
  - tot = total number of patterned faults per exchange
  - new = number of patterned faults in exchange not yet analysed and actioned
  - Above the exchange list are displayed:
    - Region name
    - 'Printable' link providing plain text view of region
    - Last refresh date
    - % faults unchecked in region
  - Below the exchange list are displayed:
    - Total faults in region
    - Number unchecked faults in region
- **Determine the exchange requiring the greatest focus**
  - with the highest percentage of unchecked faults
  - with the largest volume of unchecked faults
- **Access the required exchange by clicking the Exchange link**
  - Exchanges are listed alphabetically



Home [Pattern Manager Home](#) [Logout](#)

**Broadband CAN Patternner 2.0**

BRIS [Printable](#)  
as at Mon Dec 05 21:41:51 EST  
2016  
57% checked

exch	tot	new
BNPS	8	
OCER	6	6

14 faults, 6 unchecked

**Broadband CAN Pattern Manager Version 2.0**

**BB CAN Patternner Version 2.0 (Fri 18-Nov-16)**

The following changes have been made:

1. Pattern Manager has been moved onto the new NODS platform Web GUI to enable automated NODS creation
2. New columns have been added to display 'Gateway' and Gateway 'o pair'
3. Patterns will form on Gateways according to the standard CAN patterning rules
4. A single check-off code selection drop down list has been added to enable rapid checking-off of multiple faults.
5. Individual checkboxes have been added against all rows to enable rapid selection of faults for checking off or de-checking.
6. An Update All checkbox has been added to enable rapid checking off of all faults on the patternner screen

No Other Changes have been made to the BB CAN Patterning display or rules

## 11.3. BB CAN Exchange screen

When an Exchange is clicked, the Exchange screen will present, displaying any related fault patterns present in the exchange along with key information to assist with initial analysis.

Exchange List remains visible at left to allow quick selection of the next exchange.

The main section of the screen displays basic details of customer ADSL faults reports which meet BB CAN patterning criteria (see next section 11.4).

The following details are displayed from left to right in the middle section of the screen

- HP Hyperlinks – if the fault also appears in a fault pattern in another Patternner (e.g. PGS) the hyperlink letter will be bold and underlined:
  - C (CAN) – P (PGS) – S (Switch)
- Faulty FNN (Full National Number)
- Date & Time of fault report
- Fault Symptom code (e.g. DTG – NSYN – No Sync)
- PGS, DSLAM & basic CAN Network Elements
  - Access Core large PGS ID – Type – P/S/C (Panel/Slot/Channel) e.g. CMUX or RIM
  - Main cable/mpair – Cabinet/bpair – Gateway/opair – Pillar/opair
  - DSLAM (Digital Subscriber Line Access Multiplexer) ID – Type – P/S/C e.g. AM35
  - If a Network Element column is blank, that type of network element is not present in that FNNs service

NOTE: to simplify the display and make analysis easier, only Access and DSLAM PGS and basic CAN network elements are displayed in PGS Patternner. To see other CAN or Switch devices present in a service or pattern it is necessary to use the hyperlinks (if active) or consult Shazbot or NPAMS.

- 'X' – Service Type as recorded in NPAMS e.g. XR = ADSL service – SS = PSTN service (see table section x.x)
- NODS ID
  - If a NODS has been created automatically by Priority Patternner or manually from within CAN Patternner, the NODS ID will display here
  - NODS manually created in native NODS will NOT display
  - NODS auto-created by Mozart or other external interfaces will NOT display
- User ID of the user who has Checked off the fault pattern
- Check List ('Chk Lst') indicating determination made/action taken on fault pattern e.g. CVH – Confirmed Volume Hold – NYV – Not Yet Volume Hold (refer table section 14.8)

#### NOTE:

The left hand PGS columns display details for Access Core Large PGS e.g. CMUX, RIM, RCM, DCS20 and SSNMUX

The right hand PGS columns display details for DSLAM PGS e.g. AM31, AM35, ASAM, ISAM and CMUX (with ADSL port/card type)

Pattern Manager Home Logout

**Broadband CAN Patterner 2.0**

Browns Plains (BNPS) UPDATE

No Selection UPDATE ALL

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_TYPE	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	PGS_Id	PGS_TYPE	P/S/C	X	USER	Chk list
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738067103	03/12/16	22:41	DTG	E00009/4	CMUX	1/20/8			G103	52	104	10	E04014	ISAM7330-2	XR	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738067408	04/12/16	10:14	DTG	E00009/4	CMUX	1/14/22			G103	85	104	13	E04014	ISAM7330-2	XS	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738090007	04/12/16	10:54	DTG	E00009/4	CMUX	1/11/8			G103	77	104	35	E04014	ISAM7330-2	XS	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738093167	03/12/16	22:27	DTG	E00009/4	CMUX	1/14/29			G103	45	104	38	E04014	ISAM7330-2	XR	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738069939	04/12/16	13:43	DTI	E00009/4	CMUX	1/14/18			G103	91	104	111	E04014	ISAM7330-2	XR	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738007843	04/12/16	10:41	DTG	E00009/4	CMUX	2/9/8			G103	98	104	140	E04014	ISAM7330-2	XR	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738069504	04/12/16	10:34	DTG	E00009/4	CMUX	1/17/22			G103	92	104	157	E04014	ISAM7330-2	XS	d270503	BVH	<input type="checkbox"/>
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738009382	03/12/16	22:01	DTG	E00009/4	CMUX	2/9/17			G103	81	104	161	E04014	ISAM7330-2	XS	d270503	BVH	<input type="checkbox"/>

end as c687775 8 fnn(s)  
last refresh: Mon Dec 05 21:32:52 EST 2016

## 11.4. BB CAN Fault Patterning Rules

In CAN Patterner there are separate rules for:

- Forming a pattern of faults
- Displaying a pattern of faults
- CMUX Display rules
- Special patterning & display rules

### 11.4.1. Form BB CAN fault pattern

A related fault pattern will form **in the background** in BB CAN Patterner whenever:

- 2 or more SIIAM customer trouble reports meet the following criteria:
  - Symptom code is one of: DTG, DTI, URS, SSI, SSS, DTA, DTB, DTC, DTD, DTE, DTF, DTH, DTJ, DTK, DTL, DTM, DTN, DTO, DTP, DTQ, DTR, DTS, DTT, DTU, DTW, DTX, ULI, and...
  - Faults are in the same Exchange Service Area (ESA) and...
  - Faults are in the same Pillar or...
  - Where there is no Pillar, in the same Gateway
  - Where there is no Gateway, in the same Cabinet or...
  - Where there is no Pillar, Gateway or Cabinet, in the same Main Cable and...
  - The O, branch or main pair is within 30 pairs of the lowest pair in the pattern
- Fault pattern will be retained for 72 hours from fault report date or for the timeframe configured by SOM in the 'Update Age of Pattern Data' table of Pattern Manager Admin 2.0
- Only the valid Symptom Code and Age of Pattern Data timeframe rules can be changed by SOM. Changes can only be made by a user with NODS-PM Super User Access Level via the Pattern Manager Admin function. All other rules are hard coded into Pattern Manager.

### 11.4.2. Display BB CAN fault pattern

While a basic BB CAN fault pattern will ALWAYS form in the background of BB CAN Patternner, fault patterns will only become visible in an Exchange screen in BB CAN Patternner when the following criteria are met:

- The above patterning rules have been met and patterns have formed in the background
- The number of patterned faults is equal to or greater than the patterning threshold configured by SOM in the Update Patterning Threshold' table of Pattern Manager Admin 2.0

For example, when the Threshold Setting is set to '5' a fault pattern will only display when there are 5 patterned faults in the same exchange and the same pillar, etc.

- Faults so displayed can be in the one 30 pair grouping or in a combination of 30 pair patterns

e.g. If the Threshold was set to 5 then the rule would be met if there were:

- 5 faults in one 30 pair group
  - E.g. P5 – pairs 3 + 9 +10 +18 +25
- 2 faults in one 30 pair group plus 3 faults in another 30 pair group or "2+3":
  - E.g. P5 – pairs 3 + 9 plus 74 + 87 + 91
- 2 faults in one 30 pair group plus 2 faults in another plus 2 faults in another or "2+2+2":
  - E.g. P5 – pairs 3 + 9 plus 51 + 56 plus 89+ 97

- Each 30 pair grouping is distinguished by a band of different background colour

### 11.4.3. CMUX display rules in BB CAN Patternner

There are special rules for the display of CMUX in BB CAN patternner:

CMUX will display differently in BB CAN Patternner depending on the network roles they play in providing customers' services.

- **CMUX provides Access Core**
  - will display in the left hand PGS column when the CMUX is performing an Access Core using a POTS or ISDN 2B1Q port/card or combined Access/DSLAM role using a combination ('combo') port/card
- **CMUX provides ADSL DSLAM**
  - will display in the right hand PGS column when the CMUX is performing a purely DSLAM role using an ADSL port/card

Refer PGS Section 9.4.3 for more detail

[Pattern Manager Home](#)

Broadband CAN Patterner 2.0

Browns Plains (BNPS)

UPDATE

No Sel

HP	FNN	DATE	TIME	SYM	PGS_ID	PGS_TYPE	P/S/C	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	PGS_Id	PGS_TYPE	P/S/C	X	
<a href="#">C</a>	<a href="#">P</a>	<a href="#">S</a>	0738067103	03/12/16	22:41	DTG	E00009/4	CMUX	1/20/8				G103	52	104	10	E04014	ISAM7330-2		XR

#### 11.4.4. Special patterning & display rules

There are some special patterning and display rules in BB CAN Patterner rules for the display of CMUX in BB CAN Patterner:

- **Control Joints**
  - Control Joints are not considered for patterning and are not displayed
- **ULL/SSS services**
  - ULL/SSS services for other Service Providers may appear in BB CAN Patterner but do not utilise a Telstra DSLAM device. The right hand DSLAM PGS column will always appear blank for ULL/SSS services
- **Non-Broadband services appearing in BB CAN Patterner**
  - Some non-Broadband services are also reported using a DTP (Data Transmission Problem) symptom code but this is not an ADSL code.
  - These may be ISDN, Faxstream or Dial-up Internet. These will also appear in BB CAN Patterner. In these cases, the right hand DSLAM PGS columns will always be blank and the 'X' code will be non-ADSL (e.g. 'SS' or 'RA')

#### 11.5. Analyse BB CAN Fault Pattern

A related fault pattern in BB CAN Patterner is only an indication of a potential outage. To confirm the presence of an outage to a single network element having caused all the faults in the pattern, further detailed investigation and analysis must be conducted by SOM Complex Consultants using both the information in Pattern Manager itself and in external systems.

A primary method of determining if the BB CAN pattern is more likely to indicate a CAN issue versus a DSLAM issue is to check the right hand PGS column:

- Fault pattern with common DSLAM is more likely to be due to a broadband issue
  - Fault pattern with multiple DSLAMs may indicate a CAN issue – investigate further
1. Check CONEN for a network Incident on the affected DSLAM
  2. Check WFC Outage board for a known ADSL outage on the affected DSLAM
  3. Investigate fault and network detail within the BB CAN pattern e.g. fault report times, symptom codes and contiguity of affected pairs and whether services are provided over common DSLAM or not.
  4. Use hyperlinks to compare fault and network detail in other Patterners e.g. which fault pattern gives the clearer and more compelling evidence



- 
5. Investigate individual customer and fault details of each FNN in pattern, e.g. SIIAM case details, history and notes
  6. Run a SIIAM query to identify any related faults which did not meet patterning display criteria
  7. Investigate customer type and address patterns and pair occupancy of range in CASINO (Clarification of Affected Services in Network Outage) tool or NPAMS
  8. Check cable location and route and relative location of faults using GDD (Graphical Data Display) network maps
  9. Test services in SULTAN or OATS particularly when there is an apparent gap in the affected range ("testing within the range")
  10. Ring CT's or WFC for more information

### 11.6. Create NODS

There is no functionality to enable NODS to be created directly in BB CAN Patternner.

If the evidence points strongly towards a CAN issue affecting Broadband services, this should be brought to the attention of Assurance Ops Workflow Coordinators (WFC) so that further investigation can be undertaken.

If it was deemed necessary to create a NODS for a BB CAN pattern, this will need to be done in native NODS.

### 11.7. Check off BB CAN Fault Pattern

Once the pattern has been analysed and a determination made as to the findings and the action to be taken, each fault in the pattern must be 'checked off' to indicate this finding/action e.g. CVH = Confirmed Volume Hold or NYV = Not Yet Volume Hold.

Initially, when first appearing, faults in a pattern will display the SIIAM case status of the fault when it first met Pattern Manager criteria e.g. Test-Pending or Field-Open.

There are 3 methods of applying a check-off code:

1. Apply a common code to all faults in the Exchange using the Update All function
2. Apply a common code to selected faults in the Exchange using the selection boxes
3. Apply a single code to each individual fault using the individual drop down lists

To apply a check off action code to each fault in the pattern follow these basic steps:

1. Choose the most appropriate Check off method from the above e.g. if all faults in the exchange are part of the one outage use Method 1
2. Apply the correct code
3. Click the Update or Update All buttons to save the code and update the exchange display and the totals in the Exchange list and Region Dashboard

### 11.7.1. BVH Check off code

There is a specific Check Off code to indicate a fault pattern which has been identified by SOM as belonging to an ADSL Outage already set up by WFC:

## BVH (Broadband Volume Hold)

This can be identified by checking the WFC Outage Board on the following URL:

<http://outageboard.in.telstra.com.au/ob/outageboard.php>

The WFC Outage board contains both Active and Ceased outage lists. SOM need to check both. BVH will be applied to either an Active or Ceased WFC outage as these outages also use a Callbacks process to verify restoration.

For detailed instructions on Checking off patterns, refer section 14.7

For a table of valid check off codes and their meanings refer to section 14.8

---

## 12. Priority Outage Dashboard

Priority Outage Dashboard displays key details of fault patterns in any of the 4 Patterners which have met the criteria for a fast forming or large unchecked Priority Pattern (PP) alert.

Priority Patterns (PP) are those which pose the greatest risk to customer service and business operations.

The Priority Patterning functionality is designed to assist SOM in periods of peak fault volumes and/or natural disaster when the capability of SOM and other workgroups to respond to the very high fault volumes can be severely tested.

There are 2 triggers for the forming and display of a Priority Pattern alert in the Dashboard:

- **Fast**
  - A fault pattern has formed rapidly in a short timeframe
  - Configured by SOM in 'Update Priority Thresholds' in Pattern Manager Admin
  - Configured as 'x' number of faults per 'y' hours e.g. 12/6 = 12 faults in 6 hours
  - Fast PPs form on specific Network Elements e.g. main cables or PGS
  - Pattern Manager will automatically create a NODS ('Auto-NODS') for CAN or PGS PPs
- **Unchecked**
  - A large fault pattern has not been checked off
  - Configured by SOM in 'Update Priority Thresholds' in Pattern Manager Admin
  - Configured as 'x' number of faults e.g. 20 = 20 faults unchecked
  - Unchecked PPs just form on the whole exchange
  - Auto-NODS are never created for Unchecked PPs

Priority Pattern alerts can be triggered from fault patterns in any of the 4 Patterners, if they meet the Priority patterning criteria:

- CAN Patterner
- PGS Patterner
- Switch Patterner
- BB CAN Patterner


Auto-NODS will only be created by Pattern Manager for:

- CAN Priority Patterns
- PGS Priority Patterns


When an Auto-NODS has been created, faults in the pattern will be automatically checked off with the Check Off code 'AVH' (Automatic Volume Hold)

SOM Complex Consultants investigate, validate and manage Priority Patterns by use of the Priority Outage Dashboard.

Click the Priority Outage Dashboard link from the Pattern Manager home screen to access Priority Dashboard.



The Priority Outage Dashboard will display:



Priority Settings	Region	Exch/Node	Network Element	NE ID	Range	Type	Associated Patterners	Current Reports	Active Trigger	Auto NODS	Created Date	User	Action
12 / 6	Brisbane	<a href="#">GNBH</a>	AXE	GNBE		SWITCH		14	Fast	No	03/12/16 01:51 PM	d2	In Progress
12 / 6	Melbourne	<a href="#">HDBG</a>	MAIN	4		CAN		17	Fast	No	04/12/16 12:01 PM	d2	In Progress
12 / 6	Melbourne	<a href="#">HDBG</a>	MAIN	4	1-800	CAN		20	Fast	Yes	04/12/16 12:21 PM	d2	In Progress
12 / 6	Sydney South	<a href="#">WETH</a>	MAIN	5		CAN	B	9	Fast	No	03/12/16 02:51 PM	d2	In Progress
12 / 6	Sydney North	<a href="#">PENN</a>	AXE	PNNX		SWITCH		16	Fast	No	03/12/16 08:01 AM	d2	In Progress
20	Melbourne	<a href="#">HDBG</a>				CAN		21	Unchecked	No	04/12/16 11:41 AM	d2	In Progress

## 12.1. Priority Outage Display

The Priority Outage Dashboard displays the following information:

- **Priority Settings**
  - The currently configured threshold for the type of Priority pattern e.g. 12/6 (Fast) or 20 (Unchecked)
- **Region**
  - The standard pattern Manager Region in which the Priority Pattern has formed
- **Exch/Node**
  - The Exchange in which the Priority Pattern has formed
  - Is an active hyperlink to the Exchange where the Priority pattern has formed
  - If the Priority Pattern has formed on a Switch, the Exch hyperlink will take the user to the first FNN in the pattern for that exchange within the relevant AXE/S12 Node
- **Network Element**
  - The Network element on which the Priority Pattern has formed
  - CAN = Main, cabinet, Gateway, Pillar or Control Joint
  - PGS = PGS Type e.g. RIM or RAM 8
  - Switch = Switching technology i.e. AXE or S12

- 
- BB Can = as per CAN
  - **NE ID**
    - The Cable, Pillar, etc. number or PGS or Switch ID on which the Priority pattern has formed
  - **Range**
    - The Pair or LI/EN device range on which the Priority Pattern has formed
  - **Type**
    - The Patternner in which the pattern has formed e.g. CAN, PGS, Switch or BB CAN
  - **Associated Patternners**
    - The Standard hyperlink code letter of any other Patternners in which any of the faults in the Priority pattern also belong
    - Since the Priority pattern record in the Dashboard represents a number of faults it is not possible for this to be an active hyperlink
  - **Current Reports**
    - The number of fault reports in the Priority patterns at the time it formed
    - If new fault reports again meet the Priority patterning criteria, a new Priority pattern will be formed and displayed
  - **Active Trigger**
    - The trigger which caused the Priority pattern to form i.e. 'Fast' or 'Unchecked'
  - **Auto NODS**
    - Whether or not an Auto-NODS has been created – Yes/No
  - **Created Date**
    - The Date and Time the Priority pattern was formed
  - **User**
    - The SOM User who has actioned the Priority pattern record in the Priority Outage Dashboard
  - **Action**
    - The determination made/action taken by SOM after investigation of the Priority Pattern

## 12.2. Priority Patterning Rules - Unchecked

An Unchecked Priority Pattern (PP) will be formed in any of the 4 Patternners when the current Priority Patterning criteria as configured in Pattern Manager Admin are met.

Very simple rules apply to the patterning rules for Unchecked PPs:

- The number of unchecked patterned faults in an exchange has met or exceeded the Unchecked Reports Threshold set by SOM in Pattern Manager Admin e.g. 20
- The PP alert will display in the Priority Outage dashboard on the whole exchange and may relate to a number of network elements e.g. more than one PGS ID
- An Auto-NODS will never be created

## 12.3. Priority Patterning Rules - Fast

More complex rules apply to the patterning and display of Fast PPs:

- The number of patterned faults has met or exceeded the threshold number set by SOM in Priority Manager Admin for a particular timeframe threshold in a region e.g. a pattern of 6 faults has been reported within a timeframe of 5 hours for NSW region which meets the threshold set by SOM of 6 faults in 5 hours for that region.
- In addition to this basic trigger rule, additional rules apply as to:
  - Which Patternner the PP will be formed in if FNNs exist in more than one Patternner
    - E.g. a Fast pattern of FNNs in PGS Patternner is also present in CAN
  - Which Network Element the PP will be formed on
    - E.g. will a Fast CAN pattern be formed on main cable or Pillar
  - Which pair range (if any) the PP will be formed on
    - E.g. will the Fast pattern be formed on the whole PGS or just a C pair range
  - Whether a NODS will be auto-created for the Fast pattern

See the following sub-sections for details of these rules.

### 12.3.1. Patternner Hierarchy rule

The Priority Patternner hierarchy rule determines in which Patternner and on which network element the PP (and auto-NODS) is created:

- If a fault pattern in any of the 4 Patternners meets PP criteria and is NOT in any other patternner, form the PP on that Patternner and NE
  - E.g. a pattern of faults on a Switch meets PP criteria – a PP is formed on the Switch and displayed in Priority Outage Dashboard
- If a fault pattern in either Switch and/or BB CAN meets PP criteria but is also in either CAN and/or PGS patternners, form the PP on either CAN or PGS Patternner according to the next 2 rules
  - E.g. a pattern of faults on a Switch meets PP criteria but is also on a main cable in CAN patternner – a PP is formed on the main cable in CAN patternner in Priority Outage Dashboard along with a S entry in the hyperlink column
- If a fault pattern in both PGS and CAN Patternners meets PP criteria, form the PP on the one with the greater number of faults in it.
  - E.g. a pattern of faults on a Pillar in CAN Patternner meets PP criteria but is also on a Small PGS in PGS Patternner. There are more faults in the CAN pattern– a PP is formed on the Pillar in CAN Patternner and displayed in Priority Outage Dashboard along with a P entry in the hyperlink column
- If a fault pattern in both PGS and CAN Patternners meets PP criteria, and the number of faults in each is equal, form the PP on the PGS Patternner and element
  - E.g. a pattern of faults on a Cabinet in CAN Patternner meets PP criteria but is also on a RIM in PGS Patternner. There are an equal number of faults in each – a PP is formed on the RIM in PGS Patternner in Priority Outage Dashboard along with a C entry in the hyperlink column

### 12.3.2. Network Element rules

As well as determining which Pattern a Priority Pattern must be formed in, Pattern Manager also has to determine on which of the Network Elements present in the faults in the pattern it should create the PP (and the Auto-NODS).

Pattern Manager determines the network element on which to set up a PP by the following rules.

There are different rules for each Pattern:

#### 12.3.2.1. PGS Pattern

The following rules are used by Pattern Manager to determine the Network Element and range on which to form a Fast PGS Priority pattern and Auto-NODS

- If, according to Pattern Hierarchy rules, the PP will be formed on the PGS pattern...
- Priority Pattern will form on the PGS ID e.g. TBNE RIM E9801
- If PGS Type is RIM or CMUX and all faults are on same Panel AND Slot, create PP just on that on Panel and Slot of the PGS ID e.g. TBNE RIM E9801 Panel 3 Slot 4
- If PGS Type is RIM or CMUX and all faults are on same Panel but different Slots, create PP just on that on the Panel of the PGS ID e.g. TBNE RIM E9801 Panel 3
- If PGS Type is RIM or CMUX and faults are on different Panels, create PP on whole PGS ID e.g. TBNE RIM E9801
- If PGS Type is RCM, DC20 or SSNMUX create PP on whole PGS ID e.g. STHE DCS20 E20
- If PGS Type is CAN Electronic Small PGS e.g. 6/16 or RAM 8 create PP on whole PGS ID e.g. CHLT RAM8 Ph1 E7
- Display PP alert details in the Priority Outage dashboard according to whichever of the above rules applies
- Create an Auto-NODS according to whichever of the above rules applies

#### 12.3.2.2. Switch Pattern

The following rules are used by Pattern Manager to determine the Network Element on which to form a Fast Switch Priority pattern

- If, according to Pattern Hierarchy rule, the PP will be formed on the Switch pattern...
- Priority Pattern will form on the alpha character component of the Switch ID which meets the PP Trigger criteria e.g. VPNS
- E.g. If the combined total of faults across Switch IDs VPNS01, VPNS02 and VPNS03 meets the criteria for PP, a single PP will be created across faults in all 3 Switch IDs and display in Priority Outage Dashboard as a single PP alert on AXE VPNS SWITCH
- Switch magazines and LI/EN ranges will always be ignored when Switch Priority patterns are being created
- Display PP alert details in the Priority Outage dashboard according to the above rules

**NOTE:** An Auto-NODS is never created for a Switch Priority Pattern

C	P	B	0732070444	071216	1117	NTN	VAPT	12	20	VPNS01	LI3	55049	430	Outage-Child	<input type="checkbox"/>
C	P	B	0732078034	071216	0851	ICP	VAPT	13	30	VPNS01	LI3	55116	430	Outage-Child	<input type="checkbox"/>
C	P	B	0732070831	071216	0949	ICP	VAPT	13	31	VPNS01	LI3	55145	430	Outage-Child	<input type="checkbox"/>
C	P	B	0732077025	071216	1037	NTN	VAPT	2	P1	VPNS01	LI3	55045	430	Outage-Child	<input type="checkbox"/>
C	P	B	0738206182	071216	0834	NTN	VAPT	1	11	VPNS02	LI3	63722	497	Test-Accepted	<input type="checkbox"/>
C	P	B	0732076491	071216	1515	COS	VAPT	2	P2	VPNS02	LI3	63631	497	Outage-Child	<input type="checkbox"/>
C	P	B	0738209159	071216	0854	NTN	VAPT	3	26	VPNS02	LI3	63672	497	Consultant-Accepted	<input type="checkbox"/>
C	P	B	0732070638	071216	1234	NTN	VAPT	6	12	VPNS02	LI3	63654	497	Outage-Child	<input type="checkbox"/>

Priority Settings	Region	Exch/Node	Network Element	NE ID	Range	Type	Associated Patterns	Current Reports	Active Trigger	Auto NODS	Created Date	User	Action
30 / 5	New South Wales North	WDBN	AXE	WDBJ		SWITCH		11	Fast	No	06/12/16 03:01 PM		New
30 / 5	New South Wales North	SSEA	AXE	SSEJ		SWITCH		11	Fast	No	08/12/16 12:31 PM		New
30 / 5	Brisbane	VAPT	AXE	VPNS		SWITCH		31	Fast	No	07/12/16 01:11 PM		New

### 12.3.2.3. BB CAN Patternner

The following rules are used by Pattern Manager to determine the Network Element on which to form a Fast BB CAN Priority pattern

- If, according to Patternner Hierarchy the PP will be formed on the BB CAN pattern...
- Priority Pattern will form on the CAN Network Element closest to the exchange according to the same criteria as for CAN Patternner 6.0 above
- Display PP alert details in the Priority Outage dashboard according to the above rules

**NOTE:** An Auto-NODS is never created for a BB CAN Priority Pattern

Priority Settings	Region	Exch/Node	Network Element	NE ID	Range	Type	Associated Patterns	Current Reports	Active Trigger	Auto NODS	Created Date	User	Action
20	Sydney South	WETH				BBAND	C	51	Unchecked	No	02/12/16 11:00 PM		New

### 12.3.2.4. CAN Patternner

The following rules are used by Pattern Manager to determine the Network Element and range on which to form a Fast CAN Priority pattern and Auto-NODS.

Due to the number of possible Network Elements and valid cable Pair ranges involved in CAN fault patterns, the rules which Pattern Manager uses to determine on which Network Element and pair range to set up a CAN Priority Pattern and Auto-NODS are quite complex

- If, according to Patternner Hierarchy rules, the PP will be formed on the CAN pattern...
- Priority Pattern will form on the CAN Network Element in order of the closest to the exchange which meets CAN rules #1, #2 and #3:

**CAN PP Rule #1 First decide on the Network Element on which all the faults are:**

- are all services on one Main Cable
- If no, are all services on one Cabinet
- If no, are all services on one Gateway
- If no, are all services on one Pillar



- 
- If no, are all services on one Control Joint

**Rule #2 next, selecting the first CAN NE above which meets Rule #1, apply Pair Range Contiguity Rule #2, as follows:**

- If Main Cable, does the main pair range include a break in contiguity of > 100 pairs
- If yes, then does the Cabinet B Pair range (if present) include a break in contiguity of > 50 pairs
- If yes, the does the Gateway O Pair range (if present) include a break in contiguity of > 50 pairs
- If yes, the does the Pillar O Pair range (if present) include a break in contiguity of > 30 pairs
- If yes, the does the CJ O Pair range (if present) include a break in contiguity of > 30 pairs
- The first CAN network element and pair range which meets Rules #1 and #2 will be selected by Pattern Manager on which to create the CAN Priority Pattern and Auto-NODS
- If NO CAN network element meets BOTH Rule #1 and #2 but can meet Rule #1 then Pattern manager will use Rule #3 below

**Rule #3 next, selecting the first CAN NE above which meets Rule #1, apply Pair Range Contiguity Rule #2, as follows:**

- If Main Cable, does the main pair range include a break in contiguity of > 200 pairs
- If yes, then does the Cabinet B Pair range (if present) include a break in contiguity of > 100 pairs
- If yes, the does the Gateway O Pair range (if present) include a break in contiguity of > 50 pairs
- If yes, the does the Pillar O Pair range (if present) include a break in contiguity of > 50 pairs
- If yes, the does the CJ O Pair range (if present) include a break in contiguity of > 30 pairs
- If NO network element can meet either Rules #1 and #2 or #1 and #3, Pattern Manager will NOT create an Auto-NODS but will display a Priority Pattern alert on the Dashboard
- If Rules #1 and #3 can be met, the first CAN network element and pair range which meets Rules #1 and #3 will be selected by Pattern Manager on which to create the CAN Priority Pattern and Auto-NODS
- However, before an CAN Auto-NODS can be created, Pattern Manager must consult the following rule to determine the start and end pairs of the pair range to be used:

**Rule #4 Rounding out the CAN pair ranges**

---

**Main Cable**

- the start pair of the Auto-NODS range will be rounded down to the next even '100 +1' below the lowest displayed value, including 0.
  - E.g. if the lowest pair in the pattern was 71 the start pair of the NODS range will be Pair 1
  - if the lowest pair in the pattern was 245 the start pair of the NODS range will be Pair 201
- the end pair of the Auto-NODS range will be rounded up to the nearest '100'
  - E.g. if the highest pair in the pattern was 71 the end pair of the NODS range will be Pair 1500
  - if the highest pair in the pattern was 1483 the end pair of the NODS range will be Pair 201

**Cabinet or Gateway**

- the start pair of the Auto-NODS range will be rounded down to the next even '50 +1' below the lowest displayed value, including 0.
  - E.g. if the lowest pair in the pattern was 71 the start pair of the NODS range will be Pair 51
  - if the lowest pair in the pattern was 245 the start pair of the NODS range will be Pair 201
- the end pair of the Auto-NODS range will be rounded up to the nearest '100'
  - E.g. if the highest pair in the pattern was 21 the end pair of the NODS range will be Pair 50
  - if the highest pair in the pattern was 783 the end pair of the NODS range will be Pair 800

**Pillar or Control Joint**

- the start pair of the Auto-NODS range will be rounded down to the next even '10 +1' below the lowest displayed value, including 0.
  - E.g. if the lowest pair in the pattern was 21 the start pair of the NODS range will be Pair 21
  - if the lowest pair in the pattern was 245 the start pair of the NODS range will be Pair 240
- the end pair of the Auto-NODS range will be rounded up to the nearest '10'
  - E.g. if the highest pair in the pattern was 21 the end pair of the NODS range will be Pair 30
  - if the highest pair in the pattern was 383 the end pair of the NODS range will be Pair 380

---

## 12.4. Priority Pattern Auto NODS

As well as triggering a Priority Pattern alert on the Priority Outage dashboard, Pattern Manager will also attempt to automatically create a NODS on the Exchange, network element and pair range on which the Priority Pattern was formed.

Priority Pattern auto-NODS will only be created on:

- CAN Priority Patterns
- PGS Priority patterns

Pattern Manager will use the same logic for creating the CAN or PGS Auto-NODS as it uses to create the Priority pattern itself. Refer previous sections 12.2 and 12.3.

E.g. a Priority Pattern has been triggered by Fast criteria and has been created according to the Patterning rules in sections 12.2 and 12.3 on PTMA PGS RIM E2013 Panel 4. An Auto NODS will also be created on PTMA PGS RIM E2013 Panel 4.

If a PGS on which a Priority pattern and an Auto-NODS is being created is one belonging to a secondary exchange which is feeding services in a smaller sub-exchange, Pattern Manager will create the Auto-NODS on the secondary PGS exchange but also add the customer sub-exchange. Refer section 9.4.4.

When Pattern Manager has been able to create an Auto-NODS for a priority pattern, the following will occur:

- The 'Auto-NODS' column in Priority Outage Dashboard will have a 'Yes' entry
- The Auto-NODS ID will be added to the 'NODS\_ID' column of all FNNs in the relevant Pattern

If, despite using the rules in sections 12.1 and 12.3, Pattern Manager has not been able to determine the correct Network Element and range, it will create the PP and display on the Priority Outage Dashboard but will NOT create an Auto-NODS. The 'auto-NODS' column on the dashboard will display 'No'

Auto-NODS are NEVER created for Switch or BB CAN Priority Patterns.

Auto-NODS created by Pattern Manager will have the identical attributes to one created in native NODS by a SOM user with the following exceptions:

- An Expected Restoration and ETR will ALWAYS be derived from the SOM Outage ETR matrix table
- There will be NO Outage Parent case or CONEN entered in the Outage Description text
- Source System will be Pattern Manager
- Created User will be Auto-CAN or Auto-PGS

Refer also work Instruction [017921w08](#) NODS for Service Outage Management

---

## 12.5. Investigate Priority Pattern

When a new Priority pattern appears in the Priority Outage Dashboard it will need to be investigated by a SOM Complex Consultant.

Investigation of a Priority pattern has 3 objectives:

- Validate the Priority Patterning
- Update the Auto-NODS (if one was created)
- Perform any other required Outage Set-up actions or delegate to other SOM staff

SOM Complex Consultants will follow this basic routine to manage Priority Outage Dashboard:

1. Monitor Priority Outage Dashboard frequently and regularly throughout the day
2. Action 'New' PP alerts as they appear
3. Select 'In Progress' in the Action drop down list
4. Review the key details of the PP in the Dashboard to quickly get a picture of size, risk and urgency:
  - a. What is the Trigger?
  - b. How many faults in the outage?
  - c. Has an Auto NODS been created
  - d. Where is the outage?
  - e. What Network Element and range has the PP formed on?
5. Click the Exchange link to open the Exchange or Node in which the Priority Pattern has formed:
  - a. PP will be Checked off 'AVH'
  - b. NODS ID will be present if NODS auto-created
6. Analyse the Pattern as per BAU Pattern Manager related fault pattern analysis procedures
7. Determine the following:
  - a. Is there a valid outage?
  - b. Has Pattern Manager correctly identified the affected network element and range?
  - c. Is the Auto-NODS correctly created?

- 
- d. What needs to be done to set up the outage or perform other response (e.g. link faults)?
  8. Carry out required actions or delegate to other SOM staff or Partners:
    - a. Place on Watch in dashboard and patterner(s) if more evidence required or...
    - b. Update auto-NODS or...
    - c. Create manual NODS from within Patterner
    - d. Set up outage Parent, Query SIIAM, create CNO Log, etc. or...
    - e. Email SOM Simplex or Partners to complete the Outage setup or...
    - f. Cease auto-NODS and update Patterner Check off code if an alternative response is required e.g. Linking faults
  9. Action the PP alert in the Dashboard according to the findings, as per section 12.5 below
  10. Repeat the above process for the next 'New' PP alert

## 12.6. Action Priority Pattern

When a new Priority Pattern alert first appears in the Priority Outage Dashboard the Action field will display 'New' to alert SOM Complex consultants to the need to investigate it.

When the SOM Complex Consultant commences their investigation they will change the Action code to 'In progress' and click the 'Update' button. This will update the User field with their User ID.

After completing required investigations and actions, the SOM Complex consultant will change the Action code to one of two outcome Actions (and click Update button):

- 'Watch' – Priority pattern has been investigated but findings are inconclusive - awaiting further evidence
- 'Complete' – Priority pattern has been investigated and validated All required actions have been completed or delegated to other staff to complete e.g. update Auto-NODS, Set up Outage, etc.

When 'Complete' action is selected & updated the record will clear from the Priority Outage Dashboard but the actual related fault pattern in the relevant patterner will remain

UPDATE

Priority Settings	Region	Exch/Node	Network Element	NE ID	Range	Type	Associated Patterns	Current Reports	Active Trigger	Auto NODS	Created Date	User	Action
5 / 5	Brisbane	GNBH	AXE	GNBE		SWITCH		12	Fast	No	02/12/16 11:00 PM		New
5 / 5	Brisbane	LAND	PILLAR	P6	21-50	CAN	S	6	Fast	Yes	02/12/16 04:00 AM	c687775	In Progress
5 / 5	New South Wales North	NLTN	MAIN	5	1-600	CAN		12	Fast	Yes	02/12/16 01:00 AM	c687775	Watch
5 / 5	New South Wales North	BRPT	PILLAR	P22		CAN	S.P	7	Fast	No	02/12/16 04:26 PM	c687775	Watch In Progress Complete
5 / 5	New South Wales North	NLTN	PILLAR	P10		CAN		9	Fast	No	02/12/16 04:26 PM		
5 / 5	New South Wales North	NLTN	MAIN	5	1-500	CAN	B	9	Fast	Yes	02/12/16 05:00 AM		New


### 13. Pattern Manager Admin Version 2.0

Pattern Manager Admin Version 2.0 allows SOM staff to configure the way Pattern Manager forms and displays fault patterns.


Only SOM staff with SOM NODS-PM Super User access level are able to see and access the Pattern Manager Admin Version 2.0 link from the Pattern Manager Home screen.

To access Pattern Manager Admin to make changes follow these steps:

1. On the Pattern Manager Home screen, select the Pattern Manager Admin Version 2.0 option



2. Administration Page listing the various available Threshold and Value Configuration options will display
3. Select the required 'Update' option



---

The following functions can be configured from Pattern Manager Admin Version 2.0 option:

- **Update Priority Thresholds**

- Allows SOM to change the thresholds at which a fault pattern will be deemed a Priority Pattern
- There are 2 Priority Patterning thresholds:
  - Fast Forming
  - Large Unchecked

- **Update Patterner Thresholds**

- Allows changes to be made to the minimum number of patterned faults which will be displayed in a pattern for each Patterner and Region.
- Allows SOM to respond quickly to changes in workload, staffing and other operational requirements in order to maintain the most efficient, effective outage identification

- **Update Age of Patterning data**

- Allows SOM to change the timeframe in which faults will remain in Pattern Manager

- **Update Checklist Code**

- Allows SOM to add new check-off codes or delete obsolete ones

- **Update Symptom Code**

- Allows SOM to modify the types of faults considered as candidates for patterning.

- **Update PGS Types**

- Allows SOM to include new PGS types into Pattern Manager or to delete obsolete types withdrawn from service

- **Update Exchange**

- Allows SOM to add new or delete obsolete exchanges or to move exchanges between Regions (e.g. to align with Regional restructures)

- **Auto Outage Exchange**

- Allows SOM to exclude exchanges from having NODS auto-created. This is most commonly done for exchanges which have been asset transferred to Nbnco

- **Audit Trail Report**

- Allows SOM Manager to keep track of changes in order to ensure that
  - Required changes have been made



- 
- Due process and governance has been followed

**NOTE:** Changes made in SOM Admin 2.0 will only take effect at the next system update. Pattern Manager updates (refreshes) approximately every 10 - 15 minutes. Refer to Section 8.3 Patternner System Refresh Rates Table 9 for details on how to calculate when the changes will take effect.

### 13.1. Guidelines for Pattern Manager Admin changes

Changes to Pattern Manager Admin settings can be made in order to implement:

- General, long-term system, process and operational performance improvements as a result of
  - continuous improvement, new initiatives, troubleshooting, feedback, etc. or
  - changes to systems, process or business objectives
- Short Term, local changes to manage a local, short duration issue e.g.
  - Peak workload or natural disaster

To ensure that changes made to pattern Manager have the desired positive outcomes, the following guidelines should be followed:

- Propose changes on the basis of clear thinking and evidence
- Test changes in a low risk way, e.g. by introducing to one region
- Advise other users of the change and the reason
- Advise other users of any changes to their ways of working as a result of the change
- Review results of the change
- Document adopted changes
  - Long term general changes should be documented by updating this work instruction 017921w14 Pattern Manager 6.0
  - Short Term changes which are likely to be adopted as a Mode of Operations may need to be documented in other work instructions such as 017921w01 SOM Natural Disasters as well this work instruction.

### 13.2. Update Priority Thresholds

The Update Priority Threshold option allows SOM Super Users to reconfigure the triggers for forming Priority Patterns:

- Reset number of faults and required timeframe to form a 'Fast Forming' priority pattern
- Reset number of unchecked faults required to form an 'Unchecked' priority pattern

The 'Current Priority Outage Threshold values' table displays the current thresholds for each Priority pattern type and each region.

**To re-configure the Priority Pattern Unchecked Threshold follow these steps:**

1. On Administration Page select the 'Update Priority Thresholds' option
2. In 'Modify Unchecked Reports' type the new number of faults at which a Priority pattern will be triggered e.g. '15'
3. Click Modify button

**NOTE:** The Unchecked value always applies to ALL Patterners in ALL Regions

**To re-configure the Priority Pattern Fast Forming Threshold follow these steps:**

1. On Administration Page select the 'Update Patterner Thresholds' option
2. In 'Select Region to set Threshold' select the required Region from the drop down list e.g. QLDC – Queensland Country
3. In '# of reports' type the number of faults necessary to trigger a Priority pattern e.g. '12'
4. In 'Hours' type the number of hours in which the above number of faults must be reported in order to trigger a Priority Pattern e.g. '6'
5. Click Update button

**NOTE:** Different thresholds can be set for different regions. The threshold for fast patterns will apply to ALL Patterners in the selected Region

Warning! Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

**Current Priority Outage Threshold values**

Region	NSWN	NSWS	MELB	QLDC	BRIS	SANT	SYDN	SYDS	VICT	WA
Active Trigger										
Number of reports	5	5	5	5	5	5	5	5	5	5
Hours	5	5	5	5	5	5	5	5	5	5

Unchecked Reports	20
-------------------	----

Modify Unchecked Reports	<input type="text" value="15"/>	<input type="button" value="modify"/>
--------------------------	---------------------------------	---------------------------------------

Modify Threshold	
Select Region to set Threshold	<input type="text" value="QLDC - Queensland Country"/>
# of reports	<input type="text" value="12"/>
Hours	<input type="text" value="6"/>
Action Required	<input type="button" value="update"/>

---

### 13.3. Update Patterner Thresholds

The Update Patterner Threshold option allows SOM Super Users to reset the number of faults in a pattern at which a Pattern Manager will display a related fault pattern.

Different threshold can be applied for different Patterners and for different regions in Patterners

E.g. If all regions in CAN Patterner are set to a threshold of '5', patterns will not be presented until there are at least 5 faults in the same exchange and same pillar which are in 30 pair groupings.

If Brisbane and QLDC are then reset to 3, fault patterns will appear earlier in those particular regions, when there are only 3 faults in a pattern.

The fault display threshold settings for each Patterner/Region are also known as the Mode of Operation ('MO'). The Patterner Threshold applied will appear.

To re-configure the Patterner Thresholds follow these steps:

1. On Administration Page select the 'Update Patterner Thresholds' option
2. In the 'Modify Thresholds' window enter the required values:
  - a. New Threshold number
  - b. Required Region
  - c. Required Patterner
3. Click 'Update' button
4. To make multiple selections, repeat steps '6' and '7'
5. Return to selected Patterner Region dashboard – 'MO' (Mode of Operations) column will now display new updated threshold in **blue**
6. Change to fault threshold will take place at next refresh - note time on the Exchange Selection list that the system was last refreshed and add 10 minutes to calculate when change will occur.
7. Advise users

Warning! Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

**Current Threshold values**

Region	MELB	NSWN	NSWS	QLDC	BRIS	SANT	SYDN	SYDS	VICT	WA
Patterner										
CAN	5	5	5	5	5	5	5	5	5	5
PGS	4	4	4	4	4	4	4	4	4	4
SWITCH	5	5	5	5	5	5	5	5	5	5
BBAND	5	5	5	5	5	5	5	5	5	5

Modify Threshold	
Threshold	<input type="text" value="3"/>
Select Region to set Threshold	<input type="text" value="BRIS - Brisbane"/>
Select Patterner to set Threshold	<input type="text" value="CAN"/>
Action Required	<input type="button" value="update"/>

### 13.4. Update Age of Patterning Data

The Update Age of Patterning Data option allows SOM Super Users to modify the timeframe on which a fault pattern will be retained in Pattern Manager prior to expiring.

To re-configure the Age of Patterning Data timeframe follow these steps:

1. On Administration Page select the 'Update Age of Patterning Data' option
2. 'Age of patterning data (days)' field displays the current setting
3. In Modify Data Age, in data Age (in days) select the required number of days the fault pattern is to remain active in Pattern Manager e.g. '5'
4. Click Update button

**NOTE:** The Age of Data value selected will apply to ALL Patterners in ALL Regions

Warning! Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

Age of patterning data(days)	3
------------------------------	---

Modify Data Age	
Data Age(In Days)	No Selection
Action Required	<div> <div>3</div> <div>4</div> <div>5</div> <div>6</div> <div>7</div> <div>8</div> <div>9</div> <div>10</div> </div> <div>update</div>

St, Sydney NSW 2000 AUSTRALIA. All rights reserved

### 13.5. Update Checklist Code

The Update Checklist Codes option allows SOM Super Users to add new or delete or modify existing Checklist codes

Checklist codes represent standard options for the way SOM actions related fault patterns.

To re-configure the Check Off Code List follow these steps:

1. On the Administration page, select the 'Update Checklist Codes' option
2. In the 'Modify Checklist Codes' window enter the required Checklist code to be added or deleted:
3. Click 'Add' button to add a new code
4. Click 'Delete' button to delete an existing code
5. To make multiple selections, repeat steps '6' and '7' or '6' and '8'
6. The new code will now be available immediately in the Check code drop down list

Warning! Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

Update Checklist Code	
Existing CHECKLIST CODE	
Existing Checklist Codes	BVH CAN CLR CVH DIS LGT LNK NBN NYV PVH TCT WCH AVH aaa

Modify CHECKLIST CODE	
Checklist Code	aaa
Action Required	<div>add</div> <div>delete</div>

### 13.6. Update Symptom Code

The Update Symptom Codes option allows SOM Super Users to add new or delete existing SIIAM fault symptom codes.

To re-configure the Symptom Code List follow these steps:

1. On the Administration Page, select the 'Update Symptom Codes' option
2. In the 'Modify Symptom Codes' window enter the required Symptom code to be added or deleted:
3. Click 'Add' button to add a new code
4. Click 'Delete' button to delete an existing code
5. To make multiple selections, repeat steps '6' and '7' or '6' and '8'
6. Change to symptom codes included in fault patterns will take place at next refresh - note time on the Exchange Selection list that the system was last refreshed and add 10 minutes to calculate when change will occur.
7. Advise other users of change and reason

**Warning!** Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

Existing SYMPTOM CODES	
Existing CAN Symptom Codes	NTN CBO CTX EXO ICP NSF NSY NWO OGP PLR SSI SSS TSM UCC ULI ULL VMT DTP DTI DTG COS CCO DTD DTH
Existing PGS Symptom Codes	CBO CCO CEF COS CTX EXO ICP NSF NWO OGP TSM VMT NTN UCC NSY CBL DTP DTD DTG DTI
Existing Broadband CAN Symptom Codes	DTG DTI ULL URS SSI SSS DTA DTB DTC DTD DTE DTF DTH DTJ DTK DTL DTM DTN DTO DTP DTQ DTR DTS DTT DTU DTV DTW DTX ULI

Modify SYMPTOM CODES	
Symptom Code	<input type="text" value="ULL"/>
Select Patternner to set Symptom Code	<input type="text" value="BBAND"/>
Action Required	<input type="button" value="add"/> <input type="button" value="delete"/>

### 13.7. Update PGS Type

The Update PGS types option allows SOM Super Users to add new or delete existing Pair Gain System (PGS) types.

Changes to PGS type would normally only be made when:

- New PGS Types are introduced into service
- Older existing PGS types are withdrawn from service

Pattern Manager only recognises PGS Types which are entered in the precise format used by SIIAM – the system from Pattern Manager collects its data.

Each PGS Type must be allocated a 'PGS Class' i.e. network role. There are 3 PGS Network roles recognised by pattern Manager:

- Access Core (large PGS e.g. CMUX, RIM, etc.)
- CAN electronic (small PGS e.g. RAM 8, SCADS, etc.)

- ADSL DSLAM (e.g. AM35, ISAM, etc.)

To re-configure the PGS Type List follow these steps:

1. On Administration Page, select the 'Update PGS Types' option
2. In the 'Modify PGS Types' window enter the required 'PGS Type' to be added or deleted:
3. In the 'PGS Class' field enter the required network role e.g. 'Access Core'
4. Click 'Add' button to add a new type
5. Click 'Delete' button to delete an existing type
6. To make multiple selections, repeat steps '8', '9' and '10' or '8', '9' and '11'
7. Change to PGS Type included in fault patterns will take place at next refresh - note time on the Exchange Selection list that the system was last refreshed and add 10 minutes to calculate when change will occur.
8. Advise other users

**Warning!** Prior to proceeding Complete all required actions in the 'Admin Change Checklist' in 017921w14 Pattern Manager User Guide. Changes made to the system from these pages may jeopardise patterning, system performance or business process.

Existing PGS Types	
Existing Access Core PGS Types	CMUX SSNMUX RCM DCS20 RIM
Existing CAN Electronic PGS Types	1+4W 16/96 SCADS RAM81 RAM82 RAM8PH1 RAM8V901 RAM8V901 RAM8V90/2 RAM8/1 RAM8/2 MLC6/15 2DPGS 4DPGS 6/16
Existing Broadband PGS Types	AM31 AM35 ISAM ASAM

Modify PGS Types	
PGS Type	UMUX
PGS Class	No Selection Access Core CAN Electronic Broadband
Action Required	<input type="button" value="add"/> <input type="button" value="delete"/>

### 13.8. Update Exchange

Clicking the Update Exchange option allows SOM Super Users to add new or delete existing Exchanges or to move an existing exchange from one Pattern Manager Region to another (e.g. from country to metro).

Changes to Exchange will be rare and would normally only be made when:

- New exchange has been commissioned
- Old exchange has been decommissioned
- A Regional restructure has caused an exchange previously in a country area to now be metro (or vice versa)

To re-configure the Exchange List follow these steps:

1. On Administration Page, select the 'Update Exchange' option
2. In the 'Modify Exchange' window enter the required 'Exchange code' to be added or deleted:
3. In the 'Region from' field enter the Region from which the exchange is to be removed
4. In the 'Region to' field enter the Region to which the exchange is to be moved
5. Click 'Add' button to add a new exchange
6. Click 'Delete' button to delete an existing exchange
7. Click 'Move' button to move an existing exchange
8. To make multiple selections, repeat steps '8', '9' and '10' or '8', '9' and '11'
9. Change to Exchange included in fault patterns will take place at next refresh - note time on the Exchange Selection list that the system was last refreshed and add 10 minutes to calculate when change will occur.
10. Advise other users

Welcome c687775  
please click here for [HELP](#)

**Update Exchange Database**

<b>Exchange Code</b>	RAMS
<b>Exchange Name</b>	RAMSGATE
<b>FROM Exchange Region</b>	SYDS - Sydney South
<b>TO Exchange Region</b>	NSWS - New South Wales South
<b>Action Required</b>	<input type="button" value="add"/> <input type="button" value="delete"/> <input type="button" value="update"/> <input type="button" value="move"/> <input type="button" value="reset"/>

### 13.9. Update Auto Outage Exchange

Clicking the Update Auto Outage Exchange option allows SOM Super Users to add Exchanges to an 'exclusion' list which will prevent Pattern Manger from creating auto-outages on these exchanges.

This is primarily used to prevent inappropriate outages being automatically set up on exchanges whose CAN copper cables have been asset-transferred to Nbnco.

To update the Auto-Exchange exclusion List follow these steps:

1. On Administration Page, select the 'Update Auto Exchange' option
2. In the 'Modify Exchange' window enter the required 'Exchange code' to be added or deleted:
3. In the 'Region from' field enter the Region from which the exchange is to be removed
4. In the 'Region to' field enter the Region to which the exchange is to be moved



5. Click 'Add' button to add a new exchange
6. Click 'Delete' button to delete an existing exchange
7. Click 'Move' button to move an existing exchange
8. To make multiple selections, repeat steps '8', '9' and '10' or '8', '9' and '11'
9. Change to Exchange included in fault patterns will take place at next refresh - note time on the Exchange Selection list that the system was last refreshed and add 10 minutes to calculate when change will occur.
10. Advise other users

Welcome c687775  
please click here for [HELP](#)

Update Exchange Database

Exchange Code	RAMS
Exchange Name	RAMSGATE
FROM Exchange Region	SYDS - Sydney South
TO Exchange Region	NSWS - New South Wales South
Action Required	<input type="button" value="add"/> <input type="button" value="delete"/> <input type="button" value="update"/> <input type="button" value="move"/> <input type="button" value="reset"/>

### 13.10. Audit Trail Report

Clicking the 'Audit Trail Report' option allows users with a SOM Administrator access profile to produce a report listing all SOM Administrator changes made, when and by whom for the specified period.

This report is normally accessed by the SOM Team Manager to:

- Ensure due governance over Pattern Manager changes
- Maintain the integrity of Pattern Manager patterning effectiveness
- Investigate issues, complaints or Post Incident Reviews (PIR)

#### Step-by-step instructions for accessing Audit Trail Report

1. Identify a valid business need to access the Audit Trail report
2. On the main Pattern Selection screen, select the SOM Administrator option
3. On the SOM Administration screen, select the 'Audit Trail Report' option
4. In the 'Audit Trail Report' window enter the following details:
  - a. From date (dd/mm/yyyy)
  - b. To date (dd/mm/yyyy)
  - c. Module (i.e. SOM Admin setting change e.g. Symptom Codes)
5. Click 'Submit' button to produce the report
6. At the 'File Download' window (Audit Trail.csv) click the following buttons:

- a. 'Open' – to open the Report as csv file on user's desktop
- b. 'Save' – to save the report as csv file to selected location on user's hard drive

7. The csv report will display/be available as in the example below.

[Home](#) [Pattern Manager Home](#) [Logout](#)


## ADMINISTRATION PAGE

Welcome c687775

**Audit Trail Report**

<b>From Date</b>	01/12/2016 (dd/mm/yyyy)
<b>To Date</b>	04/12/2016 (dd/mm/yyyy)
<b>For Module</b>	Priority Threshold
<b>Action Required</b>	<input type="button" value="SUBMIT"/> <input type="button" value="RESET"/>

Copyright © 1998 TELSTRA Level 3, 175 Liverpool St, Sydney NSW 2000 AUSTRALIA. All rights reserved



The screenshot shows an Excel spreadsheet titled 'Audit Report'. The data is organized into columns: Field, User ID, Region Name, Pattern, Modified Date, Prior Value, Modified Value, Action, Updated, UPGS, Class, Number, and Hours. The data rows show various 'Priority Threshold' updates for different regions and users, all dated 2016-12-01, with actions of 'UPDATE' and a value of 6.

	A	B	C	D	E	F	G	H	I	J	K	L
	Field	User ID	Region Na	Pattern	Modified Da	Prior Value	Modified V	Action	Updated U	PGS Clas	Number of	Hours
2	Priority Threshold	d318354	NSWN	-	2016-12-01	-	-	UPDATE	-	-	6	6
3	Priority Threshold	d318354	NSWS	-	2016-12-01	-	-	UPDATE	-	-	6	6
4	Priority Threshold	d318354	MELB	-	2016-12-01	-	-	UPDATE	-	-	6	6
5	Priority Threshold	d318354	QLDC	-	2016-12-01	-	-	UPDATE	-	-	6	6
6	Priority Threshold	d318354	BRIS	-	2016-12-01	-	-	UPDATE	-	-	6	6
7	Priority Threshold	d318354	SANT	-	2016-12-01	-	-	UPDATE	-	-	6	6
8	Priority Threshold	d318354	SYDN	-	2016-12-01	-	-	UPDATE	-	-	6	6
9	Priority Threshold	d318354	SYDS	-	2016-12-01	-	-	UPDATE	-	-	6	6
10	Priority Threshold	d318354	VICT	-	2016-12-01	-	-	UPDATE	-	-	6	6
11	Priority Threshold	d318354	WA	-	2016-12-01	-	-	UPDATE	-	-	6	6
12	Priority Threshold	d318354	NSWN	-	2016-12-01	-	-	UPDATE	-	-	12	6
13	Priority Threshold	d318354	NSWS	-	2016-12-01	-	-	UPDATE	-	-	12	6
14	Priority Threshold	d318354	MELB	-	2016-12-01	-	-	UPDATE	-	-	12	6
15	Priority Threshold	d318354	QLDC	-	2016-12-01	-	-	UPDATE	-	-	12	6
16	Priority Threshold	d318354	BRIS	-	2016-12-01	-	-	UPDATE	-	-	12	6

### 13.11. Pattern Manager Admin Messages

When an Update to one of the Pattern Manager Admin settings has been successfully completed, a success message will display.

Select 'Continue' to return to Administration Page

[Pattern Manager Home](#)

## ADMINISTRATION PAGE

**You have successfully deleted the Symptom Code a from CAN Patterner**

[Continue](#)


If invalid information is entered or required information is not entered on any of the Pattern Manager Admin options, a pop-up error message will display similar to below

Click 'OK' to return to the Administration Page and enter correct/missing information.

**Current Threshold values**

Region	QLDC	BRIS	NSWN	NSWS	SYDN	SYDS	MELB	VICT	SANT	WA
<b>Patternner</b>										
CAN	5	5	5	5	5	5	5	5	5	5
PGS	4	4	4	4	4	4	4	4	4	4
SWITCH	5	5	5	5	5	5	5	5	5	5
BBAND	5	5	5	5	5	5	5	5	5	5

Message from webpage



Threshold has not been selected

[OK](#)

<b>Threshold</b>	No Selection ▼
<b>Select Region to set Threshold</b>	QLDC - Queensland Country ▼
<b>Select Patternner to set Threshold</b>	CAN ▼
<b>Action Required</b>	<a href="#">update</a>

## 14. Functionality common to all Patterners

The following sections describe key functionality, common to all the patterners, in detail.

The order of the following sections follows the approximate order in which each function will be encountered in the Patterners from left to right.

### 14.1. Plain Text View


Each Exchange and Region can be viewed in plain text view for printing, emailing etc. One advantage of the plain view is that each separate pattern is identified by a unique ID.

There are 2 plain views available:

- Exchange plain text view
- Region plain text view

#### Exchange plain text

WA | [printable](#)  
as at 01-12-2016 16:47  
72% checked



Riverton (RIVT) [UPDATE](#)

exch	tot	new	HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR
<a href="#">BALD</a>	21	8											
<a href="#">BYFD</a>	17												
<a href="#">HAMS</a>	11	4	P S B	1614146577	29/11/16	10:45	ULL	15	381				36

Select ▼

Se

CAN PATTERN MANAGER

WA

Thu Dec 1 16:47:54 2016

EXCH	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	chk	Pattern ID	NODS_ID
RIVT	1614146577	29/11/16	10:45	ULL	15	381					36	41					CVH	417	
	0894578395	29/11/16	11:30	NTN	15	321					36	32					CVH	417	
	0894573450	29/11/16	16:53	NSY	15	350					36	33					CVH	417	
	1610644726	29/11/16	21:12	ULL	7	235					36	68					CVH	418	
	0892596223	30/11/16	09:06	NTN	15	233					36	82					CVH	418	
	0894573535	28/11/16	13:13	NTN													Field-Open		

End of Report: 6 FNNs (shows all fnns)

1. Click on the 'Scroll' icon at the left of the blue banner
2. A new tab will open displaying the exchange fault pattern in plain text
3. The individual patterns will be denoted by separate Pattern Ids

#### Region Fault Pattern plain text view

WA   <a href="#">printable</a> as at 01-12-2016 16:47 72% checked		Riverton (RIVT) <a href="#">UPDATE</a>														
exch	tot	new	HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	I		
<a href="#">BALD</a>	21	8														
<a href="#">BYFD</a>	17															
<a href="#">HAMS</a>	11	4	P S B	1614146577	29/11/16	10:45	ULL	15	381						36	



- If a code letter against a particular FNN appears in plain black text and not underlined then the FNN does not appear in that Patternner.
- When an active hyperlink is clicked the following will occur:
  - The other Patternner will open - in a new tab - displaying its Exchange Fault Pattern screen with the selected FNN highlighted in blue text
  - The windows can then be arranged to best view and compare the pattern information

Clicking the 'X' in the new tab will close it and return the user to the original Patternner.

### 14.3. Table of PSTN Symptom Codes

The following table lists standard SIIAM Symptom (Report) codes selected by FOH consultants to represent the problem being experienced by the customer with their PSTN service and which appear in P{pattern manager fault pattern displays:

SYM CODE	DESCRIPTION	CAN	PGS	BB CAN
CBL	Cable (on customers' premises) Problem	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CBO	IVR created fault on Cable Cut NODS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CCO	Calls Cutting Off	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CEF	Customer Equipment Fault	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
COS	Cut Off (while) Speaking	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CTK	Cross-talk	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DTP	Data Transmission Problem e.g. ISDN, Fax or Dial-up	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EXO	IVR created fault on Exchange NODS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
ICP	Incoming Call Problem	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
NSF	Non-Standard Fault	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
NSY	Noisy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
NTN	No Tone	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
NWO	IVR created fault on Network Facility NODS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OGP	Outgoing (call) Problem	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
PLR	Pillar (damage / wires exposed)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SSI	Spectrum Sharing (Service) Interference	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SSS	Spectrum Sharing Service	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
TSM	Transmission Problems	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UCC	Underground Cable Cut	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
ULI	Unconditioned Local (Loop) Interference	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

ULL	Unconditioned Local Loop	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
URS	Unconditioned (Local Loop) Reliability Standard (breached)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
VMT	Voices Music Tones (on line)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

#### 14.4. Table of ADSL Symptom Codes

The following table lists the 3 character code conversion from the standard SIIAM 4 character Symptom (Report) codes selected by FOH consultants to represent the problem being experienced by the customer with their ADSL service and which appear in Pattern manager fault pattern displays:

SIIAM SYM CODE	DESCRIPTION	ADSL SYM CODE
DTC	Fails to authenticate on connection	AUTH
DTD	Loss of connectivity/intermittent problem	DROP
DTE	No data flow	NDAT
DTF	No sync – new service	NNSY
DTG	No sync – existing service	NSYN
DTH	Speed-related issue	SPEE
DTI	Times out when connecting	TIME
DTJ	Tech visit required	DOCT
DTK	Self-instal failure	
DTL	Fails to authenticate on connection-wireless	WIRELESS AUTH
DTM	Tech visit required-wireless	WIRELESS DOCT
DTN	Loss of connectivity/intermittent problem - wireless	WIRELESS DROP
DTO	No data flow - wireless	WIRELESS NDAT
DTQ	No sync – new service - wireless	WIRELESS NNSY
DTR	No sync – existing service - wireless	WIRELESS NSYN
DTS	Speed-related issue - wireless	WIRELESS SPEE
DTT	Times out when connecting - wireless	WIRELESS TIME
DTU	Email issues - wireless	
DTV	Web browser issues - wireless	
DTX	Connectivity issues - wireless	

## 14.5. Create NODS from Patterner

The Create NODS functionality allows SOM consultants to immediately create a NODS outage notification (which will appear in SIIAM) directly from within the Patterner Exchange screen as soon as an outage has been analysed and confirmed.

This reduces the amount of time and 'swivel-chairing' necessary to set-up outages and to notify FOH and customers.


The Create NODS functionality is available in the following Patterners:

- CAN Patterner
- PGS Patterner
- Switch Patterner

Follow these steps to Create a NODS using the PM Create NODS function

1. From the information in Pattern Manager and external systems (e.g. CASINO, GDD, etc.) confirm the outage and determine the correct network element and pair range
  - E.g. network element Pillar P1 and O pair range 81-100 have been determined as the correct scope
2. Using the drop down boxes select:
  - The CAN network element - P1
  - Enter the pair range 81-100
3. Click Create NODS button
  - A NODS will be created 'semi-automatically'
  - NODS ID will appear in the NODS column
  - User can click the NODS ID link to view and update the NODS
  - The NODS will be created by Pattern Manager with the standard values, ETR and Outage Description as used by SOM to create manual NODS
  - A CVH check-off code will be automatically applied
  - Some information, e.g. Parent case and CONEN ID and instructions to offer interims will have to be manually added by using the NODs Update button
  - NODS created this way will have a Source System of 'Pattern Manager' and a Created User of the name of the consultant who used the function

### CAN PATTERNER 6.0



The screenshot shows the 'CAN PATTERNER 6.0' interface. At the top, there is a header bar with 'Carmilla (CARM)' and buttons for 'UPDATE' and 'Create NODS'. Below the header is a table with columns: HP, FNN, DATE, TIME, SYM, MAIN, mPR, CAB, bPR, GAT, oPR, PILL, oPR, CJ1, oPR1, CJ2, oPR2, X, NODS\_ID, USER, and Chk\_List. The table contains several rows of data. A red circle highlights the 'PILL' column, showing a dropdown menu with 'Select P1' and '81-100' selected. Another red circle highlights the 'oPR' column, showing a dropdown menu with '81-100' selected. At the bottom of the interface, there is a status bar with the text 'end CARM as c687775 6 fnn(s)' and 'last refresh: Wed Nov 30 19:04:44 2016 EST'.





## 14.6. Service Types

The following table lists the various NPAMS Service Type codes which indicate the basic service type of each FNN e.g. whether PSTN, ADSL or ISDN

X Code	Service Type	X Code	Service Type
AB	Line Hunt Auxiliary	RK	ISDN Primary
DB	Line Hunt Primary	SL	PSTN - Silent
LA	Line Hunt ADSL Auxiliary	SS	PSTN
LB	Line Hunt ADSL Primary	UL	ULL
MA	Faxstream Primary	XR	ADSL
MC	Faxstream Auxiliary	XS	ADSL - Silent
RA	ISDN Auxiliary		

## 14.7. Check off Codes

When a fault pattern first displays in Pattern Manager, each fault in the pattern will display its SIIAM case status at the time the pattern was formed e.g. Field-Open or Test-Pending.

This status appears in a field called the Chk\_Lst (Check List) which also contains a series of 3 character codes used by SOM to indicate the results of their analysis of the fault pattern e.g. 'CVH' when an outage has been confirmed or 'NYV' when an outage has not yet been confirmed.

The Check Code is used:

- To indicate that a pattern has been analysed and actions
- To alert users to new faults which have arrived within a pattern or which have formed new patterns
- To display the respective volumes and percentages of checked vs unchecked faults in each exchange and region which is an indication of workload and potential risk
- By the Blackhawk interface to display colour coded alerts on the Sauron Switch Pattern display in the GOC which helps alert SAO to potential Switch issues

The user Id of the staff member who last actioned a check-off code will be recorded in the User column.

Once a Check code has been selected the screen changes must be saved by use of the 'Update' button.

There are three methods of checking off fault patterns:

- **Individual Update**
  - Click the Chk\_Lst Drop Down against the fault and select the required code e.g. NYV
  - Click the Update button in the centre of the banner

Gundillia (GDLN) UPDATE Create NODS No Selection UPDATE ALL

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_lst		
P	S	B	0248471266	30/11/16	12:47	NTN	1														Field-Open	<input type="checkbox"/>
P	S	B	0248471199	01/12/16	12:17	NTN	1														BVH	<input type="checkbox"/>
P	S	B	0248471186	01/12/16	15:09	NTN	1														PVH	<input type="checkbox"/>
P	S	B	0248471121	01/12/16	11:33	NTN	1														CVH	<input type="checkbox"/>
P	S	B	0248471203	01/12/16	11:51	NTN	1														CLR	<input type="checkbox"/>
P	S	B	QGLDNE0001	26/11/16	11:55	NSF															CAN	<input type="checkbox"/>
																					LGT	<input type="checkbox"/>
																					LNK	<input type="checkbox"/>
																					NYV	<input type="checkbox"/>
																					WCH	<input type="checkbox"/>
																					NBN	<input type="checkbox"/>
																					DIS	<input type="checkbox"/>
																					TCT	<input type="checkbox"/>
																					AVH	<input type="checkbox"/>

end GDLN as c687775 6 fnn(s)  
last refresh: Thu Dec 1 00:32:06 2016 EST

### • Multiple Update

- Click the 'No Selection' drop down list next to the Update All button
- Select the required Check code e.g. CVH
- Tick the check boxes next to each of the faults to be checked off
- Click the Update All at the right of the banner


Carmilla (CARM) UPDATE Create NODS No Selection UPDATE ALL

HP	FNN	DATE	TIME	SYM	MAIN	mPR	CAB	bPR	GAT	oPR	PILL	oPR	CJ1	oPR1	CJ2	oPR2	X	NODS_ID	USER	Chk_lst		
P	S	B	0749502356	29/11/16	17:33	UCC					1	98										<input type="checkbox"/>
P	S	B	0749502284	29/11/16	19:01	NTN					1	96										<input type="checkbox"/>
P	S	B	0749502254	29/11/16	19:06	NTN					1	100										<input type="checkbox"/>
P	S	B	0749502236	29/11/16	19:08	NTN					1	93										<input type="checkbox"/>
P	S	B	0749502274	30/11/16	09:28	NTN					1	83										<input type="checkbox"/>
P	S	B	0749502027	01/12/16	10:46	NTN					1	94										<input type="checkbox"/>
P	S	B	QCARME5002	30/11/16	13:46	NSF																<input type="checkbox"/>

end CARM as c687775 7 fnn(s)

### • Update All

- Click the 'No Selection' drop down list next to the Update All button
- Select the required Check code e.g. LNK
- Tick the check box at the top - this will auto-tick all checkboxes against all faults on the screen
- Click the Update All at the right of the banner



Actioned check-off codes can be changed by simply re-selecting a new code and clicking 'Update' e.g. if a pattern checked off as 'NYV' was subsequently found to be an outage, the code can be changed to 'CVH'.

Once the exchange screen has been updated, the browser refresh button can be clicked to immediately update the totals in the Exchange list. Otherwise totals will update at the next 10-minute system refresh.

If a user has created a NODS from within Pattern Manager, the Check List will be automatically updated with CVH and the User ID of the consultant who created the NODS.

If a NODS has been auto-created by Priority Patterner, the Check List will be automatically updated with AVH – no user ID will be recorded.

Refer Table Check-off codes

## 14.8. Table Check Off Codes

The following table lists standard check off codes in use by SOM and their meanings:

Code	Meaning	Use
AVH	Automatic Volume Hold	Pattern meets Priority Patterning criteria and a NODS has been automatically created
CLR*	Cleared	Fault has been confirmed as having no valid significance to fault pattern and has been removed from Patterner or...  Very large volumes of faults removed from Patterner after actioning to prevent system performance issues.
CVH	Confirmed Volume Hold	Sufficient evidence exists for a potential outage and a Volume Hold Queue has been set up.  Also applied when a NODS is created from within Pattern Manager

CAN	CAN Rehab	Fault is being managed as part of a CAN Rehabilitation project in a SOM CAN Rehab queue – NO CNO
DIS	Dismantled	Fault is part of a CNO has been dismantled after advice from Field staff that patterned faults are not part of an outage
LGT	Lightning	Fault has been confirmed as caused by lightning strike with NO common affected network element AND individual attendance of customer premises is required – NO CNO
LNK	Linked	Fault has been deemed better managed by linking in Connect. Linking team advised – NO CNO
NBN	National Broadband Network	Fault is an NBN Access Seeker service
NYV	Not Yet Volume Hold	Insufficient evidence exists AT THIS TIME for a potential outage and a Volume Hold Queue has NOT yet been set up.
PVH	Planned Volume Hold	Fault is part of a CNO set up to manage a large number of faults associated with a CAN Rehab Planned Outage
TCT	Telstra Continuity Team	Fault is part of an outage on Continuity copper cable asset transferred to Nbnco and is being managed by TCT-SOM
WCH	Watch!	<p>Strong but so far inconclusive evidence exists for a potential outage. No CNO has yet been set up but this pattern MUST be watched closely or...</p> <p>Strong evidence for a potential outage exists but waiting on confirmation from another workgroup (e.g. NS). No CNO has yet been set up - this pattern MUST be followed up and watched closely</p>

#### 14.9. Pattern Refresh Rates and Timings

The following table provides an indication of the timeframes and frequency for system refresh of data in each of the Patterners.

Example:

SOM Super User changes CAN Pattern Threshold at 9:27

Changes will take until 9:30-9:31 to be processed

New patterns according to changed thresholds will display at next System update 9:35

Task	Refresh Run Days	Refresh Run Hours	Refresh Rate / Interval	Refresh Timings (example)	Refresh Job Average Duration
Fault Download from SIIAM	Everyday	0300 - 2300	Every 10 mins	...10:00 10:10 10:20 10:30 10:40 10:50 11:00...	3-4 mins
CAN Patterning	Everyday	0300 - 2300	Every 10 mins	...10:05 10:15 10:25 10:35 10:45 10:55 11:05...	3-4 mins
PGS Patterning	Everyday	0300 - 2300	Every 10 mins	...10:00 10:10 10:20 10:30 10:40 10:50 11:00...	3-4 mins
Switch Patterning	Everyday	0300 - 2300	Every 15 mins	...10:10 10:25 10:40 10:55 11:10 11:25 11:40...	3-4 mins
Broadband CAN Patterning	Everyday	0300 - 2300	Every 10 mins	...10:00 10:05 10:15 10:25 10:35 10:45 10:55 11:00...	3-4 mins

## 15. References

Document number	Title
<a href="#">017921</a>	SOM Procedure
<a href="#">017921w06</a>	Outage Identification & Setup
<a href="#">017921w07</a>	Pattern Manager – Identification & Actioning of Related Fault Patterns
<a href="#">017921w08</a>	NODS for Service Outage Management

## 16. Attachments

Document number	Title

## 17. Definitions

Term	Definition
ADSL	Asynchronous Digital Subscriber Line
ARMES	Alarm Receipt and Monitoring Evaluation System
AXE	Automatic Exchange Equipment (switching technology)
BB	Broadband
CAN	Customer Access Network
CASINO	Clarification of Associated Services in Network Outages
CMUX	Customer Multiplexer
CNSC	Customer Network Support Centre
CPAS	Cable Pressure Alarm System
CT	Communications Technician
DSL	Digital Subscriber Line
DSLAM	Digital Subscriber Line Access Multiplexer
EM	Exchange Magazine
EMG	Exchange Magazine Group
EN	Equipment Number (S12 device)
FTTP	Fibre To The Premises
GDD	Graphical Data Display
GOC	Global Operations Centre
ISAM	Intelligent Services Access Manager
ISDN	Integrated Services Digital Network
LI	Line Interface (AXE device)

Term	Definition
NICAD	National ISDN Customised Alarm Display
NODS	Network Outage Database System
NPAMS	National Plant Assignment Management System
PGS	Pair Gains System
PIR	Post Incident Report
POTS	Plain Old Telephone Service
RSA	Remote Subscriber Access (S12 Switch)
RSS	Remote Switching Stage (AXE Switch)
S12	System 12 (switching technology)
SAO	Service Assurance Operations
Shazbot	Application which acts as a user friendly interface to display associated service details from a number of sources e.g. NPAMS and Axis, including a schematic cable details diagram view
SIIAM	Service Improvement In Assurance Management – core customer fault management system
SLCT	Sultan Line Circuit Test
SOM	Service Outage Management
SSS	Spectrum Sharing Service
TADA	Test and Diagnostics Application
TSO	Telstra Service Ops
ULL	Unconditioned Local Loop

## 18. Document Control Sheet

Who to reach out to if you have any queries, questions, changes or concerns.

Name	Lambley, Jason
Position	Process Specialist
Phone	0415 350 012
Email	Jason.Lambley@team.telstra.com



If you have a suggestion for improving this document, please contact the person listed above.

Issue number	Issue date	Details on the change
1	2 Dec 2009	1 <sup>st</sup> issue incorporating system changes and improvements introduced in Pattern Manager Upgrade project Phase 1 & Phase 2 Drop 1 & 2 - PK
2	3 May 2010	Revised to incorporate system changes as a result of Pattern Manager Upgrade Project Phase 2 Drop 3 April 2010. Added sections for Region Selection Dashboard, Fault Display Thresholds and SOM Administrator changes. PK
3	8 Oct 2010	Revised to incorporate system changes as a result of Pattern Manager Upgrade Project Phase 2 Drop 4 October 2010. New section on DummyFNN in CAN Patternner. Revised sections on CMUX handling in PGS & BB CAN Patternners. PK
4	2 Jun 2015	Correct content on CMUX DSLAM failures in Section 5.3 as provided previously by TSO SME Adam Edwards. Update SOM and TSO business unit names PK
5	8 December 2016	Completely revised content and screenshots to support deployment of Priority Patternner Enhancement on web-NODS platform on 9 December 2016. New sections on Priority outage Dashboard, priority patterning and Auto-NODS creation. PK
6	21 July 2017	Completely revised content and screenshots to support deployment of Priority Patternner Enhancement on web-NODS platform on 9 December 2016. New sections on Priority outage Dashboard, priority patterning and Auto-NODS creation. PK

This publication has been prepared and written by Telstra Corporation Limited (ABN 33 051 775 556), and is copyright. Other than for the purposes of and subject to the conditions prescribed under the Copyright Act, no part of it may in any form or by any means (electronic, mechanical, microcopying, photocopying, recording or otherwise) be reproduced, stored in a retrieval system or transmitted without prior written permission from the document controller. Product or company names are trademarks or registered trademarks of their respective holders.

Note for non-Telstra readers: The contents of this publication are subject to change without notice. All efforts have been made to ensure the accuracy of this publication. Notwithstanding, Telstra Corporation Limited does not assume responsibility for any errors nor for any consequences arising from any errors in this publication.