



You can • use Microsoft® Windows™ Media Player 11 to transfer music from your PC to your phone

1. Music Tips

- You need a music library on your PC. Create or add to your music library by copying music CDs to your PC (called *ripping*) or downloading music from the web.
- Use Windows Media Player to rip CDs. Insert your CD and click the **Rip** tab.
- Music types supported on your phone: AMR NB, XMF, MP3, AAC, WMA v10, WMA v9, AAC+ Enhanced, AAC+, WAV.
If your music is in any other format, convert it to a supported format before transferring it to your phone.

- You can purchase Microsoft Janus DRM-protected music files from supported online music stores such as Yahoo, Napster, and Urge.

2. To transfer music to your phone, press **Settings** > **Connections** > **USB Setting** > **Media Sync**.

3. Connect the USB cable to your phone and PC.

4. In Windows Media Player, click the **Sync** tab.

If this is the first time connecting your phone to Windows Media Player, you will be prompted to complete the Device Setup wizard first.

5. Drag the music you want to transfer to the **Sync List** (see 1 and 2) and click **Start Sync** (see 3).

6. Before disconnecting the cable, use the **Safely Remove Hardware** tool in your PC system tray to stop the USB connection.

