

RTL8192D operation mode

Supported operation mode:

🚩 92D-VS:

- SMSP(Single MAC Single PHY):
- 2.4G/5G 2x2.

🚩 92D-VC:

- DMDP(Dual MAC Dual PHY): (default setting.)
- 2.4G 1x1(MAC0) and 5G 1x1(MAC1).
- SMSP(Single MAC Single PHY):
- 2.4G/5G 2x2.
- DMSP(Dual MAC Single PHY): (To do)
- 2.4G/5G 2x2 for MAC0 or MAC1.

Interface in Linux:

DMDP or DMSP has two interface - wlanX (MAC0) and wlanY(MAC1).

SMSP has only one interface – wlanX.

X and Y are numbers. Y should be larger than X. In most condition $Y = X+1$.

How to change operation mode for 92D-VC

Use the following command for DMDP To SMSP:

1. `rmmod 8192du`
2. `insmod 8192du.ko rtw_mac_phy_mode=1`