

Hands-On Training


Pre-requisites:

1. For Windows users, pre-install PuTTY and WinSCP/Filezilla or other serial console/scp client tools.

PuTTY (<http://www.putty.org/>) – serial console tool
WinSCP(<https://winscp.net/eng/download.php>) or Filezilla (<https://filezilla-project.org/>) or other scp client for Windows

2. Install ARTIK IDE and ARTIK 530s SDK on your laptop. Instruction is at: <https://developer.artik.io/documentation/developer-guide/artik-ide/install-ide.html>.

After you install ARTIK IDE, please go to Help-> ARTIK Package Manager, and install ARTIK 530s SDK v1.7.1 and gcc-arm-linux-gnueabi toolchain




3. For Windows users, Please

- a. Browse to the ARTIK_IDE_Installation_Directory\tools directory.

- b. Run the zadig-2.3.exe application.
- c. Under **Options**, select **List All Devices**.
- d. Under the devices drop-down list, select Interface 1 of the dual COM port.
- e. Update the driver to the WinUSB driver by clicking **Replace**

Driver.



- f. Now select Interface 0 of the FTDI device, and change it to a `libusb` driver.