

# **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

**Product Version IC23.1  
November 2023**

© 2023 Cadence Design Systems, Inc.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

**Trademarks:** Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

---

# Contents

---

## 1

### Virtuoso Automated Standard Cell Placement and Routing . 7

Environment Setup for Automated Standard Cell Placement and Routing Flow . . . . . 8

Virtuoso Automated Standard Cell Placement and Routing Flow . . . . . 10

## 2

### Initializing a Layout in the Auto P&R Standard Cell Flow. . . . 13

Setting Up a Design in the Auto P&R Standard Cell Flow . . . . . 15

Standard Cell Components Generated During Placement . . . . . 19

Placing Standard Cells Automatically . . . . . 20

Adding Boundary Cells During Automated Standard Cell Placement . . . . . 22

Adding Tap Cells During Automated Standard Cell Placement . . . . . 24

Adding Filler Cells During Automated Standard Cell Placement . . . . . 27

## 3

### Virtuoso Automated Standard Cell Routing . . . . . 31

Configuring Standard Cell Router Settings . . . . . 32

Assigning Wire Types to Nets . . . . . 34

Generating Width Spacing Patterns for Standard Cell Routing . . . . . 35

Checking Layout Routability after Running Standard Cell Placer . . . . . 38

Generating a Supply Grid . . . . . 43

Running Signal Routing for Standard Cells . . . . . 45

Viewing and Analyzing Standard Cell Routing Results . . . . . 49

## 4

# Standard Cell Placement and Routing Environment Variables

53

<u>FB1RouteBlockageLayer</u>	56
<u>FB1SpecialDRCRegionLayer</u>	57
<u>abstractViewName</u>	58
<u>alternativeBoundaryLayer</u>	59
<u>check_displayLog</u>	60
<u>check_existingDRCs</u>	61
<u>check_generateMarkers</u>	62
<u>check_overwriteLog</u>	63
<u>checkerLogDir</u>	64
<u>checkerLogPrefix</u>	65
<u>coverTermPins</u>	66
<u>createNewFigGroupsPerRun</u>	67
<u>disableInvsWSPGen</u>	68
<u>fixAllPreroutes</u>	69
<u>invsLicenseArgs</u>	70
<u>layoutViewName</u>	71
<u>ldrsCG</u>	72
<u>multiTechLEFOVERRIDE</u>	73
<u>omitRedundantPatchShapes</u>	74
<u>omitTrimLayers</u>	75
<u>physOnlyFigGroupPrefix</u>	76
<u>postInitCmds</u>	77
<u>postPlacementCmds</u>	78
<u>postRouteCmds</u>	79
<u>postRouteTrigger</u>	80
<u>preBndyTapCmds</u>	81
<u>preInitCmds</u>	82
<u>prePlacementCmds</u>	83
<u>preRouteCmds</u>	84
<u>preRouteTrigger</u>	85
<u>preserveFillerPlaceStatus</u>	86
<u>remasterLayoutLibs</u>	87

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

<u>results_nets</u>	88
<u>results_netsWithin</u>	89
<u>results_supplyNets</u>	90
<u>route_createRoutingAsAGroup</u>	91
<u>route_defaultRoutedView</u>	92
<u>route_deletePreroutes</u>	93
<u>route_deleteWiresAndVias</u>	94
<u>route_displayLog</u>	95
<u>route_fixPostRouteDRCErrors</u>	96
<u>route_nets</u>	97
<u>route_netsWithin</u>	98
<u>route_overwriteLog</u>	99
<u>route_routedLOC</u>	100
<u>route_saveRoutingOnly</u>	101
<u>route_supplyNets</u>	102
<u>route_updatePinOption</u>	103
<u>route_updatePins</u>	104
<u>routerLogPrefix</u>	105
<u>runDir</u>	106
<u>separateStdCellLibs</u>	107
<u>setPinFixedWithinBoundary</u>	108
<u>setup_checkDRCsAfterRouting</u>	109
<u>setup_lockColorsAfterRouting</u>	110
<u>signalRouteFigGroupPrefix</u>	111
<u>siteDefHeight</u>	112
<u>siteDefSymmetricInR90</u>	113
<u>siteDefSymmetricInX</u>	114
<u>siteDefSymmetricInY</u>	115
<u>siteDefWidth</u>	116
<u>supply_connectToTerminals</u>	117
<u>supply_createGridAsGroup</u>	118
<u>supply_createPinLabel</u>	119
<u>supply_createPins</u>	120
<u>supply_createPinsOnEnds</u>	121
<u>supply_createPinsOnPinPurpose</u>	122
<u>supply_defaultRoutedCellExpression</u>	123

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

---

<u>supply_defaultRoutedView</u>	124
<u>supply_defaultWireCGOVERRIDE</u>	125
<u>supply_deleteStripes</u>	126
<u>supply_deleteVias</u>	127
<u>supply_genSupplyStripes</u>	128
<u>supply_generateStaples</u>	129
<u>supply_ignoreBoundaryTracks</u>	130
<u>supply_ignoreBoundaryVias</u>	131
<u>supply_insertTrim</u>	132
<u>supply_insertVias</u>	133
<u>supply_nets</u>	134
<u>supply_netsWithin</u>	135
<u>supply_pinLayers</u>	136
<u>supply_pinLayerSet</u>	137
<u>supply_routedLOC</u>	138
<u>supply_saveRoutingOnly</u>	139
<u>supply_shareTracks</u>	140
<u>supply_useExistingPGTracks</u>	141
<u>tracksCmds</u>	142
<u>useMultipleTapCells</u>	143
<u>useStylusMode</u>	144
<u>Standard Cell Placement Environment Variables</u>	145
<u>advNode</u>	147
<u>init_boundaryAspectRatioOrHeight</u>	148
<u>init_boundaryAspectRatioVal</u>	149
<u>init_boundaryHeightVal</u>	150
<u>init_boundaryUtilizationOrWidth</u>	151
<u>init_boundaryUtilizationVal</u>	152
<u>init_boundaryWidthVal</u>	153
<u>init_createPowerPins</u>	154
<u>init_generateBoundary</u>	155
<u>init_generateInstances</u>	156
<u>init_generatePins</u>	157
<u>init_mode</u>	158
<u>init_scope</u>	159
<u>init_useSourceLayout</u>	160

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

<u>init_useSourceLayoutBoundary</u>	161
<u>init_useSourceLayoutInstances</u>	162
<u>init_useSourceLayoutPins</u>	163
<u>place_addBoundaryCells</u>	164
<u>place_addCellRowRouting</u>	165
<u>place_addDecapFillerCells</u>	166
<u>place_addTapCells</u>	167
<u>place_boundaryCellsContainTapCells</u>	168
<u>place_createPhysOnlyAsAGroup</u>	169
<u>place_defaultPlacedView</u>	170
<u>place_deleteBoundaryCells</u>	171
<u>place_deleteFillerCells</u>	172
<u>place_deleteTapCells</u>	173
<u>place_displayLog</u>	174
<u>place_overwriteLog</u>	175
<u>place_placedLocation</u>	176
<u>place_placeStdCells</u>	177
<u>place_showInformation</u>	178
<u>postPlaceTrigger</u>	179
<u>prePlaceTrigger</u>	180
<u>runDir</u>	181
<u>setup_createRowRegionInArea</u>	182
<u>setup_displayLog</u>	183
<u>setup_Innovus1stRowOrientation</u>	184
<u>setup_overwriteLog</u>	185
<u>setup_rowCount</u>	186
<u>setup_rowCreation</u>	187

## 5

### Automated Standard Cell Placement and Routing User Interface

<u>Auto P&amp;R Assistant User Interface for Standard Cell</u>	190
<u>Auto P&amp;R Assistant Toolbar</u>	190
<u>Auto P&amp;R Assistant Tabs</u>	191
<u>Auto P&amp;R Command Buttons</u>	197

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

---

<u>Routing Assistant User Interface for Standard Cell</u> .....	197
<u>Routing Assistant Toolbar</u> .....	197
<u>Routing Assistant Tabs</u> .....	198
<u>Routing Assistant Command Buttons</u> .....	208
<u>Assign Wire Types to Nets Form</u> .....	209
<u>Boundary Cells Form</u> .....	210
<u>Choose Source Layout Cellview Form</u> .....	211
<u>Filler Cells Form</u> .....	211
<u>Load Option Presets Form</u> .....	212
<u>Map WSP Wire Types to Symbols Form</u> .....	213
<u>Pull Back and Offset Values Form</u> .....	213
<u>Save Option Presets Form</u> .....	214
<u>Select Row Template Form</u> .....	214
<u>Tap Cells Form</u> .....	215



---

# Virtuoso Automated Standard Cell Placement and Routing

---



The Virtuoso automated standard cell placement and routing flow comprises a series of tasks to generate automatically placed and routed layouts.

The standard cell placement and routing solution in Virtuoso seamlessly integrates the Innovus placer (GigaPlacer– GP) and router NanoRoute (NR) for designs less than 2K instances that are not timing driven. The flow starts from a schematic design and generates the layout view from source. Then it goes through creating WSPs, creating placement rows, doing supply routing, IO pin planning, placement cell selection, and placement. At this point, placement is complete and the design is ready for routing. It uses the Pre-Route Browser to guide you in selecting the nets for routing and then route the nets. The routing results can be viewed in the Routing Results Browser.

In standard cell routing, there are different ways for you to generate WSPs. You can also route the design without them, relying on Innovus-created tracks instead.

The Verilog, LEF/DEF (EMH) flow is not supported. It can cause module problems where cells are being created when they already exist as leaf cells.

In the Virtuoso standard cell placement and routing flow, you use the Auto P&R assistant for standard cell placement and the Routing assistant for standard cell routing in the Layout MXL cockpit.

You can use environment variables to change the value of many aspects of your environment either for an individual design session or permanently until you change the value of the variable again.

## ***Related Topics***

[Environment Setup for Automated Standard Cell Placement and Routing Flow](#)

[Virtuoso Automated Standard Cell Placement and Routing Flow](#)

[Routing Assistant User Interface for Standard Cell](#)

# **Environment Setup for Automated Standard Cell Placement and Routing Flow**

To run the automated standard cell placement and routing flow, ensure the following:

## ■ **Virtuoso Release**

- ☐ Standard Cell Routing: IC23.1 or later
- ☐ Standard Cell Placement: IC23.1 or later

## ■ **Innovus**

Innovus 20.14 version or later must be available in the build path.

## ■ **PDK Settings**

- ☐ PDK settings are available either from the foundry or built from the technology file from the foundry
- ☐ An RMSOA PDK matching layer stack of base PDK with non-colliding siteDef, NDR, and via names

## ■ **Standard cells must have a PR boundary (layout and abstract views)**

Use a library that has both the layout and abstract views for standard cells in the same library. This allows automatic remastering of layout views to abstracts in Innovus.

## ■ **Abstract views for standard cells and blocks are recommended**

- ☐ Site definitions or names
- ☐ Antenna information
- ☐ EDGETYPES (advanced node)
- ☐ Blocks with IO pins not on the PR boundary must have detailed abstracts

## ■ **Pcells in the design**

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Placement and Routing

---

When Pcells exist in the design, the `CDS_ENABLE_EXP_PCELL` shell environment variable must be set to `true` and the Pcell cache saved.

- Supply and ground sigTypes are set on power and ground nets.
- Virtuoso Standard Cell placement is run on the design and the placement is LVS correct and DRC compliant as specified in the technology file.
- Pins are grouped or clustered in close proximity and that buses are typically used for pins between blocks.
- All pins are on a routing layer.
- The minimum number of wire widths do not conform to the `LEFDefaultRouteSpec` or `NonDefaultRules` (NDRs) rules.

#### ■ License:

##### **Standard Cell Placement**

Virtuoso Layout Suite MXL

##### **Standard Cell Routing**

Virtuoso Layout Suite MXL

This license is limited to 2000 standard cell instances in the design, which allows use of Virtuoso Layout Suite MXL without checking out additional Innovus startup licenses. For designs featuring more than 2000 instances, one or more Innovus startup licenses are required. The Innovus license can be configured using the `invsLicenseArgs` environment variable. There might be other Innovus licenses required based on the chosen methodology, such as `Innovus_hfr_opt` for high-frequency routing (NRHF).

The Innovus ENG100 (Encounter\_NG100) license is needed until Innovus 23.1X is available for `cdsFixedVias`.


### ***Related Topics***

[Virtuoso Automated Standard Cell Placement and Routing](#)

[Virtuoso Automated Standard Cell Placement and Routing Flow](#)

## Virtuoso Automated Standard Cell Placement and Routing Flow

The following diagram summarizes the Virtuoso automated standard cell placement and routing flow.



Flow Steps:

### Standard Cell Placement:

Standard cell placement involves the following steps:

- Initializing the layout: The first step is layout generation, where information about the PR boundary, instances, nets, and pins is generated in the target layout as per the source schematic.
- Setting up the design for placement: In this step, you prepare the design for placement and routing by generating WSPs, rows, and supply grid.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Placement and Routing

---

- **Placing Standard Cells:** Here, you run the automated standard cell placer. This step involves placing IO pins and adding boundary and tap cells before running the placer, and adding filler cells after running the placer.

#### **Standard Cell Routing:**

The following steps summarize the standard cell routing flow.

- **Generate Width Spacing Patterns:** The first step in the routing technology flow is WSP generation. Information about the shapes on the layer, tracks, and patterns is generated in the design.
- **Check Routability:** In this step, you select the checks that should run before routing a design.
- **Generate Supply Grid:** The next step in the flow lets you generate power rails for VDD and GND nets.
- **Run Automatic Routing:** This step in the flow helps you to route all or selected nets.
- **View and Analyze Routing Results:** Finally, you can analyze the routing results from a single table using the Routing Results Browser. It shows the number of opens, shorts, wire length, DRC, vias, and so on.

#### ***Related Topics***

[Virtuoso Automated Standard Cell Placement and Routing](#)

[Environment Setup for Automated Standard Cell Placement and Routing Flow](#)

[Virtuoso Automated Standard Cell Routing](#)

# **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

## Virtuoso Automated Standard Cell Placement and Routing

---

---

## Initializing a Layout in the Auto P&R Standard Cell Flow

---


To initialize a layout view in the Auto P&R standard cell flow:

1. Open the *Initialize* tab of the Auto P&R assistant.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

2. Select *Generate* to generate new objects in the layout canvas or *Update* to update the existing objects.



3. Set the scope of layout generation to either *All* or *Selected*.
4. Select *Instances* to generate all instances from the source schematic.
5. Select *Pins* to generate pins during initialization.
6. Select *Power Pin Layer* to generate power pins.
7. Select an LPP from the *Pin layer* list that contains the standard cell pins to be generated. The default value is the first metal layer in the layer stack.
8. Select a layer from the *Power pin layer* list that contains the power and ground pins to be generated during initialization.
9. Select *Boundary* to generate a PR boundary as per the specified combination of *Utilization* and *Aspect Ratio* or *Width* and *Height*.



## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

---

10. In Layout MXL, the *Migration Options* section is available, which lets you run the assisted flow of the Virtuoso® Custom Design Migration solution. For more information, see [Setting Options for Custom Layout Design Migration](#).

11. In the *PDK Settings* section, select a process node from the *Process Setup* drop-down list.

The process setup name is displayed below and the settings for the selected process node are loaded in the form. There is a direct mapping of this *Process Setup* in the Virtuoso Digital Implementation (VDI) GUI. The specified process setup triggers different placement and routing strategies that are built into Innovus.

12. Click *Generate* to generate the selected objects in the layout canvas.

Instances and pins are generated below the PR boundary.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Setting Up a Design in the Auto P&R Standard Cell Flow](#)

[Placing Standard Cells Automatically](#)

## Setting Up a Design in the Auto P&R Standard Cell Flow

In the Auto P&R standard cell flow, after generating the PR boundary, instances, nets, and pins in the layout, the next step is to prepare the design for placement and routing.


Use the *Setup* tab of the Auto P&R assistant to configure the WSP settings, routing preferences, pin attributes, row generation options, and routing checks before running the standard cell placer.

To specify placement and routing settings for standard cells:

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide


## Initializing a Layout in the Auto P&R Standard Cell Flow

1. Open the *Setup* tab of the Auto P&R assistant.



2. Set up WSPs by selecting *Browse* beside one of the following options:
  - ☐ *Create manually* to use the WSP Manager. After specifying the required settings, close the form.
  - ☐ *Create automatically* to use the *Setup* tab of the Routing assistant.
  - ☐ *Set active WSPs* to use the Track Pattern assistant.
3. In the *Rows* section, specify how rows are to be created—imported from Innovus or created in Virtuoso.
  - ☐ When set to *Import Innovus rows*, the tool imports the entire row region that either fits within the PR boundary or the region you draw with *Create rows in area*.

Set *First row orientation* to the orientation of the bottom-most (first) row in the row region.




## Virtuoso Automated Standard Cell Placement and Routing Flow Guide


### Initializing a Layout in the Auto P&R Standard Cell Flow

---

- ❑ When *Rows* is set to *Create row region*, click the *Browse* button next to *Row template* and select a row template based on which rows are to be generated.



4. Select *Create rows in area* to enable the row region selection options.
  - a. Set the row area to either the visible area ( [Red dashed box icon] ) or draw the required area ( [Blue box with hand icon] ) in the design canvas.
  - b. Select [Eye icon] to toggle visibility of the area bbox in the design canvas.
5. Select *Display log* to specify whether the setup log must be displayed in the CIW.
6. Select *Overwrite log* to overwrite the existing setup log. When this option is not selected, a new log file is created.
7. Click [Red X icon] to delete any existing created rows.
8. Click [Green + icon] to create a new row region.
9. Click *Browse* beside *Generate supply grid* to open the *Supply* tab of the Routing assistant, which lets you create a uniform width and pitch pattern-based WSP.



If the boundary cells have blockages on the power rails, select the *Add cell row routing* option on the *Route* tab of the Routing assistant. Do not create stripes on the standard cell power rails (cell row) layer with the supply router. Instead Innovus creates the stripes after the boundary cells are placed, and it respects the blockages in them.

10. Click *Browse* next to *Specify pin positions and attributes* to open the *Pin Planner* tab of the Pin Placement form, where you can specify pin constraints and pin attributes.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

---

11. Click *Browse* beside *Run checks* to display the *Check* tab of the Routing assistant, where you can select the required pre-routing checks to be run during design placement.

Your design is now ready for placement.

#### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

Routing assistant - [Setup](#) tab

Routing assistant - [Supply](#) tab

Routing assistant - [Check](#) tab

[Pin Planner tab of the Pin Placement form](#)

## Standard Cell Components Generated During Placement

Placement of standard cells has a unique set of requirements when compared to the placement of devices. In addition to standard cells, you require:

- **Boundary Cells:** At advanced nodes, adjacent cells (core cells) are placed in close proximity, which can lead to undesirable electrical effects. Adding boundary cells around core cells isolates the core cells from each other, and therefore prevents undesired effects.

Boundary cells are represented by cells that have their component class set to `BOUNDARYCELL`. Component types are defined in the *Cells* table of the [Configure Physical Hierarchy window—Component Types](#) mode. After ensuring that the boundary cell definitions are in place, you can insert them between the core cells in your design.

- **Tap Cells:** In addition to boundary cells, you can insert either single-height or multi-height tap cells in the empty spaces between the standard cells. Tap cells are a set of contacts that are used to reduce latch-up effects between power and ground connections and the connections with wells or substrate contacts.

Tap cells are represented by cells that have their component class set to `STDSUBCONT`. Component types are defined in the *Cells* table of the [Configure Physical Hierarchy window—Component Types](#) mode.

- **Filler Cells:** After standard cell placement, there might be some gaps or unfilled areas in layout designs. Unfilled areas might also result if the *Utilization* setting was selected on the *Initialize* tab when generating the design. Running a DRC check on such designs at this point could report several spacing violations. To avoid these violations, you must generate filler cells in the unfilled area between standard cells.

Filler cells are assigned to a component type with their component class set to `FILLER`.

Before inserting new filler cells, delete any existing filler cells. Otherwise, the placement of cells is prevented because of over congestion.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Placing Standard Cells Automatically](#)

[Adding Boundary Cells During Automated Standard Cell Placement](#)

[Adding Tap Cells During Automated Standard Cell Placement](#)


## Adding Filler Cells During Automated Standard Cell Placement

# Placing Standard Cells Automatically

In the Virtuoso standard cell automatic placement flow, you first initialize the layout and then set up the design for routing. You can then run the automated standard cell placer to place the standard cells in the design. While running the placer, you can add boundary cells and tap cells to prevent any undesired effect during routing.

To run the Virtuoso standard cell automatic placer:

1. Open the *Place* tab of the Auto P&R assistant.



2. Insert boundary cells by doing one of the following:

- ☐ Select *Boundary cells contain tap cells* to insert boundary cells and tap cells automatically.
- ☐ Select *Add boundary cells* and click the *Browse* button beside it to open the Boundary Cells from.

Use the options in the form to insert boundary cells. See [Adding Boundary Cells During Automated Standard Cell Placement](#).

3. Select *Add tap cells* and click the *Browse* button beside it to open the Tap Cells from.


Use the options in the form to add tap cells. See [Adding Tap Cells During Automated Standard Cell Placement](#).

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide


### Initializing a Layout in the Auto P&R Standard Cell Flow

---

4. Select *Add cell row routing* to add follow-pin (cell row) routing and insert vias with correct color in Innovus.
5. Select *Place std cells* to add the command to place standard cells into the Tcl command script.
6. Select *Add decap/filler cells* and click the *Browse* button beside it to open the Filler Cells from.
7. Use the options in the form to add filler cells. See [Adding Filler Cells During Automated Standard Cell Placement](#).
8. To insert decap cells, select only decap cells and then follow the procedure to add filler cells.
9. Select *Create physical only cells as group* to add physical-only instances (boundary, tap, and filler or decap) cells into a figGroup.
10. In the *Update* section, select the components to be deleted before generating new ones in the design.



11. In the *Output* section, specify the placement log settings.



- a. Select *Display log* to specify whether the placement log must be displayed in the CIW.
- b. Click the view icon to display the contents of the log file in the CIW.
- c. Select *Overwrite log* to overwrite the existing placement log. When this option is not selected, a new log file is created.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide


### Initializing a Layout in the Auto P&R Standard Cell Flow

---

- d. Specify where the placement results are to be stored: *Current view* or *Other view*.

When set to *Other cellview*, click *Browse* and select a location from the Choose Source Layout Cellview form.

12. In the *Interactive Placement* section, select *Show information* to display information about placement in the CIW.



13. Click the *Run*  button to run the Virtuoso standard cell automatic placer.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Standard Cell Components Generated During Placement](#)

[Adding Boundary Cells During Automated Standard Cell Placement](#)

[Adding Tap Cells During Automated Standard Cell Placement](#)

[Adding Filler Cells During Automated Standard Cell Placement](#)

## **Adding Boundary Cells During Automated Standard Cell Placement**

In standard cell designs, we adding boundary cells around core cells to isolate these core cells from each other, and therefore prevent any undesired effects. In the Virtuoso standard cell automatic placement and routing flow, boundary cells are added as part of the placement step.

To add boundary cells:

1. Open the *Place* tab of the Auto P&R assistant in Standard Cell mode
2. Select *Add boundary cells* and click the ellipses button.




## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

---

The Boundary Cells form appears.



3. From the drop-down list at the top, select the side on which to insert boundary cells.
4. In the *Cells* table, select the boundary cells to be inserted on the selected side.

The boundary cells are added to the specified side. The *Filter* field supports regular expressions to help you find the cells if many cells are present. The table at the bottom shows the count of boundary cells. For example, if you have selected one boundary cell to be added to the *Top* edge, the table displays the following:

T	B	L	R	TLC	TRC	BLC	BRC
1	0	0	0	0	0	0	0

5. Repeat the above steps to add boundary cells to other edges.
6. Click *OK*.

Boundary cells are generated as specified when you run the automated standard cell placer.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Standard Cell Components Generated During Placement](#)

[Placing Standard Cells Automatically](#)

[Adding Tap Cells During Automated Standard Cell Placement](#)

[Adding Filler Cells During Automated Standard Cell Placement](#)

## **Adding Tap Cells During Automated Standard Cell Placement**

In the Virtuoso standard cell automatic placement and routing flow, adding tap cells helps reduce latch-up effects between power and ground connections and the connections with wells or substrate contacts. Tap cells are inserted as part of the placement step.

To specify tap cell settings:

1. Open the *Place* tab of the Auto P&R assistant in Standard Cell mode.
2. Select *Add tap cells* and click the ellipsis button.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

---

The Tap Cells form appears.




3. From the *Cells* list, select the required cells to be used as tap cells. These are the cells with their component class set to `STDSUBCONT`.
  - ☐ You can filter cells by typing the required substring in the *Filter* box. The *Filter* field supports regular expressions.
  - ☐ To clear all filters, select *Clear selected*.
  - ☐ Select *Show selected Only* to hide the cells that are not selected.


## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

4. In *Tap to Tap spacing*, specify the spacing to be maintained between adjacent tap cells.
5. From the *Pattern* list, select the pattern in which tap cells are to be inserted: *Regular* or *Checker Board*.



**Pattern: Regular**




**Pattern: Checker Board**

The *Skip Row Count* and *Avoid Abutment* settings are not available when the *Checker Board* pattern is selected.

6. Set *Skip Row Count* to the number rows to be skipped while inserting tap cells. The top row cannot be skipped. In the following example, alternate rows are skipped.



7. In *Start Row Number*, specify the row number from which tap cell insertion must start.
8. Specify the *Offset from Row Start*, which is the initial offset for the first tap cell in each row.
9. Select *Avoid Abutment* to specify that the tap cells must not be abutted vertically. By default, tap cells are abutted.



10. In *Well Pitch*, specify the pitch or the minimum spacing between standard cells and the tap cell wall.
11. In *Well Offset*, specify the offset of the tap cell wall from their adjoining standard cells.
12. Click *OK* to close the form and go back to the *Place* tab of the Auto P&R assistant.

Tap cells are added when you run the automated standard cell placer.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Standard Cell Components Generated During Placement](#)

[Placing Standard Cells Automatically](#)

[Adding Boundary Cells During Automated Standard Cell Placement](#)

[Adding Filler Cells During Automated Standard Cell Placement](#)

## **Adding Filler Cells During Automated Standard Cell Placement**

Use the Filler Cells form to select the filler cells to be inserted after running the placer. To specify filler cell settings:


1. Open the *Place* tab of the Auto P&R assistant in Standard Cell mode.
2. Select *Add decap/filler cells* and click *Browse*.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Initializing a Layout in the Auto P&R Standard Cell Flow

---

The Filler Cells form appears.



3. From the *Cells* list, select the required cells to be used as filler cells. These are the cells with their component class set to `FILLER`.
  - ☐ To filter the cells list, specify the keywords in the *Filter* box. The *Filter* field supports regular expressions.
  - ☐ To clear all filters, select *Clear Selected*.
  - ☐ Select *Show selected only* to hide the cells that are not selected.
4. Click *OK* to close the form and go back to the *Place* tab of the Auto P&R assistant.

Filler cells settings are saved and are generated after running the automated standard cell placer.

### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Standard Cell Components Generated During Placement](#)

## **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

Initializing a Layout in the Auto P&R Standard Cell Flow

---

Placing Standard Cells Automatically

Adding Boundary Cells During Automated Standard Cell Placement

Adding Tap Cells During Automated Standard Cell Placement

## **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

### Initializing a Layout in the Auto P&R Standard Cell Flow

---



---

# Virtuoso Automated Standard Cell Routing

---

The Virtuoso standard cell routing solution seamlessly integrates the Innovus NanoRoute™ router in the Virtuoso Studio design environment. The flow starts from a schematic design from which a layout view is generated. You can then import IO pin and boundary information from an existing layout and step through the creation of Innovus-compatible row regions before completing power routing and the placement of tap cells and standard cells.

The Verilog, LEF/DEF flow is not supported. It can cause module problems where cells are being created when they already exist as leaf cells.

In standard cell routing, there are different ways for you to generate WSPs. You can also route the design without them, relying on Innovus created tracks instead.

## ***Related Topics***

[Routing Assistant User Interface for Standard Cell](#)

[Configuring Standard Cell Router Settings](#)

[Generating Width Spacing Patterns for Standard Cell Routing](#)

[Checking Layout Routability after Running Standard Cell Placer](#)

[Generating a Supply Grid](#)

[Running Signal Routing for Standard Cells](#)

[Viewing and Analyzing Standard Cell Routing Results](#)


## Configuring Standard Cell Router Settings

After the standard cell placement, use the Routing Assistant to configure the various routing options for standard cell routing before you run the router. To configure router settings:

1. Open a design in Layout MXL.
2. Choose *Window – Assistants – Routing*.

Alternatively, right-click anywhere on the layout window menu bar and choose *Assistants – Routing*.

The *Setup* tab of the Routing assistant is displayed.



3. Select *Check DRCs after routing* to automatically run design rule checks after routing.


## Virtuoso Automated Standard Cell Placement and Routing Flow Guide


### Virtuoso Automated Standard Cell Routing

---

4. Select *Lock colors after routing* to automatically color-lock the shapes after routing.
5. Select the appropriate process node from the *Process setup* drop-down list. *Default* is selected if a process node does not exist.

If the RMSOA PDK has multiple techLEFs, an additional Multi-tech LEF option is displayed. The different foundry rules are available as options in the drop-down list.


6. Choose the bottom and top preferred routing layers from the *Bottom* and *Top* drop-down lists. Specifying valid routing layers updates the WSPs visible in the table and specifies which layers the router should use for routing.
7. Select the layers for which you want to configure the router settings. You can either select all layers or one or more of them.
8. Click *Wire Types Map*  to open the Map WSP Wire Types to Symbols form, which shows the wire type-to-symbol mapping information. You can add custom wire types and map them to unique symbols.




The dialog box titled "Map WSP Wire Types to Symbols" contains a table with two columns: "Wire Type" and "Symbol".

Wire Type	Symbol
power	p
ground	g
signal	s
none	n

At the bottom of the dialog are buttons for "+", "-", "OK", and "Cancel".

9. Click *Assign to Nets*  to open the Assign Wire Types to Nets form, which shows a table for wireTypes to nets assignment.



The dialog box titled "Assign Wire Types to Nets" contains a table with three columns: "Net", "Signal Type", and "Wire Type".

Net	Signal Type	Wire Type
vdd	supply	power
vss	ground	ground

At the bottom of the dialog are buttons for "+", "-", "OK", and "Cancel".

10. Once the router settings are configured, you can generate width spacing patterns (WSPs).

### ***Related Topics***

[Routing Assistant User Interface for Standard Cell](#)

[Generating Width Spacing Patterns for Standard Cell Routing](#)

[Checking Layout Routability after Running Standard Cell Placer](#)


[Map WSP Wire Types to Symbols Form](#)


[Assigning Wire Types to Nets](#)

[Assign Wire Types to Nets Form](#)

## **Assigning Wire Types to Nets**

The Assign Wire Types to Nets form is used to set `sigType` for the supply router and to know which tracks to create stripes for nets. To assign wire types to nets:

1. Click *Assign to Nets*  button in the Setup tab of the Routing Assistant. It opens the Assign Wire Types to Nets form with a table that assigns wireTypes to nets.



The dialog box titled "Assign Wire Types to Nets" contains a table with three columns: Net, Signal Type, and Wire Type. The table has two rows: vdd (supply, power) and vss (ground, ground). Below the table is a large empty area for additional assignments. At the bottom are buttons for +, -, OK, and Cancel.

Net	Signal Type	Wire Type
vdd	supply	power
vss	ground	ground

2. Click the + button to add a new wire type and net assignment.
3. Specify the net names as `VDD` and `VSS` in the *Net* column.
4. Specify the signal type as `power` and `ground` in the *Signal Type* column.

5. Select the wire type as `power` or `ground` in the *Wire Type* column. You can assign multiple wireTypes to a net.
6. Click *OK*.

### ***Related Topics***

[Assign Wire Types to Nets Form](#)

[Configuring Standard Cell Router Settings](#)

[Routing Assistant User Interface for Standard Cell](#)

## **Generating Width Spacing Patterns for Standard Cell Routing**

In automated Routing Technology, there are three methods for generating WSPs.

- Using the WSP Manager
- Importing WSPs from a design
- Generating WSPs automatically

This topic covers the method of generating WSPs automatically. For information on generating WSPs using WSP Manager and importing WSPs, see [Creating and Modifying WSPs](#) and [Importing WSPs from Another Design](#).

To automatically generate WSPs:

1. Open a design in Layout MXL.
2. Choose *Window – Assistants – Routing*.

Alternatively, right-click anywhere on the layout window menu bar and choose *Assistants – Routing*. The Routing Assistant is displayed.

3. In the *Setup* tab, select the bottom and top routing layers from the *Bottom* and *Top* drop-down list. Specifying valid routing layers updates the WSPs visible in the table and specifies which layers the router should use for routing.
4. Select the required routing layers by clicking the check box in the layer table. WSPs are generated only on the selected layers. You can select all layers or specific ones. You can

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

also select one or more layers by clicking the check box next to the layer name. The check box selection indicates for which layers you want to generate WSPs.

<input type="checkbox"/>	Layer	Pattern	Dir	W	S	WSP
<input type="checkbox"/>	Poly		#	0	0.068	
<input type="checkbox"/>	LiAct			0	0.045	
<input type="checkbox"/>	LiPo		#	0	0.034	
<input checked="" type="checkbox"/>	M1	gs9ps9	≡	0.032	0.032	M1_WSP1
<input checked="" type="checkbox"/>	M2	gs9ps9		0.032	0.032	APR_gs9ps9_M2_WSP_0
<input checked="" type="checkbox"/>	M3	gs9ps9	≡	0.032	0.032	APR_gs9ps9_M3_WSP_0
<input checked="" type="checkbox"/>	M4	gs8ps8		0.032	0.048	APR_gs8ps8_M4_WSP_0
<input checked="" type="checkbox"/>	M5	n	≡	0.058	0.068	APR_M5_252_WSP1
<input checked="" type="checkbox"/>	M6	n		0.058	0.068	APR_M6_252_WSP1
<input checked="" type="checkbox"/>	M7	n	≡	0.069	0.09	APR_M7_318_WSP1
<input checked="" type="checkbox"/>	MT	n		0.22	0.2	APR_MT_840_WSP1

Multiple active WSP definitions are not allowed on the same layer. Multiple widths are supported in the same WSP (coincident tracks) but not multiple WSP definitions. This is because, in such cases, it is difficult to assume that all the effective tracks are DRC clean in terms of color and spacing.

5. Leave the *Pattern* column of the layer table blank for the M5 layer. The *Filter* field supports regular expressions to help you find the cells if many cells are present. If the standard cell power rail layer does not match a uniform width and spacing track pattern, it is appropriate to either use add\_tracks with width and spacing parameters or use the Wire Assistant Derive functionality to create the WSPs for that layer.

The WSPs are automatically generated from the tracks that Innovus generates when the *Pattern* field is left blank. If there are existing WSPs, the Innovus tracks are not generated. Ensure that all the WSPs are inactive in the Track Pattern assistant before doing this step.

If the *Pattern* field is not blank, WSPs are generated based on the pattern with the WSP pattern generator. The *Pattern* field determines whether WSPs are generated from Innovus or from a pattern.


WSPs generated from Innovus do not have a wireType assigned. They can be used as a starting point in WSP Manager and the wireType can be added there.


6. Specify a pattern for example, gs9ps9, for metal layers in the *Pattern* column of the layer table. The pattern gs9ps9 means that the track wireTypes are ground, signal, signal, signal, signal, signal, signal, signal, signal, signal, signal, power, signal, signal, signal, signal, signal, signal, signal, signal. It generates WSPs based on the pattern with the WSP pattern generator.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide


### Virtuoso Automated Standard Cell Routing

The Map WSP Wire Types to Symbols Form informs you which character represents the wireType in the WSP that is to be created. The particular character or symbol is used in the pattern string.

- Click *Auto-generate WSPs*  at the bottom of the Routing assistant. WSPs are automatically generated for the selected metal layers.



Layer	Pattern	Dir	W	S	WSP
M1	gs9ps9	≡			M1_WSP1
M2	gs9ps9	≡	0.032	0.032	APR_gs9ps9_M2_WSP_0
M3	gs9ps9	≡	0.032	0.032	APR_gs9ps9_M3_WSP_0
M4	gs9ps9	≡	0.032	0.048	APR_gs9ps9_M4_WSP_0
M5	gs9ps9	≡	0.058	0.068	APR_gs9ps9_M5_WSP_0
M6	gs9ps9	≡	0.058	0.068	APR_gs9ps9_M6_WSP_0
M7	gs9ps9	≡	0.069	0.09	APR_gs9ps9_M7_WSP_0

- Click *Snap pins to WSPs*  and check if the IO pins can snap to the WSPs.
- Select any layer in the layer table to view its WSP attributes.

Multiple active WSP definitions are not allowed on the same layer. However, multiple widths in the same WSP (coincident tracks) are supported but not multiple WSP definitions. This is because you cannot assume all the effective tracks are DRC clean, for example, in terms of color and spacing.

- Click the *Show WSP Manager* button at the bottom of the Routing assistant.

The WSP attributes of the selected layer are displayed.



WSP Manager

Edit Import Derive Options

Pattern

Name: APR\_gs9ps9\_M5\_WSP\_0

Layer: M5

Pattern Type: Routing

Track Direction: Horizontal

Auto-Compute Period: 22.704

Period Offset: 0


- Choose *Window – Assistant – Track Pattern* from the layout window menu bar to open the Track Pattern assistant.
- Click the *Show All* check box.

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Virtuoso Automated Standard Cell Routing

---

You can see the pattern-based auto-generated WSPs prefixed with `APR_`.



### ***Related Topics***

[Configuring Standard Cell Router Settings](#)

[Checking Layout Routability after Running Standard Cell Placer](#)

[Generating a Supply Grid](#)

[Running Signal Routing for Standard Cells](#)

[Viewing and Analyzing Standard Cell Routing Results](#)

[Routing Assistant User Interface for Standard Cell](#)

## **Checking Layout Routability after Running Standard Cell Placer**

You can run pre-routing checks to detect design issues before routing a design. Running the checks lets you identify potential violations or issues that you might run into while routing the design or objects that might cause trouble for the router later in the flow. You can fix these issues before running the router.

To check the routability of a design:



# Virtuoso Automated Standard Cell Placement and Routing Flow Guide


## Virtuoso Automated Standard Cell Routing

---

1. Open a design in Layout MXL.
2. Choose *Window – Assistants – Routing*.

Alternatively, right-click anywhere on the layout window menu bar and choose *Assistants – Routing*.

3. In the Routing assistant, click the *Check* tab.




4. Click *All* to select all pre-routing checks or select one or more checks by clicking the check box next to each check.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---

5. In the *Output* section, specify the routing checks log settings.
  - a. Select *Display log* to specify whether the routing log must be displayed.
  - b. Click the *Display existing log file* button next to the *Display log* option to view the log file. You can use this log file to check for any issues after the pre-route checks are run.



Log file provides additional information with clickable links to show the issue in the layout. You can also view the issues in the Annotation Browser using the *Markers* option.


- c. Select *Overwrite log* to overwrite the existing routing log. When this option is not selected, a new log file is created.
- d. Select *Markers* to specify whether the markers must be displayed in the Annotation Browser.


## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---

- e. Click the *Show Annotation Browser* button next to the Markers option to view the issues reported for the pre-route checks. The issues are displayed in the *Misc* tab of the Annotation Browser.




6. Click *Run pre-route checks* .

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---

Once the checks are run, the status flags appear in green, orange, and red. A green flag indicates that the check was passed, orange indicates a warning, and red indicates an error. Ensure that no red flags appear. This means that the design is correctly setup.



Clicking the flag button takes you to the location in the log file where that check result was reported.

### ***Related Topics***

[Configuring Standard Cell Router Settings](#)

[Generating Width Spacing Patterns for Standard Cell Routing](#)

[Generating a Supply Grid](#)

[Running Signal Routing for Standard Cells](#)

[Viewing and Analyzing Standard Cell Routing Results](#)

[Virtuoso Pre-Route Browser](#)

Routing Assistant User Interface for Standard Cell

## Generating a Supply Grid

In certain standard cell libraries, boundary cells have blockages. In such case, the flow should be modified not to use rails in the row region and to place boundary cells before routing. Generally, a supply grid should be created before the standard cell placement so that placement can prevent routing from interfering with access to standard cell pins.

To generate power rails of VDD and GND nets:

1. Open a design in Layout MXL.
2. Choose *Window – Assistants – Routing*.


Alternatively, right-click anywhere on the layout window menu bar and choose *Assistants – Routing*.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---


3. In the Routing assistant, click the *Supply* tab.




4. Click *All* to define the scope of supply nets to route. You can also select to route *Selected* nets.
5. Click *Guardring/FigGroup* to route everything within a guard ring or figGroup.
6. Select the bottom and top layers for supply stripes from the *Supply Stripes Bottom* and *Top* drop-down list. It generates stripes only on tracks with power and ground wire types that are assigned to nets that have their `sigTypes` set to supply and ground.

Automatic generation of WSPs is the simplest method to specify the wire types for the tracks. See [Assigning Wire Types to Nets](#) to find out how nets with `sigTypes` are assigned to wire types.

7. Select *Generate supply stripes*.
8. Select *Insert vias for supply stripes*.

9. Click *Run power route*  at the lower-right corner of the *Supply* tab.

You can see power stripes and vias generated inside the PR boundary.



### ***Related Topics***

[Configuring Standard Cell Router Settings](#)

[Generating Width Spacing Patterns for Standard Cell Routing](#)

[Checking Layout Routability after Running Standard Cell Placer](#)

[Running Signal Routing for Standard Cells](#)

[Viewing and Analyzing Standard Cell Routing Results](#)

[Routing Assistant User Interface for Standard Cell](#)

## **Running Signal Routing for Standard Cells**

To run signal routing:

1. Open a design in Layout MXL.
2. Choose *Window – Assistants – Routing*.


Alternatively, right-click anywhere on the layout window menu bar and choose *Assistants – Routing*.


## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---

3. In the Routing assistant, click the *Route* tab.



4. Click *Selected* to define the scope of nets to route. You can also select to route *All*, *Open*, or *Shorted* nets.
5. Select *Include Supply Nets* to route the `tieHi` and `tieLo` nets.
6. Deselect the *Update Pins* option. This option should be enabled only if WSPs are not used.
7. Click *Run signal route*  at the lower-right corner of the *Route* tab.




## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Virtuoso Automated Standard Cell Routing

---


The selected nets are routed.



# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Virtuoso Automated Standard Cell Routing

While the router is running, the *Run signal route button* changes to a *Stop* button. A directory called `routerLogs` is created in the run directory.



```
/home/parula/StdcellRouting/ART_stdcell_USV2/routerLogs/innovus.designLib.dut.layout_preRouting.log
File Edit View Help
cadence

**WARN: (IMPOAX-1313): The library 'designLib' has its data compression level set to '0', while the compression level for this Innovus
Type 'man IMPOAX-1313' for more detail.
FE units: 0.0005 microns/dbu, OA units: 0.0005 microns/dbu, Conversion factor: 1
Special routes: 0 strips and 0 vias are created in OpenAccess database.
Signal Routes: Created 3214 routes.
Created 1837 insts; 3674 instTerms; 750 nets; 0 routes.
Created 1072 markers.
TIMER: Write OA to disk: 0h 0m 0.01s cpu {0h 0m 0s elapsed} Memory = 0.0.
TIMER: Purge OA from memory: 0h 0m 0.00s cpu {0h 0m 0s elapsed} Memory = 0.0.
TIMER: write_oa total process: 0h 0m 0.16s cpu {0h 0m 0s elapsed} Memory = 0.0.
% Begin Save ccopt configuration ... (date=01/13 11:40:12, mem=1087.8M)
% End Save ccopt configuration ... (date=01/13 11:40:13, total cpu=0:00:00.0, real=0:00:01.0, peak res=1088.7M, current mem=1088.7M)
Saving congestion map file /home/parula/StdcellRouting/ART_stdcell_USV2/designLibs/designLib/_art_dut/layout_preRouting_routed/_art_o
% Begin Save AAE data ... (date=01/13 11:40:14, mem=1088.8M)
Saving AAE Data ...
% End Save AAE data ... (date=01/13 11:40:14, total cpu=0:00:00.0, real=0:00:00.0, peak res=1088.8M, current mem=1088.8M)
Saving preference file /home/parula/StdcellRouting/ART_stdcell_USV2/designLibs/designLib/_art_dut/layout_preRouting_routed/inn_data/g
Saving mode setting ...
Saving root attributes to be loaded post write_db ...
Saving global file ...
Saving root attributes to be loaded previous write_db ...
#Saving pin access data to file /home/parula/StdcellRouting/ART_stdcell_USV2/designLibs/designLib/_art_dut/layout_preRouting_routed/i
#
% Begin Save power constraints data ... (date=01/13 11:40:16, mem=1092.4M)
% End Save power constraints data ... (date=01/13 11:40:16, total cpu=0:00:00.0, real=0:00:00.0, peak res=1092.5M, current mem=1092.5
Generated self-contained design: /home/parula/StdcellRouting/ART_stdcell_USV2/designLibs
Saving property file /home/parula/StdcellRouting/ART_stdcell_USV2/designLibs/designLib/_art_dut/layout_preRouting_routed/inn_data/_ar
*** Completed saveOALibCellAnnotation (cpu=0:00:00.0 real=0:00:00.0 mem=1281.0M) ***
## End save design ... (date=01/13 11:40:16, total cpu=0:00:01.6, real=0:00:04.0, peak res=1094.9M, current mem=1094.9M)

*** Summary of all messages that are not suppressed in this session:
Severity ID Count Summary
WARNING IMPSYT-7316 1 Cellview contents at '%s' will be copied...
WARNING IMPOAX-793 33 Problem in processing library definition...
WARNING IMPOAX-1313 1 The library '%s' has its data compressio...
*** Message Summary: 35 warning(s), 0 error(s)

#@ End verbose source: /home/parula/StdcellRouting/ART_stdcell_USV2/.cadence/dfII/routing/1/replays/designLib/dut/layout_preRouting/a
@[DEV]innovus 2>

4 L1.327 C17
```

Routing errors are reported in the CIW, which might be hidden underneath other windows. The CIW can be raised automatically by setting the following environment variable:

```
envSetVal("ui" "raiseCIWonError" 'boolean t)
```

8. In the *Update* section of the *Route* tab, select the *Delete Wires and vias*.
9. Click the *Delete* button to delete the routed wires and vias for the selected nets.

The routed data is deleted.

## Related Topics

### [Configuring Standard Cell Router Settings](#)

### [Generating Width Spacing Patterns for Standard Cell Routing](#)

[Checking Layout Routability after Running Standard Cell Placer](#)

[Generating a Supply Grid](#)

[Viewing and Analyzing Standard Cell Routing Results](#)


[Routing Assistant User Interface for Standard Cell](#)

## Viewing and Analyzing Standard Cell Routing Results

You can analyze the routing results using the Routing Results Browser. It shows the number of opens, shorts, wire length, DRC, vias, and so on.

To view and analyze the results:

1. Click the *Results* tab in the Routing Assistant.



# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Virtuoso Automated Standard Cell Routing


2. Select the scope of nets to analyze the routing result. You can either select *All*, *Selected*, or *Open* nets.
3. Select *Supply Nets* to see the routing results of the power and ground nets.
4. Select *All* to display all the output columns in the Routing Results Browser.

You can also select specific outputs for which you want the columns to be displayed in the Routing Results Browser.

5. Click *Show results browser*  at the bottom right corner.

The Routing Results Browser is displayed. Examine the spreadsheet and observe the wirelength, via count, and ratio (routed length and ideal length). The ratio can be calculated with MST, Steiner, or Spine ideal routes.

You can also see the total number of routed nets, opens, shorts and details of various violations.



Virtuoso® Routing Results Browser : chipAssemblyUSV LP\_pil step3

signals: 119 supplies: 8 routed: 127 unrouted: 0 selected: 0

Net Tot: 127	Opens Tot: 0	Shorts Tot: 0	DRCs Tot: 0	Wirelength Tot: 4416.34	Vias Tot: 155	Ratio Avg: 0.6247	Pin Count Tot: 525	Manhattan X Tot: 11686.1	Manhattan Y Tot: 20199.4
Filter	Filter	Filter	Filter	Filter	Filter	Filter	Filter	Filter	Filter
refclk				0	0	0	2	9.66	0.16
txclk				0	0	0	2	0.5	0.6
txclk				0	0	0	2	0.5	0.6
txclk				0	0	0	1	106.36	150.13
txclk_h				439.155	15	1.10048	2	25.565	376.68
txclk_h				767.415	16	0.702618	4	314.37	418.25
startvocal				0	0	0	2	0.54	0.19
vocaldone				0	0	0	2	0.54	0.19
SSO				0	0	0	2	0.54	0.19
dgnd				0	0	0	1	106.82	150.13
SSI				0	0	0	2	0.54	0.19
SClk				0	0	0	2	0.54	0.19
test_mode				0	0	0	2	0.54	0.19
mt_n				0	0	0	2	0.54	0.19
vocaldone				0	0	0	2	0.54	0.19
startvocal				0	0	0	2	0.54	0.19
scan_out<1>				0	0	0	2	0.54	0.19
scan_out<0>				0	0	0	2	0.54	0.19
scan_in<1>				0	0	0	2	0.54	0.19
scan_in<0>				0	0	0	2	0.54	0.19
atb_p				0	0	0	4	338.9	168.305
atb_m				0	0	0	4	338.36	168.305
refclk_n				0	0	0	2	9.66	0.16

### Related Topics

[Generating Width Spacing Patterns for Standard Cell Routing](#)

[Checking Layout Routability after Running Standard Cell Placer](#)

[Generating a Supply Grid](#)

[Running Signal Routing for Standard Cells](#)

# **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

## **Virtuoso Automated Standard Cell Routing**

---

[Routing Assistant User Interface for Standard Cell](#)

[Virtuoso Routing Results Browser](#)

# **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

## **Virtuoso Automated Standard Cell Routing**

---

---

## Standard Cell Placement and Routing Environment Variables

---

The standard cell placement and routing environment variables are used to set default values for various standard cell placement and routing options in the *Auto P&R* and the *Routing* assistants.

Only the public environment variables are documented and supported for public use. All other standard cell routing environment variables, regardless of their name or prefix, are private and undocumented and are subject to change at any time.

The following list provides the names of the Automated Standard Cell Placement and Routing Flow environment variables.

### Standard Cell Placement

<u>advNode</u>	<u>init_boundaryAspectRatioOrHeight</u>
<u>init_boundaryAspectRatioVal</u>	<u>init_boundaryHeightVal</u>
<u>init_boundaryUtilizationOrWidth</u>	<u>init_boundaryUtilizationVal</u>
<u>init_boundaryWidthVal</u>	<u>init_createPowerPins</u>
<u>init_generateBoundary</u>	<u>init_generateInstances</u>
<u>init_generatePins</u>	<u>init_mode</u>
<u>init_scope</u>	<u>init_useSourceLayout</u>
<u>init_useSourceLayoutBoundary</u>	<u>init_useSourceLayoutInstances</u>
<u>init_useSourceLayoutPins</u>	<u>physOnlyFigGroupPrefix</u>
<u>place_addBoundaryCells</u>	<u>place_addCellRowRouting</u>
<u>place_addDecapFillerCells</u>	<u>place_addTapCells</u>
	<u>place_boundaryCellsContainTapCells</u>
<u>place_createPhysOnlyAsAGroup</u>	<u>place_defaultPlacedView</u>

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

<u>place_deleteBoundaryCells</u>	<u>place_deleteFillerCells</u>
<u>place_deleteTapCells</u>	<u>place_displayLog</u>
<u>place_overwriteLog</u>	<u>place_placeStdCells</u>
<u>place_placedLocation</u>	<u>place_showInformation</u>
<u>postPlaceTrigger</u>	<u>prePlaceTrigger</u>
<u>remasterLayoutLibs</u>	<u>runDir</u>
	<u>setup_Innovus1stRowOrientation</u>
<u>setup_createRowRegionInArea</u>	<u>setup_displayLog</u>
<u>setup_overwriteLog</u>	<u>setup_rowCount</u>
<u>setup_rowCreation</u>	

### Standard Cell Routing

<u>FB1RouteBlockageLayer</u>	<u>abstractViewName</u>	<u>alternativeBoundaryLayer</u>
<u>check_displayLog</u>	<u>check_existingDRCs</u>	<u>check_generateMarkers</u>
<u>check_overwriteLog</u>	<u>checkerLogDir</u>	<u>checkerLogPrefix</u>
<u>coverTermPins</u>	<u>createNewFigGroupsPerRun</u>	<u>disableInvsWSPGen</u>
<u>fixAllPreroutes</u>	<u>invsLicenseArgs</u>	<u>layoutViewName</u>
<u>ldrsCG</u>	<u>multiTechLEFOVERRIDE</u>	<u>omitRedundantPatchShapes</u>
<u>omitTrimLayers</u>	<u>postInitCmds</u>	<u>postPlacementCmds</u>
<u>postRouteCmds</u>	<u>postRouteTrigger</u>	<u>preBndyTapCmds</u>
<u>preInitCmds</u>	<u>prePlacementCmds</u>	<u>preRouteCmds</u>
<u>preRouteTrigger</u>	<u>preserveFillerPlaceStatus</u>	<u>results_nets</u>
<u>results_netsWithin</u>	<u>results_supplyNets</u>	<u>route_createRoutingAsAGroup</u>
<u>route_defaultRoutedView</u>	<u>route_deletePreroutes</u>	<u>route_deleteWiresAndVias</u>
<u>route_displayLog</u>	<u>route_fixPostRouteDRCErrors</u>	<u>route_nets</u>
<u>route_netsWithin</u>	<u>route_overwriteLog</u>	<u>route_routedLOC</u>
<u>route_saveRoutingOnly</u>	<u>route_supplyNets</u>	<u>route_updatePinOption</u>



## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

<u>route_updatePins</u>	<u>routerLogPrefix</u>	<u>runDir</u>
<u>separateStdCellLibs</u>	<u>setPinFixedWithinBoundary</u>	<u>setup_checkDRCsAfterRouting</u>
<u>setup_lockColorsAfterRouting</u>	<u>signalRouteFigGroupPrefix</u>	<u>siteDefHeight</u>
<u>siteDefSymmetricInR90</u>	<u>siteDefSymmetricInX</u>	<u>siteDefSymmetricInY</u>
<u>siteDefWidth</u>	<u>supply_connectToTerminals</u>	<u>supply_createGridAsGroup</u>
<u>supply_createPinLabel</u>	<u>supply_createPins</u>	<u>supply_createPinsOnEnds</u>
<u>supply_defaultRoutedView</u>	<u>supply_deleteStripes</u>	<u>supply_deleteVias</u>
<u>supply_genSupplyStripes</u>	<u>supply_generateStaples</u>	<u>supply_ignoreBoundaryTracks</u>
<u>supply_ignoreBoundaryVias</u>	<u>supply_insertTrim</u>	<u>supply_insertVias</u>
<u>supply_nets</u>	<u>supply_netsWithin</u>	<u>supply_pinLayerSet</u>
<u>supply_routedLOC</u>	<u>supply_saveRoutingOnly</u>	<u>supply_shareTracks</u>
<u>supply_useExistingPGTracks</u>	<u>tracksCmds</u>	<u>useMultipleTapCells</u>
<u>useStylusMode</u>		

## **FB1RouteBlockageLayer**

```
APR.stdcell.route FB1RouteBlockageLayer string "layername"
```

### **Description**

Specifies the layers option for `create_route_blockage` command in the Tcl command file generated for Innovus. If empty, the `create_route_blockage` command is not added.

The default is `FB1`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "FB1RouteBlockageLayer")  
envSetVal("APR.stdcell.route" "FB1RouteBlockageLayer" 'string "layer1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **FB1SpecialDRCRegionLayer**

```
APR.stdcell.route FB1SpecialDRCRegionLayer string "regionlayername"
```

### **Description**

Creates a donut of FB1 region around a region of rows if it is significantly smaller than the prBoundary to apply FB1 rules outside.

The default is "".

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "FB1SpecialDRCRegionLayer")  
envSetVal("APR.stdcell.route" "FB1SpecialDRCRegionLayer" 'string "FB1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### **abstractViewName**

```
APR.stdcell.route abstractViewName string "abstractname"
```

#### **Description**

Specifies the name of the abstract cellview of Innovus. The default is `abstract`.

#### **GUI Equivalent**

None

#### **Examples**

```
envGetVal("APR.stdcell.route" "abstractViewName")  
envSetVal("APR.stdcell.route" "abstractViewName" 'string "view1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### alternativeBoundaryLayer

```
APR.stdcell.route alternativeBoundaryLayer string "layername"
```

#### Description

Specifies the alternative boundary layer if the PR boundary does not exist. This value is used to calculate the bounding box of a cellview when the bBox is unavailable.

The default is "".

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "alternativeBoundaryLayer")
envSetVal("APR.stdcell.route" "alternativeBoundaryLayer" 'string
"fboundarylayer_1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### check\_displayLog

```
APR.stdcell.route check_displayLog boolean { t | nil }
```

#### Description

Controls the display of the checker log window once the checks are run. When set to `nil`, the log window is not displayed.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Check</i> tab
Field	<i>Display Log</i>

#### Examples

```
envGetVal("APR.stdcell.route" "check_displayLog")  
envSetVal("APR.stdcell.route" "check_displayLog" 'boolean nil)
```

#### ***Related Topics***

### **Standard Cell Placement and Routing Environment Variables**

### check\_existingDRCs

```
APR.stdcell.route check_existingDRCs boolean { t | nil }
```

#### Description

Specifies whether to run design rule checks for DRD.

The default is `nil`.

#### GUI Equivalent

Command      Routing assistant – *Check* tab

Field          *Existing DRCs*

#### Examples

```
envGetVal("APR.stdcell.route" "check_existingDRCs")
envSetVal("APR.stdcell.route" "check_existingDRCs" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### check\_generateMarkers

```
APR.stdcell.route check_generateMarkers boolean { t | nil }
```

#### Description

Controls the generation of markers for errors. These error markers can be viewed in the *Misc* tab of Annotation Browser. When set to `t`, the markers are generated.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Check</i> tab
Field	<i>Markers</i>

#### Examples

```
envGetVal("APR.stdcell.route" "check_generateMarkers")  
envSetVal("APR.stdcell.route" "check_generateMarkers" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



### check\_overwriteLog

```
APR.stdcell.route check_overwriteLog boolean { t | nil }
```

#### Description

Controls the overwriting of the last log file. When set to `nil`, the existing log file is retained.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Check</i> tab
Field	<i>Overwrite last log</i>

#### Examples

```
envGetVal("APR.stdcell.route" "check_overwriteLog")  
envSetVal("APR.stdcell.route" "check_overwriteLog" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### checkerLogDir

```
APR.stdcell.route checkerLogDir string "directory"
```

#### Description

Specifies the path to the directory that saves the checker log file from the *Check* tab of the standard cell router.

The default directory is `./checkerLogs`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "checkerLogDir")
envSetVal("APR.stdcell.route" "checkerLogDir" 'string "log1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### checkerLogPrefix

```
APR.stdcell.route checkerLogPrefix string "logprefixname"
```

#### Description

Specifies the prefix for the checker log file names. The checker log files follow the pattern of *checkerLogPrefix.libName.cellName.viewName.log*.

The default is artChecker.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "checkerLogPrefix")  
envSetVal("APR.stdcell.route" "checkerLogPrefix" 'string "deviceChecker")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### coverTermPins

```
APR.stdcell.route coverTermPins boolean { t | nil }
```

### Description

Extends the wire to completely cover the IO pins. The standard cell router routes to the center of the pin with 0-extent wires.

The default is `nil`.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "coverTermPins")  
envSetVal("APR.stdcell.route" "coverTermPins" 'boolean t)
```

### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)

### createNewFigGroupsPerRun

```
APR.stdcell.route createNewFigGroupsPerRun boolean { t | nil }
```

#### Description

Creates a new fig group for the routing results. The results of each routing run is created in a different figGroup.

The default is `nil`, which means that the routing results are copied into the same figGroup along with the other routing results.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "createNewFigGroupsPerRun")
envSetVal("APR.stdcell.route" "createNewFigGroupsPerRun" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### disableInvsWSPGen

```
APR.stdcell.route disableInvsWSPGen boolean { t | nil }
```

#### Description

Disables Innovus derived tracks. When set to `t`, the Innovus derived tracks are considered by the router to generate WSPs.

The default is `nil`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "disableInvsWSPGen")
envSetVal("APR.stdcell.route" "disableInvsWSPGen" 'boolean t)
```

#### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)

### **fixAllPreroutes**

```
APR.stdcell.route fixAllPreroutes boolean { t | nil }
```

#### **Description**

Fixes pre-routes for the current routing run. The default is `nil`.

#### **GUI Equivalent**

None

#### **Examples**

```
envGetVal("APR.stdcell.route" "fixAllPreroutes")  
envSetVal("APR.stdcell.route" "fixAllPreroutes" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### invsLicenseArgs

```
APR.stdcell.route invsLicenseArgs string "licenseName"
```

#### Description

Specifies the name of the Innovus license.

The default is `layout`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "invsLicenseArgs")  
envSetVal("APR.stdcell.route" "invsLicenseArgs" 'string "licenseA")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## **layoutViewName**

```
APR.stdcell.route layoutViewName string "layoutname"
```

### **Description**

Specifies the name of the Innovus layout cellview.

The default is `layout`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "layoutViewName")  
envSetVal("APR.stdcell.route" "layoutViewName" 'string "layout1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### ldrsCG

```
APR.stdcell.route ldrsCG string "CGname"
```

### Description

Specifies the name of the override `LEFDefaultRouteSpec` constraint group name.

The default is `" "`. This means no constraint group name is specified.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "ldrsCG")  
envSetVal("APR.stdcell.route" "ldrsCG" 'string "constraint1")
```

### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)

## multiTechLEFOVERRIDE

```
APR.stdcell.route multiTechLEFOVERRIDE string "list_of_CGnames"
```

### Description

Specifies the constraint group name that overrides `foundryRule`, `LEFDefaultRouteSpec` and `LEFSpecialRouteSpec`. The value is parsed and passed to Innovus as `init_oa_foundry_rule`, `init_oa_default_rule`, `init_oa_special_rule`. It overrides what is specified in the GUI.

The default is an empty string `" "`. This means a constraint group name is not specified.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "multiTechLEFOVERRIDE")
envSetVal("APR.stdcell.route" "multiTechLEFOVERRIDE" 'string "foundry_innovus_1
LEFDefaultRouteSpec_1 LEFSpecialRouteSpec_1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### omitRedundantPatchShapes

```
APR.stdcell.route omitRedundantPatchShapes boolean { t | nil }
```

#### Description

Omits synchronization of redundant patch shapes from the Innovus routed view. The default is `nil`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "omitRedundantPatchShapes")
envSetVal("APR.stdcell.route" "omitRedundantPatchShapes" 'boolean t)
```

#### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)

### omitTrimLayers

```
APR.stdcell.route omitTrimLayers boolean { t | nil }
```

#### Description

Omits trim layers and bridge metal from syncing routing results back from Innovus.

The default is `nil`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "omitTrimLayers")  
envSetVal("APR.stdcell.route" "omitTrimLayers" 'boolean t)
```

#### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)

## **physOnlyFigGroupPrefix**

```
APR.stdcell.place physOnlyFigGroupPrefix string "GroupPrefixname"
```

### **Description**

Specifies a unique figGroup prefix for the name of the figGroup.

The default is `place`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.place" "physOnlyFigGroupPrefix")  
envSetVal("APR.stdcell.place" "physOnlyFigGroupPrefix" 'string "place1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### postInitCmds

```
APR.stdcell.route postInitCmds string "filename"
```

#### Description

Specifies the path to the post-initialization hook file that is sourced after design initialization stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is " ". This means a filename is not specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "postInitCmds")  
envSetVal("APR.stdcell.route" "postInitCmds" 'string "postinit1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### postPlacementCmds

```
APR.stdcell.route postPlacementCmds string "filename"
```

#### Description

Specifies the path to the post-placement hook file that is sourced after the placement stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is " ". This means a filename is not specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "postPlacementCmds")  
envSetVal("APR.stdcell.route" "postPlacementCmds" 'string "postPlacel")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



### postRouteCmds

```
APR.stdcell.route postRouteCmds string "filename"
```

#### Description

Specifies the post-route hook file that is sourced after the routing stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is "". This means a filename is not specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "postRouteCmds")  
envSetVal("APR.stdcell.route" "postRouteCmds" 'string "postRoute1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### postRouteTrigger

```
APR.stdcell.route postRouteTrigger string "procedurename"
```

#### Description

Specifies SKILL procedure to be executed after routing has completed.

The default is "", which means no additional processing is done.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "postRouteTrigger")  
envSetVal("APR.stdcell.route" "postRouteTrigger" 'string "postRouteProcedure")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### preBndyTapCmds

```
APR.stdcell.route preBndyTapCmds string "tapCmdNames"
```

#### Description

Sources the Tcl plugin to be sourced before running the `add_endcaps` and `add_well_taps` commands. The default is an empty string `" "`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "preBndyTapCmds")
envSetVal("APR.stdcell.route" "preBndyTapCmds" 'string "foundry_innovus_1
LEFDefaultRouteSpec_1 ")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### preInitCmds

```
APR.stdcell.route preInitCmds string "filename"
```

### Description

Specifies the path to the pre-initialization hook file that is sourced before design initialization stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is " ". This means a filename is not specified.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "preInitCmds")
envSetVal("APR.stdcell.route" "preInitCmds" 'string "preinit1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### prePlacementCmds

```
APR.stdcell.route prePlacementCmds string "filename"
```

#### Description

Specifies the path to the pre-placement hook file that is sourced before the placement stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is " ". This means a filename is not specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "prePlacementCmds")  
envSetVal("APR.stdcell.route" "prePlacementCmds" 'string "prePlacel")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## preRouteCmds

```
APR.stdcell.route preRouteCmds string "filename"
```

### Description

Specifies the path to the pre-route hook file that is sourced before the routing stage. The file can be placed anywhere and can be specified as an absolute path or a relative path from the current working directory.

The default is " ". This means a filename is not specified.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "preRouteCmds")
envSetVal("APR.stdcell.route" "preRouteCmds" 'string "route1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### preRouteTrigger

```
APR.stdcell.route preRouteTrigger string "procedurename"
```

#### Description

Specifies SKILL procedure to be executed before routing.

The default is "", which means no additional processing is done.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "preRouteTrigger")  
envSetVal("APR.stdcell.route" "preRouteTrigger" 'string "preRouteProcedure")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### preserveFillerPlaceStatus

```
APR.stdcell.route preserveFillerPlaceStatus boolean { t | nil }
```

#### Description

Preserves the placement status of the filler cells in the scratch view instead of changing it to fixed. It can be changed in Innovus. The default is `nil`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "preserveFillerPlaceStatus")
envSetVal("APR.stdcell.route" "preserveFillerPlaceStatus" 'boolean t)
```

#### *Related Topics*

[Standard Cell Placement and Routing Environment Variables](#)



### remasterLayoutLibs

```
APR.stdcell.place remasterLayoutLibs string "libname"
```

#### Description

Specifies a library that contains layout views. It is similar to `separateStdCellLibs`, except that it specifies layout library names instead of abstract library names if layout and abstract views are not in the same library. It is used for the final `remaster_instance` when the data is synced back to virtuoso after the placement is run.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.place" "remasterLayoutLibs")
envSetVal("APR.stdcell.place" "remasterLayoutLibs" 'string "Layout1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[separateStdCellLibs](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### results\_nets

```
APR.stdcell.route results_nets cyclic { "All" | "Selected" | "Open" }
```

### Description

Specifies whether you want all nets, selected nets, or only open nets to be included in the results table.

The default is "All".

### GUI Equivalent

Command	Routing assistant – <i>Results</i> tab
Field	<i>Nets – All, Selected, Open</i>

### Examples

```
envGetVal("APR.stdcell.route" "results_nets")  
envSetVal("APR.stdcell.route" "results_nets" 'cyclic "Selected")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### results\_netsWithin

```
APR.stdcell.route results_netsWithin cyclic { "PR boundary" | "Area" }
```

#### Description

Specifies whether to route everything inside the PR boundary or within an area.

The default is "PR boundary".

#### GUI Equivalent

Command      Routing assistant – *Results* tab

Field          *Within*

#### Examples

```
envGetVal("APR.stdcell.route" "results_netsWithin")
envSetVal("APR.stdcell.route" "results_netsWithin" 'cyclic "Area")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

#### results\_supplyNets

```
APR.stdcell.route results_supplyNets boolean { t | nil }
```

#### Description

Includes power and ground in the results table. When set to `nil`, power and ground nets are not included in the results table.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Results</i> tab
Field	<i>Supply nets</i>

#### Examples

```
envGetVal("APR.stdcell.route" "results_supplyNets")
envSetVal("APR.stdcell.route" "results_supplyNets" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **route\_createRoutingAsAGroup**

```
APR.stdcell.route route_createRoutingAsAGroup boolean { t | nil }
```

### **Description**

Specifies whether or not to create routing as a figGroup. When set to `t`, the routing is created as a figGroup.

The default is `nil`.

### **GUI Equivalent**

Command	Routing assistant – <i>Route</i> tab
Field	<i>Create routing as a group</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "route_createRoutingAsAGroup")  
envSetVal("APR.stdcell.route" "route_createRoutingAsAGroup" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[signalRouteFigGroupPrefix](#)

### route\_defaultRoutedView

```
APR.stdcell.route route_defaultRoutedView string "defaultViewName"
```

#### Description

Specifies the default name for the routed view if signal routing is written to another cellview.

The default is `layout.routed`.

#### GUI Equivalent

Command      Routing assistant – *Route* tab

Field          *Output – Other cellview*

#### Examples

```
envGetVal("APR.stdcell.route" "route_defaultRoutedView")  
envSetVal("APR.stdcell.route" "route_defaultRoutedView" 'string "route2")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### route\_deletePreroutes

```
APR.stdcell.route route_deletePreroutes boolean { t | nil }
```

#### Description

Specifies that the pre-routed wires and vias that are manually created are automatically deleted.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Delete – Preroutes</i>

#### Examples

```
envGetVal("APR.stdcell.route" " route_deletePreroutes")
envSetVal("APR.stdcell.route" " route_deletePreroutes" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### route\_deleteWiresAndVias

```
APR.stdcell.route route_deleteWiresAndVias boolean { t | nil }
```

#### Description

Specifies that wires, vias, and shield lines created by the router are automatically deleted.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Delete – Wires and vias</i>

#### Examples

```
envGetVal("APR.stdcell.route" " route_deleteWiresAndVias")
envSetVal("APR.stdcell.route" " route_deleteWiresAndVias" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



### route\_displayLog

```
APR.stdcell.route route_displayLog boolean { t | nil }
```

#### Description

Controls the display of the log window when standard cell routing is run. When set to `nil`, the log window is not displayed.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Display Log</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_displayLog")
envSetVal("APR.stdcell.route" "route_displayLog" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **route\_fixPostRouteDRCErrors**

```
APR.stdcell.route route_fixPostRouteDRCErrors boolean { t | nil }
```

### **Description**

Runs `fix_errors` command to resolve existing shorts and spacing violations after running the `route_design` command. The default is `nil`.

### **GUI Equivalent**

Command	Routing assistant – <i>Route</i> tab
Field	<i>Fix post-route DRC errors</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "route_fixPostRouteDRCErrors")  
envSetVal("APR.stdcell.route" "route_fixPostRouteDRCErrors" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### route\_nets

```
APR.stdcell.route route_nets cyclic { "All" | "Selected" | "Open" | "Shorted" }
```

### Description

Specifies whether you want to route all nets, selected nets, or only nets with opens or shorts.

The default is "All".

### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Nets – All, Selected, Open, Shorted</i>

### Examples

```
envGetVal("APR.stdcell.route" "route_nets")  
envSetVal("APR.stdcell.route" "route_nets" 'cyclic "Selected")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### route\_netsWithin

```
APR.stdcell.route route_netsWithin cyclic { "PR boundary" | "FigGroup" | "Area" }
```

#### Description

Specifies whether to route everything inside the PR boundary or only within a specified figGroup or area.

The default is "PR boundary".

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Within</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_netsWithin")
envSetVal("APR.stdcell.route" "route_netsWithin" 'cyclic "FigGroup"')
envSetVal("APR.stdcell.route" "route_netsWithin" 'cyclic "Area"')
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### route\_overwriteLog

```
APR.stdcell.route route_overwriteLog boolean { t | nil }
```

#### Description

Specifies whether to overwrite or keep the existing log. When set to `t`, the existing log is overwritten.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Overwrite last log</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_overwriteLog")  
envSetVal("APR.stdcell.route" "route_overwriteLog" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### route\_routedLOC

```
APR.stdcell.route route_routedLOC cyclic { "Current cellview" | "Other cellview" }
```

#### Description

Specifies whether to write the signal routing to the current cellview or to a different cellview.

The default is "Current cellview".

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Current cellview, Other cellview</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_routedLOC")  
envSetVal("APR.stdcell.route" "route_routedLOC" 'cyclic "Other cellview")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### route\_saveRoutingOnly

```
APR.stdcell.route route_saveRoutingOnly boolean { t | nil }
```

#### Description

Specifies whether or not to save standard cell routing settings.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Save routing only</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_saveRoutingOnly")  
envSetVal("APR.stdcell.route" "route_saveRoutingOnly" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### route\_supplyNets

```
APR.stdcell.route route_supplyNets boolean { t | nil }
```

#### Description

Specifies whether to route power and ground (`tieHi` and `tieLo`) nets. When set to `nil`, the power and ground nets are not routed.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Supply Nets</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_supplyNets")
envSetVal("APR.stdcell.route" "route_supplyNets" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## route\_updatePinOption

```
APR.stdcell.route route_updatePinOption cyclic { "Snap to closest same edge track"  
  | "Snap to any edge" }
```

### Description

Specifies whether to snap IO pins to the closest track on the same layer and same edge or to any edge on any layer within the specified layer range. This variable is effective only if route\_updatePins is set to t.

The default is "Snap to closest same edge track".

### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Update Pins – Snap to closest same edge track, Snap to any edge</i>

### Examples

```
envGetVal("APR.stdcell.route" "route_updatePinOption")  
envSetVal("APR.stdcell.route" "route_updatePinOption" 'cyclic "Snap to any edge")
```

### Related Topics

Standard Cell Placement and Routing Environment Variables

### route\_updatePins

```
APR.stdcell.route route_updatePins boolean { t | nil }
```

#### Description

Controls pin placement in Innovus. When set to `nil`, the pin placement does not happen.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Route</i> tab
Field	<i>Update Pins</i>

#### Examples

```
envGetVal("APR.stdcell.route" "route_updatePins")  
envSetVal("APR.stdcell.route" "route_updatePins" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### routerLogPrefix

```
APR.stdcell.route routerLogPrefix string "logprefixname"
```

#### Description

Specifies the prefix for the router log file name. The router log files follow the pattern of *routerLogPrefix.libName.cellName.viewName.logxx* where xx is a number.

The default is `innovus`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "routerLogPrefix")
envSetVal("APR.stdcell.route" "routerLogPrefix" 'string "inn")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### runDir

```
APR.stdcell.route runDir string "dirname"
```

### Description

Specifies the path to the Innovus router log directory. The default directory is ./routerLogs.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "runDir")  
envSetVal("APR.stdcell.route" "runDir" 'string "run1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **separateStdCellLibs**

```
APR.stdcell.route separateStdCellLibs string "libname"
```

### **Description**

Specifies a library that contains abstract views. If the abstract views are not in the same library as the layout views and not in any library in the technology graph then this environment variable must be set. If no abstracts are available then the `cellType` of the layout view must be set to `core` or the `INVS_QAI_CELL_OVERRIDE` cellview property must be set.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "separateStdCellLibs")  
envSetVal("APR.stdcell.route" "separateStdCellLibs" 'string "run1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **setPinFixedWithinBoundary**

```
APR.stdcell.route setPinFixedWithinBoundary boolean { t | nil }
```

### **Description**

Changes the placement status of IO pins to fixed if they are contained within the PR boundary. The default is `t`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "setPinFixedWithinBoundary")  
envSetVal("APR.stdcell.route" "setPinFixedWithinBoundary" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## setup\_checkDRCsAfterRouting

```
APR.stdcell.route setup_checkDRCsAfterRouting boolean { t | nil }
```

### Description

Specifies whether to automatically run design rule checks after routing. When set to `t`, the design rule checks are run automatically.

The default is `nil`.

### GUI Equivalent

Command	Routing assistant – <i>Setup</i> tab
Field	<i>Check DRCs after routing</i>

### Examples

```
envGetVal("APR.stdcell.route" "setup_checkDRCsAfterRouting")
envSetVal("APR.stdcell.route" "setup_checkDRCsAfterRouting" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **setup\_lockColorsAfterRouting**

```
APR.stdcell.route setup_lockColorAfterRouting boolean { t | nil }
```

### **Description**

Specifies whether to automatically lock colored shapes after routing. If the process has trim shapes that cuts locked color shapes, then the GUI option is selected and disabled. If the process does not have trim shapes, the GUI option is unselected and disabled. If, the process has trim shapes and it cuts unlocked color shapes, it is off by default but is enabled.

The default is `t`.

### **GUI Equivalent**

Command	Routing assistant – <i>Setup</i> tab
Field	<i>Lock colors after routing</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "setup_lockColorAfterRouting")
envSetVal("APR.stdcell.route" "setup_lockColorAfterRouting" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## signalRouteFigGroupPrefix

```
APR.stdcell.route signalRouteFigGroupPrefix string "figGroupPrefixName"
```

### Description

Specifies the prefix used to create the figGroup to store signal routing figs when the *Create routing as a group* option is selected in the *Route* tab.

The default is `route`.

### GUI Equivalent

None

### Examples

```
envGetVal("APR.stdcell.route" "signalRouteFigGroupPrefix")  
envSetVal("APR.stdcell.route" "signalRouteFigGroupPrefix" 'string "fig1")
```

### Related Topics

[Standard Cell Placement and Routing Environment Variables](#)

[route\\_createRoutingAsAGroup](#)

### siteDefHeight

APR.stdcell.route siteDefHeight float *float\_number*

#### Description

Specifies the height of the siteDef used to create inter-operable rows. The value is specified in user units. If the value is not specified, the width is calculated as the minimum height of standard cell instances.

The default is -1. This means no value is specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "siteDefHeight")
envSetVal("APR.stdcell.route" "siteDefHeight" 'float 1.0)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### siteDefSymmetricInR90

```
APR.stdcell.route siteDefSymmetricInR90 boolean { t | nil }
```

#### Description

Specifies whether the siteDef used to create inter-operable rows is symmetric in the R90 direction.

The default is `t`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "siteDefSymmetricInR90")
envSetVal("APR.stdcell.route" "siteDefSymmetricInR90" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### siteDefSymmetricInX

```
APR.stdcell.route siteDefSymmetricInX boolean { t | nil }
```

#### Description

Specifies whether the siteDef used to create inter-operable rows is symmetric in the X direction.

The default is `t`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "siteDefSymmetricInX")  
envSetVal("APR.stdcell.route" "siteDefSymmetricInX" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### siteDefSymmetricInY

```
APR.stdcell.route siteDefSymmetricInY boolean { t | nil }
```

#### Description

Specifies whether the siteDef used to create inter-operable rows is symmetric in the Y direction.

The default is `nil`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "siteDefSymmetricInY")  
envSetVal("APR.stdcell.route" "siteDefSymmetricInY" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### siteDefWidth

APR.stdcell.route siteDefWidth float *float\_number*

#### Description

Specifies the width of the siteDef used to create interoperable rows. The value is specified in user units. If the value is not specified, the width is calculated as the greatest common factor of the widths of the standard cell instances.

The default is -1. This means no value is specified.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "siteDefWidth")  
envSetVal("APR.stdcell.route" "siteDefWidth" 'float 1.0)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_connectToTerminals**

```
APR.stdcell.route supply_connectToTerminals boolean { t | nil }
```

### **Description**

Specifies whether or not the supply router should connect to IO pins and guard rings.

The default is `t`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Connect to overlapped terminals</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_connectToTerminals")  
envSetVal("APR.stdcell.route" "supply_connectToTerminals" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_createGridAsGroup**

```
APR.stdcell.route supply_createGridAsGroup boolean { t | nil }
```

### **Description**

Creates the supply grid as a figGroup.

The default is `t`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Create supply grid as a group</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_createGridAsGroup")  
envSetVal("APR.stdcell.route" "supply_createGridAsGroup" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## supply\_createPinLabel

```
APR.stdcell.route supply_createPinLabel boolean { t | nil }
```

### Description

Creates labels on pins when the *Pins Create* option is selected in the *Supply* tab of the Routing assistant.

The default is `nil`.

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Create label</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_createPinLabel")  
envSetVal("APR.stdcell.route" "supply_createPinLabel" 'boolean t)
```

### Related Topics

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_createPins

```
APR.stdcell.route supply_createPins boolean { t | nil }
```

### Description

Creates a pin instead of a pathSeg for the supply stripe.

The default is `t`.

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Create pins on supply stripes</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_createPins")  
envSetVal("APR.stdcell.route" "supply_createPins" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_createPinsOnEnds**

```
APR.stdcell.route supply_createPinsOnEnds boolean { t | nil }
```

### **Description**

Creates pins on the ends of stripes instead of one long pin when the *Pins Create* option is selected in the *Supply* tab of the Routing assistant.

The default is `nil`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Create on ends</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_createPinsOnEnds")  
envSetVal("APR.stdcell.route" "supply_createPinsOnEnds" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_createPinsOnPinPurpose**

```
APR.stdcell.route supply_createPinsOnPinPurpose boolean { t | nil }
```

### **Description**

Creates supply routing pins on pin purpose instead of drawing purpose.

The default is `nil`.

### **GUI Equivalent**

Command      Routing assistant – *Supply* tab

Field            *Create on pin purpose.*

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_createPinsOnPinPurpose")  
envSetVal("APR.stdcell.route" "supply_createPinsOnPinPurpose" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_defaultRoutedCellExpression

```
APR.stdcell.route supply_defaultRoutedCellExpression string "viewName"
```

### Description

Specifies the output to the other cell view. The cell is created as an instance in the design library. You can search for the cell name in the design library with `<cellname>_proute`.

The default is `%_proute`, where the symbol `%` is `<cellname>`.

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Specify Routed Cellview</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_defaultRoutedCellExpression")
envSetVal("APR.stdcell.route" "supply_defaultRoutedCellExpression" 'string
"dut_proute")
```

### Related Topics

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_defaultRoutedView

```
APR.stdcell.route supply_defaultRoutedView string "viewName"
```

#### Description

Specifies the routed view name if supply routing is written to another cellview.

The default is `layout.routed`.

#### GUI Equivalent

Command      Routing assistant – *Supply* tab

Field          *Output – Other cellview*

#### Examples

```
envGetVal("APR.stdcell.route" "supply_defaultRoutedView")
envSetVal("APR.stdcell.route" "supply_defaultRoutedView" 'string "routed1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_defaultWireCGOverride

```
APR.stdcell.route supply_defaultWireCGOverride string "WireCGName"
```

### Description

Lets you specify a different default wire constraint group while the supply router is running.

The default is "".

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
---------	---------------------------------------

Field	<i>Output – Other cellview</i>
-------	--------------------------------

### Examples

```
envGetVal("APR.stdcell.route" "supply_defaultWireCGOverride")
envSetVal("APR.stdcell.route" "supply_defaultWireCGOverride" 'string
"virtuosoDefaultSetup")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_deleteStripes

```
APR.stdcell.route supply_deleteStripes boolean { t | nil }
```

#### Description

Specifies that the stripes generated by the supply router are automatically deleted before power routing.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Delete – Supply stripes</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_deleteStripes")
envSetVal("APR.stdcell.route" "supply_deleteStripes" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## supply\_deleteVias

```
APR.stdcell.route supply_deleteVias boolean { t | nil }
```

### Description

Specifies that the vias generated by the supply router are automatically deleted before power routing.

The default is `nil`.

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Delete – Supply vias</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_deleteVias")  
envSetVal("APR.stdcell.route" "supply_deleteVias" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_genSupplyStripes

```
APR.stdcell.route supply_genSupplyStripes boolean { t | nil }
```

### Description

Specifies that supply stripes should be generated. When set to `nil`, the supply stripes are not generated.

The default is `t`.

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Generate supply stripes</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_genSupplyStripes")
envSetVal("APR.stdcell.route" "supply_genSupplyStripes" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_generateStaples**

```
APR.stdcell.route supply_generateStaples boolean { t | nil }
```

### **Description**

Enables supply stapling.

The default is `nil`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_generateStaples")  
envSetVal("APR.stdcell.route" "supply_generateStaples" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_IgnoreBoundaryTracks**

```
APR.stdcell.route supply_IgnoreBoundaryTracks boolean { t | nil }
```

### **Description**

Ignores generating stripes on tracks that are on the PR boundary.

The default is `nil`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Ignore boundary tracks</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_IgnoreBoundaryTracks")  
envSetVal("APR.stdcell.route" "supply_IgnoreBoundaryTracks" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_IgnoreBoundaryVias

```
APR.stdcell.route supply_IgnoreBoundaryVias boolean { t | nil }
```

#### Description

Ignores generating vias on tracks that are on the PR boundary.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Ignore boundary vias</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_IgnoreBoundaryVias")
envSetVal("APR.stdcell.route" "supply_IgnoreBoundaryVias" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_insertTrim

```
APR.stdcell.route supply_insertTrim boolean { t | nil }
```

#### Description

Inserts trims between the intersection of the layer above and below the via in the supply grid to fix DRC errors.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Insert trim to fix DRCs</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_insertTrim")
envSetVal("APR.stdcell.route" "supply_insertTrim" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_insertVias

```
APR.stdcell.route supply_insertVias boolean { t | nil }
```

#### Description

Specifies that vias are inserted between the intersection of the layer above and below the via in the supply grid.

The default is `t`.

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Insert vias for supply stripes</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_insertVias")  
envSetVal("APR.stdcell.route" "supply_insertVias" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_nets

```
APR.stdcell.route supply_nets cyclic { "All" | "Selected" }
```

#### Description

Specifies whether to route all or selected supply nets.

The default is "All".

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Supply Nets – All, Selected</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_nets")  
envSetVal("APR.stdcell.route" "supply_nets" 'cyclic "Selected")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



### supply\_netsWithin

```
APR.stdcell.route supply_netsWithin cyclic { "PR boundary" | "Guardring/FigGroup" }
```

#### Description

Specifies whether to route everything inside the PR boundary or only within a guard ring or figGroup.

The default is "PR boundary".

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Within</i> – <i>PR boundary</i> , <i>Guardring/FigGroup</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_netsWithin")  
envSetVal("APR.stdcell.route" "supply_netsWithin" 'cyclic "Guardring/FigGroup")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_pinLayers

```
APR.stdcell.route supply_pinLayers string "pinLayer"
```

### Description

Lets you specify a list of layers to create pins on for supply routing.

The default is "".

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Use Selected Layers</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_pinLayers")  
envSetVal("APR.stdcell.route" "supply_pinLayers" 'string "metall")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_pinLayerSet

```
APR.stdcell.route supply_pinLayerSet cyclic { "Use all supply stripe layers" | "Use  
selected layers" }
```

#### Description

Specifies the top and bottom layers of the supply stripes layer range that pins should be created on.

The default is "Use all supply stripe layers".

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Pins create</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_pinLayerSet")  
envSetVal("APR.stdcell.route" "supply_pinLayerSet" 'cyclic "Use selected layers")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## supply\_routedLOC

```
APR.stdcell.route supply_routedLOC cyclic { "Current cellview" | "Other cellview" }
```

### Description

Specifies whether to write the supply routing to the current cellview or to a different cellview.

The default is "Current cellview".

### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Current cellview, Other cellview</i>

### Examples

```
envGetVal("APR.stdcell.route" "supply_routedLOC")  
envSetVal("APR.stdcell.route" "supply_routedLOC" 'cyclic "Other cellview")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_saveRoutingOnly**

```
APR.stdcell.route supply_saveRoutingOnly boolean { t | nil }
```

### **Description**

Specifies whether to copy only the supply grid or all initial data and the supply grid to the new cellview.

The default is `nil`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Save routing only</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_saveRoutingOnly")  
envSetVal("APR.stdcell.route" "supply_saveRoutingOnly" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### supply\_shareTracks

```
APR.stdcell.route supply_shareTracks boolean { t | nil }
```

#### Description

Distinguishes upper and below areas for one WSP track by instance's pin name.

The default is `nil`.

#### GUI Equivalent

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Share tracks for supply nets</i>

#### Examples

```
envGetVal("APR.stdcell.route" "supply_shareTracks")  
envSetVal("APR.stdcell.route" "supply_shareTracks" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **supply\_useExisitingPGTracks**

```
APR.stdcell.route supply_useExisitingPGTracks boolean { t | nil }
```

### **Description**

Lists layers in Supply Stripes that have PG tracks.

The default is `t`.

### **GUI Equivalent**

Command	Routing assistant – <i>Supply</i> tab
Field	<i>Only use layers with WSP P/G tracks</i>

### **Examples**

```
envGetVal("APR.stdcell.route" "supply_useExisitingPGTracks")  
envSetVal("APR.stdcell.route" "supply_useExisitingPGTracks" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### tracksCmds

```
APR.stdcell.route tracksCmds string "filename"
```

#### Description

Specifies the Tcl plugin hook file for custom `add_tracks` settings that is sourced before the placement stage. The file can be placed anywhere and can be specified with the absolute path or the relative path to the current working directory. The default is " ".

**Note:** The plugin is skipped if one or more 0-width active WSPs exists on metal layers in the design. This indicates that they were imported from Innovus-generated tracks in a previous step. A message is displayed to notify whether the plugin was sourced or skipped.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "tracksCmds")  
envSetVal("APR.stdcell.route" "tracksCmds" 'string "track1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## **useMultipleTapCells**

```
APR.stdcell.route useMultipleTapCells cyclic { "disable" | "enable" | "auto" }
```

### **Description**

Changes the output to support multiple tap cells.

The default is "auto".

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.route" "useMultipleTapCells")
envSetVal("APR.stdcell.route" "useMultipleTapCells" 'cyclic "enable"')
envSetVal("APR.stdcell.route" "useMultipleTapCells" 'cyclic "disable"')
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### useStylusMode

```
APR.stdcell.route useStylusMode boolean { t | nil }
```

#### Description

Controls whether to use stylus mode for the Tcl plugin syntax. If set to `t`, stylus mode is used. Otherwise, legacy mode is used.

The default is `t`.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.route" "useStylusMode")
envSetVal("APR.stdcell.route" "useStylusMode" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## Standard Cell Placement Environment Variables

- init\_boundaryAspectRatioOrHeight
- init\_boundaryAspectRatioVal
- init\_boundaryHeightVal
- init\_boundaryUtilizationOrWidth
- init\_boundaryUtilizationVal
- init\_boundaryWidthVal
- init\_generateBoundary
- init\_generateInstances
- init\_useSourceLayout
- init\_useSourceLayoutBoundary
- init\_useSourceLayoutInstances
- init\_useSourceLayoutPins
- place\_addBoundaryCells
- place\_addCellRowRouting
- place\_addDecapFillerCells
- place\_addTapCells
- place\_boundaryCellsContainTapCells
- place\_defaultPlacedView
- place\_deleteBoundaryCells
- place\_deleteFillerCells
- place\_deleteTapCells
- place\_displayLog
- place\_overwriteLog
- place\_placedLocation
- place\_placeStdCells

## **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

### **Standard Cell Placement and Routing Environment Variables**

---

- place\_showInformation
- setup\_createRowRegionInArea
- setup\_Innovus1stRowOrientation
- setup\_rowCreation

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

#### **advNode**

```
APR.stdcell.place advNode boolean { t | nil }
```

#### **Description**

Controls the GUI behavior. For example, some standard cells have well taps inside boundary cells and must place boundary and tap cells together. The default is `nil`.

#### **GUI Equivalent**

None

#### **Examples**

```
envGetVal("APR.stdcell.place" "advNode")  
envSetVal("APR.stdcell.place" "advNode" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### init\_boundaryAspectRatioOrHeight

```
APR.stdcell.place init_boundaryAspectRatioOrHeight cyclic { "Aspect ratio" |  
    "Height" }
```

#### Description

Specifies whether the aspect ratio or the height is used as the basis for determining the PR boundary.

The default is "Aspect ratio".

#### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

#### Examples

```
envGetVal("APR.stdcell.place" "init_boundaryAspectRatioOrHeight")  
envSetVal("APR.stdcell.place" "init_boundaryAspectRatioOrHeight" 'cyclic  
"Height")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **init\_boundaryAspectRatioVal**

```
APR.stdcell.place init_boundaryAspectRatioVal float float_number
```

### **Description**

Specifies the width-to-height ratio of the PR boundary.

The default value is 1 indicates a square boundary. An aspect ratio of 0.5 specifies a boundary twice as high as it is wide. A value of 2 specifies a boundary twice as wide as its height.

### **GUI Equivalent**

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

### **Examples**

```
envGetVal("APR.stdcell.place" "init_boundaryAspectRatioVal")  
envSetVal("APR.stdcell.place" "init_boundaryAspectRatioVal" 'float 0.5)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### init\_boundaryHeightVal

APR.stdcell.place init\_boundaryHeightVal float *float\_number*

#### Description

Specifies the height of the PR boundary.

The default value is 10.0.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

#### Examples

```
envGetVal("APR.stdcell.place" "init_boundaryHeightVal")
envSetVal("APR.stdcell.place" "init_boundaryHeightVal" 'float 5.0)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## **init\_boundaryUtilizationOrWidth**

```
APR.stdcell.place init_boundaryUtilizationOrWidth cyclic { "Utilization" | "Width"
}
```

### **Description**

Specifies whether the PR boundary is to be calculated based on the utilization percentage or the width.

The default is "Utilization".

### **GUI Equivalent**

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

### **Examples**

```
envGetVal("APR.stdcell.place" "init_boundaryUtilizationOrWidth")
envSetVal("APR.stdcell.place" "init_boundaryUtilizationOrWidth" 'cyclic "Width")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **init\_boundaryUtilizationVal**

```
APR.stdcell.place init_boundaryUtilizationVal float float_number
```

### **Description**

Specifies the area utilization to be used when generating the PR boundary. It is the ratio of the combined area of the logical cells to the area of the PR boundary expressed as a percentage.

The default value is 25.0.

### **GUI Equivalent**

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

### **Examples**

```
envGetVal("APR.stdcell.place" "init_boundaryUtilizationVal")  
envSetVal("APR.stdcell.place" "init_boundaryUtilizationVal" 'float 15.0)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### init\_boundaryWidthVal

```
APR.stdcell.place init_boundaryWidthVal float float_number
```

#### Description

Specifies the width of the PR boundary.

The default value is 10.0.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

#### Examples

```
envGetVal("APR.stdcell.place" "init_boundaryWidthVal")  
envSetVal("APR.stdcell.place" "init_boundaryWidthVal" 'float 5.0)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## init\_createPowerPins

```
APR.stdcell.place init_createPowerPins boolean { t | nil }
```

### Description

Controls whether IO power and ground pins are created during initialization of the layout view. The default is `t`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Power pin layer</i>

### Examples

```
envGetVal("APR.stdcell.place" "init_createPowerPins")
envSetVal("APR.stdcell.place" "init_createPowerPins" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## init\_generateBoundary

```
APR.stdcell.place init_generateBoundary boolean { t | nil }
```

### Description

Generates a PR boundary.

The default is `nil`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Boundary</i>

### Examples

```
envGetVal("APR.stdcell.place" "init_generateBoundary")  
envSetVal("APR.stdcell.place" "init_generateBoundary" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

#### init\_generateInstances

```
APR.stdcell.place init_generateInstances boolean { t | nil }
```

#### Description

Generates all the instances in the schematic that do not have any ignore properties attached to them.

The default is `t`.

#### GUI Equivalent

Command      Auto P&R assistant – *Initialize* tab

Field          *Instances*

#### Examples

```
envGetVal("APR.stdcell.place" "init_generateInstances")  
envSetVal("APR.stdcell.place" "init_generateInstances" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### init\_generatePins

```
APR.stdcell.place init_generatePins boolean { t | nil }
```

#### Description

Specifies that signal IO pins and power IO pins on a layer are to be generated.

The default is `t`.

#### GUI Equivalent

Command      Auto P&R assistant – *Initialize* tab

Field          *Pins*

#### Examples

```
envGetVal("APR.stdcell.place" "init_generatePins")  
envSetVal("APR.stdcell.place" "init_generatePins" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## init\_mode

```
APR.stdcell.place init_mode cyclic { "Generate" | "Update" }
```

### Description

Specifies a standard cell generation mode. The available options are:

- **Generate:** Generates new standard cells in the layout design.
- **Update:** Updates existing standard cells in the layout design.

The default value is `Generate`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Generation Options</i> – <i>Generate, Update</i>

### Examples

```
envGetVal("APR.stdcell.place" "init_mode")  
envSetVal("APR.stdcell.place" "init_mode" 'cyclic "Update")
```

### Related Topics

[Standard Cell Placement and Routing Environment Variables](#)



### init\_scope

```
APR.stdcell.place init_scope cyclic { "All" | "Selected" }
```

#### Description

Specifies the scope of layout generation.

- **All**: Generates all standard cells present in the source.
- **Selected**: Generates only the selected standard cells.

The default value is **All**.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Initialize</i> tab
Field	<i>Generation Options</i> – <i>All, Selected</i>

#### Examples

```
envGetVal("APR.stdcell.place" "init_scope")  
envSetVal("APR.stdcell.place" "init_scope" 'cyclic "Selected")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **init\_useSourceLayout**

```
APR.stdcell.place init_useSourceLayout boolean { t | nil }
```

### **Description**

Specifies that a source layout is to be reused during layout generation. When set to `t`, you can further specify which components from the source layout are to be reused by using the `init_useSourceLayoutBoundary`, `init_useSourceLayoutInstancePositions`, and `init_useSourceLayoutPins` environment variables.

The default is `nil`.

### **GUI Equivalent**

Command      Auto P&R assistant – *Initialize* tab

Field          *Reuse Options – Use Source Layout*

### **Examples**

```
envGetVal("APR.stdcell.place" "init_useSourceLayout")  
envSetVal("APR.stdcell.place" "init_useSourceLayout" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[init\\_useSourceLayoutBoundary](#)

[init\\_useSourceLayoutInstances](#)

[init\\_useSourceLayoutPins](#)

### init\_useSourceLayoutBoundary

```
APR.stdcell.place init_useSourceLayoutBoundary boolean { t | nil }
```

#### Description

Adjusts the PR boundary in the current cellview as per its setting in the source cellview. This environment variable is honored only when `init_useSourceLayout` is set to `t`.

The default is `nil`.

#### GUI Equivalent

Command      Auto P&R assistant – *Initialize* tab

Field          *Reuse Options – Use Source Layout – Boundary*

#### Examples

```
envGetVal("APR.stdcell.place" "init_useSourceLayoutBoundary")  
envSetVal("APR.stdcell.place" "init_useSourceLayoutBoundary" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[init\\_useSourceLayout](#)

[init\\_useSourceLayoutInstances](#)

[init\\_useSourceLayoutPins](#)

### init\_useSourceLayoutInstances

```
APR.stdcell.place init_useSourceLayoutInstances boolean { t | nil }
```

#### Description

Updates the positions of standard cells, custom cells, and macros in the current cellview as per the source cellview. This environment variable is honored only when `init_useSourceLayout` is set to `t`.

The default is `nil`.

#### GUI Equivalent

Command      Auto P&R assistant – *Initialize* tab

Field          *Reuse Options – Use Source Layout – Instance Positions*

#### Examples

```
envGetVal("APR.stdcell.place" "init_useSourceLayoutInstances")
envSetVal("APR.stdcell.place" "init_useSourceLayoutInstances" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[init\\_useSourceLayout](#)

[init\\_useSourceLayoutBoundary](#)

[init\\_useSourceLayoutPins](#)

### init\_useSourceLayoutPins

```
APR.stdcell.place init_useSourceLayoutPins boolean { t | nil }
```

#### Description

Places pins in the current cellview as per their positions in the source cellview. This environment variable is honored only when `init_useSourceLayout` is set to `t`.

The default is `nil`.

#### GUI Equivalent

Command      Auto P&R assistant – *Initialize* tab

Field          *Reuse Options – Use Source Layout – Instance Positions*

#### Examples

```
envGetVal("APR.stdcell.place" "init_useSourceLayoutPins")
envSetVal("APR.stdcell.place" "init_useSourceLayoutPins" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

[init\\_useSourceLayout](#)

[init\\_useSourceLayoutInstances](#)

[init\\_useSourceLayoutBoundary](#)

### place\_addBoundaryCells

```
APR.stdcell.place place_addBoundaryCells boolean { t | nil }
```

#### Description

Adds boundary cells around core cells.

The default is `t`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Placement Options</i> – <i>Add boundary cells</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_addBoundaryCells")  
envSetVal("APR.stdcell.place" "place_addBoundaryCells" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **place\_addCellRowRouting**

```
APR.stdcell.place place_addCellRowRouting boolean { t | nil }
```

### **Description**

Inserts standard cell power routing stripes for the layers that have standard cell power pins and connects to the layer above using vias. The inserted vias are color correct in Innovus.

The default is `nil`.

### **GUI Equivalent**

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Placement Options</i> – <i>Add cell row routing</i>

### **Examples**

```
envGetVal("APR.stdcell.place" "place_addCellRowRouting")  
envSetVal("APR.stdcell.place" "place_addCellRowRouting" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## place\_addDecapFillerCells

```
APR.stdcell.place place_addDecapFillerCells boolean { t | nil }
```

### Description

Adds decap/filler cells into the design. Select decap cells first and place them. You can then follow it up with selected filler cells for the remaining spaces.

The default is `t`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Placement Options</i> – <i>Add decap/filler cells</i>

### Examples

```
envGetVal("APR.stdcell.place" "place_addDecapFillerCells")
envSetVal("APR.stdcell.place" "place_addDecapFillerCells" 'boolean nil)
```

### Related Topics

[Standard Cell Placement and Routing Environment Variables](#)



### place\_addTapCells

```
APR.stdcell.place place_addTapCells boolean { t | nil }
```

#### Description

Adds single-height or multi-height tap cells in the empty spaces between the standard cells.

The default is `t`.

#### GUI Equivalent

Command      Auto P&R assistant – *Place* tab

Field          *Placement Options – Add tap cells*

#### Examples

```
envGetVal("APR.stdcell.place" "place_addTapCells")  
envSetVal("APR.stdcell.place" "place_addTapCells" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **place\_boundaryCellsContainTapCells**

```
APR.stdcell.place place_boundaryCellsContainTapCells boolean { t | nil }
```

### **Description**

Disables the independent selection of *Add boundary cells* and *Add tap cells* options and makes them both selected. This is to ensure that boundary cells are not fixed from a previous run so they cannot be swapped with tap cells as needed when tap cells are placed. If done in the same run, boundary cells do not have a fixed or locked status when tap cells are added.

The default is `nil`.

### **GUI Equivalent**

Command      Auto P&R assistant – *Initialize* tab

Field          *Reuse Options – Use Source Layout – Instance Positions*

### **Examples**

```
envGetVal("APR.stdcell.place" "place_boundaryCellsContainTapCells")  
envSetVal("APR.stdcell.place" "place_boundaryCellsContainTapCells" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **place\_createPhysOnlyAsAGroup**

```
APR.stdcell.place place_createPhysOnlyAsAGroup boolean { t | nil }
```

### **Description**

Controls whether the physical-only cells are added to a figGroup. The default is `nil`.

### **GUI Equivalent**

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Create physical only cells as group</i>

### **Examples**

```
envGetVal("APR.stdcell.place" "place_createPhysOnlyAsAGroup")
envSetVal("APR.stdcell.place" "place_createPhysOnlyAsAGroup" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **place\_defaultPlacedView**

```
APR.stdcell.place place_defaultPlacedView string "placementView"
```

### **Description**

Specifies the default view name when the results of placement are written to a different view.

The default is "layout.placed".

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("APR.stdcell.place" "place_defaultPlacedView")  
envSetVal("APR.stdcell.place" "place_defaultPlacedView" 'string "layout.placed1")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_deleteBoundaryCells

```
APR.stdcell.place place_deleteBoundaryCells boolean { t | nil }
```

#### Description

Deletes the boundary cells in the design.

The default is `nil`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Update – Delete Boundary cells</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_deleteBoundaryCells")  
envSetVal("APR.stdcell.place" "place_deleteBoundaryCells" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_deleteFillerCells

```
APR.stdcell.place place_deleteFillerCells boolean { t | nil }
```

#### Description

Deletes the filler cells in the design.

The default is `nil`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Update – Delete Filler cells</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_deleteFillerCells")
envSetVal("APR.stdcell.place" "place_deleteFillerCells" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_deleteTapCells

```
APR.stdcell.place place_deleteTapCells boolean { t | nil }
```

#### Description

Deletes the tap cells in the design.

The default is `nil`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Update – Delete Tap cells</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_deleteTapCells")
envSetVal("APR.stdcell.place" "place_deleteTapCells" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_displayLog

```
APR.stdcell.place place_displayLog boolean { t | nil }
```

#### Description

Controls the display of the placement log.

The default is `t`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Output – Display Log</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_displayLog")
envSetVal("APR.stdcell.place" "place_displayLog" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



## place\_overwriteLog

```
APR.stdcell.place place_overwriteLog boolean { t | nil }
```

### Description

Controls the overwriting of the last log file. When set to `nil`, the existing log file is retained and data is not updated.

The default is `t`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Output – Overwrite log</i>

### Examples

```
envGetVal("APR.stdcell.place" "place_overwriteLog")
envSetVal("APR.stdcell.place" "place_overwriteLog" 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

#### place\_placedLocation

```
APR.stdcell.place place_placedLocation cyclic { "Current cellview" | "Other  
cellview" }
```

#### Description

Specifies whether to write the output of the cell placement to the current cellview or a different cellview.

The default is "Current cellview".

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Output – Current cellview, Other cellview</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_placedLocation")  
envSetVal("APR.stdcell.place" "place_placedLocation" 'cyclic "Other cellview")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_placeStdCells

```
APR.stdcell.place place_placeStdCells boolean { t | nil }
```

#### Description

Places the standard cells in the design.

The default is `nil`.

#### GUI Equivalent

Command      Auto P&R assistant – *Place* tab

Field          *Placement Options – Place std cells*

#### Examples

```
envGetVal("APR.stdcell.place" "place_placeStdCells")
envSetVal("APR.stdcell.place" "place_placeStdCells" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### place\_showInformation

```
APR.stdcell.place place_showInformation boolean { t | nil }
```

#### Description

Displays information about the placement.

The default is `nil`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Interactive Placement – Show information</i>

#### Examples

```
envGetVal("APR.stdcell.place" "place_showInformation")  
envSetVal("APR.stdcell.place" "place_showInformation" 'boolean t)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### postPlaceTrigger

```
APR.stdcell.place postPlaceTrigger string "cmdName"
```

#### Description

Specifies a SKILL command that is executed after placement. The default is an empty string "".

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.place" "postPlaceTrigger")  
envSetVal("APR.stdcell.place" "postPlaceTrigger" 'string "cmd1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### prePlaceTrigger

```
APR.stdcell.place prePlaceTrigger string "cmdName"
```

#### Description

Specifies a SKILL command that is executed before placement. The default is an empty string "".

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.place" "prePlaceTrigger")  
envSetVal("APR.stdcell.place" "prePlaceTrigger" 'string "cmd1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Standard Cell Placement and Routing Environment Variables

---

#### runDir

```
APR.stdcell.place runDir string "directoryName"
```

#### Description

Specifies a directory to place the placer log files. The default is ./placerLogs.

#### GUI Equivalent

None

#### Examples

```
envGetVal("APR.stdcell.place" "runDir")  
envSetVal("APR.stdcell.place" "runDir" 'string "dir1")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **setup\_createRowRegionInArea**

```
APR.stdcell.place setup_createRowRegionInArea boolean { t | nil }
```

### **Description**

Specifies the area within which a row region must be created. If a region is not specified, the entire PR boundary is considered for creating the row region.

The default is `nil`.

### **GUI Equivalent**

Command      Auto P&R assistant – *Setup* tab

Field            *Rows – Create row region – Create rows in area*

### **Examples**

```
envGetVal("APR.stdcell.place" "setup_createRowRegionInArea")  
envSetVal("APR.stdcell.place" "setup_createRowRegionInArea" 'boolean t)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)



### setup\_displayLog

```
APR.stdcell.place setup_displayLog boolean { t | nil }
```

#### Description

Specifies whether to display the row generation log file after the placement setup is done. The default is `t`.

#### GUI Equivalent

Command	Auto P&R assistant – <i>Setup</i> tab
Field	<i>Display log</i>

#### Examples

```
envGetVal("APR.stdcell.place" "setup_displayLog")
envSetVal("APR.stdcell.place" "setup_displayLog" 'boolean nil)
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## setup\_Innovus1stRowOrientation

```
APR.stdcell.place setup_Innovus1stRowOrientation cyclic { "R0" | "MX" }
```

### Description

Specifies the orientation of the bottom-most (first) row in the row region when generating rows in Innovus.

The default is "R0".

### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Rows – First row orientation</i>

### Examples

```
envGetVal("APR.stdcell.place" "setup_Innovus1stRowOrientation")  
envSetVal("APR.stdcell.place" "setup_Innovus1stRowOrientation" 'cyclic "MX")
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## setup\_overwriteLog

```
APR.stdcell.place setup_overwriteLog boolean { t | nil }
```

### Description

Specifies whether the row generation log file must be overwritten. The default is `t`.

### GUI Equivalent

Command	Auto P&R assistant – <i>Setup</i> tab
Field	<i>Overwrite log</i>

### Examples

```
envGetVal("APR.stdcell.place" "setup_overwriteLog ")  
envSetVal("APR.stdcell.place" "setup_overwriteLog " 'boolean nil)
```

### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Standard Cell Placement and Routing Environment Variables

---

### setup\_rowCount

```
APR.stdcell.place setup_rowCount cyclic { "Auto" | "Even" | "Odd" }
```

#### Description

Specifies whether to fit as many rows as possible, or an even number of rows, or an odd numbers within the PR boundary or drawn area. The default is "Auto".

#### GUI Equivalent

Command	Auto P&R assistant – <i>Setup</i> tab
Field	<i>Row Count</i>

#### Examples

```
envGetVal("APR.stdcell.place" "setup_rowCount")
envSetVal("APR.stdcell.place" "setup_rowCount" 'cyclic "Even")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

### setup\_rowCreation

```
APR.stdcell.place setup_rowCreation cyclic { "Import Innovus rows" | "Create row region" }
```

#### Description

Specifies whether to create rows in Innovus or from Virtuoso as a row region.

- `Import Innovus rows`: imports rows from Innovus.
- `Create row region`: creates a row region in Virtuoso using an existing row template.

The default is "Import Innovus rows".

#### GUI Equivalent

Command	Auto P&R assistant – <i>Place</i> tab
Field	<i>Rows – Import Innovus rows, Create row region</i>

#### Examples

```
envGetVal("APR.stdcell.place" "setup_rowCreation")  
envSetVal("APR.stdcell.place" "setup_rowCreation" 'cyclic "Create row region")
```

#### ***Related Topics***

[Standard Cell Placement and Routing Environment Variables](#)

## **Virtuoso Automated Standard Cell Placement and Routing Flow Guide**

### **Standard Cell Placement and Routing Environment Variables**

---

---

# Automated Standard Cell Placement and Routing User Interface

---

In the Virtuoso standard cell placement and routing flow, you use the Auto P&R assistant for standard cell placement and the Routing assistant for standard cell routing in the Layout MXL cockpit.

The Auto P&R assistant is the integrated, automatic placement and routing solution available in Virtuoso. Use the Auto P&R assistant to initialize, set up, place, and route the standard cells in the layout design automatically as per your requirements.

The Routing assistant has the same look-and-feel for device, standard cell, and chip assembly routing with a common toolbar for all routing types. The Routing assistant is a dockable assistant pane that provides various options to let you perform tasks related to various routing types.

This topic lists the standard cell placement and routing assistant and forms.

## ***Standard Cell Placement and Routing Assistants***

[Auto P&R Assistant User Interface for Standard Cell](#)

[Routing Assistant User Interface for Standard Cell](#)

## ***Standard Cell Placement Forms (Auto P&R Assistant)***

[Boundary Cells Form](#)

[Choose Source Layout Cellview Form](#)

[Filler Cells Form](#)

[Load Option Presets Form](#)

[Save Option Presets Form](#)

[Select Row Template Form](#)

[Tap Cells Form](#)

## ***Standard Cell Routing Forms (Routing Assistant)***

[Assign Wire Types to Nets Form](#)

[Map WSP Wire Types to Symbols Form](#)

[Pull Back and Offset Values Form](#)

## ***Related Topics***

[Routing Assistant](#)

[Accessing Routing Assistant](#)

[Virtuoso Routing Constraint Manager](#)

[Opening Routing Constraint Manager](#)

## **Auto P&R Assistant User Interface for Standard Cell**

The Auto P&R assistant is the integrated, automatic placement and routing solution available in Virtuoso. Use the Auto P&R assistant to initialize, set up, place, and route the standard cells in the layout design automatically as per your requirements.

The Auto P&R assistant has the following components:

---




<a href="#"><u>Routing Assistant Toolbar</u></a>	Lets you access the buttons to complete the steps of the routing flow.
<a href="#"><u>Routing Assistant Tabs</u></a>	Lets you specify the options for running the selected routing type.
<a href="#"><u>Auto P&amp;R Command Buttons</u></a>	Lets you access the buttons on each tab to complete a routing task.

---

## **Auto P&R Assistant Toolbar**

The following table lists the functions of the different buttons on the Auto P&R assistant toolbar:


---

<b>Icon</b>	<b>Command</b>	<b>Description</b>
	<i>Change placer type.</i>	Changes the type of placement you want to run on the design. The two placement types are: <i>Device</i> and <i>Stdcell</i> .
	<i>Load preset options</i>	Lets you load the placement options from an existing preset file.
	<i>Save preset options</i>	Lets you save the placement preset options to a file.



# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Automated Standard Cell Placement and Routing User Interface

Icon	Command	Description
	<i>Raise the Routing Assistant</i>	Opens the Routing Assistant.

## Auto P&R Assistant Tabs

The following table lists the functions of the different tabs in the Auto P&R assistant:

Tab	Description
<i><u>Initialize</u></i>	Generates layout representations of the schematic design components. Any existing components in the layout view are deleted and are regenerated from scratch.
<i><u>Setup</u></i>	Generates a row region and width spacing pattern (WSP), gate, and source and drain tracks. The rows are used for standard cell placement. The tracks are used for standard cell snapping and routing.
<i><u>Place</u></i>	Lets you customize placement settings and run the placer.

## Initialize

The following table describes the fields available on the *Initialize* tab of the Auto P&R assistant for standard cell placement.

Field	Description
<b><i>Generation Options</i></b>	Lets you select the objects to be generated in the layout.
<i>Generate</i>	Generates the instances and pins in the schematic that do not have any ignore properties attached to them.
<i>Instances</i>	Generates all the instances in the schematic that do not have any ignore properties attached to them.
<i>Pins</i>	Generates signal and IO power pins.
<i>Pin Layer</i>	Specifies the layer in the target layout view for the signal pin from the schematic.

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Power pin layer</i>	Specifies the layer in the target layout view for the power or ground pin from the schematic. Deselecting the check box prevents power IO pin from being created, if you plan to create power IO pins with the supply router.  The first metal layer in the layer stack is set as the default value.
<i>Boundary</i>	Generates a PR boundary.
<i>Utilization</i>	Specifies the percentage of area within the PR boundary that can be filled with objects. The default is 25%.
<i>Aspect Ratio</i>	Specifies the width-to-height ratio of the PR boundary. The default value is 1, which indicates a square boundary. An aspect ratio of 0.5 specifies a boundary twice as high as it is wide. A value of 2 specifies a boundary twice as wide as its height.
<b>Migration Options</b>	This section is available only in Layout MXL and is part of the assisted custom layout design migration flow.  Use the options in this section to capture source data and apply it to a target layout.
<i>Migration Directory</i>	Specifies the path to the directory in which the captured source data is stored. The target layout references this location for applying the captured source data.
<i>Capture Placement from Layout</i>	Captures data from the source layout and stores it in the specified <i>Migration Directory</i> .
<i>Apply Placement to Layout</i>	Specifies the target layout to which the captured reuse information must be applied.
Layout Objects	Specifies the objects in the target layout to which reuse settings are to be applied. The available options are: <ul style="list-style-type: none"> <li>■ <i>Instances</i></li> <li>■ <i>Pins</i></li> <li>■ <i>Boundary</i></li> <li>■ <i>Constraints</i></li> </ul>
<b>PDK Settings</b>	Specifies the process setup and LEFDefaultRouteSpec name.
<i>Process Setup</i>	Specifies the process setup name to use for the Innovus process node.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Multi-tech LEF Foundry Rule</i>	Lets you select a foundry rule for Innovus from the multi-tech LEFs in the RMSOA PDK. This option is available only for Rapid Mixed-Signal Open Access (RMSOA) multi-tech PDKs.
<i>LEFDefaultRouteSpec</i>	Displays the name of the <i>LEFDefaultRouteSpec</i> to be used in Innovus.  This option works with the multi-tech LEF selection.




### Setup

The following table describes the fields available on the *Setup* tab of the Auto P&R assistant.

Field	Description
<b>WSPs</b>	Specifies WSP settings.
<i>Create manually</i>	Opens the WSP Manager, which lets you create and modify WSPs, import WSPs from other designs, and generate WSPs from existing shapes in the layout canvas.
<i>Create automatically</i>	Opens the <i>Setup</i> tab of the Routing assistant.  Use the <i>Layer</i> and <i>Pattern</i> columns in the table in this assistant to specify WSP attributes.
<i>Set active WSPs</i>	Opens the Track Pattern assistant.  For WSSPDefs that have more than one allowed pattern, you can change the active pattern using the Track Pattern assistant. You can also change the active WSSPDef.
<b>Rows</b>	Specifies how rows and row regions are to be created.
<i>Import Innovus rows</i>	Imports rows from Innovus.
<i>Create row region</i>	Creates a row region in Virtuoso using an existing row template.
<i>First row orientation</i>	Specifies the orientation of the bottom-most (first) row in the row region.  This option is displayed only when <i>Import Innovus rows</i> is selected.

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Row template</i>	<p>Specifies the row template based on which rows are to be created.</p> <p>Clicking the <i>Browse</i> button opens the Select Row Template form. You can navigate to the required cellview and select a row template.</p> <p>This option is displayed only when <i>Create row region</i> is selected.</p>
<i>Create rows in area</i>	<p>Specifies the area within which a row must be created. The available icons are:</p> <ul style="list-style-type: none"> <li>■ <i>Set area bbox to the visible area</i> : Sets the visible area of the design canvas as the row region.</li> <li>■ <i>Draw the area bbox</i> : Lets you draw the row region on the design canvas.</li> </ul> <p>Use <i>Show/hide the area bbox</i>  to display or hide the highlight around the row region.</p> <p>If a region is not specified, the entire PR boundary is considered for creating row region. This works for both Innovus-imported rows and row template-created rows.</p>
<i>Row count</i>	<p>Specifies whether to fit as many rows as possible, or an even number of rows, or an odd numbers within the PR boundary or drawn area.</p>
<b>Supply Routing</b>	Creates a supply grid.
<i>Generate Supply Grid</i>	<p>Opens the <i>Supply</i> tab for standard cell routing in the Routing assistant. Use this option when boundary cells have blockages.</p> <p>You can create a supply grid before running the placer to prevent routing from interfering with access to standard cell pins.</p>
<b>IO Pins</b>	Specifies IO pin attributes.
<i>Specify pin positions and attributes</i>	<p>Opens the <i>Pin Planner</i> tab of the Pin Placement form.</p> <p>Use the options in this form to specify pin constraints and pin placement attributes.</p>
<b>Checks</b>	Runs pre-routing checks to detect design issues before routing the design.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Run checks</i>	Opens the <i>Check</i> tab for standard cell routing in the Routing assistant. You can select the pre-routing checks to be run.

## Place

The following table describes the fields available on the *Place* tab of the Auto P&R assistant.

Field	Description
<b><i>Placement Options</i></b>	Specifies the options for placement of standard cells. All placement options can be run individually or simultaneously if all are selected.
<i>Boundary cells contain tap cells</i>	<p>Inserts boundary cells and tap cells together automatically.</p> <p>With this option selected, <i>Add boundary cells</i> and <i>Add tap cells</i> are automatically selected and disabled so that these commands cannot be run independently. As boundary and tap cells are added simultaneously, boundary cells do not have a fixed or locked status when tap cells are added. This ensures that boundary cells are not swapped with tap cells when tap cells are placed.</p> <p>If this option is not selected, boundary cells and tap cells can be added independently.</p>
<i>Add boundary cells</i>	Adds boundary cells around core cells. The <i>Browse</i> button opens the <u>Boundary Cells Form</u> , which lets you select boundary cells to be inserted along each edge of the PR boundary.
<i>Add tap cells</i>	<p>Adds single-height or multi-height tap cells in the empty spaces between the standard cells. The <i>Browse</i> button opens the <u>Tap Cells Form</u>, which lets you specify tap cell attributes.</p> <p><i>Add tap cells</i> is not available if <i>Boundary cells contain tap cells</i> is selected.</p>
<i>Add cell row routing</i>	Inserts follow-pin (cell row) routing for standard cell rails and vias with correct color in Innovus.
<i>Place std cells</i>	Adds the command to place standard cells into the Tcl command script.



## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Add decap/filler cells</i>	Adds decap/filler cells into a design. The <i>Browse</i> button opens the <u>Filler Cells Form</u> , which lets you specify filler cell attributes.
<i>Create physical only cells as group</i>	Adds physical only instances (boundary, tap, and filler or decap) cells into a figGroup.
<b>Update</b>	Allows cells of the type selected to be deleted.
<i>Boundary cells</i>	Deletes the boundary cells in the design.
<i>Tap cells</i>	Deletes the tap cells in the design.
<i>Filler cells</i>	Deletes the filler cells in the design.
<b>Output</b>	Specifies settings to display the placement log and to save output to a different placed view.
<i>Display log</i>	Controls the display of the placement log in the CIW once the cells are placed.
<i>Overwrite log</i>	<p>Specifies whether the previous log files are to be retained or overwritten by the new one.</p> <p>When the standard cell placer is run, three files are created in the <code>routerLogs</code> directory within the run directory—two log files with extensions <code>.log</code> and <code>.logv</code> and a <code>.cmd</code> file.</p> <p>The naming convention followed for these files is:</p> <pre>innovus.&lt;libName&gt;.&lt;cellName&gt;.&lt;viewName&gt;.{ cmd   log   logv }</pre> <p>When <i>Overwrite log</i> is switched off, the tool appends a # to the end of the three existing files. When switched on, the tool overwrites the highest # log file.</p>
<i>Current view</i>	Writes the output of the cell placement to the current cellview.
<i>Other view</i>	Lets you save the output to a different view.
<b>Interactive Placement</b>	Refines the interactive placement settings.
<i>Show Information</i>	Displays information about the placement.

## Auto P&R Command Buttons

The following table lists the functions of the different command buttons on the Auto P&R assistant:

Icon	Command	Description
	<i>Generate with specified options</i>	Generates width spacing patterns automatically on the selected layers.
	<i>Run GigaPlace</i>	Runs the standard cell placer.

### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Initializing a Layout in the Auto P&R Standard Cell Flow](#)


## Routing Assistant User Interface for Standard Cell

The Routing Assistant has the following components:

<a href="#">Routing Assistant Toolbar</a>	Lets you access the buttons to complete the steps of the routing flow.
<a href="#">Routing Assistant Tabs</a>	Lets you specify the options for running the selected routing type.
<a href="#">Routing Assistant Command Buttons</a>	Lets you access the buttons on each tab to complete a routing task.







### Routing Assistant Toolbar

The following table lists the functions of the different buttons on the Routing assistant toolbar:

Icon	Command	Description
	<i>Change routing mode</i>	Selects the routing mode. The two routing modes are <i>Automatic</i> and <i>Interactive</i> .

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Icon	Command	Description
	<i>Change routing type</i>	Changes the type of routing you want to run on the design. The three routing types are: <i>Device</i> , <i>StdCell</i> , <i>Chip Assembly</i> .
	<i>Raise the pre-routing browser</i>	Provides net information prior to routing.
	<i>Set router constraints</i>	Opens the Routing Constraint Manager.
	<i>Load preset options</i>	Lets you load options from an existing preset file.
	<i>Save preset options</i>	Lets you save the Routing Assistant options to a file.
	<i>Delete preset options</i>	Lets you delete an existing preset file.

## Routing Assistant Tabs

The following table lists the functions of the different tabs in the Routing assistant:

Tab	Description
<u>Setup</u>	Lets you specify the settings for running the router.
<u>Check</u>	Lets you select the checks that you want to run before routing the design.
<u>Supply</u>	Lets you run the power router. You need to have power and ground wireType tracks in your width spacing patterns. Usually, you run this routing before placement.
<u>Route</u>	Lets you specify the scope of signal routing.
<u>Results</u>	Lets you select the scope and the results column that should be displayed in Routing Results Browser.

The options in the Routing Assistant depend on the routing type in which the design is open. The three routing types are:

- **Device-level** flow helps users become familiar with the device-level placement and routing solution in Virtuoso for advanced nodes, with the focus on uniform designs.
- **Standard Cell** routing technology seamlessly integrates the NanoRoute™ router in the Virtuoso environment. It provides different ways for you to generate WSPs as well as route without them, relying on Innovus-created tracks.



## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

- **Chip Assembly** routing technology targets top-level designs that have macro instances, I/O pads, and can also contain standard cell areas. It also addresses memory type designs using spine routing.

### Setup

The following table describes the fields available on the *Setup* tab of the Routing assistant for standard cell routing.

Field	Description
<b>Options</b>	Lets you setup some general options for standard cell routing.
<i>Check DRCs after routing</i>	Automatically runs DRD design rule checks before routing. Environment variable: <u>setup_checkDRCsAfterRouting</u>
<i>Lock Colors after routing</i>	Locks colored shapes for routing.  This option is set based on the technology file layer rules. If the process has trim shapes that cut only locked color shapes, than the option is selected by default and editable. However, if the process has no trim shapes, the option is deselected by default and not editable.  If, trim shapes work on locked and unlocked shapes, the option is selected by default and editable.  Environment variable: <u>setup_lockColorsAfterRouting</u>
<i>Process setup</i>	Selects the process node to be used for routing.
<b>Layer Settings</b>	Lets you specify the layers for which to generate WSPs.
<i>Routing Layers</i>	Specifies valid bottom and top routing layers. The bottom and top layer fields contain both frontside layers and backside layers as defined in the technology file.       When a backside layer is specified in the bottom and top layer fields, the standard cell Nano Router is unable to run. As a result, the routing process is aborted and an error message is displayed in CIW.
<i>Wire Types Map</i>	Displays a form with a table that maps the wireType to the symbol to be used in the pattern specification in the table.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Wire Types Assign to nets</i>	Displays a form with a table that assigns wireTypes to nets.
<b>Layer table</b>	Provides a list of layers on which WSPs are generated.
<i>Layer</i>	The name of the layer.
<i>Pattern</i>	Generates the pattern of WSP as per your requirement. For example, <i>gs3ns2g3</i> where <i>g</i> stands for ground, <i>s</i> for signal, <i>n</i> for Null, <i>p</i> for power, and so on.
<i>Dir</i>	The routing direction of the layer. The supported routing directions include <i>Horizontal</i> , <i>Vertical</i> , <i>Orthogonal</i> , and <i>Forbid</i> . <i>Forbid</i> implies that no direction is considered.
<i>W</i>	The width specified for the layer.
<i>S</i>	The spacing specified for the layer.
<i>WSP</i>	The width spacing patterns defined for the layer.

### Check

The following table describes the fields available on the *Check* tab of the Routing assistant for standard cell routing.

Field	Description
<b>Check</b>	Provides a list of various checks that can be run for the routing type.
<i>Select</i>	Lets you specify the checks to be run. Click <i>All</i> or <i>None</i> to select or deselect all checks with a single click.
<b>Technology setup</b>	Lets you specify the checks related to the technology setup.
<i>R-MSOA PDK in tech graph</i>	Checks that there is a R-MSOA library in the technology graph.
<i>Design ITDB check</i>	Checks if the design library has an incremental technology database (ITDB) library that references a Rapid MSOA PDK.
<b>Abstract data</b>	Lets you specify the checks related to abstract data in the design.
<i>Abstract &amp; layout views available</i>	Checks for availability of abstract and layout views for standard cell instances.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Abstract &amp; layout pins match</i>	Checks that all pins match between layout and abstract views for standard cell instances.
<b>Design interoperability</b>	Lets you specify the design interoperability checks between Innovus and Virtuoso.
<i>Net sigTypes specified</i>	Checks that signal nets at level 0 are not connected to power and ground nets at level 1.
<i>Net sigTypes consistency</i>	Checks that there is a power and ground sigType net in the layout.
<i>Existing wiring in route object</i>	Checks for pre-existing wires in the routing objects.
<i>Existing wiring compatible</i>	Checks for the incompatible wires and wire segments. It also checks the name of standard via variants. If the via variant name is invalid, a message is displayed for the invalid name in CIW.
<i>Pins on routing layers</i>	Checks whether there are pins on non-routing layers in the design.
<i>Complete NDR specification</i>	Checks for the completeness of constraint group non-default rules (NDR), such as valid layers, spacing values, and so on.
<i>Custom constraints compatible</i>	Checks the compatibility of custom constraints.
<i>Rows interoperable</i>	Checks the row interoperability to ensure that each active row has a siteDef.
<i>WSPs interoperable</i>	Checks for the interoperability of active WSPs of each layer.
<i>Pins conform to active WSPs</i>	Checks for the conformance of pins to active WSPs.
<i>Bus terms order &amp; interface bit</i>	Checks bus annotation and reports any bus terminals ( <code>busTerms</code> ) that do not have ordering ( <code>busOrder</code> ) information. It also checks the status of interface bits.
<i>VLS XL compliant</i>	Checks whether or not the design is XL compliant. This means that the connectivity is XL compliant so that hierarchy is set up correctly between terms and <code>instTerms</code> throughout the design hierarchy.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Express pcell cache</i>	Checks for the presence of a Pcell cache.
<b>Routability</b>	Lets you specify the routability checks.
<i>Existing DRCs</i>	Specifies whether to run design rule checks using DRD. Environment variable: <u>check_existingDRCs</u>
<i>Objects outside PR boundary</i>	Lets you check for the objects that are outside the PR boundary.
<i>Blocked pins</i>	Lets you check if there are any blocked pins in the design.
<b>Output</b>	Settings to display the output of routing checks.
<i>Display Log</i>	Controls the display of the checker log in the CIW once the checks are run. Environment variable: <u>check_displayLog</u>
<i>Overwrite last log</i>	Controls the overwriting of the last log file. When the option is deselected, the existing log file is retained. Environment variable: <u>check_overwriteLog</u> , <u>checkerLogDir</u>
<i>Markers</i>	Controls the generation of markers for errors. These error markers can be viewed in the <i>Misc</i> tab of the Annotation Browser. Environment variable: <u>check_generateMarkers</u>

## Supply

The following table describes the fields available on the *Supply* tab of the Routing assistant for standard cell routing.

Field	Description
<b>Scope</b>	Defines the scope of supply routing.
<i>Supply Nets</i>	Specifies whether to route all or selected supply nets. Environment variable: <u>supply_nets</u>

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Within</i>	<p>Specifies whether to route everything inside the PR boundary or only within a guard ring or figGroup, or specify an area. You can also create supply stripes inside a row region or wsp region.</p> <p>The available options are: <i>PR boundary</i>, <i>Guardring/FigGroup</i>, <i>Area</i>, and <i>WSP/Row</i>.</p> <p>Environment variable: <u>supply_netsWithin</u></p>
<b>Options</b>	Lets you specify the options for supply routing.
<i>Only use layers with WSP P/G tracks</i>	<p>Provides a list of layers in the <i>Supply stripes</i> cyclic field for bottom and top layers that have power or ground tracks in the active WSP for that layer.</p> <p>Environment variable: <u>supply_useExistingPGTracks</u></p>
<i>Supply stripes</i>	Specifies the top and bottom layers of the supply stripes layer range that pins should be created on.
<i>Generate supply stripes</i>	<p>Generates stripes when supply routing is run.</p> <p>Environment variable: <u>supply_genSupplyStripes</u></p>
<i>Insert vias for supply stripes</i>	<p>Inserts the vias between the intersection of the layer above and below the via.</p> <p>Environment variable: <u>supply_insertVias</u></p>
<i>Connect to overlapped terminals</i>	<p>Specifies whether or not the supply router should connect to IO pins and guard rings.</p> <p>Environment variable: <u>supply_connectToTerminals</u></p>
<i>Insert trim to fix DRCs</i>	<p>Inserts trims between the intersection of the layer above and below the via in the supply grid to fix DRC errors.</p> <p>Environment variable: <u>supply_insertTrim</u></p>
<i>Share tracks for supply nets</i>	<p>Distinguishes upper and below areas for one WSP track by instance's pin name.</p> <p>Environment variable: <u>supply_shareTracks</u></p>
<i>Create supply grid as a group</i>	<p>Creates the supply grid as a figGroup.</p> <p>Environment variable: <u>supply_createGridAsGroup</u></p>

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Ignore boundary tracks</i>	<p> Ignores generating stripes on tracks that are on the PR boundary.</p> <p> Environment variable: <u>supply IgnoreBoundaryTracks</u></p>
<i>Ignore boundary vias</i>	<p> Ignores generating vias on tracks that are on the PR boundary.</p> <p> Environment variable: <u>supply IgnoreBoundaryVias</u></p>
<i>Assign to nets</i>	<p> Opens a form with a table that assigns wireTypes to nets.</p>
<i>Pull-back</i>	<p> Controls the spacing of power nets per layer from the PR boundary to avoid any DRC violation.</p>
<b>Pins</b>	<p> Lets you specify the supply routing options for pins in the design.</p>
<i>Create</i>	<p> Creates a pin instead of a pathSeg for the supply stripe.</p> <p> Environment variable: <u>supply createPins</u></p>
<i>Create label</i>	<p> Creates labels on pins when the <i>Pins Create</i> option is selected in the <i>Supply</i> tab of the Routing assistant.</p> <p> Environment variable: <u>supply createPinLabel</u></p>
<i>Use all supply stripe layers</i>	<p> Creates pins on the layers on which stripes are generated.</p> <p> Environment variable: <u>supply pinLayerSet</u></p>
<i>Use selected layers</i>	<p> Creates pins on only the layers that are selected.</p> <p> Environment variable: <u>supply pinLayerSet</u></p>
<i>Create on ends</i>	<p> Creates pins on the ends of stripes instead of one long pin when the <i>Pins Create</i> option is selected.</p> <p> Environment variable: <u>supply createPinsOnEnds</u></p>
<i>Create on pin purpose</i>	<p> Lets you use a pin as the layer purpose for the created pin.</p> <p> Environment variable: <u>supply createPinsOnPinPurpose</u></p>
<b>Update</b>	<p> Lets you select the supply routing options to be deleted.</p>
<i>Delete Supply stripes</i>	<p> Deletes the stripes generated by the supply router before power routing.</p> <p> Environment variable: <u>supply deleteStripes</u></p>
<i>Delete Supply vias</i>	<p> Deletes the vias generated by the supply router before power routing.</p> <p> Environment variable: <u>supply deleteVias</u></p>

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<b>Output</b>	Lets you specify the settings to display the routing results.
<i>Current cellview</i>	Write the output of the supply routing to the current cellview. Environment variable: <u>supply_defaultRoutedView</u> , <u>supply_routedLOC</u>
<i>Other cellview</i>	Lets you select a view name to write the output of the supply routing to another cellview. You can also specify a non-database existing name.  The name of the cell is <code>\$cell_proute</code> with <code>_proute</code> as the postfix to the cell name. The view name is always <code>layout</code> .  Environment variable: <u>supply_defaultRoutedView</u> , <u>supply_routedLOC</u> , <u>supply_defaultRoutedCellExpression</u>
<i>Save routing only</i>	Specifies whether to copy only the supply grid or all initial data and the supply grid to the new cellview.  Environment variable: <u>supply_saveRoutingOnly</u>

## Route

The following table describes the fields available on the *Route* tab of the Routing assistant for standard cell routing type.

Field	Description
<b>Scope</b>	Defines the scope of signal routing.
<i>Nets</i>	Specifies whether you want to route all nets, selected nets, or nets with opens or shorts.  Environment variable: <u>route_nets</u>
<i>Include Supply Nets</i>	Specifies whether to route power and ground ( <code>tieHi</code> and <code>tieLo</code> ) nets.  Environment variable: <u>route_supplyNets</u>
<i>Within</i>	Specifies whether to route everything inside the PR boundary or area.  Environment variable: <u>route_netsWithin</u>
<b>Options</b>	Lets you specify the options for signal routing.
<i>Update pins</i>	Controls whether the placement and snapping of IO pins will be done in Innovus.  Environment variable: <u>route_updatePins</u>

# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Snap to closest same edge track</i>	Snaps the IO pin to the closest track on the same layer and same edge. Environment variable: <a href="#">route_updatePinOption</a>
<i>Snap to any edge</i>	Snaps the IO pin to snap to any edge on any layer within the specified layer range. Environment variable: <a href="#">route_updatePinOption</a>
<i>Allowed layer range</i>	Specifies the layer range on which to snap the IO pin to any edge.
<i>Create routing as a group</i>	Specifies whether or not to create routing as a figGroup. Environment variable: <a href="#">route_createRoutingAsAGroup</a>
<i>Fix post-route DRC errors</i>	Resolves existing shorts and spacing violations by removing violating routes and repairing connectivity on the target nets. Environment variable: <a href="#">route_fixPostRouteDRCErrors</a>
<b>Update</b>	Lets you select the signal routing options to be deleted.
<i>Delete Wires and vias</i>	Deletes the wires, vias, and shield lines created by the router. Environment variable: <a href="#">route_deleteWiresAndVias</a>
<i>Delete Manual routing</i>	Deletes the pre-routed wires and vias that are created manually. Environment variable: <a href="#">route_deletePreroutes</a>
<b>Output</b>	
<i>Display log</i>	Controls the display of the Innovus routing log when signal routing is run. Environment variable: <a href="#">route_displayLog</a>
<i>Overview last log</i>	Specifies whether to overwrite the last log or keep the existing one. When the option is selected, the existing log is overwritten. Environment variable: <a href="#">route_createRoutingAsAGroup</a>
<i>Current cellview</i>	Write the output of the supply routing to the current cellview. Environment variable: <a href="#">route_routedLOC</a> , <a href="#">route_defaultRoutedView</a>
<i>Other cellview</i>	Lets you specify a view name to write the output of the signal routing to another cellview. Environment variable: <a href="#">route_routedLOC</a> , <a href="#">route_defaultRoutedView</a>






# Virtuoso Automated Standard Cell Placement and Routing Flow Guide

## Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Save routing only</i>	Specifies whether or not to save standard cell routing settings. Environment variable: <code>route_saveRoutingOnly</code>

## Results

The following table describes the fields available on the *Results* tab of the Routing assistant for standard cell routing type.

Field	Description
<b>Scope</b>	Defines the scope of the routing results.
<i>Nets</i>	Specifies whether you want to show the routing result of all nets, selected nets, or only nets with opens. Environment variable: <code>results_nets</code>
<i>Include supply Nets</i>	Shows the routing result of power and ground nets. Environment variable: <code>results_supplyNets</code>
<i>Within</i>	Shows the routing result of nets inside the PR boundary or within an area. When the option is selected as <i>Area</i> , the available icons are: <ul style="list-style-type: none"> <li>■ <i>Set area bbox to visible area</i> : Sets the visible area of the design canvas as the region.</li> <li>■ <i>Draw the area bbox</i> : Lets you draw the region on the design canvas.</li> </ul> <p>Use <i>show/hide the area bbox</i>  to display or hide the highlight around the region.</p> <p>Environment variable: <code>results_netsWithin</code></p>
<b>Summary of latest run</b>	Displays the summary of the routing results for various parameters, such as <i>Time</i> , <i>Instances</i> , <i>Nets</i> , <i>DRCs</i> , <i>Opens</i> , <i>Shorts</i> , <i>Wire Length</i> , <i>Vias</i> .
<b>Output</b>	Specifies the output columns to be displayed in the Routing Results Browser









## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>Select</i>	Lets you select either all or none parameters for which output should be displayed. The parameters are: <i>Rule Violations, Symmetry Violations, Matched Length Violations, Shield Violations, Opens, Shorts, DRCs, Wirelength, Vias, Ratio, Pin count, Manhattan X, and Manhattan Y.</i>

## Routing Assistant Command Buttons

The following table lists the functions of the different command buttons on the Routing assistant:

Icon	Command	Description
	<i>Snap pins to WSPs</i>	Snaps IO pins to width spacing patterns.
	<i>Show WSP Manager</i>	Displays WSP Manager.
	<i>Import WSPs</i>	Imports width spacing patterns to the current cellview.
	<i>Auto-generate WSPs</i>	Generates width spacing patterns automatically on the selected layers.
	<i>Run pre-route checks</i>	Runs pre-routing checks and saves the result to a log file.
	<i>Run power route</i>	Runs power routing.
	<i>Run signal router</i>	Runs signal routing.
	<i>Show results browser</i>	Displays the Virtuoso Routing Results Browser.

## Related Topics

[Map WSP Wire Types to Symbols Form](#)

[Assign Wire Types to Nets Form](#)

[Pull Back and Offset Values Form](#)

[Routing Assistant](#)

[Accessing the Routing Assistant](#)

[Virtuoso Routing Results Browser](#)

[Virtuoso Pre-Route Browser](#)

[Virtuoso Routing Constraint Manager](#)

## Assign Wire Types to Nets Form

The Assign Wire Types to Nets form displays the nets with the power and ground signal type attribute that exists in the design. It also lets you specify on-the-fly net name that does not exist in the design. This form is used to set the sigType and for the supply router to know on which tracks to create stripes for nets.

---

Column	Description
<i>Net</i>	Specifies the net name.
<i>Signal Type</i>	Specifies the signal type. The two default signal types are supply and ground.
<i>Wire Type</i>	Lets you select the wire type. You can assign multiple wireTypes to a net. The wireTypes can be specified as a string of comma delimited names.  When a wireType is not assigned for all the nets in the table, a warning message appears stating that table settings should be considered when wireType is specified for all rows. However, when the wire types are specified for all rows, the warning message no longer appears. In this case, the supply Router considers the Assign Wire Types to Nets table.
+	Adds the net name.
-	Deletes the net name and the related wireTypes information.

---

When *All* option is selected the Routing Assistant, the Assign Wire Types to Nets form displays all the Nets from the Navigator assistant. However, when the *Selected* option is enabled, the intersection of nets in the Assign Wire Types to Nets form and the nets selected in the Navigator assistant are displayed. For example, all the nets mentioned below are power and ground signal nets.

- Assign Wire Types to Nets table nets: A, B, C, D, E, X, and Y
- All Nets in Navigator: A, B, C, D, and E
- Selected Nets in Navigator: C, D, and E

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

In this case, the nets that will be displayed in the Assign Wire Types to Nets form are mentioned in the table below.

Example	Net scope is <i>All</i>	Net Scope is <i>Selected</i>
Assign Wire Types to Nets table is setup well	A, B, C, D, and E	C, D, and E

### ***Related Topics***

[Map WSP Wire Types to Symbols Form](#)

[Assigning Wire Types to Nets](#)

[Automated Standard Cell Placement and Routing User Interface](#)

[Routing Assistant User Interface for Standard Cell](#)

## **Boundary Cells Form**

The following table describes the fields available in the Boundary Cells form.

---

Field	Description
<i>Alignment</i>	Lets you specify the position of the rail in a placement area. The table at the bottom of the form lets you view the alignment of the selected boundary cells.
<i>Show selected only</i>	Clears the filter field and only shows selected cells.
<i>Clear selected button</i>	Deselects all cells.
<i>Choose Library</i>	Opens the Library Browser from which you can select the library that contains the required cells. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.
<i>Cells</i>	<p>Lists cells that have their component class set to <code>BOUNDARYCELL</code>. You can select the required boundary cells from the list.</p> <p>If by default no boundary cells are listed, click <i>Choose Library</i> and select a library from the Library Browser. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.</p>

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

Field	Description
<i>Alignment table</i>	Mentions a number against each position of the rail in a placement area.

---

#### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Auto P&R Assistant User Interface for Standard Cell](#)

## Choose Source Layout Cellview Form

Use the Choose Source Layout Cellview form to select the library, cell, and view names to be used as a source layout.

---

Field	Description
<i>Library</i>	Specifies the library name for the source layout.
<i>Cell</i>	Specifies the cell name for the source layout.
<i>View</i>	Specifies the view name for the source layout.

---

#### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Routing Assistant User Interface for Standard Cell](#)

[Auto P&R Assistant User Interface for Standard Cell](#)

## Filler Cells Form

The following table describes the fields available in the *Filler Cells* form.

---

Field	Description
<i>Show selected only</i>	Clears the filter field and only shows selected cells.
<i>Clear selected</i>	Deselects all cells.

---

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

Field	Description
<i>Choose Library</i>	Opens the Library Browser from which you can select the library that contains the required cells. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.
<i>Cells</i>	<p>Lists cells that have their component class set to <code>FILLER</code>. You can select the required filler cells from the list.</p> <p>If by default no filler cells are listed, click <i>Choose Library</i> and select a library from the Library Browser. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.</p>

---

#### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Auto P&R Assistant User Interface for Standard Cell](#)

## Load Option Presets Form

The following table describes the fields available in the Load Option Presets form.

Field	Description
<i>Select a preset for stdCell placer type</i>	Lists all the available preset files that define standard cell placement settings. You can select the required preset file and apply the settings to the current design.

---

#### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

## Map WSP Wire Types to Symbols Form

Use the Map WSP Wire Types to Symbols form is used to create WSPs.

The four default symbols in the pattern (`p: power`, `g: ground`, `s: signal`, `n: none`) correspond to built-in wire types. These symbols are permanent and cannot be changed. However, you can add more with a different symbol to use in your patterns and the wireTypes. The symbols that you specify becomes the wireTypes in the WSP. For example, you can specify wire type `vdd` with a symbol `a` and `vss` with a symbol `b`. You can then use `a` and `b` in the table to represent wireTypes `vdd` and `vss`, respectively, in the *Pattern* column of the *Setup* tab.

---

Column	Description
<i>Wire Type</i>	Displays the wire type.
<i>Symbol</i>	Displays the symbol assigned to represent the wireType.

---

### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Assign Wire Types to Nets Form](#)

[Routing Assistant User Interface for Standard Cell](#)

## Pull Back and Offset Values Form

Use the Pull Back and Offset Values form to specify the distance the stripes should be pulled inward from the PR boundary on the ends and which strips should not be created on the other two sides. This helps to avoid shorts or DRC spacing errors if the blocks are abutted. The pull back value can be different for each layer and each side, depending on the routing layer direction.

---

Column	Description
<i>Load</i>	Lets you select the pull back file to be loaded from the Open Pullback File dialog box. The pull back values are loaded from the text file.
<i>Clear</i>	Clears the information of the loaded pull back file.
<i>Layer</i>	Displays the layer name.

---

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

---

Column	Description
<i>Direction</i>	Displays the routing direction of the layer.
<i>Left/Bottom/Right/Top</i>	Lets you specify the pull back value for each side of the routing direction. This value is read as per the direction. If a single value is provided, it is applicable for both sides.

---

#### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Routing Assistant User Interface for Standard Cell](#)

## Save Option Presets Form

The following table describes the fields available in the Save Option Presets form.

---

Field	Description
<i>Select an existing preset name (overwrite) or enter a new name</i>	Specifies the name of the preset file in which the current placement options are to be saved. If you can specify a new name to create a new preset file or an existing file name to overwrite the existing preset file.
<i>Select path</i>	Specifies the path in which the preset file is to be saved.

---

#### ***Related Topics***

[Auto P&R Assistant User Interface for Standard Cell](#)

## Select Row Template Form

The following table describes the fields available in the Select Row Template form.

---

Field	Description
<i>Library</i>	Specifies the library name for the row template.
<i>Cell</i>	Specifies the cell name for the row template.



## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

Field	Description
<i>View</i>	Specifies the view name for the row template.
<i>Select Row Template</i>	Lists the existing row templates.
<i>Details</i>	Provides the property details of the selected row template.

### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Auto P&R Assistant User Interface for Standard Cell](#)

## Tap Cells Form

The following table describes the fields available in the Tap Cells form.

Field	Description
<i>Show selected only</i>	Clears all filters field shows only selected cells.
<i>Clear selected</i>	Deselects all cells.
<i>Choose Library</i>	Opens the Library Browser from which you can select the library that contains the required cells. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.
<i>Cells</i>	<p>Lists cells that have their component class set to <code>STDSUBCONT</code>. You can select the required tap cells from the list.</p> <p>If, by default, no tap cells are listed, click <i>Choose Library</i> and select a library from the Library Browser. A list of layout and abstract views in the selected library are displayed in the <i>Cells</i> pane.</p>
<i>Tap to Tap spacing</i>	Lets you specify the tap-to-tap spacing for tap cells. This value comes from the Design Rule Manual (DRM).
<i>Pattern</i>	Lets you select a pattern to place the tap cells. The options are: <i>Regular</i> and <i>Checkerboard</i> .
<i>Skip Row Count</i>	Specifies the rows that must be skipped during tap cell placement.
<i>Start Row Number</i>	Specifies the row number to place the tap cells.

## Virtuoso Automated Standard Cell Placement and Routing Flow Guide

### Automated Standard Cell Placement and Routing User Interface

---

Field	Description
<i>Offset from Row Start</i>	Specifies the initial offset of the first tap cell in each row.
<i>Avoid Abutment</i>	Specifies whether the tap cells must not be abutted vertically.
<i>Well Pitch</i>	Specifies the minimum spacing between individual components placed in the placement area.
<i>Well Offset</i>	Defines an offset from the specified alignment. This lets you leave a channel around the edge of the placement area, or align the rail slightly off-center. Both positive and negative offset values are honored.

---

#### ***Related Topics***

[Automated Standard Cell Placement and Routing User Interface](#)

[Auto P&R Assistant User Interface for Standard Cell](#)