

# **Design Data Translators SKILL Reference**

**Product Version ICADVM20.1**

**October 2020**

© 2020 Cadence Design Systems, Inc. All rights reserved.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

**Trademarks:** Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

The publication may be used only in accordance with a written agreement between Cadence and its customer.

The publication may not be modified in any way.

Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.

The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

---

# Contents

---

|                                                         |    |
|---------------------------------------------------------|----|
| <u>Preface</u>                                          | 9  |
| <u>Scope</u>                                            | 10 |
| <u>Licensing Requirements</u>                           | 10 |
| <u>Related Documentation</u>                            | 10 |
| <u>What's New and KPNS</u>                              | 11 |
| <u>Installation, Environment, and Infrastructure</u>    | 11 |
| <u>Technology Information</u>                           | 11 |
| <u>Virtuoso Tools</u>                                   | 11 |
| <u>Relative Object Design and Inherited Connections</u> | 13 |
| <u>SKILL Documents</u>                                  | 13 |
| <u>Additional Learning Resources</u>                    | 13 |
| <u>Video Library</u>                                    | 13 |
| <u>Virtuoso Videos Book</u>                             | 14 |
| <u>Rapid Adoption Kits</u>                              | 14 |
| <u>Help and Support Facilities</u>                      | 14 |
| <u>Customer Support</u>                                 | 15 |
| <u>Feedback about Documentation</u>                     | 15 |
| <u>Understanding Cadence SKILL</u>                      | 16 |
| <u>Using SKILL Code Examples</u>                        | 16 |
| <u>Sample SKILL Code</u>                                | 16 |
| <u>Accessing API Help</u>                               | 17 |
| <u>Typographic and Syntax Conventions</u>               | 18 |
| <u>Identifiers Used to Denote Data Types</u>            | 19 |

## 1

|                                     |    |
|-------------------------------------|----|
| <u>XStream Functions</u>            | 21 |
| <u>Command Line SKILL Functions</u> | 22 |
| <u>poCellNameMap</u>                | 22 |
| <u>poLayerMap</u>                   | 24 |
| <u>textFontMap</u>                  | 25 |
| <u>piCellNameMap</u>                | 27 |

## Design Data Translators SKILL Reference

---

|                             |    |
|-----------------------------|----|
| <u>piLayerMap</u>           | 29 |
| <u>piTextMap</u>            | 30 |
| <u>poTextMap</u>            | 31 |
| <u>poParamCellNameMap</u>   | 32 |
| <u>poPreTranslate</u>       | 33 |
| <u>poPostTranslate</u>      | 34 |
| <u>piPreTranslate</u>       | 35 |
| <u>piPostTranslate</u>      | 36 |
| <u>GUI SKILL Functions</u>  | 38 |
| <u>xstInOnCancel</u>        | 38 |
| <u>xstInOnTranslate</u>     | 39 |
| <u>xstInOnCompletion</u>    | 40 |
| <u>xstOutOnCancel</u>       | 41 |
| <u>xstOutOnTranslate</u>    | 42 |
| <u>xstOutOnCompletion</u>   | 43 |
| <u>xstInGetField</u>        | 44 |
| <u>xstGetField</u>          | 46 |
| <u>xstInSetField</u>        | 47 |
| <u>xstSetField</u>          | 49 |
| <u>xstOutDoTranslate</u>    | 50 |
| <u>xstInDoTranslate</u>     | 51 |
| <u>xstInGetVMLibs</u>       | 52 |
| <u>xstInSaveVMLib</u>       | 53 |
| <u>Callback Functions</u>   | 54 |
| <u>xstInOnCancelCB</u>      | 54 |
| <u>xstInOnCompletionCB</u>  | 56 |
| <u>xstInOnTranslateCB</u>   | 58 |
| <u>xstOutOnCancelCB</u>     | 60 |
| <u>xstOutOnCompletionCB</u> | 62 |
| <u>xstOutOnTranslateCB</u>  | 64 |

## 2

|                                                  |    |
|--------------------------------------------------|----|
| <u>XOasis Functions</u>                          | 67 |
| <u>User-defined SKILL Functions</u>              | 68 |
| <u>User-defined Command Line SKILL Functions</u> | 69 |

## Design Data Translators SKILL Reference

---

|                                         |    |
|-----------------------------------------|----|
| <u>poCellNameMap</u>                    | 69 |
| <u>poLayerMap</u>                       | 69 |
| <u>poTextMap</u>                        | 69 |
| <u>poParamCellNameMap</u>               | 69 |
| <u>poPreTranslate</u>                   | 69 |
| <u>poPostTranslate</u>                  | 69 |
| <u>piCellNameMap</u>                    | 69 |
| <u>piLayerMap</u>                       | 69 |
| <u>piTextMap</u>                        | 70 |
| <u>piPreTranslate</u>                   | 70 |
| <u>piPostTranslate</u>                  | 70 |
| <u>User-defined GUI SKILL Functions</u> | 71 |
| <u>xoasInOnCancel</u>                   | 71 |
| <u>xoasInOnTranslate</u>                | 72 |
| <u>xoasInOnCompletion</u>               | 73 |
| <u>xoasOutOnCancel</u>                  | 74 |
| <u>xoasOutOnTranslate</u>               | 75 |
| <u>xoasOutOnCompletion</u>              | 76 |
| <u>GUI SKILL Functions</u>              | 77 |
| <u>xoasInGetField</u>                   | 77 |
| <u>xoasInSetField</u>                   | 79 |
| <u>xoasInDoTranslate</u>                | 81 |
| <u>xoasOutGetField</u>                  | 82 |
| <u>xoasOutSetField</u>                  | 84 |
| <u>xoasOutDoTranslate</u>               | 86 |
| <u>Callback Functions</u>               | 87 |
| <u>xoasInOnCancelCB</u>                 | 87 |
| <u>xoasInOnCompletionCB</u>             | 89 |
| <u>xoasInOnTranslateCB</u>              | 91 |
| <u>xoasOutOnCancelCB</u>                | 93 |
| <u>xoasOutOnCompletionCB</u>            | 95 |
| <u>xoasOutOnTranslateCB</u>             | 97 |

### 3

|                                      |    |
|--------------------------------------|----|
| <b><u>SpiceIn Function</u></b> ..... | 99 |
| <u>spcinGuiDisplay</u> .....         | 99 |

### 4

|                                             |     |
|---------------------------------------------|-----|
| <b><u>CDL Out Functions</u></b> .....       | 101 |
| <u>auCdIAlwaysAddPrefixInInstName</u> ..... | 101 |
| <u>hnlCDLPrintBJTElement</u> .....          | 103 |
| <u>hnlCDLPrintGeneralElement</u> .....      | 104 |
| <u>hnlCDLPrintICIsrElement</u> .....        | 105 |
| <u>hnlCDLPrintICVsrElement</u> .....        | 106 |
| <u>hnlCDLPrintCds_Thru</u> .....            | 107 |
| <u>hnlCDLPrintInductorElement</u> .....     | 108 |
| <u>hnlCDLPrintIsrElement</u> .....          | 109 |
| <u>hnlCDLPrintJfetElement</u> .....         | 110 |
| <u>hnlCDLPrintNMOSfetElement</u> .....      | 111 |
| <u>hnlCDLPrintNPNElement</u> .....          | 112 |
| <u>hnlCDLPrintPMOSfetElement</u> .....      | 113 |
| <u>hnlCDLPrintPNPElement</u> .....          | 114 |
| <u>hnlCDLPrintResistorElement</u> .....     | 115 |
| <u>hnlCDLPrintSchottkyTranElement</u> ..... | 116 |
| <u>hnlCDLPrintTlineElement</u> .....        | 117 |
| <u>hnlCDLPrintVCIsrElement</u> .....        | 118 |
| <u>hnlCDLPrintVCVsrElement</u> .....        | 119 |
| <u>hnlCDLPrintVsrElement</u> .....          | 120 |
| <u>hnlCDLPrintMultiCNPNElement</u> .....    | 121 |
| <u>hnlCDLPrintMultiCPNPElement</u> .....    | 122 |
| <u>hnlCDLPrintMultiENPNElement</u> .....    | 123 |
| <u>hnlCDLPrintMultiEPNPElement</u> .....    | 124 |
| <u>hnlCDLPrintCapElement</u> .....          | 125 |
| <u>hnlCDLPrintCapacitorElement</u> .....    | 126 |
| <u>hnlCDLPrintDiodeElement</u> .....        | 127 |
| <u>hnlCDLPrintBSIM3SOIElement</u> .....     | 128 |
| <u>hnlCDLPrintResElement</u> .....          | 129 |

## Design Data Translators SKILL Reference

---

|                                     |     |
|-------------------------------------|-----|
| <u>hnlCDLPrintInstPropVal</u> ..... | 130 |
| <u>transCdlOutDisplay</u> .....     | 131 |

### 5

|                                |     |
|--------------------------------|-----|
| <u>LEF/DEF Functions</u> ..... | 133 |
|--------------------------------|-----|

|                                           |     |
|-------------------------------------------|-----|
| <u>ldtrLefReadOA</u> .....                | 133 |
| <u>ldtrLefWriteOA</u> .....               | 139 |
| <u>ldtrDefReadOA</u> .....                | 142 |
| <u>ldtrDefWriteOA</u> .....               | 148 |
| <u>Command Line SKILL Functions</u> ..... | 159 |
| <u>defoutPreTranslate</u> .....           | 159 |
| <u>defoutPostTranslate</u> .....          | 160 |
| <u>definPreTranslate</u> .....            | 161 |
| <u>definPostTranslate</u> .....           | 162 |

## Design Data Translators SKILL Reference

---



---

# Preface

---

The SKILL programming language lets you customize and extend your design environment. SKILL provides a safe, high-level programming environment that automatically handles many traditional system programming operations, such as memory management. SKILL programs can be immediately executed in the Cadence environment.

This information set describes custom layout SKILL functions for layout editor, parameterized cells, compactor, structure compiler, placement and routing translation, layout XL, custom digital placer, and Virtuoso constraint manager. It is aimed at developers and designers of integrated circuits and assumes that you are familiar with:

- The SKILL programming language.
- The Virtuoso design environment and application infrastructure mechanisms designed to support consistent operations between all Cadence tools.
- The applications used to design and develop integrated circuits in the Virtuoso design environment, notably Virtuoso Layout Suite and Virtuoso Schematic Editor.
- The OpenAccess version 2.2 technology file.
- Component description format (CDF), which lets you create and describe your own components for use with Layout XL.

This preface contains the following topics:

- [Scope](#)
- [Licensing Requirements](#)
- [Related Documentation](#)
- [Additional Learning Resources](#)
- [Customer Support](#)
- [Feedback about Documentation](#)
- [Typographic and Syntax Conventions](#)
- [Identifiers Used to Denote Data Types](#)

## Scope

Unless otherwise noted, the functionality described in this guide can be used in both mature node (for example, IC6.18) and advanced node (for example, ICADVM20.1) releases.

| Label             | Meaning                                                                                     |
|-------------------|---------------------------------------------------------------------------------------------|
| (ICADVM20.1 Only) | Features supported only in the ICADVM20.1 advanced node and advanced methodologies release. |
| (IC6.1.8 Only)    | Features supported only in mature node releases.                                            |

## Licensing Requirements

This section describes an overview of how licensing is implemented in physical translators, Stream In, Stream Out, LEF In, LEF Out, DEF In, and DEF Out translators. The licensing scheme is the same for both command line and GUI.

Incase, a license is not available for a translator and you select *File – Import – LEF/DEF/Stream* option from CIW, a form will be displayed without a license. You can specify the values in the form and click the OK button. The translator in this case would perform a validation check for license and try to checkout the license. You will not be able to do the translation if the license is unavailable.

This license "111" is required to run all these physical design translators.

**Note:** These translators work only with the Design Framework II license "111" and with no other product license. Therefore, even if Layout XL or a higher tier license is available, you will not be able to run these translators if license "111" is not available. Also, to be able to run some advanced SKILL APIs that used in `libInit.il` or Pcell SKILL code, you will require functionality based licenses (L/XL/GXL).

For information about licensing in the Virtuoso design environment, see [Virtuoso Software Licensing and Configuration Guide](#).

## Related Documentation

Translators are often used with other Cadence products, or require knowledge of special language such as SKILL, TLF, DEF, and Verilog. The following documents give you more information about these tools and languages.

# Design Data Translators SKILL Reference

## Preface

---

- (IC6.1.8 Only) For more information about CDL syntax, see the LOGLVS chapter of the Dracula Reference. Circuit Description Language (CDL) format is a subset of SPICE format. CDL uses node names as well as node numbers.

## What's New and KPNS

- [\*Design Data Translators What's New\*](#)
- [\*Design Data Translators Known Problems and Solutions\*](#)

## Installation, Environment, and Infrastructure

- [\*Cadence Installation Guide\*](#)
- [\*Virtuoso Design Environment User Guide\*](#)
- [\*Virtuoso Design Environment SKILL Reference\*](#)
- [\*Cadence Application Infrastructure User Guide\*](#)

## Technology Information

- [\*Virtuoso Technology Data User Guide\*](#)
- [\*Virtuoso Technology Data ASCII Files Reference\*](#)
- [\*Virtuoso Technology Data SKILL Reference\*](#)

## Virtuoso Tools

### IC6.1.8 Only

- [\*Virtuoso Layout Suite L User Guide\*](#)
- [\*Virtuoso Layout Suite XL User Guide\*](#)
- [\*Virtuoso Layout Suite GXL Reference\*](#)

### ICADVM20.1 Only

- [\*Virtuoso Layout Viewer User Guide\*](#)
- [\*Virtuoso Layout Suite XL: Basic Editing User Guide\*](#)

## Design Data Translators SKILL Reference

### Preface

---

- [\*Virtuoso Layout Suite XL: Connectivity Driven Editing Guide\*](#)
- [\*Virtuoso Layout Suite EXL Reference\*](#)
- [\*Virtuoso Concurrent Layout User Guide\*](#)
- [\*Virtuoso Design Planner User Guide\*](#)
- [\*Virtuoso Electromagnetic Solver Assistant User Guide\*](#)
- [\*Virtuoso Multi-Patterning Technology User Guide\*](#)
- [\*Virtuoso Placer User Guide\*](#)
- [\*Virtuoso RF Flow Guide\*](#)
- [\*Virtuoso Simulation Driven Interactive Routing User Guide\*](#)
- [\*Virtuoso Width Spacing Patterns User Guide\*](#)

#### IC6.1.8 and ICADVM20.1

- [\*Virtuoso Abstract Generator User Guide\*](#)
- [\*Virtuoso Custom Digital Placer User Guide\*](#)
- [\*Virtuoso Design Rule Driven Editing User Guide\*](#)
- [\*Virtuoso Electrically Aware Design Flow Guide\*](#)
- [\*Virtuoso Floorplanner User Guide\*](#)
- [\*Virtuoso Fluid Guard Ring User Guide\*](#)
- [\*Virtuoso Interactive and Assisted Routing User Guide\*](#)
- [\*Virtuoso Layout Suite SKILL Reference\*](#)
- [\*Virtuoso Module Generator User Guide\*](#)
- [\*Virtuoso Parameterized Cell Reference\*](#)
- [\*Virtuoso Pegasus Interactive User Guide\*](#)
- [\*Virtuoso Space-based Router User Guide\*](#)
- [\*Virtuoso Symbolic Placement of Devices User Guide\*](#)
- [\*Virtuoso Voltage Dependent Rules Flow Guide\*](#)

## Relative Object Design and Inherited Connections

- [\*Virtuoso Relative Object Design User Guide\*](#)
- [\*Virtuoso Schematic Editor User Guide\*](#)

## SKILL Documents

- Design data translators SKILL functions are documented in the following manual:
  - [\*Design Data Translator's SKILL Reference\*](#)
- The SKILL programming language is documented in the following manuals:
  - [\*Virtuoso Design Environment SKILL Reference\*](#)
  - [\*Cadence SKILL Language User Guide\*](#)
  - [\*Cadence SKILL Language Reference\*](#)
  - [\*Cadence SKILL Development Reference\*](#)
  - [\*Cadence SKILL IDE User Guide\*](#)
- SKILL access to other applications is provided in the following manuals:
  - [\*Virtuoso Technology Data SKILL Reference\*](#)
  - [\*Virtuoso Layout Suite SKILL Reference\*](#)
  - [\*Virtuoso Schematic Editor SKILL Functions Reference\*](#)
  - [\*Cadence User Interface SKILL Reference\*](#)
  - [\*Cadence Interprocess Communication SKILL Reference\*](#)

## Additional Learning Resources

### Video Library

The [Video Library](#) on the Cadence Online Support website provides a comprehensive list of videos on various Cadence products.

To view a list of videos related to a specific product, you can use the *Filter Results* feature available in the pane on the left. For example, click the *Virtuoso Layout Suite* product link to view a list of videos available for the product.

You can also save your product preferences in the Product Selection form, which opens when you click the *Edit* icon located next to *My Products*.

## **Virtuoso Videos Book**

You can access certain videos directly from Cadence Help. To learn more about this feature and to access the list of available videos, see [Virtuoso Videos](#).

## **Rapid Adoption Kits**

Cadence provides a number of [Rapid Adoption Kits](#) that demonstrate how to use Virtuoso applications in your design flows. These kits contain design databases and instructions on how to run the design flow.

In addition, Cadence offers the following training courses:

- [Virtuoso Layout Design Basics](#)
- [Virtuoso Layout for Advanced Nodes](#)
- [SKILL Language Programming Introduction](#)
- [SKILL Language Programming](#)
- [Advanced SKILL Language Programming](#)

To explore the full range of training courses provided by Cadence in your region, visit [Cadence Training](#) or write to [training\\_enroll@cadence.com](mailto:training_enroll@cadence.com).

**Note:** The links in this section open in a separate web browser window when clicked in Cadence Help.

## **Help and Support Facilities**

Virtuoso offers several built-in features to let you access help and support directly from the software.

- The Virtuoso *Help* menu provides consistent help system access across Virtuoso tools and applications. The standard Virtuoso *Help* menu lets you access the most useful help and support resources from the Cadence support and corporate websites directly from the CIW or any Virtuoso application.

- The Virtuoso Welcome Page is a self-help launch pad offering access to a host of useful knowledge resources, including quick links to content available within the Virtuoso installation as well as to other popular online content.

The Welcome Page is displayed by default when you open Cadence Help in standalone mode from a Virtuoso installation. You can also access it at any time by selecting *Help – Virtuoso Documentation Library* from any application window, or by clicking the *Home* button on the Cadence Help toolbar (provided you have not set a custom home page).

For more information, see [Getting Help](#) in *Virtuoso Design Environment User Guide*.

## Customer Support

For assistance with Cadence products:

- Contact Cadence Customer Support

Cadence is committed to keeping your design teams productive by providing answers to technical questions and to any queries about the latest software updates and training needs. For more information, visit <https://www.cadence.com/support>.

- Log on to Cadence Online Support

Customers with a maintenance contract with Cadence can obtain the latest information about various tools at <https://support.cadence.com>.

## Feedback about Documentation

You can contact Cadence Customer Support to open a service request if you:

- Find erroneous information in a product manual
- Cannot find in a product manual the information you are looking for
- Face an issue while accessing documentation by using Cadence Help

You can also submit feedback by using the following methods:

- In the Cadence Help window, click the *Feedback* button and follow instructions.
- On the Cadence Online Support [Product Manuals](#) page, select the required product and submit your feedback by using the *Provide Feedback* box.

## Understanding Cadence SKILL

Cadence SKILL is a high-level, interactive programming language based on the popular artificial intelligence language, Lisp. It lets you customize and extend your design environment. Using SKILL you can validate the steps of your algorithm incrementally before incorporating them into a larger program.

For more information about the SKILL language, see [Getting Started](#) in the *SKILL Language User Guide*.

## Using SKILL Code Examples

The SKILL APIs in this user manual are explained with illustrative code examples.

You can copy these examples from the manual and paste them directly into the Command Interpreter Window (CIW) or use the code in non-graphical SKILL mode.

## Sample SKILL Code

The following code sample shows the syntax of a SKILL API that accepts three arguments.

### axlGetRunStatus

```
axlGetRunStatus(  
    t_sessionName      ← Required argument  
    [ ?optionName t_optionName ] ← Optional keyword argument  
    [ ?historyName t_historyName ] ← Optional keyword argument  
)  
=> l_statusValues      ← Return value
```

The first argument `t_sessionName` is a required argument, where `t` signifies the data type of the argument. The second and third arguments `?optionName t_optionName` and `?historyName t_historyName` are optional keyword arguments (identified by a question mark), which are specified in name-value pairs and can be placed in any order during the function call.



## Design Data Translators SKILL Reference


### Preface

---

The return value is the value that the SKILL API returns after evaluating the expression. In this case, it is a list of status values, *l\_statusValues*.

#### Example

```
axlSession=axlGetWindowSession( hiGetCurrentWindow() )
=> "session0"
axlGetRunStatus("session0" ?historyName "Interactive.10" ?optionName "tests")
=> (1 2)
```



Return value

Value of the session name argument

Question mark and argument name before the value of the keyword argument

Question mark and argument name before the value of the keyword argument

## Accessing API Help

Quick reference information for SKILL APIs is available from the CIW and the SKILL API Finder. To access the reference information for a particular SKILL API, do one of the following:

- Type `help <function_name>` in the CIW.
- Type `startFinder ( [ ?funcName t_functionName ] )` in the CIW.
- Start the **SKILL API Finder** from the CIW by choosing *Tools – Finder* or type `cdsFinder` on the UNIX command line.

In the *Search in* field of the displayed Cadence SKILL API Finder window, type the SKILL API name for which you want to display the help information and click *Go*.

The matches for the searched SKILL API appear in the *Results* area.

To view the complete documentation of the searched SKILL API, select the API name in the *Results* area and click the More Info button. The complete documentation of the selected SKILL API appears in a new Cadence Help window.

## Typographic and Syntax Conventions

The following typographic and syntax conventions are used in this manual.

|                           |                                                                                                                                                                                          |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>text</i>               | Indicates names of manuals, menu commands, buttons, and fields.                                                                                                                          |
| text                      | Indicates text that you must type exactly as presented. Typically used to denote command, function, routine, or argument names that must be typed literally.                             |
| <i>z_argument</i>         | Indicates text that you must replace with an appropriate argument value. The prefix (in this example, <i>z_</i> ) indicates the data type the argument can accept and must not be typed. |
|                           | Separates a choice of options.                                                                                                                                                           |
| { }                       | Encloses a list of choices, separated by vertical bars, from which you <b>must</b> choose one.                                                                                           |
| [ ]                       | Encloses an optional argument or a list of choices separated by vertical bars, from which you <b>may</b> choose one.                                                                     |
| [ ?argName <i>t_arg</i> ] | Denotes a <i>key argument</i> . The question mark and argument name must be typed as they appear in the syntax and must be followed by the required value for that argument.             |
| ...                       | Indicates that you can repeat the previous argument.                                                                                                                                     |
|                           | Used with brackets to indicate that you can specify zero or more arguments.                                                                                                              |
|                           | Used without brackets to indicate that you must specify at least one argument.                                                                                                           |
| , ...                     | Indicates that multiple arguments must be separated by commas.                                                                                                                           |
| =>                        | Indicates the values returned by a Cadence® SKILL® language function.                                                                                                                    |
| /                         | Separates the values that can be returned by a Cadence SKILL language function.                                                                                                          |

If a command-line or SKILL expression is too long to fit within the paragraph margins of this document, the remainder of the expression is moved to the next line and indented. In code excerpts, a backslash ( \ ) indicates that the current line continues on to the next line.

## Identifiers Used to Denote Data Types

Data type identifiers are used to indicate the type of value required by an API argument. These data types are denoted by a single letter that is prefixed to the argument label and is separated from the argument by an underscore; for example,  $t$  is the data type in  $t\_viewName$ . Data types and underscores are used only as identifiers; they must not be typed when specifying the argument in a function.

| Prefix | Internal Name         | Data Type                                   |
|--------|-----------------------|---------------------------------------------|
| $a$    | array                 | array                                       |
| $A$    | amsobject             | AMS object                                  |
| $b$    | ddUserType            | DDPI object                                 |
| $B$    | ddCatUserType         | DDPI category object                        |
| $C$    | opfcontext            | OPF context                                 |
| $d$    | dbobject              | Cadence database object (CDBA)              |
| $e$    | envobj                | environment                                 |
| $f$    | flonum                | floating-point number                       |
| $F$    | opffile               | OPF file ID                                 |
| $g$    | general               | any data type                               |
| $G$    | gdmSpecIIUserType     | generic design management (GDM) spec object |
| $h$    | hdbobject             | hierarchical database configuration object  |
| $I$    | dbgenobject           | CDB generator object                        |
| $K$    | mapioobject           | MAPI object                                 |
| $l$    | list                  | linked list                                 |
| $L$    | tc                    | Technology file time stamp                  |
| $m$    | nmplIUserType         | nmplI user type                             |
| $M$    | cdsEvalObject         | cdsEvalObject                               |
| $n$    | number                | integer or floating-point number            |
| $o$    | userType              | user-defined type (other)                   |
| $p$    | port                  | I/O port                                    |
| $q$    | gdmSpecListIIUserType | gdm spec list                               |

## Design Data Translators SKILL Reference

### Preface

---

| Prefix       | Internal Name | Data Type                                                                                |
|--------------|---------------|------------------------------------------------------------------------------------------|
| <i>r</i>     | defstruct     | defstruct                                                                                |
| <i>R</i>     | rodObj        | relative object design (ROD) object                                                      |
| <i>s</i>     | symbol        | symbol                                                                                   |
| <i>S</i>     | stringSymbol  | symbol or character string                                                               |
| <i>t</i>     | string        | character string (text)                                                                  |
| <i>T</i>     | txobject      | transient object                                                                         |
| <i>u</i>     | function      | function object, either the name of a function (symbol) or a lambda function body (list) |
| <i>U</i>     | funobj        | function object                                                                          |
| <i>v</i>     | hdbpath       | hdbpath                                                                                  |
| <i>w</i>     | wtype         | window type                                                                              |
| <i>sw</i>    | swtype        | subtype session window                                                                   |
| <i>dw</i>    | dwtype        | subtype dockable window                                                                  |
| <i>x</i>     | integer       | integer number                                                                           |
| <i>y</i>     | binary        | binary function                                                                          |
| <i>&amp;</i> | pointer       | pointer type                                                                             |

---

For more information, see *Cadence SKILL Language User Guide*.

---

# XStream Functions

---

This section provides syntax, descriptions, and examples for the SKILL functions associated with the XStream translator.

There are two types of SKILL functions in XStream:

- Command Line SKILL Functions
- GUI SKILL Functions
- Callback Functions

## Command Line SKILL Functions

### poCellNameMap

```
poCellNameMap(  
    t_lib  
    t_cell  
    t_view  
)  
=> t_mapName / nil
```

#### Description

Passes the library name, cell name and the view name for each cell in the library to a user-defined procedure.

While translating a cellview, Stream Out first checks for the cell name map file. If a cell name map file is not specified, then Stream Out checks whether the user-defined SKILL file is provided and the `poCellNameMap` function is defined. If the function is defined, it is called and the library name, cell name, and view name are passed to this function. The string value returned by this function is considered as new name for the cellview. For more information, see the [Cell Name Map File](#) section.

#### Arguments

|               |                         |
|---------------|-------------------------|
| <i>t_lib</i>  | OpenAccess library name |
| <i>t_cell</i> | OpenAccess cell name    |
| <i>t_view</i> | OpenAccess view name    |

#### Value Returned

|                  |                                |
|------------------|--------------------------------|
| <i>t_mapName</i> | The translated cell name       |
| <i>nil</i>       | If the cell name is not mapped |

## Design Data Translators SKILL Reference

### XStream Functions

---

#### Example

In this example, the characters "\_po" are added to every cell name. The library and view are ignored.

```
procedure( poCellNameMap( lib cell view )
  prog( ( mapname )
    sprintf( mapName "%s_po" cell)
    return( mapName )
  );prog
);procedure
```

## poLayerMap

```
poLayerMap(  
    t_layerName  
    t_purposeName  
)  
=> l_layerDatatype / nil
```

### Description

This is a user-defined function that passes the layer number and datatype for each layer in the input Stream file, when it is called. Stream Out interprets the output of the procedure in the same way it interprets the OpenAccess name and purpose. However, Stream Out checks for this function only if the layer map file (`-layerMap` option) is not specified. If the layer map file is specified, the `poLayerMap` function is ignored. For more information, see the [Layer Map File](#) section.

### Arguments

|                      |                          |
|----------------------|--------------------------|
| <i>t_layerName</i>   | OpenAccess layer name.   |
| <i>t_purposeName</i> | OpenAccess purpose name. |

### Value Returned

|                        |                                                                                                                                   |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| <i>l_layerDataType</i> | A list containing two integers. The first integer is the translated layer number. The second integer is the translated data type. |
| <i>nil</i>             | If no mapping is provided.                                                                                                        |

### Example

In this example, the "text drawing" layer-purpose pair is mapped to GDSII layer 15 and data type 0. The "diff drawing" layer-purpose pair is mapped to layer 18 and data type 0.

```
procedure( poLayerMap( layerName layerPurpose )  
    prog( ( lay )  
        case( layerName  
            ( "text"          return( list( 15 0 ) ) )  
            ( "diff"         return( list( 18 0 ) ) )  
            ( "substrate"     return( list( 20 0 ) ) )  
            ( t               return( list( 55 0 ) ) );default  
        );case  
    );prog  
);procedure
```



## textFontMap

```
textFontMap(  
    t_fontName  
)  
=> l_streamFont / nil
```

### Description

Passes each font type in a Design Framework II library to a user-defined procedure.

While translating the OpenAccess label, Stream Out checks whether the font is mapped through text font map file. If the text font map file is not provided or the font is not mapped through the text font map file, then Stream Out checks for the `textFontMap` SKILL function. If the function is defined, then Stream Out calls this function and OpenAccess font name as the argument.

Valid Stream font numbers are 0, 1, 2, and 3. The OpenAccess font names are `Unknown`, `EuroStyle`, `Gothic`, `Math`, `Roman`, `Script`, `Stick`, `Fixed`, `Swedish`, and `MilSpec`. For more information, see the [Text Font Map File](#) section.

### Arguments

|                         |                           |
|-------------------------|---------------------------|
| <code>t_fontName</code> | The OpenAccess font name. |
|-------------------------|---------------------------|

### Value Returned

|                           |                     |
|---------------------------|---------------------|
| <code>l_streamFont</code> | Stream font number. |
| <code>nil</code>          | Font not mapped.    |

### Example

In this example, the DFII fonts `Gothic`, `Roman`, and `Script` are mapped to Stream fonts 3, 1, and 2. All others are mapped to the Stream font 0.

```
procedure( textFontMap( font )  
    prog( ()  
        case( font  
            ( "Gothic"      return( 3 ) )  
            ( "Roman"      return( 1 ) )  
            ( "Script"     return( 2 ) )  
            ( t             return( 0 ) )  
        );case  
    )
```

## Design Data Translators SKILL Reference

### XStream Functions

---

```
);prog  
);procedure
```

## piCellNameMap

```
piCellNameMap(  
    t_cell  
)  
=> l_cellview / nil
```

### Description

Passes the cell name for each cell name in the input file to a user-defined procedure.

Stream In interprets the output of the procedure in the same way as it interprets the output of the same procedure in the OpenAccess library, cell, and view names. For more information, see the [Cell Name Map File](#) section.

### Arguments

|               |                      |
|---------------|----------------------|
| <i>t_cell</i> | The input cell name. |
|---------------|----------------------|

### Value Returned

|                   |                                                                 |
|-------------------|-----------------------------------------------------------------|
| <i>l_cellview</i> | A list containing the OpenAccess library, cell, and view names. |
| <i>nil</i>        | No cell and view names are found.                               |

### Example

In this example, the characters "\_pi" are added to every cell name and `reflib1` and `layout` is returned as library name and view name.

```
procedure( piCellNameMap( cell )  
    prog( ( mapname )  
        sprintf( mapname "%s_pi" cell )  
        return( list( "reflib1" mapname "layout" ) )  
    );prog  
);procedure  
  
procedure( piCellNameMap( cell )  
    prog( ( mapname )  
        sprintf( mapname "%s_pi" cell )  
        return( list( "XST_TARGET_LIB" mapname "layout" ) )  
    );prog  
);procedure
```

**Note:** Here, the `XST_TARGET_LIB` name will be replaced with the library name specified using the `-lib` option.

## Design Data Translators SKILL Reference

### XStream Functions

---

In this example, the special character / in a cell name is replaced with \_.

```
procedure( piCellNameMap( cell )
    prog( ( mapname )
        cellName=sprintf( nil "%s" cell )
        rexCompile("/")
        mapname=rexReplace( cellName "_" 0)
        println( mapname)
    return( list( "myLib" mapname "layout" ) )
    );prog
);procedure
```

## piLayerMap

```
piLayerMap(  
    x_layer  
    x_dataType  
)  
=> l_lpp / nil
```

### Description

This is a user-defined function that passes the layer number and datatype for each layer in the input Stream file, when it is called. Stream In interprets the output of the procedure in the same way it interprets the OpenAccess name and purpose. However, Stream In checks for this function only if the layer map file (`-layerMap` option) is not specified. If the layer map file is specified, the `piLayerMap` function is ignored. For more information, see the [Layer Map File](#) section.

### Arguments

|                         |                        |
|-------------------------|------------------------|
| <code>x_layer</code>    | Input layer number.    |
| <code>x_dataType</code> | Input datatype number. |

### Value Returned

|                    |                                                                                                                    |
|--------------------|--------------------------------------------------------------------------------------------------------------------|
| <code>l_lpp</code> | A list containing two strings. The first string is the dfl layer name. The second string is the dfl layer purpose. |
| <code>nil</code>   | No layer or datatype numbers are found.                                                                            |

### Example

In this example, the input layers 1 to 10 are mapped to the Design Framework II layer-purpose pair text drawing.

```
procedure( piLayerMap( layer datatype )  
    prog( ( lay )  
        lay=layer  
        if( lay >= 1 && lay <= 10 then
```

## piTextMap

```
piTextMap(  
    t_label  
)  
=> t_changedLabel
```

### Description

Modifies the text that is translated from the Stream file to a dfl library.

During Stream In, if you specify a SKILL file having `piTextMap` defined in it, then this function is called for each text object and the text string is passed as an argument to this function. The string returned by this function is used to modify the text in the target dfl library.

### Arguments

|                |                      |
|----------------|----------------------|
| <i>t_label</i> | Text to be modified. |
|----------------|----------------------|

### Value Returned

|                       |                |
|-----------------------|----------------|
| <i>t_changedLabel</i> | Modified text. |
|-----------------------|----------------|

### Example

During Stream In, you can replace the character [ with < and character ] with > by using the `piTextmap` function.

```
procedure( piTextMap( label )  
    prog( ( newLabel )  
        rexCompile( "\\[" )  
        newLabel = rexReplace( label "<" 1 )  
        rexCompile( "\\]" )  
        newLabel = rexReplace( newLabel ">" 1 )  
        return( newLabel )  
    );prog  
);procedure
```

## poTextMap

```
poTextMap (  
    t_label  
)  
=> t_changedLabel
```

### Description

Modifies the text that is translated from the dfl library to the Stream file.

During Stream Out, if you specify a SKILLfile having `poTextMap` defined in it, then this function is called for all text objects and the text string is passed as an argument to this function.

The string returned by this function is used to create the text object in the Stream file. It is applicable to all the strings present in the dfl library and being translated as text in the Stream file as labels. The string is also applicable to the text translated corresponding to pins when you use the *Convert Pin to* option to translate pins as texts.

### Arguments

|                      |                      |
|----------------------|----------------------|
| <code>t_label</code> | Text to be modified. |
|----------------------|----------------------|

### Value Returned

|                             |                |
|-----------------------------|----------------|
| <code>t_changedLabel</code> | Modified text. |
|-----------------------------|----------------|

### Example

During Stream In, you can replace the character [ with < and character ] with > by using the `poTextmap` function.

## poParamCellNameMap

```
poParamCellNameMap (
    t_name
    d_cvid
)
=> t_mapName
```

### Description

This is a user-defined function that is called with the parameterized cell name (super-master name) and sub-master cellView identifier. Stream Out interprets the output of the procedure in the same way as it interprets the translated name for the parameterized cell.

### Arguments

|               |                                                                                                  |
|---------------|--------------------------------------------------------------------------------------------------|
| <i>t_name</i> | The Virtuoso Design Environment parameterized cell name (super-master name) defined by the user. |
| <i>d_cvid</i> | The Virtuoso Design Environment parameterized cell variant (sub-master) cellview identifier.     |

### Value Returned

|                  |                                                |
|------------------|------------------------------------------------|
| <i>t_mapName</i> | The name of the translated parameterized cell. |
|------------------|------------------------------------------------|

### Example

In this example, the translator appends the cellview identifier to every parameterized cell name, making the cell name unique.

```
procedure( poParamCellNameMap( name ID )
    sprintf( nil "%s_%L" name ID )
);procedure
```



## poPreTranslate

```
poPreTranslate(  
    lib  
    cell  
    view  
)
```

### Description

During StreamOut, this function is called just before the translation starts.

### Arguments

|             |                                                                              |
|-------------|------------------------------------------------------------------------------|
| <i>lib</i>  | Contains the input library specified by the user.                            |
| <i>cell</i> | Contains the topCell specified by the user or empty string if not specified. |
| <i>view</i> | Contains the view specified by the user or empty string if not specified.    |

### Value Returned

None

### Example

In this example, the function will print the values of *lib*, *cell*, and *view*.

```
procedure( poPreTranslate( lib cell view )  
    prog( ( )  
        printf("In PreTranslate of Stream Out\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```

## poPostTranslate

```
poPostTranslate(  
    lib  
    cell  
    view  
)
```

### Description

During StreamOut, this function is called just after the translation is completed.

### Arguments

|             |                                                                              |
|-------------|------------------------------------------------------------------------------|
| <i>lib</i>  | Contains all libraries created by StreamIn, separated by space.              |
| <i>cell</i> | Contains the topCell specified by the user or empty string if not specified. |
| <i>view</i> | Contains the view specified by the user or empty string if not specified.    |

### Value Returned

None

### Example

In this example, the function will print the values of *lib*, *cell*, and *view*.

```
procedure( poPostTranslate( lib cell view )  
    prog( ( )  
        printf("In PostTranslate of Stream Out\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```

## piPreTranslate

```
piPreTranslate(  
    lib  
    cell  
    view  
)
```

### Description

During StreamIn, this function is called just before the translation starts.

### Arguments

|             |                                                                              |
|-------------|------------------------------------------------------------------------------|
| <i>lib</i>  | Contains the destination library specified by the user.                      |
| <i>cell</i> | Contains the topCell specified by the user or empty string if not specified. |
| <i>view</i> | Contains the view specified by the user or empty string if not specified.    |

### Value Returned

None

### Example

In this example, the function will print the values of *lib*, *cell*, and *view*.

```
procedure( piPreTranslate( lib cell view )  
    prog( ( )  
        printf("In PreTranslate of Stream In\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```

## piPostTranslate

```
piPostTranslate(  
    lib  
    cell  
    view  
)
```

### Description

During XStream In translation, this function is called just after the translation is completed. If the `-topCell` option is not specified, `piPostTranslate` is called with all the top cells found during Xstream In translation as a string of space separated names.

### Arguments

|             |                                                                                                                                 |
|-------------|---------------------------------------------------------------------------------------------------------------------------------|
| <i>lib</i>  | Contains all the libraries created by StreamIn, separated by space.                                                             |
| <i>cell</i> | Contains the top cell specified by the user or a string of top cells identified by the Xstream In translator, if not specified. |
| <i>view</i> | Contains the view specified by the user or empty string if not specified.                                                       |

### Value Returned

None

### Examples

#### **Example 1**

In this example, the function will print the values of `lib`, `cell`, and `view`.

```
procedure( piPostTranslate( lib cell view )  
    prog( ( )  
        printf("In PostTranslate of Stream In\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```

## Design Data Translators SKILL Reference

### XStream Functions

---

#### **Example 2**

```
procedure(piPostTranslate(lib cell view)
  let((c sumFile logFile)
    if(listp(cell) == nil then
      printf("\n piPostTranslate is called with topcell = (%s)\n" cell)
    else
      printf("\n piPostTranslate is called with topcell list = (")
      foreach( c cell
        printf(" %s" c)
      )
      printf(")\n")
    )))
```

#### **Output:**

```
piPostTranslate is called with topcell = (topCell11 topCell12 topCell13)
```

## GUI SKILL Functions

### **xstInOnCancel**

`xstInOnCancel()`

#### **Description**

This is a user-defined function, which is called when user presses the *Cancel* button.

#### **Arguments**

None

#### **Value Returned**

None

#### **Example**

```
procedure( xstInOnCancel()  
    sprintf("Translation canceled")  
);procedure
```

## **xstInOnTranslate**

`xstInOnTranslate()`

### **Description**

This is a user-defined function, which is called when user presses the *Apply* or *Translate* button.

### **Arguments**

None

### **Value Returned**

None

### **Example**

```
procedure( xstInOnTranslate()  
    sprintf("Starting Translation")  
);procedure
```

## **xstInOnCompletion**

`xstInOnCompletion(x_num)`

### **Description**

This is a user-defined function, which is called when the translation is completed.

### **Arguments**

|                    |                                                                                                                                                                         |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>x_num</code> | It is an integer parameter. If the translation is completed without any error, this value is zero. However, if error occurs during translation, this value is non-zero. |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### **Value Returned**

None

### **Example**

```
procedure( xstInOnCompletion( status )  
  
    fprintf(outPort "In xstInOnCompletion of XStream In GUI: %d\n" status)  
    if( status == 0 then  
        fprintf(outPort "Successfully completed\n" status)  
    else  
        fprintf(outPort "Error occurred during translation\n" status)  
    );if  
  
)
```

In this example, if the function is called with status value 0, it means that translation has completed successfully. However, if the function is called with a non-zero status value, it means that error occurred during translation.



## **xstOutOnCancel**

`xstOutOnCancel()`

### **Description**

This is a user-defined function, which is called when user presses the *Cancel* button.

### **Arguments**

None

### **Value Returned**

None

### **Example**

```
procedure ( xstOutOnCancel()
            sprintf("Translation canceled")
);procedure
```

## **xstOutOnTranslate**

`xstOutOnTranslate()`

### **Description**

This is a user-defined function, which is called when user presses the *Apply* or *Translate* button.

### **Arguments**

None

### **Value Returned**

None

### **Example**

```
procedure( xstOutOnTranslate()  
    sprintf("Starting Translation")  
);procedure
```

## **xstOutOnCompletion**

`xstOutOnCompletion(x_num)`

### **Description**

This is a user-defined function, which is called when the translation is completed.

### **Arguments**

|                    |                                                                                                                                                                         |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>x_num</code> | It is an integer parameter. If the translation is completed without any error, this value is zero. However, if error occurs during translation, this value is non-zero. |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### **Value Returned**

None

### **Example**

```
procedure( xstOutOnCompletion( status )  
  
    fprintf(outPort "In xstOutOnCompletion of XStream Out GUI: %d\n"  
        status)  
    if( status == 0 then  
        fprintf(outPort "Successfully completed\n" status)  
    else  
        fprintf(outPort "Error occurred during translation\n" status)  
    );if  
  
)
```

In this example, if the function is called with status value 0, translation is completed successfully. However, if the function is called with a non-zero status value, it implies that error occurred during translation.

## xstInGetField

```
xstInGetField(  
    t_optionName  
)  
=> t_value / nil
```

### Description

Enables you to access GUI field values from the *XStream In* form. You can access all the GUI field values using the appropriate option name.

### Arguments

|                     |                                                                                                                                                                                                                                                                                                                                        |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be accessed from the <i>XStream In</i> form. Valid values are the command line option name of the <i>XStream In</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <u><a href="#">XStream In GUI and Template File Options</a></u> . |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### Value Returned

|                  |                                                                                  |
|------------------|----------------------------------------------------------------------------------|
| <i>t_value</i>   | The value returned from the <i>XStream In</i> form.                              |
| <code>nil</code> | The field name specified in the <code>t_optionName</code> argument is incorrect. |

### Example

Using SKILL commands, you can access the values specified in various fields, such as text box, check box, radio button, drop-down menu, and mapping tables, of the *XStream In* form. A few examples are given below:

- **Text box:** To access the value specified in the *Stream File* field of the *XStream In* form, enter the following syntax in CIW:

```
xstInGetField("strmFile")  
=> "test.gds"
```

- **Check box:** On the *Geometry* tab, if you want to access the value selected in the *Ignore Box Records* option, then you need to enter the following syntax in CIW:

```
xstInGetField("ignoreBoxes")  
=> "true"
```

## Design Data Translators SKILL Reference

### XStream Functions

---

This field returns a boolean value.

- **Radio Button:** On the *General* tab, if you want to access the value selected in *Label Case Sensitivity* option, then you need to enter the following syntax in CIW:

```
xstInGetField("labelCase")  
=> "upper"
```

- **Drop-down Menu:** On the *General* tab, if you want to access the value selected from the *Text Namespace* drop-down menu, then you need to enter the following syntax in CIW:

```
xstInGetField("strmTextNS")  
=> "verilog"
```

This field returns a string value.

- **Mapping Table:** On the *Layer* tab, if you want to access the table with the layer map entries, then you need to enter the following syntax in CIW:

```
xstInGetField("layerMap")  
=> "l.map"
```

**Note:** Here, the `l.map` file contains the layer mapping entries.

## xstGetField

```
xstGetField(  
    t_optionName  
)  
=> t_value / nil
```

### Description

Enables you to access GUI field values from the *XStream Out* form. You can access all the GUI field values using the appropriate option name.

### Arguments

|                     |                                                                                                                                                                                                                                                                                                                                                   |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be accessed from the <i>XStream Out</i> form. Valid values are the command line option name of the <i>XStream Out</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <u><a href="#">XStream Out Option Names in GUI and Template File</a></u> . |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### Value Returned

|                  |                                                                                  |
|------------------|----------------------------------------------------------------------------------|
| <i>t_value</i>   | The value returned from the <i>XStream Out</i> form.                             |
| <code>nil</code> | The field name specified in the <code>t_optionName</code> argument is incorrect. |

### Example

If you want to access the value in the *Stream File* field in the *XStream Out* form, then you need to enter the following syntax in CIW:

```
xstGetField("strmFile")  
=> "test.gds"
```

If you want to access the value selected in the *Virtual Memory* check box, then you need to enter the following syntax in CIW:

```
xstGetField("virtualMemory")  
  
=> "true"
```

This field returns a boolean value.

## xstInSetField

```
xstInSetField(  
    t_optionName  
    t_value  
)  
=> t / nil
```

### Description

Enables you to populate GUI field values in the *XStream In* form. You can populate all the GUI field values using the appropriate option name and value.

### Arguments

|                     |                                                                                                                                                                                                                                                                                                  |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be populated. Valid values are the command line option name of the <i>XStream In</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <a href="#">XStream In GUI and Template File Options</a> . |
| <i>t_value</i>      | The value by which the field needs to be populated.                                                                                                                                                                                                                                              |

### Value Returned

|            |                                                           |
|------------|-----------------------------------------------------------|
| <i>t</i>   | The value is populated in the <i>XStream In</i> form.     |
| <i>nil</i> | The value is not populated in the <i>XStream In</i> form. |

### Example

Using SKILL commands, you can populate the values in various fields, such as text box, check box, radio button, drop-down menu, and mapping tables, of the *XStream In* form. A few examples are given below:

- **Text box:** If you want to populate the *Stream File* field in the *XStream In* form, then you need to enter the following syntax in CIW:

```
xstInSetField("strmFile" "test.gds")
```

- **Check box:** On the *Geometry* tab, if you want to select the *Ignore Box Records* option, then you need to enter the following syntax in CIW:

```
xstInSetField("ignoreBoxes" "true")
```

This field accepts the boolean value.

## Design Data Translators SKILL Reference

### XStream Functions

---

- **Radio Button:** On the *General* tab, if you want to select the *Label Case Sensitivity* option as *upper*, then you need to enter the following syntax in CIW:

```
xstInSetField("labelCase" "upper")
```

- **Drop-down Menu:** On the *General* tab, if you want to select the *verilog* option from the *Text Namespace* drop-down menu, then you need to enter the following syntax in CIW:

```
xstInSetField("strmTextNS" "verilog")
```

This field accepts the string value.

- **Mapping Table:** On the *Layer* tab, if you want to populate the table with the layer map entries, then you need to enter the following syntax in CIW:

```
xstInSetField("layerMap" "l.map")
```

**Note:** Here, the `l.map` file contains the layer mapping entries.



## **xstSetField**

```
xstSetField(  
    t_optionName  
    t_value  
)  
=> t / nil
```

### **Description**

Enables you to populate GUI field values in the *XStream Out* form. You can populate all the GUI field values using the appropriate option name and value.

### **Arguments**

|                     |                                                                                                                                                                                                                                                                                                                                                 |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be populated in the <i>XStream Out</i> form. Valid values are the command line option name of the <i>XStream In</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <u><a href="#">XStream Out Option Names in GUI and Template File</a></u> . |
| <i>t_value</i>      | The value by which the field needs to be populated.                                                                                                                                                                                                                                                                                             |

### **Value Returned**

|                  |                                                            |
|------------------|------------------------------------------------------------|
| <i>t</i>         | The value is populated in the <i>XStream Out</i> form.     |
| <code>nil</code> | The value is not populated in the <i>XStream Out</i> form. |

### **Example**

If you want to populate the *Stream File* field in the *XStream Out* form, then you need to enter the following syntax in CIW:

```
xstSetField("strmFile" "test.gds")
```

However, there are some special cases where you want to strmout a copy of the design present in virtual memory. To do this, you need to select the Virtual Memory check box by using the following syntax in CIW:

```
xstSetField("virtualMemory" "true")
```

## **xstOutDoTranslate**

`xstOutDoTranslate()`

### **Description**

Issues the StreamOut command based on the GUI field values. By default, this function is a non-blocking function. However, if the Stream Out From Virtual Memory option is selected, then this function becomes a blocking function.

**Note:** Before executing the `xstOutDoTranslate` function, you need to either specify the values for both the Stream File and Library fields or the Cell List File field in the Stream Out form.

### **Argument**

None

### **Value Returned**

nil

### **Example**

In this example, you need to translate library, lib1 to Stream File, out.gds. To do this, you need to execute the following functions:

```
xstSetField("strmFile" "out.gds")
xstSetField("library" "lib1")
xstOutDoTranslate()
```

## **xstInDoTranslate**

`xstInDoTranslate()`

### **Description**

Issues the StreamIn command based on the GUI field values. By default, this function is a non-blocking function. However, if the `Stream In to Virtual Memory` option is selected, then this function becomes a blocking function.

**Note:** Before executing the `xstInDoTranslate` function, you need to specify the value for the `Stream File` and specify the value for either `Library fields` or `Stream Tech File` field in the `Stream In` form.

### **Argument**

None

### **Value Returned**

nil

### **Example**

In this example, you need to translate Stream File, `in.gds` to library, `lib1`. To do this, you need to execute the following functions:

```
xstInSetField("strmFile" "in.gds")
xstInSetField("library" "lib1")
xstInDoTranslate()
```

## **xstInGetVMLibs**

```
xstInGetVMLibs (  
    )  
=> l_vmLibList / nil
```

### **Description**

Returns the list of virtual memory libraries created by XStream In. Only the primary libraries created by XStream In are returned. The additional libraries that are created if the number of cellviews is more than the value specified in the *Maximum Cells in Target Library* field are not returned by this function.

### **Argument**

None

### **Value Returned**

|                          |                                                             |
|--------------------------|-------------------------------------------------------------|
| <code>l_vmLibList</code> | The list of virtual libraries created by XStream In.        |
| <code>nil</code>         | Returns <code>nil</code> if the function is not successful. |

### **Example**

If XStream In is done in virtual memory mode and “vmLib” is the library name, then this library is created in virtual memory. In this case, `xstGetVMLibs()` returns “vmLib”.

```
xstInGetVMLibs (  
=> ("vmLib")
```

## xstInSaveVMLib

```
xstInSaveVMLib(  
    t_vmLibName  
    [ t_path ]  
)  
=> t / nil
```

### Description

Saves the specified virtual memory library, `t_vmLibName`, to either the specified directory, `t_path`, or the current working directory, if `t_path` is not specified. Multiple libraries are created in a single translation using XStream In if the number of cellviews is more than the value specified in the *Maximum Cells in Target Library* field. All the libraries created during a single XStream In translation are also saved.

**Note:** When this function is called, the Virtuoso session is blocked. All the layout editor windows corresponding to the virtual memory library cellviews are also closed. The design management (DM) preferences are also not obeyed.

### Argument

|                          |                                              |
|--------------------------|----------------------------------------------|
| <code>t_vmLibName</code> | The virtual library created by XStream In.   |
| <code>t_path</code>      | The path where the virtual library is saved. |

### Value Returned

|                  |                                  |
|------------------|----------------------------------|
| <code>t</code>   | The operation is successful.     |
| <code>nil</code> | The operation is not successful. |

### Example

If XStream In is done in virtual memory mode and “vmLib” is the library name, then this library is created in the virtual memory.

Now, `xstSaveVMLib("vmLib" "/home/user")` saves the library, “vmLib” to the directory, “/home/user”. If the operation is successful, this function returns “t”.

```
xstSaveVMLib("vmLib" "/home/user")  
=> t
```

## Callback Functions

### xstInOnCancelCB

```
xstInOnCancelCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

#### Description

Registers or unregisters a user-defined callback function when you click the *Cancel* button on the XStream In form.

#### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

#### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

#### Examples

Register the user-defined callback function `myxstInOnCancel` when the *Cancel* button is clicked on the XStream In form.

## Design Data Translators SKILL Reference

### XStream Functions

---

```
procedure( myxstInOnCancel()
    print("Cancel button clicked")
)
xstInOnCancelCB("r" 'myxstInOnCancel)
```

**or**

```
xstInOnCancelCB("r" "myxstInOnCancel")
```

Unregister the user-defined callback function `myxstInOnCancel` when the *Cancel* button is clicked on the XStream In form.

```
procedure( myxstInOnCancel()
    print("Cancel button clicked")
)
xstInOnCancelCB ("d" 'myxstInOnCancel)
```

**or**

```
xstInOnCancelCB("d" "myxstInOnCancel")
```

## xstInOnCompletionCB

```
xstInOnCompletionCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when the XStream In translation is complete.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxstInOnCompletion` when the XStream In translation is complete.

```
procedure( myxstInOnCompletion()  
    print("Translation completed with status %L")  
)
```



## Design Data Translators SKILL Reference

### XStream Functions

---

```
xstInOnCompletionCB("r" 'myxstInOnCompletion)
```

or

```
xstInOnCompletionCB("r" "myxstInOnCompletion")
```

**Unregister the user-defined callback function `myxstInOnCompletion` when the XStream In translation is complete.**

```
procedure( myxstInOnCompletion()  
    print("Cancel button clicked")  
)  
xstInOnCompletionCB ("d" 'myxstInOnCompletion)
```

or

```
xstInOnCompletionCB("d" "myxstInOnCompletion")
```

## xstInOnTranslateCB

```
xstInOnTranslateCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when you click the *Apply* or *Translate* button on the XStream In form

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxstInOnTranslate` when the XStream In translation is complete.

```
procedure ( myxstInOnTranslate ()  
    print ("Translate button clicked")  
)
```

## Design Data Translators SKILL Reference

### XStream Functions

---

```
xstInOnTranslateCB("r" 'myxstInOnTranslate)
```

or

```
xstInOnTranslateCB("r" "myxstInOnTranslate")
```

Unregister the user-defined callback function `myxstInOnTranslate` when the XStream In translation is complete.

```
procedure( myxstInOnTranslate()  
    print("Translate button clicked")  
)  
xstInOnTranslateCB ("d" 'myxstInOnTranslate)
```

or

```
xstInOnTranslateCB("d" "myxstInOnTranslate")
```

## xstOutOnCancelCB

```
xstOutOnCancelCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when you click the *Cancel* button on the XStream Out form.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxstOutOnCancel` when you click the *Cancel* button on the XStream Out form.

```
procedure( myxstOutOnCancel()  
    print("Cancel button clicked")  
)
```

## Design Data Translators SKILL Reference

### XStream Functions

---

```
xstOutOnCancelCB("r" 'myxstOutOnCancel)
```

or

```
xstOutOnCancelCB("r" "myxstOutOnCancel")
```

Unregister the user-defined callback function `myxstOutOnCancel` when you click the *Cancel* button on the XStream Out form.

```
procedure( myxstInOnTranslate()  
    print("Cancel button clicked")  
)
```

```
xstOutOnCancelCB("d" 'myxstOutOnCancel)
```

or

```
xstOutOnCancelCB("d" "myxstOutOnCancel")
```

## xstOutOnCompletionCB

```
xstOutOnCompletionCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when the XStream Out translation is complete.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

|     |                                                      |
|-----|------------------------------------------------------|
| t   | Function is successfully registered or unregistered. |
| nil | Function is not registered or unregistered.          |

### Examples

Register the user-defined callback function `myxstOutOnCompletion` when the XStream Out translation is complete.

```
procedure ( myxstOutOnCompletion()  
    print("Cancel button clicked")  
)
```

## Design Data Translators SKILL Reference

### XStream Functions

---

```
xstOutOnCompletionCB("r" 'myxstOutOnCompletion)
```

or

```
xstOutOnCompletionCB("r" "myxstOutOnCompletion")
```

**Unregister the user-defined callback function `myxstOutOnCompletion` when the XStream Out translation is complete.**

```
procedure( myxstInOnCompletion()  
    print("Translation completed with status %L")  
)  
xstOutOnCompletionCB ("d" 'myxstOutOnCompletion)
```

or

```
xstOutOnCompletionCB("d" "myxstOutOnCompletion")
```

## **xstOutOnTranslateCB**

```
xstOutOnTranslateCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### **Description**

Registers or unregisters a user-defined callback function when you click the *Apply* or *Translate* button on the XStream Out form

### **Arguments**

|               |                                                                                                                                                                                                                                                                                               |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_mode</i> | Specifies mode to register or unregister the user-defined callback function.<br><br>Valid values: <ul style="list-style-type: none"><li>■ "r"<br/>Registers the user-defined callback function.</li><li>■ "d"<br/>Unregisters an already registered user-defined callback function.</li></ul> |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                           |                                                              |
|---------------------------|--------------------------------------------------------------|
| <i>S_callbackFunction</i> | Name or function symbol of a user-defined callback function. |
|---------------------------|--------------------------------------------------------------|

### **Value Returned**

|     |                                                      |
|-----|------------------------------------------------------|
| t   | Function is successfully registered or unregistered. |
| nil | Function is not registered or unregistered.          |

### **Examples**

Register the user-defined callback function `myxstOutOnTranslate` when the XStream Out translation is complete.

```
procedure( myxstOutOnTranslate()  
    print("Cancel button clicked")  
)
```



## Design Data Translators SKILL Reference

### XStream Functions

---

```
xstOutOnTranslateCB("r" 'myxstOutOnTranslate)
```

or

```
xstOutOnTranslateCB("r" "myxstOutOnTranslate")
```

**Unregister the user-defined callback function `myxstOutOnTranslate` when the XStream Out translation is complete.**

```
procedure( myxstOutOnTranslate()
    print("Cancel button clicked")
)
xstOutOnTranslateCB ("d" 'myxstOutOnTranslate)
```

or

```
xstOutOnTranslateCB("d" "myxstOutOnTranslate")
```

## Design Data Translators SKILL Reference

### XStream Functions

---

---

## XOasis Functions

---

This section provides syntax, descriptions, and examples for the SKILL functions associated with the XOasis translator.

There are two types of SKILL functions in XOasis:

- User-defined SKILL Functions
- GUI SKILL Functions
- Callback Functions

## **User-defined SKILL Functions**

There are two types of user-defined SKILL functions in XOasis:

- User-defined Command Line SKILL Functions
- User-defined GUI SKILL Functions

## **User-defined Command Line SKILL Functions**

### **poCellNameMap**

For information related to this function, see [poCellNameMap](#).

### **poLayerMap**

For information related to this function, see [poLayerMap](#).

### **poTextMap**

For information related to this function, see [poTextMap](#).

### **poParamCellNameMap**

For information related to this function, see [poParamCellNameMap](#).

### **poPreTranslate**

For information related to this function, see [poPreTranslate](#).

### **poPostTranslate**

For information related to this function, see [poPostTranslate](#).

### **piCellNameMap**

For information related to this function, see [piCellNameMap](#).

### **piLayerMap**

For information related to this function, see [piLayerMap](#).

## **piTextMap**

For information related to this function, see [piTextMap](#).

## **piPreTranslate**

For information related to this function, see [piPreTranslate](#).

## **piPostTranslate**

For information related to this function, see [piPostTranslate](#).

## User-defined GUI SKILL Functions

### **xoasInOnCancel**

`xoasInOnCancel()`

#### **Description**

This is a user-defined function, which is called when you press the *Cancel* button.

#### **Value Returned**

None

#### **Example**

```
procedure( xoasInOnCancel()  
    sprintf("Translation canceled")  
);procedure
```

## **xoasInOnTranslate**

`xoasInOnTranslate()`

### **Description**

This is a user-defined function, which is called when you press the *Apply* or *Translate* button.

### **Value Returned**

None

### **Example**

```
procedure( xoasInOnTranslate()  
    sprintf("Starting Translation")  
);procedure
```



## **xoasInOnCompletion**

```
xoasInOnCompletion(  
    t_num  
)  
=> t_num
```

### **Description**

This is a user-defined function, which is called when the translation is completed.

### **Arguments**

|              |                             |
|--------------|-----------------------------|
| <i>t_num</i> | It is an integer parameter. |
|--------------|-----------------------------|

### **Value Returned**

|              |                                                                                                                                                                                         |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_num</i> | Returns an integer value. If the translation is completed with error then it returns a non-zero value. However, if the translation is completed without any error then it returns zero. |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### **Example**

In this example, if the function returns 0, the translation is completed successfully. However, if the function returns any non-zero value, then errors occurred during translation.

```
procedure( xoasInOnCompletion( status )  
    prog( ( )  
        fprintf(outPort "In xoasInOnCompletion of XOasis In GUI: %d\n" status)  
        if( status == 0 then  
            fprintf(outPort "Successfully completed\n" status)  
        else  
            fprintf(outPort "Error occured during translation\n" status)  
        );if  
    );prog  
)
```

## **xoasOutOnCancel**

`xoasOutOnCancel()`

### **Description**

This is a user-defined function, which is called when you press the *Cancel* button.

### **Arguments**

None

### **Value Returned**

None

### **Example**

```
procedure ( xoasOutOnCancel()
            sprintf("Translation canceled")
);procedure
```

## **xoasOutOnTranslate**

`xoasOutOnTranslate()`

### **Description**

This is a user-defined function, which is called when you press the *Apply* or *Translate* button.

### **Arguments**

None

### **Value Returned**

None

### **Example**

```
procedure ( xoasOutOnTranslate ()  
            sprintf("Starting Translation")  
);procedure
```

## **xoasOutOnCompletion**

```
xoasOutOnCompletion(  
    t_num  
)  
=> t_num
```

### **Description**

This is a user-defined function, which is called when the translation is completed.

### **Arguments**

|              |                             |
|--------------|-----------------------------|
| <i>t_num</i> | It is an integer parameter. |
|--------------|-----------------------------|

### **Value Returned**

|              |                                                                                                                                                                                      |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_num</i> | Returns an integer value. If the translation is completed with error then it returns a non-zero value. However, if the translation is completed without any error then it returns 0. |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### **Example**

In this example, if the function returns 0, the translation is completed successfully. However, if the function returns any non-zero value, then the error has occurred during translation.

```
procedure( xoasOutOnCompletion( status )  
    prog( ( )  
        fprintf(outPort "In xoasOutOnCompletion of XOasis Out GUI: %d\n"  
            status)  
        if( status == 0 then  
            fprintf(outPort "Successfully completed\n" status)  
        else  
            fprintf(outPort "Error occurred during translation\n" status)  
        );if  
    );prog  
)
```

## GUI SKILL Functions

### xoasInGetField

```
xoasInGetField(  
    t_optionName  
)  
=> t_value / nil
```

#### Description

Enables you to access GUI field values from the *XOasis In* form. You can access all the GUI field values using the appropriate option name.

#### Arguments

*t\_optionName*

The name of the field that needs to be accessed from the *XOasis In* form.

Valid values are the command line option name of the *XOasis In* form field, `virtualMemory` and `showCompletionMsgBox`. For list of valid values, see [XOasis In Option Names in GUI and Template File](#).

#### Value Returned

*t\_value*

The value returned from the *XOasis In* form

`nil`

If the field name specified in the `t_optionName` argument is incorrect

#### Example

Using SKILL commands, you can access the values specified in various fields, such as text box, check box, radio button, drop-down menu, and mapping tables, of the *XOasis In* form. A few examples are given below:

- **Text box:** If you want to access the value in the *OASIS File* field in the *XOasis In* form, then you need to enter the following syntax in CIW:

```
xoasInGetField("oasisFile")  
=> "test.gds"
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

- **Check box:** On the *Geometry* tab, if you want to access the value selected in the *Ignore Box Records* option, then you need to enter the following syntax in CIW:

```
xoasInGetField("ignoreBoxes")  
=> "true"
```

This field returns a Boolean value.

- **Radio Button:** On the *General* tab, if you want to access the value selected in the *Label Case Sensitivity* option, then you need to enter the following syntax in CIW:

```
xoasInGetField("labelCase")  
=> "upper"
```

- **Mapping Table:** On the *Layer* tab, if you want to access the table with the layer map entries, then you need to enter the following syntax in CIW:

```
xoasInGetField("layerMap")  
=> "l.map"
```

Here, the `l.map` file contains the layer mapping entries.

## xoasInSetField

```
xoasInSetField(  
    t_optionName  
    t_value  
)  
=> t / nil
```

### Description

Enables you to populate GUI field values in the *XOasis In* form. You can populate all the GUI field values using the appropriate option name and value.

### Arguments

|                     |                                                                                                                                                                                                                                                                                                                                        |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be populated in <i>XOasis In</i> form.<br><br>Valid values are the command line option name of the <i>XOasis In</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <a href="#">XOasis In Option Names in GUI and Template File</a> . |
| <i>t_value</i>      | The value by which the field needs to be populated.                                                                                                                                                                                                                                                                                    |

### Value Returned

|            |                                                            |
|------------|------------------------------------------------------------|
| <i>t</i>   | The value is populated in the <i>XOasis In</i> form        |
| <i>nil</i> | If the value is not populated in the <i>XOasis In</i> form |

### Example

Using SKILL commands, you can populate the values in various fields, such as text box, check box, radio button, drop-down menu, and mapping tables, of the *XOasis In* form. A few examples are given below:

- **Text box:** If you want to populate the *OASIS File* field in the *XOasis In* form, then you need to enter the following syntax in CIW:  

```
xoasInSetField("oasisFile" "test.gds")
```
- **Check box:** On the *Geometry* tab, if you want to select the *Ignore Box Records* option, then you need to enter the following syntax in CIW:

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasInSetField("ignoreBoxes" "true")
```

This field accepts the Boolean value.

- **Radio Button:** On the *General* tab, if you want to select the *Label Case Sensitivity* option as *upper*, then you need to enter the following syntax in CIW:

```
xoasInSetField("labelCase" "upper")
```

- **Mapping Table:** On the *Layer* tab, if you want to populate the table with the layer map entries, then you need to enter the following syntax in CIW:

```
xoasInSetField("layerMap" "l.map")
```

**Note:** Here, the `l.map` file contains the layer mapping entries.



## **xoasInDoTranslate**

`xoasInDoTranslate()`

### **Description**

Issues the XOasis In command based on the GUI field values. By default, this function is a non-blocking function. However, if the *Import OASIS into Virtual Memory* option is selected, then this function becomes a blocking function.

**Note:** Before executing the `xoasInDoTranslate` function, you need to specify the value for the `OASIS File` and specify the value for either `Library` fields or the `OASIS File` field in the XOasis In form.

### **Argument**

None

### **Value Returned**

`nil`

### **Example**

In this example, you translate OASIS File, `in.gds`, to library, `lib1`. To do this, you need to execute the following functions:

```
xoasInSetField("oasisFile" "in.gds")
xoasInSetField("library" "lib1")
xoasInDoTranslate()
```

## **xoasOutGetField**

```
xoasOutGetField(  
    t_optionName  
)  
=> t_value / nil
```

### **Description**

Enables you to access GUI field values from the *XOasis Out* form. You can access all the GUI field values using the appropriate option name.

### **Arguments**

|                     |                                                                                                                                                                                                                                                                                                                                                |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be accessed from the <i>XOasis Out</i> form.<br><br>Valid values are the command line option name of the <i>XOasis Out</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <a href="#">XOasis Out Option Names in GUI and Template File</a> . |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### **Value Returned**

|                  |                                                                                    |
|------------------|------------------------------------------------------------------------------------|
| <i>t_value</i>   | The value returned from the <i>XOasis Out</i> form                                 |
| <code>nil</code> | If the field name specified in the <code>t_optionName</code> argument is incorrect |

### **Example**

If you want to access the value in the *OASIS File* field in the *XOasis Out* form, then you need to enter the following syntax in CIW:

```
xoasOutGetField("strmFile")  
=> "test.gds"
```

If you want to access the value selected in the *Export OASIS from Virtual Memory* check box, then you need to enter the following syntax in CIW:

```
xoasOutGetField("virtualMemory")  
=> "true"
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

This field returns a Boolean value.

## **xoasOutSetField**

```
xoasOutSetField(  
    t_optionName  
    t_value  
)  
=> t / nil
```

### **Description**

Enables you to populate GUI field values in the *XOasis Out* form. You can populate all the GUI field values using the appropriate option name and value.

### **Arguments**

|                     |                                                                                                                                                                                                                                                                                                                                               |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_optionName</i> | The name of the field that needs to be populated in the <i>XOasis Out</i> form.<br><br>Valid values are the command line option name of the <i>XOasis Out</i> form field, <code>virtualMemory</code> and <code>showCompletionMsgBox</code> . For list of valid values, see <a href="#">XOasis Out Option Names in GUI and Template File</a> . |
| <i>t_value</i>      | The value by which the field needs to be populated.                                                                                                                                                                                                                                                                                           |

### **Value Returned**

|            |                                                              |
|------------|--------------------------------------------------------------|
| <i>t</i>   | The value is populated in the <i>XOasis Out</i> form.        |
| <i>nil</i> | If the value is not populated in the <i>XOasis Out</i> form. |

### **Example**

If you want to populate the *OASIS File* field in the *XOasis Out* form, then you need to enter the following syntax in CIW:

```
xoasOutSetField("oasisFile" "test.gds")
```

However, there are some special cases where you want to translate a copy of the design present in the virtual memory. To do this, you need to select the *Export OASIS from Virtual Memory* check box by using the following syntax in CIW:

```
xoasOutSetField("virtualMemory" "true")
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

## **xoasOutDoTranslate**

`xoasOutDoTranslate()`

### **Description**

Issues the XOasis Out command based on the GUI field values. By default, this function is a non-blocking function. However, if the *Export OASIS from Virtual Memory* option is selected, then this function becomes a blocking function.

**Note:** Before executing the `xoasOutDoTranslate` function, you need to either specify the values for both the *OASIS File* and *Library* fields or the *Cell List File* field in the XOasis Out form.

### **Argument**

None

### **Value Returned**

`nil`

### **Example**

In this example, you translate library, `lib1`, to OASIS file, `out.gds`. To do this, you need to execute the following functions:

```
xoasOutSetField("oasisFile" "out.gds")
xoasOutSetField("library" "lib1")
xoasOutDoTranslate()
```

## Callback Functions

### xoasInOnCancelCB

```
xoasInOnCancelCB(  
    t_mode  
    S_callbackFunction  
)  
t / nil
```

#### Description

Registers or unregisters a user-defined callback function when you click the *Cancel* button on the XOasis In form.

#### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

#### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

#### Examples

Register the user-defined callback function `myxoasInOnCancel` when the *Cancel* button is clicked on the XOasis In form.

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
procedure( myxoasInOnCancel()
    print("Cancel button clicked")
)
xoasInOnCancelCB("r" 'myxoasInOnCancel)
```

**or**

```
xoasInOnCancelCB("r" "myxoasInOnCancel")
```

**Unregister the user-defined callback function `myxoasInOnCancel` when the *Cancel* button is clicked on the XOasis In form.**

```
procedure( myxstInOnCancel()
    print("Cancel button clicked")
)
xoasInOnCancelCB("d" 'myxoasInOnCancel)
```

**or**

```
xoasInOnCancelCB("d" "myxoasInOnCancel")
```



## xoasInOnCompletionCB

```
xoasInOnCompletionCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when the XOasis In translation is complete.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxoasInOnCompletion` when the XOasis In translation is complete.

```
procedure( myxoasInOnCompletion()  
    print("Translation completed with status %L")  
)
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasInOnCompletionCB("r" 'myxoasInOnCompletion)
```

or

```
xoasInOnCompletionCB("r" "myxoasInOnCompletion")
```

**Unregister the user-defined callback function `myxoasInOnCompletion` when the XOasis In translation is complete.**

```
procedure( myxoasInOnCompletion()  
    print("Cancel button clicked")  
)  
xoasInOnCompletionCB ("d" 'myxoasInOnCompletion)
```

or

```
xoasInOnCompletionCB("d" "myxoasInOnCompletion")
```

## xoasInOnTranslateCB

```
xoasInOnTranslateCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when you click the *Apply* or *Translate* button on the XOasis In form.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxoasInOnTranslate` when the XOasis In translation is complete.

```
procedure ( myxoasInOnTranslate ()  
    print("Translate button clicked")  
)
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasInOnTranslateCB("r" 'myxoasInOnTranslate)
```

or

```
xoasInOnTranslateCB("r" "myxoasInOnTranslate")
```

**Unregister the user-defined callback function `myxoasInOnTranslate` when the XOasis In translation is complete.**

```
procedure( myxstInOnTranslate()  
    print("Cancel button clicked")  
)  
xoasInOnTranslateCB("d" 'myxoasInOnTranslate)
```

or

```
xoasInOnTranslateCB("d" "myxoasInOnTranslate")
```

## xoasOutOnCancelCB

```
xoasOutOnCancelCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when you click the *Cancel* button on the XOasis Out form.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxoasOutOnCancel` when you click the *Cancel* button on the XOasis Out form.

```
procedure ( myxoasOutOnCancel ()  
    print("Cancel button clicked")  
)
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasOutOnCancelCB("r" 'myxoasOutOnCancel)
```

or

```
xoasOutOnCancelCB("r" "myxoasOutOnCancel")
```

Unregister the user-defined callback function `myxoasOutOnCancel` when you click the *Cancel* button on the XOasis Out form.

```
procedure( myxoasOutOnCancel()
    print("Cancel button clicked")
)
```

```
xoasOutOnCancelCB("d" 'myxoasOutOnCancel)
```

or

```
xoasOutOnCancelCB("d" "myxoasOutOnCancel")
```

## xoasOutOnCompletionCB

```
xoasOutOnCompletionCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when the XOasis Out translation is complete.

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxoasOutOnCompletion` when the XOasis Out translation is complete.

```
procedure( myxoasOutOnCompletion()  
    print("Translation completed with status %L")  
)
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasOutOnCompletionCB("r" 'myxoasOutOnCompletion)
```

or

```
xoasOutOnCompletionCB("r" "myxoasOutOnCompletion")
```

**Unregister the user-defined callback function `myxoasOutOnCompletion` when the XOasis Out translation is complete.**

```
procedure( myxoasOutOnCompletion()
    print("Cancel button clicked")
)
xoasOutOnCompletionCB ("d" 'myxoasOutOnCompletion)
```

or

```
xoasOutOnCompletionCB("d" "myxoasOutOnCompletion")
```



## xoasOutOnTranslateCB

```
xoasOutOnTranslateCB(  
    t_mode  
    S_callbackFunction  
)  
=> t / nil
```

### Description

Registers or unregisters a user-defined callback function when you click the *Apply* or *Translate* button on the XOasis Out form

### Arguments

*t\_mode*

Specifies mode to register or unregister the user-defined callback function.

Valid values:

- "r"  
Registers the user-defined callback function.
- "d"  
Unregisters an already registered user-defined callback function.

*S\_callbackFunction*

Name or function symbol of a user-defined callback function.

### Value Returned

t

Function is successfully registered or unregistered.

nil

Function is not registered or unregistered.

### Examples

Register the user-defined callback function `myxoasOutOnTranslate` when the XOasis Out translation is complete.

```
procedure ( myxoasOutOnTranslate ()  
    print("Translate button clicked")  
)
```

## Design Data Translators SKILL Reference

### XOasis Functions

---

```
xoasOutOnTranslateCB("r" 'myxoasOutOnTranslate)
```

or

```
xoasOutOnTranslateCB("r" "myxoasOutOnTranslate")
```

**Unregister the user-defined callback function `myxoasOutOnTranslate` when the XOasis Out translation is complete.**

```
procedure( myxoasOutOnTranslate()  
    print("Cancel button clicked")  
)  
xoasOutOnTranslateCB ("d" 'myxoasOutOnTranslate)
```

or

```
xoasOutOnTranslateCB("d" "myxoasOutOnTranslate")
```

---

## SpiceIn Function

---

This section provides syntax, descriptions, and examples for the SKILL function associated with the SpiceIn translator.

### spcinGuiDisplay

```
spcinGuiDisplay()  
=> t / nil
```

#### Description

Displays the Virtuoso SpiceIn form.

An alternative way of launching the SpiceIn GUI is by selecting *File — Import — Spice* from a workbench CIW that includes the SpiceIn menu. The workbenches from which SpiceIn can be launched are `icde`, `icds`, `icms`, `virtuoso`, `layout`, `layoutPlus`, and `msfb`.

#### Arguments

None

#### Value Returned

|                  |                                                                 |
|------------------|-----------------------------------------------------------------|
| <code>t</code>   | Returns <code>t</code> on successful execution of the function. |
| <code>nil</code> | Returns <code>nil</code> when the function encounters an error. |

## Design Data Translators SKILL Reference

### SpiceIn Function

---

---

## CDL Out Functions

---

This section provides syntax, descriptions, and examples for the SKILL functions associated with the CDL Out translator.

### **auCdIAlwaysAddPrefixInInstName**

```
auCdIAlwaysAddPrefixInInstName (  
    )  
=> t / nil
```

#### **Description**

Enables you to use the `simAlwaysAddPrefixInInstName` variable to prefix instance names with the `namePrefix` of a device type based on your `auCdI` netlisting requirements.

#### **Arguments**

None

#### **Value Returned**

|                  |                                                        |
|------------------|--------------------------------------------------------|
| <code>t</code>   | Prefix will always be added to the instance names.     |
| <code>nil</code> | Prefix will not be added to the instance names always. |

#### **Example**

If you want to always add a prefix in hierarchical instance name, however, you do not always want to add a prefix to the primitive instance name then you can define the `auCdIAlwaysAddPrefixInInstName` procedure as shown below:

```
procedure (auCdIAlwaysAddPrefixInInstName ())
```

## Design Data Translators SKILL Reference

### CDL Out Functions

---

```
;;do not always add prefix to primitives
if(hnlIsAStoppingCell( hnlCurrentMaster ) then
    simAlwaysAddPrefixInInstName = nil
else
    ;;always add prefix to hierarchical instances
    simAlwaysAddPrefixInInstName = t
)
)
```

## hnlCDLPrintBJTElement

`hnlCDLPrintBJTElement()`

### Description

Prints the CDL syntax of an instance of the BJT element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName C B E [SUB] cellName $EA=@area $L=@l $W=@w {$SUB=@sub}  
@offic=@icm=@m
```

If you create a library element similar to the BJT element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintBJTElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintGeneralElement

`hnlCDLPrintGeneralElement()`

### Description

Prints the CDL syntax of an instance of any general element. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*InstanceName O1 O2 ... I1 I2 ... OT1 OT2 ...*

where,

| Keyword           | Description              |
|-------------------|--------------------------|
| <i>O1 O2...</i>   | Nets on output terminals |
| <i>I1 I2...</i>   | Nets on input terminals  |
| <i>OT1 OT2...</i> | Nets on other terminals  |

To use this function, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintGeneralElement()`

### Arguments

None

### Value Returned

None



## **hnlCDLPrintICIsrElement**

`hnlCDLPrintICIsrElement()`

### **Description**

Prints the CDL syntax of an instance of an `ICIsrElement` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*InstanceName N+ N- VcontrolVoltage @value*

If you create a library element similar to the `ICIsrElement` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintICIsrElement()`

### **Arguments**

None

### **Value Returned**

None

## **hnlCDLPrintICVsrcElement**

`hnlCDLPrintICVsrcElement()`

### **Description**

Prints the CDL syntax of an instance of an `ICVsrc` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*HInstanceName N+ N- VcontrolVoltage @value*

If you create a library element similar to the `ICVsrc` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintICVsrcElement()`

### **Arguments**

None

### **Value Returned**

None

## **hnlCDLPrintCds\_Thru**

`hnlCDLPrintCds_Thru()`

### **Description**

Prints the CDL syntax of an instance of a `Cds_Thru` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
RInstanceName src dst @ns/100.0m $[cellName]
```

If you create a library element similar to the `Cds_Thru` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintCds_Thru()
```

### **Arguments**

None

### **Value Returned**

None

## hnlCDLPrintInductorElement

`hnlCDLPrintInductorElement()`

### Description

Prints the CDL syntax of an instance of an `Inductor` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
LInstanceName PLUS MINUS @l @tc1 @tc2 @nt ic=@ic
```

If you create a library element similar to the `Inductor` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintInductorElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintIsrcElement

`hnlCDLPrintIsrcElement()`

### Description

Prints the CDL syntax of an instance of an `Isrc` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*I InstanceName N+ N- @DCValue @TRANValue @ACMag @ACPhase*

If you create a library element similar to the `Isrc` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintIsrcElement()`

### Arguments

None

### Value Returned

None

## hnlCDLPrintJfetElement

`hnlCDLPrintJfetElement()`

### Description

Prints the CDL syntax of an instance of a `Jfet` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
JInstanceName D G S cellName w=@w l=@l @off ic=@ic m=@m
```

If you create a library element similar to the `Jfet` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintJfetElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintNMOSfetElement

`hnlCDLPrintNMOSfetElement()`

### Description

Prints the CDL syntax of an instance of a `NMOSfet` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
MInstanceName D G S global gnd, cellName w=@w l=@l ad=@ad as=@as pd=@pd  
ps=@ps nrd=@nrd nrs=@nrs @offic=@ic m=@m $LDD[ @LDD]
```

If you create a library element similar to the `NMOSfet` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintNMOSfetElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintNPNElement

`hnlCDLPrintNPNElement()`

### Description

Prints the CDL syntax of an instance of a `NPN` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName C B E cellName M=@m $EA=@area
```

If you create the library element similar to the `NPN` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintNPNElement()
```

### Arguments

None

### Value Returned

None



## hnlCDLPrintPMOSfetElement

`hnlCDLPrintPMOSfetElement()`

### Description

Prints the CDL syntax of an instance of a `PMOSfet` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
MInstanceName DGS global_Vdd cellName w=@wl l=@lad a=@adas s=@as pd=@pd  
ps=@ps nrd=@nrd nrs=@nrs @offic=@icm=@m $LDD[ @LDD]
```

If you create a library element similar to the `PMOSfet` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintPMOSfetElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintPNPElement

`hnlCDLPrintPNPElement()`

### Description

Prints the CDL syntax of an instance of a `PNP` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName C B E cellName M=@m $EA=@area
```

If you create a library element similar to the `PNP` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintPNPElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintResistorElement

`hnlCDLPrintResistorElement()`

### Description

Prints the CDL syntax of an instance of a `Resistor` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
RInstanceName PLUS MINUS @ns | @r $[cellName] m=@m {$SUB=@sub} $w=@w  
$l=@l @ns @tc1 @tc2 @scale @rsh ac=@ac {$SUB=@sub}
```

If you create a library element similar to the `Resistor` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintResistorElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintSchottkyTranElement

`hnlCDLPrintSchottkyTranElement()`

### Description

Prints the CDL syntax of an instance of a `SchottkyTran` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
CInstanceName PLUS MINUS @c $[cellName] @ns @tc1 @tc2 @scale @cj  
ic=@ic m=@m {$SUB=@sub} Q name.1 C B E @NP cellname Q name.2 B C cellname
```

If you create a library element similar to the `SchottkyTran` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintSchottkyTranElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintTlineElement

`hnlCDLPrintTlineElement()`

### Description

Prints the CDL syntax of an instance of a `Tline` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
TInstanceName N1 N2 N3 N4 z0=@z0 td=@td f=@f nl=@nl ic=@ic
```

If you create a library element similar to the `Tline` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintTlineElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintVCIsrsrcElement

`hnlCDLPrintVCIsrsrcElement()`

### Description

Prints the CDL syntax of an instance of a `VCIsrsrc` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*GInstanceName N+ N- NC+ NC- @value*

If you create a library element similar to the `VCIsrsrc` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintVCIsrsrcElement()`

### Arguments

None

### Value Returned

None

## **hnlCDLPrintVCVsrcElement**

`hnlCDLPrintVCVsrcElement()`

### **Description**

Prints the CDL syntax of an instance of a `VCVsrc` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*EInstanceName N+ N- NC+ NC- @value*

If you create a library element similar to the `VCVsrc` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintVCVsrcElement()`

### **Arguments**

None

### **Value Returned**

None

## hnlCDLPrintVsrcElement

`hnlCDLPrintVsrcElement()`

### Description

Prints the CDL syntax of an instance of a `Vsrc` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

*VInstanceName N+ N- @DCValue @TRANValue @ACMag @ACPhase*

If you create a library element similar to the `Vsrc` element, set the following property in the CDL view of the element:

`hnlCDLFormatInst = hnlCDLPrintVsrcElement()`

### Arguments

None

### Value Returned

None



## **hnlCDLPrintMultiCNPNElement**

`hnlCDLPrintMultiCNPNElement()`

### **Description**

Prints the CDL syntax of an instance of a `MultiCNPNElement` in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName.1 C1 B E cellName  
.  
QInstanceName.n Cn B E cellName
```

If you create a library element similar to the `MultiCNPNElement`, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintMultiCNPNElement()
```

### **Arguments**

None

### **Value Returned**

None

## **hnlCDLPrintMultiCPNPElement**

`hnlCDLPrintMultiCPNPElement()`

### **Description**

Prints the CDL syntax of an instance of a `MultiCPNP` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName.1 C1 B E cellName  
.  
QInstanceName.n Cn B E cellName
```

If you create a library element similar to the `MultiCPNP` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintMultiCPNPElement()
```

### **Arguments**

None

### **Value Returned**

None

## hnlCDLPrintMultiENPNElement

`hnlCDLPrintMultiENPNElement()`

### Description

Prints the CDL syntax of an instance of a `MultiENPN` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName.1 C1 B E cellName  
.  
QInstanceName.n Cn B En cellName
```

If you create a library element similar to the `MultiENPN` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintMultiENPNElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintMultiEPNPElement

`hnlCDLPrintMultiEPNPElement()`

### Description

Prints the CDL syntax of an instance of a `MultiEPNP` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
QInstanceName.1 C1 B E cellName  
.  
QInstanceName.n Cn B En cellName
```

If you create a library element similar to the `MultiEPNP` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintMultiEPNPElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintCapElement

hnlCDLPrintCapElement()

### Description

Prints the CDL syntax of an instance of a `cap` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
CInstanceName Y global_gnd @cm=@m $[cellName] {$SUB=@sub} @ns @tc1  
@tc2 @scale @cjic=@ic area=@area l=@l w=@w
```

If you create a library element similar to the `cap` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintCapElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintCapacitorElement

hnlCDLPrintCapacitorElement()

### Description

Prints the CDL syntax of an instance of a `capacitor` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

format:

```
CInstanceName PLUS MINUS @c $[cellName] {$SUB=@sub} @ns @tc1 @tc2  
@scale @cj ic=@ic m=@m {$SUB=@sub} area=@area l=@l w=@w
```

If you create a library element similar to the `capacitor` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintCapacitorElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintDiodeElement

`hnlCDLPrintDiodeElement()`

### Description

Prints the CDL syntax of an instance of a `diode` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
DInstanceName PLUS MINUS cellName AREA=@area PJ=@pj w=@w l=@l  
wp=@wp lp=@lp wm=@wm @off ic=@ic {@area} {@periphery}  
{ $SUB=@sub }
```

If you create a library element similar to the `diode` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintDiodeElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintBSIM3SOIElement

`hnlCDLPrintBSIM3SOIElement()`

### Description

Prints the CDL syntax of an instance of a `BSIM3SOI` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
M<name> <D> <G> <S> <E> <model> l=@l w=@w ad=@ad as=@as pd=@pd ps=@ps  
nrs=@nrs nrd=@nrd nrb=@nrb @off bjtoff=@bjtoff ic=@ic rtho=@rtho  
ctho=@ctho debug=@debug nbc=@nbc nseg=@nseg pdbcpr=@pdbcpr  
psbcpr=@psbcpr agbcpr=@agbcpr aebcp=@aebcp vbsusr=@vbsusr  
tnodeout=@tnodeout
```

If you create a library element similar to the `BSIM3SOI` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintBSIM3SOIElement()
```

### Arguments

None

### Value Returned

None



## hnlCDLPrintResElement

`hnlCDLPrintResElement()`

### Description

Prints the CDL syntax of an instance of a `Res` element in the netlist. An example of the syntax is shown below; if you are viewing this description in the SKILL API Finder, click *More Info* to see it.

```
RInstanceName A Y @ns | @r $ [cellName] $SUB=@sub $w=@w $l=@l @ns @tc1  
@tc2 @scale @rsh ac=@ac m=@m
```

If you create a library element similar to the `Res` element, set the following property in the CDL view of the element:

```
hnlCDLFormatInst = hnlCDLPrintResElement()
```

### Arguments

None

### Value Returned

None

## hnlCDLPrintInstPropVal

```
hnlCDLPrintInstPropVal(  
    t_propName  
)
```

### Description

Prints an instance property value in the CDL netlist during netlisting.

**Note:** This function must be called only from the user-defined instance formatting procedures.

### Arguments

|                   |                                                     |
|-------------------|-----------------------------------------------------|
| <i>t_propName</i> | The instance property name to print in CDL netlist. |
|-------------------|-----------------------------------------------------|

### Value Returned

None

### Examples

```
hnlCDLPrintInstPropVal(" $EA=%s" "area")
```

Prints `area` as the value of the property `$EA`.

```
hnlCDLPrintInstPropVal(" $L=%s" "1")
```

Prints `1` as the value of the property `$L`.

```
hnlCDLPrintInstPropVal(" $W=%s" "w")
```

Prints `w` as the value of the property `$W`.

```
hnlCDLPrintInstPropVal(" $SUB=%s" "sub")
```

Prints `sub` as the value of the property `$SUB`.

```
hnlCDLPrintInstPropVal(" off" "off")
```

Prints `off` as the value of the property `off`.

```
hnlCDLPrintInstPropVal(" ic=%s" "ic")
```

Prints `ic` as the value of the property `ic`.

## **transCdlOutDisplay**

`transCdlOutDisplay()`

### **Description**

Invokes the *CDL Out* GUI form.

### **Arguments**

None

### **Value Returned**

`t` Returns `t` when Ok button is clicked in the CDL Out form.

## Design Data Translators SKILL Reference

### CDL Out Functions

---

---

## LEF/DEF Functions

---

This section provides syntax, descriptions, and examples for the SKILL functions associated with the LEF/DEF translator.

### ldtrLefReadOA

```
ldtrLefReadOA(  
    t_fileName  
    t_libName  
    [ t_libPath ]  
    [ t_techName ]  
    [ t_techPath ]  
    [ g_overwriteTech { t | nil } ]  
    [ g_shared { t | nil } ]  
    [ t_viewName ]  
    [ t_logName logName ]  
    [ t_layermapFileName ]  
    [ t_commentChar ]  
    [ t_templateFileName ]  
    [ t_pinpurp ]  
    [ t_textLayer ]  
    [ t_textHeight ]  
    [ t_techRefs ]  
    [ g_compress { t | nil } ]  
    [ t_compressLevel ]  
    [ g_mapConflicts { t | nil } ]  
    [ g_pnrLibDataOnly { t | nil } ]  
    [ g_useFoundryInnovus { t | nil } ]  
    [ g_useTextLayerFromPin {t |nil} ]  
    [ t_textPurposeName ]  
    [ g_keepOrigDisplayDrf {t |nil} ]  
    [ g_lockColorData { t | nil } ]  
)  
=> t / nil
```

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### Description

Reads the specified LEF file into an OpenAccess library. `t_lockColorData` is an advanced nodes only argument.

#### Arguments

|                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>t_fileName</code>         | Name of the LEF file to be read into the OpenAccess library.                                                                                                                                                                                                                                                                                                                                                                                                |
| <code>t_libName</code>          | Name of the output OpenAccess library. If the output library does not exist, a new library is created in the current directory and contains the translated technology database and macros.<br><br>If the output library exists, it must contain a technology database or refer to the technology database of another library. In addition, any existing macros, if redefined in the LEF file, are overwritten and new cells are created for the new macros. |
| <code>t_libPath</code>          | Complete path where the OpenAccess library is to be created.                                                                                                                                                                                                                                                                                                                                                                                                |
| <code>t_techName</code>         | Name of the technology library that is to be created.                                                                                                                                                                                                                                                                                                                                                                                                       |
| <code>t_techpath</code>         | Path to technology library.                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <code>g_overwriteTech</code>    | Overwrite the existing technology file. Specify <code>nil</code> to update the technology file.                                                                                                                                                                                                                                                                                                                                                             |
| <code>g_shared</code>           | Share the OA library with other applications while the current application is running.                                                                                                                                                                                                                                                                                                                                                                      |
| <code>t_viewName</code>         | View name for the translated macros. The default view name is <code>abstract</code> .                                                                                                                                                                                                                                                                                                                                                                       |
| <code>t_logName</code>          | Name of the log file for storing the error messages.                                                                                                                                                                                                                                                                                                                                                                                                        |
| <code>t_layermapFileName</code> | Name of the layer map file. While creating layers, the layer numbers specified in this file are used.                                                                                                                                                                                                                                                                                                                                                       |
| <code>t_commentChar</code>      | Special character that identifies comments in the LEF file.                                                                                                                                                                                                                                                                                                                                                                                                 |
| <code>t_templateFileName</code> | Name of the template file that contains all the command options.                                                                                                                                                                                                                                                                                                                                                                                            |
| <code>t_pinpurp</code>          | Purpose for pin geometries.                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <code>t_textLayer</code>        | Defines the text layer name to use for pin labels.                                                                                                                                                                                                                                                                                                                                                                                                          |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

|                              |                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_textHeight</i>          | Defines the text height to use for pin labels.                                                                                                                                                                                                                                                                                                                                                                    |
| <i>t_techRefs</i>            | List of libraries that contain master technology databases.                                                                                                                                                                                                                                                                                                                                                       |
| <i>g_compress</i>            | Allow libraries to be compressed.                                                                                                                                                                                                                                                                                                                                                                                 |
| <i>t_compressLevel</i>       | Define the compression level to use.<br><br>Default value: 1                                                                                                                                                                                                                                                                                                                                                      |
| <i>g_mapConflicts</i>        | Map certain conflicts between incremental and base technologies to constraints and constraint parameter definitions.                                                                                                                                                                                                                                                                                              |
| <i>g_pnrLibDataOnly</i>      | Filter the Place and Route information. The information can be stored only as incremental technology database on the top of existing referenced technology database. Therefore, the <i>t_techRefs</i> option needs to be specified. For more information, see <a href="#">General Processing Rules of - pnrLibDataOnly</a> .<br><br>This option cannot be specified along with <i>g_useFoundryInnovus</i> option. |
| <i>g_useFoundryInnovus</i>   | Enables Innovus to see the same design rules that are described in LEF without impacting the Virtuoso tools. For more information, see <a href="#">General Processing Rules of useFoundryInnovus</a> .<br><br>This option cannot be specified along with <i>g_pnrLibDataOnly</i> option.                                                                                                                          |
| <i>g_useTextLayerFromPin</i> | Specify the text layer name from pin.                                                                                                                                                                                                                                                                                                                                                                             |
| <i>t_textPurposeName</i>     | Specify the purpose name.                                                                                                                                                                                                                                                                                                                                                                                         |
| <i>g_keepOrigDisplayDrf</i>  | Specify whether the original <code>display.drf</code> file is retained.                                                                                                                                                                                                                                                                                                                                           |
| <i>g_lockColorData</i>       | (ICADVM20.1 Only) Lock color data of all shapes created using the PORT and PIN definitions and are associated with a MASK construct.                                                                                                                                                                                                                                                                              |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### Value Returned

|                  |                                                                 |
|------------------|-----------------------------------------------------------------|
| <code>t</code>   | Returns <code>t</code> on successful execution of the function. |
| <code>nil</code> | Returns <code>nil</code> when the function encounters an error. |

#### Example

```
ldtrLefReadOA("tech.lef macro1.lef macro2.lef macro3.lef" "techPlusDesignLib" ""  
"" "" nil nil "abstract" "" "layer.map" "" "" "" "" "" "" t "7" )
```

In the above example, four LEF files are read into the `techPlusDesignLib` library with compress option enabled and compress level set to 7.



## Design Data Translators SKILL Reference

### LEF/DEF Functions

#### Additional Information (ICADVM20.1 Only)

The following table depicts position of `ldtrDefWriteOA` arguments in different releases.

#### ICADV12.3 ISR15

|                                      |                                         |                                     |                                         |
|--------------------------------------|-----------------------------------------|-------------------------------------|-----------------------------------------|
| (1)<br><code>t_fileName</code>       | (2)<br><code>t_libName</code>           | (3)<br><code>t_libPath</code>       | (4)<br><code>t_techName</code>          |
| (5)<br><code>t_techpath</code>       | (6)<br><code>g_overwriteTech</code>     | (7)<br><code>g_shared</code>        | (8)<br><code>t_viewName</code>          |
| (9)<br><code>t_logName</code>        | (10)<br><code>t_layermapFileName</code> | (11)<br><code>t_commentCha</code>   | (12)<br><code>t_templateFileName</code> |
| (13)<br><code>t_pinpurp</code>       | (14)<br><code>t_textLayer</code>        | (15)<br><code>t_textHeight</code>   | (16)<br><code>t_techRefs</code>         |
| (17)<br><code>g_compress</code>      | (18)<br><code>t_compressLevel</code>    | (19)<br><code>g_mapConflicts</code> | (20)<br><code>g_pnrLibDataOnly</code>   |
| (21)<br><code>g_lockColorData</code> | (22)                                    |                                     |                                         |

#### ICADV12.3 ISR16

|                                                 |                                         |                                     |                                         |
|-------------------------------------------------|-----------------------------------------|-------------------------------------|-----------------------------------------|
| (1)<br><code>t_fileName</code>                  | (2)<br><code>t_libName</code>           | (3)<br><code>t_libPath</code>       | (4)<br><code>t_techName</code>          |
| (5)<br><code>t_techpath</code>                  | (6)<br><code>g_overwriteTech</code>     | (7)<br><code>g_shared</code>        | (8)<br><code>t_viewName</code>          |
| (9)<br><code>t_logName</code>                   | (10)<br><code>t_layermapFileName</code> | (11)<br><code>t_commentCha</code>   | (12)<br><code>t_templateFileName</code> |
| (13)<br><code>t_pinpurp</code>                  | (14)<br><code>t_textLayer</code>        | (15)<br><code>t_textHeight</code>   | (16)<br><code>t_techRefs</code>         |
| (17)<br><code>g_compress</code>                 | (18)<br><code>t_compressLevel</code>    | (19)<br><code>g_mapConflicts</code> | (20)<br><code>g_pnrLibDataOnly</code>   |
| (21)<br><b><code>g_useFoundryInnovus</code></b> | (22)<br><code>g_lockColorData</code>    |                                     |                                         |

#### ICADVM18.1 Base

|                                |                                         |                                   |                                         |
|--------------------------------|-----------------------------------------|-----------------------------------|-----------------------------------------|
| (1)<br><code>t_fileName</code> | (2)<br><code>t_libName</code>           | (3)<br><code>t_libPath</code>     | (4)<br><code>t_techName</code>          |
| (5)<br><code>t_techpath</code> | (6)<br><code>g_overwriteTech</code>     | (7)<br><code>g_shared</code>      | (8)<br><code>t_viewName</code>          |
| (9)<br><code>t_logName</code>  | (10)<br><code>t_layermapFileName</code> | (11)<br><code>t_commentCha</code> | (12)<br><code>t_templateFileName</code> |
| (13)<br><code>t_pinpurp</code> | (14)<br><code>t_textLayer</code>        | (15)<br><code>t_textHeight</code> | (16)<br><code>t_techRefs</code>         |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

|                             |                                      |                                  |                                |
|-----------------------------|--------------------------------------|----------------------------------|--------------------------------|
| (17)<br>g_compress          | (18)<br>t_compressLevel              | (19)<br>g_mapConflicts           | (20)<br>g_pnrLibDataOnly       |
| (21)<br>g_useFoundryInnovus | (22)<br><b>g_useTextLayerFromPin</b> | (23)<br><b>t_textPurposeName</b> | (24)<br><i>g_lockColorData</i> |

## ICADVM18.1 ISR1

|                                |                               |                           |                                     |
|--------------------------------|-------------------------------|---------------------------|-------------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName              | (3)<br>t_libPath          | (4)<br>t_techName                   |
| (5)<br>t_techpath              | (6)<br>g_overwriteTech        | (7)<br>g_shared           | (8)<br>t_viewName                   |
| (9)<br>t_logName               | (10)<br>t_layermapFileName    | (11)<br>t_commentCha      | (12)<br>t_templateFileName          |
| (13)<br>t_pinpurp              | (14)<br>t_textLayer           | (15)<br>t_textHeight      | (16)<br>t_techRefs                  |
| (17)<br>g_compress             | (18)<br>t_compressLevel       | (19)<br>g_mapConflicts    | (20)<br>g_pnrLibDataOnly            |
| (21)<br>g_useFoundryInnovus    | (22)<br>g_useTextLayerFromPin | (23)<br>t_textPurposeName | (25)<br><b>t_keepOrigDisplayDrf</b> |
| (25)<br><i>g_lockColorData</i> |                               |                           |                                     |

## IdtrLefWriteOA

```
IdtrLefWriteOA(  
    t_fileName  
    t_libName  
    [ t_cellNames ]  
    [ t_cellListFileName ]  
    [ t_viewNames ]  
    [ t_logName ]  
    [ g_noTech { t | nil } ]  
    [ t_version ]  
    [ g_techOnly { t | nil } ]  
    [ t_templateFileName ]  
    [ g_useFoundryInnovus { t | nil } ]  
    [ g_lockedColorOnly { t | nil } ]  
)  
=> t / nil
```

### Description

Writes a LEF file from a specified OpenAccess library. `t_lockedColorOnly` is an advanced nodes only argument.

### Arguments

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_fileName</i>         | Name of the LEF file to be created from the OpenAccess library.                                                                                                                                                                                                                                                                                                                                                               |
| <i>t_libName</i>          | Name of the source OpenAccess library.                                                                                                                                                                                                                                                                                                                                                                                        |
| <i>t_cellNames</i>        | Name of the cells to be translated as a macro. You can specify more than one cell name.                                                                                                                                                                                                                                                                                                                                       |
| <i>t_cellListFileName</i> | <p>Name of the file containing a list of cell names to be translated as macros. The cell list file contains the list of library names and cell names separated by a space. In a cell list file for Virtuoso design environment on OpenAccess 2.2 you do not need to specify the view name.</p> <p>The cell names in a cell list file appear in the following format:</p> <p><code>&lt;libName&gt; &lt;cellName&gt;</code></p> |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

A sample cell list file is shown below:

```
#libName      cellName
designLib1     ACCSHCINX2
designLib1     ACCSHCINX4
designLib1     ACCSHCONX2
```

If you specify the cell names as well as a cell list file as arguments, then the cell list file is used. The specified cell names are ignored and a warning message is displayed.

|                            |                                                                                                                                                                                                     |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_viewNames</i>         | View names for the input cell names.                                                                                                                                                                |
| <i>t_logName</i>           | Name of the log file for storing the error messages.                                                                                                                                                |
| <i>g_noTech</i>            | Specify <i>t</i> if you do not want to output the technology information.                                                                                                                           |
| <i>t_version</i>           | Specify the version of LEF. Supported versions are 5.8, 5.7, 5.6, 5.5, and 5.4.                                                                                                                     |
| <i>g_techOnly</i>          | Output only the technology information and cell, cell list, and cell view options are ignored.                                                                                                      |
| <i>t_templateFileName</i>  | Name of the file that contains all the command options.                                                                                                                                             |
| <i>g_useFoundryInnovus</i> | Output the <i>foundry_innovus</i> group constraint as a LEF LAYER LEF58 property.                                                                                                                   |
| <i>g_lockedColorOnly</i>   | (ICADVM20.1 Only) Output colors for only those shapes that have their locked state set to true.<br><br>This includes pathSegs in nets, rects and polygons, and fill shapes and vias in specialnets. |

### Value Returned

|            |                                                           |
|------------|-----------------------------------------------------------|
| <i>t</i>   | Returns <i>t</i> on successful execution of the function. |
| <i>nil</i> | Returns <i>nil</i> when the function encounters an error. |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

#### Example

```
ldtrLefWriteOA("out.lef.tech" "techPlusDesignLib" "" "" "" "" nil "5.4" t)
```

In the above example, a LEF file, `out.lef.tech`, is created from the `techPlusDesignLib` library.

#### Additional Information (ICADVM20.1 Only)

The following table depicts position of `ldtrDefWriteOA` arguments in different releases.

##### **ICADV12.3 ISR15**

|                    |                            |                           |                           |
|--------------------|----------------------------|---------------------------|---------------------------|
| (1)<br>t_fileName  | (2)<br>t_libName           | (3)<br>t_cellNames        | (4)<br>t_cellListFileName |
| (5)<br>t_viewNames | (6)<br>t_logName           | (7)<br>g_noTech           | (8)<br>t_version          |
| (9)<br>g_techOnly  | (10)<br>t_templateFileName | (11)<br>g_lockedColorOnly | (12)                      |

##### **ICADV12.3 ISR16**

|                    |                            |                                    |                           |
|--------------------|----------------------------|------------------------------------|---------------------------|
| (1)<br>t_fileName  | (2)<br>t_libName           | (3)<br>t_cellNames                 | (4)<br>t_cellListFileName |
| (5)<br>t_viewNames | (6)<br>t_logName           | (7)<br>g_noTech                    | (8)<br>t_version          |
| (9)<br>g_techOnly  | (10)<br>t_templateFileName | (11)<br><b>g_useFoundryInnovus</b> | (12)<br>g_lockedColorOnly |

## IdtrDefReadOA

```
IdtrDefReadOA(  
    t_fileName  
    t_libName  
    [ t_libPath ]  
    [ t_cellName ]  
    [ t_viewName ]  
    [ t_techName ]  
    [ t_viewNameList ]  
    [ t_masterLibs ]  
    [ g_shared { t | nil } ]  
    [ g_noRouting { t | nil } ]  
    [ t_logName ]  
    [ g_useCustomVias { t | nil } ]  
    [ g_overwrite { t | nil } ]  
    [ g_createModHier { t | nil } ]  
    [ t_commentChar commentChar ]  
    [ t_templateFileName ]  
    [ t_layermapFileName ]  
    [ t_techRefs ]  
    [ t_pinpurp ]  
    [ g_compress { t | nil } ]  
    [ t_compressLevel ]  
    [ g_ignoreDrcFill { t | nil } ]  
    [ t_userSkillFile ]  
    [ g_lockColorData { t | nil } ]  
    [ t_oaMapFile ]  
)  
=> t / nil
```

## Description

Reads the specified DEF file into an OpenAccess library. `t_lockColorData` is an advanced nodes only argument.

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### Arguments

|                           |                                                                                                                              |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <i>t_fileName</i>         | Name of the DEF file to be read into the OpenAccess library.                                                                 |
| <i>t_libName</i>          | Name of the target OpenAccess library.                                                                                       |
| <i>t_libPath</i>          | Complete path where the OpenAccess library is to be created.                                                                 |
| <i>t_cellName</i>         | Output cell name.                                                                                                            |
| <i>t_viewName</i>         | View name for the translated design.                                                                                         |
| <i>t_techName</i>         | Name of the technology library to be attached to the output OpenAccess library.                                              |
| <i>t_viewNameList</i>     | List of view names for the master cells, which can be searched for the DEF COMPONENTS construct record.                      |
| <i>t_masterLibs</i>       | List of reference libraries that contain master cells.                                                                       |
| <i>g_shared</i>           | Shares the input-output library with other applications while the current application is running.                            |
| <i>g_noRouting</i>        | Specify <i>t</i> to ignore any routing data including the vias section.                                                      |
| <i>t_logName</i>          | Name of the log file for storing the error messages.                                                                         |
| <i>g_useCustomVias</i>    | Create custom vias for all DEF vias.                                                                                         |
| <i>g_overwrite</i>        | Overwrite the existing design in the target library.                                                                         |
| <i>g_createModHier</i>    | Specify this as <i>nil</i> to create only the physical data. No module hierarchy is derived from the DEF hierarchical names. |
| <i>t_commentChar</i>      | Special character that identifies comments in the DEF file.                                                                  |
| <i>t_templateFileName</i> | Name of the template file that contains all the command options.                                                             |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_layermapFileName</i> | Name of the layer map file. While creating layers, the layer numbers specified in this file are used.                                                                                                                                                                                                                                                                                                                       |
| <i>t_techRefs</i>         | List of libraries that contain master technology databases.                                                                                                                                                                                                                                                                                                                                                                 |
| <i>t_pinpurp</i>          | Purpose for pin geometries.                                                                                                                                                                                                                                                                                                                                                                                                 |
| <i>g_compress</i>         | Allow libraries to be compressed.                                                                                                                                                                                                                                                                                                                                                                                           |
| <i>t_compressLevel</i>    | Define the compression level to use.<br><br>Default value: 1                                                                                                                                                                                                                                                                                                                                                                |
| <i>g_ignoreDrcFill</i>    | Map all shapes specified with the +SHAPE DRCFILL tag in the SPECIALNETS section to the drawing purpose. If this option is not specified, such shapes are mapped to the gapFill purpose.<br><br><b>Note:</b> (ICADVM20.1 Only) When <i>lockColorData</i> is specified, the <i>ldtrDefReadOA</i> SKILL function is incompatible with ICADV12.2 ISR6 and earlier versions. For more information, see <a href="#">example</a> . |
| <i>t_userSkillFile</i>    | Specifies a file that consists of user-defined SKILL routines.                                                                                                                                                                                                                                                                                                                                                              |
| <i>g_lockColorData</i>    | (ICADVM20.1 Only) Lock color data of all shapes created using the PORT and PIN definitions and are associated with a MASK construct.                                                                                                                                                                                                                                                                                        |
| <i>t_oaMapFile</i>        | (ICADVM20.1 Only) Uses the specified mapping file to post-process the design before it is saved.<br><br>For more information, see <a href="#">Using the oaMapFile option for different OpenAccess Database Formats</a> in <i>Design Data Translators Reference</i> .                                                                                                                                                        |



## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### Value Returned

|                  |                                                                 |
|------------------|-----------------------------------------------------------------|
| <code>t</code>   | Returns <code>t</code> on successful execution of the function. |
| <code>nil</code> | Returns <code>nil</code> when the function encounters an error. |

## Examples

### Example 1

In the following example, three DEF files are read into the `definLib` library with `compress` option enabled and `compressLevel` set to 8.

```
ldtrDefReadOA("sroutes01.def sroutes02.def sroutes03.def" "definLib"  
"" "defCell" "layout" "" "layout abstract autoLayout route" "techLib  
techPlusDesignLib" t t "" t t t "" "" "" "" t "8")
```

### Example 2

(ICADVM20.1 Only) The following example shows how the code changes when `t_ignoreDrcFill` is specified in a code that already specifies `t_lockedColorData`.

In the following ICADV12.2 ISR6 or earlier version code, `t` is the 22nd value that specifies value for `t_lockedColorData`.

```
ldtrDefReadOA("defin.def" "lib" "" "design" "layout" "" "" "" nil nil "defin.log"  
nil nil nil "" "" "" "" "" nil "" t)
```

From ICADV12.2 ISR7 onward, the function also supports `t_ignoreDrcFill`. Therefore, the code that previously specified `t_lockedColorData` will have to be changed. As you can see below, in the updated code, the 22nd value `nil` now specifies the value for `t_ignoreDrcFill`, and the 23rd value `t` specifies value for `t_lockedColorData`.

```
ldtrDefReadOA("defin.def" "lib" "" "design" "layout" "" "" "" nil nil "defin.log"  
nil nil nil "" "" "" "" "" nil "" nil t)
```

The updated code is incompatible with ICADV12.2 IRSR6 and earlier versions.

## Additional Information (ICADVM20.1 Only)

The following table depicts position of `ldtrDefReadOA` arguments in different releases.

## Design Data Translators SKILL Reference

### LEF/DEF Functions

#### **ICADVM18.1 ISR7**

|                            |                         |                                |                            |
|----------------------------|-------------------------|--------------------------------|----------------------------|
| (1)<br>t_fileName          | (2)<br>t_libName        | (3)<br>t_libPath               | (4)<br>t_cellNames         |
| (5)<br>t_viewName          | (6)<br>t_techName       | (7)<br>t_viewNameList          | (8)<br>t_masterLibs        |
| (9)<br>g_shared            | (10)<br>g_noRouting     | (11)<br>t_logName              | (12)<br>g_useCustomVias    |
| (13)<br>g_overwrite        | (14)<br>g_createModHier | (15)<br>t_commentChar          | (16)<br>t_templateFileName |
| (17)<br>t_layermapFileName | (18)<br>t_techRefs      | (19)<br>t_pinpurp              | (20)<br>g_compress         |
| (21)<br>t_compressLevel    | (22)<br>g_ignoreDrcFill | (23)<br><b>t_userSkillFile</b> | (24)<br>g_lockColorData    |

#### **ICADVM18.1 ISR9**

|                            |                         |                         |                            |
|----------------------------|-------------------------|-------------------------|----------------------------|
| (1)<br>t_fileName          | (2)<br>t_libName        | (3)<br>t_libPath        | (4)<br>t_cellNames         |
| (5)<br>t_viewName          | (6)<br>t_techName       | (7)<br>t_viewNameList   | (8)<br>t_masterLibs        |
| (9)<br>g_shared            | (10)<br>g_noRouting     | (11)<br>t_logName       | (12)<br>g_useCustomVias    |
| (13)<br>g_overwrite        | (14)<br>g_createModHier | (15)<br>t_commentChar   | (16)<br>t_templateFileName |
| (17)<br>t_layermapFileName | (18)<br>t_techRefs      | (19)<br>t_pinpurp       | (20)<br>g_compress         |
| (21)<br>t_compressLevel    | (22)<br>g_ignoreDrcFill | (23)<br>t_userSkillFile | (24)<br>g_lockColorData    |
| (25)<br>t_oaMapFile        |                         |                         |                            |

## IdtrDefWriteOA

```
IdtrDefWriteOA(  
    t_fileName  
    t_libName  
    t_cellName  
    t_viewName  
    [ t_logName ]  
    [ t_version ]  
    [ t_templateFileName ]  
    [ g_skipNoneOrViaCellType ]  
    [ t_mapDividerChar ]  
    [ t_dividerChar ]  
    [ t_busbitChars ]  
    [ g_outputFloatingShapes { t | nil } ]  
    [ g_warnOnNotPlacedInsts { t | nil } ]  
    [ g_skipPhysOnlyInsts { t | nil } ]  
    [ g_gdsCompatible ]  
    [ t_userSkillFile ]  
    [ t_noDefOnError { t | nil } ]  
    [ g_lockedColorOnly { t | nil } ]  
    [ g_skipTrimShapes { t | nil } ]  
    [ g_skipTrimProductShapes { t | nil } ]  
    [ g_genBridgeMetalShapes { t | nil } ]  
    [ g_outputTrimSegsAsNets { t | nil } ]  
    [ t_maskShiftLayer ]  
    [ t_oaMapFile ]  
    [ g_skipTrimmedShapes { t | nil } ]  
    [ t_errorOnGrayShapes { t | nil } ]  
    [ t_errorOnUnlockedShapes { t | nil } ]  
)  
=> t / nil
```

## Description

Creates a DEF file from a specified OpenAccess library.

## Arguments

|                   |                                                                 |
|-------------------|-----------------------------------------------------------------|
| <i>t_fileName</i> | Name of the DEF file to be created from the OpenAccess library. |
| <i>t_libName</i>  | Name of the source OpenAccess library.                          |
| <i>t_cellName</i> | Name of the cell to be translated.                              |
| <i>t_viewName</i> | View name for the cell name to be translated.                   |

## Design Data Translators SKILL Reference

### LEF/DEF Functions


---

|                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>t_logName</i>               | Name of the log file for storing the error messages.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <i>t_version</i>               | Specify the version of DEF. Supported versions are 5.8, 5.7, 5.6, 5.5, and 5.4.                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <i>t_templateFileName</i>      | Name of the file that contains all the command options.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <i>g_skipNoneOrViaCellType</i> | Cells of type <code>none</code> or <code>via</code> will not be written in output DEF file.                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <i>t_mapDividerChar</i>        | Specifies a single character to be replaced in instance and net names by the DEF.                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <i>t_dividerChar</i>           | Specifies a new divider character to be used during output.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <i>t_busbitChars</i>           | Specifies new busbit character pair to be used during output.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <i>g_outputFloatingShapes</i>  | <p>Outputs floating shapes into the <code>SPECIALNETS</code> section.</p> <p><b>Note:</b> Floating shapes are shapes that do not have any connectivity information. All shapes on <code>tsvMetal</code> and <code>padMetal</code> layers that do not have any connectivity are also considered as floating shapes.</p> <p>When specified during DEF OUT translation, any drawing shape on a layer, which is not a member of a net is exported on a net in the <code>SPECIALNETS</code> section named <code>_FLOATING_DRAWING_SHAPES_RESERVED</code>.</p> |
| <i>g_warnOnNotPlacedInsts</i>  | Adds warnings in the log file for the instances in the DEF Out output that have no placement status.                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <i>g_skipPhysOnlyInsts</i>     | Prevents output of physical instances. If this option is not specified, physical instances are placed in the <code>DEF COMPONENTS</code> section and have the <code>+ SOURCE DIST</code> statement added to them.                                                                                                                                                                                                                                                                                                                                        |
| <i>g_gdsCompatible</i>         | Generates a DEF file with limits that make it compatible with GDS.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <i>t_userSkillFile</i>         | Specifies a file that consists of user-defined SKILL routines.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

|                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>t_noDefOnError</code>                                                                                                                                                                                                                                 | Prevents the DEF output file from being generated if there are errors during translation.                                                                                                                                                                                           |
| <code>g_lockedColorOnly</code>                                                                                                                                                                                                                              | <p>(ICADVM20.1 Only) Outputs colors for only those shapes that have their locked state set to true.</p> <p>This includes pathSegs in nets, rects and polygons, and fill shapes and vias in specialnets.</p>                                                                         |
| <code>g_skipTrimShapes</code>                                                                                                                                                                                                                               | <p>(ICADVM20.1 Only) Prevents output of trim layers shapes into the FILLS section.</p> <p><b>Note:</b> This option works only when the <code>-outputFloatingShapes</code> option is specified.</p>                                                                                  |
| <code>g_skipTrimProductShapes</code>                                                                                                                                                                                                                        | (ICADVM20.1 Only) Prevents output of trim product shapes into the SPECIALNETS section.                                                                                                                                                                                              |
| <code>g_genBridgeMetalShapes</code>                                                                                                                                                                                                                         | (ICADVM20.1 Only) Outputs the trim gap fill shapes (bridge metal shapes) into the SPECIALNETS section.                                                                                                                                                                              |
| <code>g_outputTrimSegsAsNets</code>                                                                                                                                                                                                                         | (ICADVM20.1 Only) Outputs trim product shapes into NETS section.                                                                                                                                                                                                                    |
| <div><b>Important</b></div> <p>Arguments<br/><code>t_skipTrimProductShapes</code> and<br/><code>t_outputTrimSegsAsNets</code> cannot set to <code>t</code> together.</p> |                                                                                                                                                                                                                                                                                     |
| <code>t_maskShiftLayer</code>                                                                                                                                                                                                                               | (ICADVM20.1 Only) Specifies list of layers used in COMPONENTMASKSHIFT statement.                                                                                                                                                                                                    |
| <code>t_oaMapFile</code>                                                                                                                                                                                                                                    | <p>(ICADVM20.1 Only) Uses the specified mapping file to pre-process the design before it is exported to DEF.</p> <p>For more information, see <a href="#">Using the oaMapFile option for different OpenAccess Database Formats</a> in <i>Design Data Translators Reference</i>.</p> |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

|                                |                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>g_skipTrimmedShapes</i>     | (ICADVM20.1 Only) Prevents output of trim layers shapes into the SPECIALNETS section.<br><br><b>Note:</b> This option works only when the <i>g_outputFloatingShapes</i> option is specified. ‘                                                                                                                                                                                                                 |
| <i>t_errorOnGrayShapes</i>     | (ICADVM20.1 Only) Displays errors if gray or uncolored shapes or vias are found during translation.<br><br><b>Note:</b> (ICADVM20.1 Only – 95511) When the technology library contains a <u>preColoredLayers</u> constraint in the VirtuosoMPTSetup constraint group, the layers list from the first <i>preColoredLayers</i> constraint is not considered for error checking.                                  |
| <i>t_errorOnUnlockedShapes</i> | (ICADVM20.1 Only) Displays errors if any colored shapes or vias with unlocked status are found during translation. (ICADVM20.1 Only)<br><br><b>Note:</b> (ICADVM20.1 Only – 95511) When the technology library contains a <u>preColoredLayers</u> constraint in the VirtuosoMPTSetup constraint group, the layers list from the first <i>preColoredLayers</i> constraint is not considered for error checking. |

### Value Returned

|            |                                                           |
|------------|-----------------------------------------------------------|
| <i>t</i>   | Returns <i>t</i> on successful execution of the function. |
| <i>nil</i> | Returns <i>nil</i> when the function encounters an error. |

### Examples

#### Example 1

```
ldtrDefWriteOA("out.def" "definLib" "defCell" "layout" "defout.log" "5.6")
```

In this example, a DEF file, *out.def*, is created from the *definLib* library.

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### **Example 2**

```
ldtrDefWriteOA("out.def" "definLib" "defCell" "layout" "defout.log" "5.8" "" nil ""  
"" "" t nil nil t t t nil)
```

In the above example, a DEF file, `out.def`, is created from the `definLib` library with boolean options `t_allowFloatingShapes`, `t_skipTrimShapes`, `t_skipTrimProductShapes`, and `t_genBridgeMetalShapes` set to `t`.

This example is valid only for ICADV12.3 ISR9 version. It is incompatible with older and newer versions of this function. Argument `t_allowFloatingShapes`, which was fifteenth argument in previous releases has been moved to twelfth place. Therefore, a block of code that already specified one or more of the following options will have to be modified to work correctly in ICADV12.3 ISR9:

- `g_lockedColorOnly` (Moved to thirteenth place from twelfth)
- `g_skipTrimShapes` (Moved to fourteenth place from thirteenth)
- `g_skipTrimProductShapes` (Moved to fifteenth place from fourteenth)
- `g_genBridgeMetalShapes`
- `g_outputTrimSegsAsNets`



## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### **Example 3**

```
ldtrDefWriteOA("out.def" "definLib" "defCell" "layout" "defout.log" "5.8" "" nil ""  
"" "" nil t)
```

In the above example, a DEF file, `out.def`, is created from the `definLib` library with Boolean option `t_warnOnNotPlacedInsts` set to `t`.

This example is valid only for ICADV12.3 ISR10. It is incompatible with the older versions of this function. Argument `t_warnOnNotPlacedInsts` has been added as the thirteenth argument. Therefore, a block of code that already specifies one or more of the following options will have to be modified to work correctly ICADV12.3 ISR10 onward:

- `g_lockedColorOnly` (Moved to fourteenth place from thirteenth)
- `g_skipTrimShapes` (Moved to fifteenth place from fourteenth)
- `g_skipTrimProductShapes` (Moved to sixteenth place from fifteenth)
- `g_genBridgeMetalShapes` (Moved to seventeenth place from sixteenth)
- `g_outputTrimSegsAsNets` (Moved to eighteenth place from seventeenth)

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### Additional Information (ICADVM20.1 Only)

The following table depicts position of `ldtrDefWriteOA` arguments in different releases.

#### **ICADV12.3 FCS**

|                                             |                                              |                                            |                                             |
|---------------------------------------------|----------------------------------------------|--------------------------------------------|---------------------------------------------|
| (1)<br><code>t_fileName</code>              | (2)<br><code>t_libName</code>                | (3)<br><code>t_cellName</code>             | (4)<br><code>t_viewName</code>              |
| (5)<br><code>t_logName</code>               | (6)<br><code>t_version</code>                | (7)<br><code>t_templateFileName</code>     | (8)<br><code>g_skipNoneOrViaCellType</code> |
| (9)<br><code>t_mapDividerChar</code>        | (10)<br><code>t_dividerChar</code>           | (11)<br><code>t_busbitChars</code>         | (12)<br><code>g_lockedColorOnly</code>      |
| (13)<br><code>g_skipTrimShapes</code>       | (14)<br><code>g_skipTrimProductShapes</code> | (15)<br><code>g_allowFloatingShapes</code> | (16)<br><code>g_genBridgeMetalShapes</code> |
| (17)<br><code>g_outputTrimSegsAsNets</code> | (18)                                         | (19)                                       | (20)                                        |

#### **ICADV12.3 ISR9**

|                                             |                                       |                                              |                                                   |
|---------------------------------------------|---------------------------------------|----------------------------------------------|---------------------------------------------------|
| (1)<br><code>t_fileName</code>              | (2)<br><code>t_libName</code>         | (3)<br><code>t_cellName</code>               | (4)<br><code>t_viewName</code>                    |
| (5)<br><code>t_logName</code>               | (6)<br><code>t_version</code>         | (7)<br><code>t_templateFileName</code>       | (8)<br><code>g_skipNoneOrViaCellType</code>       |
| (9)<br><code>t_mapDividerChar</code>        | (10)<br><code>t_dividerChar</code>    | (11)<br><code>t_busbitChars</code>           | (12)<br><b><code>g_allowFloatingShapes</code></b> |
| (13)<br><code>g_lockedColorOnly</code>      | (14)<br><code>g_skipTrimShapes</code> | (15)<br><code>g_skipTrimProductShapes</code> | (16)<br><code>g_genBridgeMetalShapes</code>       |
| (17)<br><code>g_outputTrimSegsAsNets</code> | (18)                                  | (19)                                         | (20)                                              |

#### **ICADV12.3 ISR10**

|                                                    |                                        |                                        |                                              |
|----------------------------------------------------|----------------------------------------|----------------------------------------|----------------------------------------------|
| (1)<br><code>t_fileName</code>                     | (2)<br><code>t_libName</code>          | (3)<br><code>t_cellName</code>         | (4)<br><code>t_viewName</code>               |
| (5)<br><code>t_logName</code>                      | (6)<br><code>t_version</code>          | (7)<br><code>t_templateFileName</code> | (8)<br><code>g_skipNoneOrViaCellType</code>  |
| (9)<br><code>t_mapDividerChar</code>               | (10)<br><code>t_dividerChar</code>     | (11)<br><code>t_busbitChars</code>     | (12)<br><code>g_allowFloatingShapes</code>   |
| (13)<br><b><code>g_warnOnNotPlacedInsts</code></b> | (14)<br><code>g_lockedColorOnly</code> | (15)<br><code>g_skipTrimShapes</code>  | (16)<br><code>g_skipTrimProductShapes</code> |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

(17)

*g\_genBridgeMetalShapes*

(18)

*g\_outputTrimSegsAsNets*

(19)

(20)

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### ICADV12.3 ISR21

|                                 |                                    |                                |                                |
|---------------------------------|------------------------------------|--------------------------------|--------------------------------|
| (1)<br>t_fileName               | (2)<br>t_libName                   | (3)<br>t_cellName              | (4)<br>t_viewName              |
| (5)<br>t_logName                | (6)<br>t_version                   | (7)<br>t_templateFileName      | (8)<br>g_skipNoneOrViaCellType |
| (9)<br>t_mapDividerChar         | (10)<br>t_dividerChar              | (11)<br>t_busbitChars          | (12)<br>g_allowFloatingShapes  |
| (13)<br>g_warnOnNotPlacedInsts  | (14)<br><b>g_skipPhysOnlyInsts</b> | (15)<br>g_lockedColorOnly      | (16)<br>g_skipTrimShapes       |
| (17)<br>g_skipTrimProductShapes | (18)<br>g_genBridgeMetalShapes     | (19)<br>g_outputTrimSegsAsNets | (20)                           |

#### ICADV18.1 ISR5

|                                |                                 |                                |                                |
|--------------------------------|---------------------------------|--------------------------------|--------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName                | (3)<br>t_cellName              | (4)<br>t_viewName              |
| (5)<br>t_logName               | (6)<br>t_version                | (7)<br>t_templateFileName      | (8)<br>g_skipNoneOrViaCellType |
| (9)<br>t_mapDividerChar        | (10)<br>t_dividerChar           | (11)<br>t_busbitChars          | (12)<br>g_allowFloatingShapes  |
| (13)<br>g_warnOnNotPlacedInsts | (14)<br>g_skipPhysOnlyInsts     | (15)<br><b>g_gdsCompatible</b> | (16)<br>g_lockedColorOnly      |
| (17)<br>g_skipTrimShapes       | (18)<br>g_skipTrimProductShapes | (19)<br>g_genBridgeMetalShapes | (20)<br>g_outputTrimSegsAsNets |

#### ICADV18.1 ISR7

|                                |                                 |                                 |                                |
|--------------------------------|---------------------------------|---------------------------------|--------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName                | (3)<br>t_cellName               | (4)<br>t_viewName              |
| (5)<br>t_logName               | (6)<br>t_version                | (7)<br>t_templateFileName       | (8)<br>g_skipNoneOrViaCellType |
| (9)<br>t_mapDividerChar        | (10)<br>t_dividerChar           | (11)<br>t_busbitChars           | (12)<br>g_allowFloatingShapes  |
| (13)<br>g_warnOnNotPlacedInsts | (14)<br>g_skipPhysOnlyInsts     | (15)<br>g_gdsCompatible         | (16)<br><b>t_userSkillFile</b> |
| (17)<br>g_lockedColorOnly      | (18)<br>g_skipTrimShapes        | (19)<br>g_skipTrimProductShapes | (20)<br>g_genBridgeMetalShapes |
| (21)<br>g_outputTrimSegsAsNets | (22)<br><b>t_maskShiftLayer</b> |                                 |                                |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

#### **ICADVM18.1 ISR9**

|                                |                             |                                 |                                |
|--------------------------------|-----------------------------|---------------------------------|--------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName            | (3)<br>t_cellName               | (4)<br>t_viewName              |
| (5)<br>t_logName               | (6)<br>t_version            | (7)<br>t_templateFileName       | (8)<br>g_skipNoneOrViaCellType |
| (9)<br>t_mapDividerChar        | (10)<br>t_dividerChar       | (11)<br>t_busbitChars           | (12)<br>g_allowFloatingShapes  |
| (13)<br>g_warnOnNotPlacedInsts | (14)<br>g_skipPhysOnlyInsts | (15)<br>g_gdsCompatible         | (16)<br>t_userSkillFile        |
| (17)<br>g_lockedColorOnly      | (18)<br>g_skipTrimShapes    | (19)<br>g_skipTrimProductShapes | (20)<br>g_genBridgeMetalShapes |
| (21)<br>g_outputTrimSegsAsNets | (22)<br>t_maskShiftLayer    | (23)<br><b>t_oaMapFile</b>      |                                |

#### **ICADVM18.1 ISR10**

|                                |                             |                                 |                                    |
|--------------------------------|-----------------------------|---------------------------------|------------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName            | (3)<br>t_cellName               | (4)<br>t_viewName                  |
| (5)<br>t_logName               | (6)<br>t_version            | (7)<br>t_templateFileName       | (8)<br>g_skipNoneOrViaCellType     |
| (9)<br>t_mapDividerChar        | (10)<br>t_dividerChar       | (11)<br>t_busbitChars           | (12)<br>g_allowFloatingShapes      |
| (13)<br>g_warnOnNotPlacedInsts | (14)<br>g_skipPhysOnlyInsts | (15)<br>g_gdsCompatible         | (16)<br>t_userSkillFile            |
| (17)<br>g_lockedColorOnly      | (18)<br>g_skipTrimShapes    | (19)<br>g_skipTrimProductShapes | (20)<br>g_genBridgeMetalShapes     |
| (21)<br>g_outputTrimSegsAsNets | (22)<br>t_maskShiftLayer    | (23)<br>t_oaMapFile             | (24)<br><b>g_skipTrimmedShapes</b> |

#### **ICADVM18.1 ISR13**

|                                |                             |                           |                                 |
|--------------------------------|-----------------------------|---------------------------|---------------------------------|
| (1)<br>t_fileName              | (2)<br>t_libName            | (3)<br>t_cellName         | (4)<br>t_viewName               |
| (5)<br>t_logName               | (6)<br>t_version            | (7)<br>t_templateFileName | (8)<br>g_skipNoneOrViaCellType  |
| (9)<br>t_mapDividerChar        | (10)<br>t_dividerChar       | (11)<br>t_busbitChars     | (12)<br>g_allowFloatingShapes   |
| (13)<br>g_warnOnNotPlacedInsts | (14)<br>g_skipPhysOnlyInsts | (15)<br>g_gdsCompatible   | (16)<br>t_userSkillFile         |
| (17)<br><b>t_noDefOnError</b>  | (18)<br>g_lockedColorOnly   | (19)<br>g_skipTrimShapes  | (20)<br>g_skipTrimProductShapes |

## Design Data Translators SKILL Reference

### LEF/DEF Functions

---

|                                     |                                         |                                             |                          |
|-------------------------------------|-----------------------------------------|---------------------------------------------|--------------------------|
| (21)                                | (22)                                    | (23)                                        | (24)                     |
| <code>g_genBridgeMetalShapes</code> | <code>g_outputTrimSegsAsNets</code>     | <code>t_maskShiftLayer</code>               | <code>t_oaMapFile</code> |
| (25)                                | (26)                                    | (27)                                        | (24)                     |
| <code>g_skipTrimmedShapes</code>    | <b><code>t_errorOnGrayShapes</code></b> | <b><code>t_errorOnUnlockedShapes</code></b> |                          |

## Command Line SKILL Functions

### defoutPreTranslate

```
defoutPreTranslate(  
    lib  
    cell  
    view  
)
```

#### Description

During DEF Out, this function is called just before the translation starts.

#### Arguments

|             |                                                   |
|-------------|---------------------------------------------------|
| <i>lib</i>  | Contains the input library specified by the user. |
| <i>cell</i> | Contains the cell specified by the user.          |
| <i>view</i> | Contains the view specified by the user.          |

#### Value Returned

**None**

#### Example

```
procedure( defoutPreTranslate( lib cell view )  
    prog( ( )  
        printf("In PreTranslate of defout")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
        );prog  
    )
```

## **defoutPostTranslate**

```
defoutPostTranslate(  
    lib  
    cell  
    view  
)
```

### **Description**

During DEF Out, this function is called just after the translation is completed.

### **Arguments**

|             |                                                   |
|-------------|---------------------------------------------------|
| <i>lib</i>  | Contains the input library specified by the user. |
| <i>cell</i> | Contains the cell specified by the user.          |
| <i>view</i> | Contains the view specified by the user.          |

### **Value Returned**

None

### **Example**

```
procedure( defoutPostTranslate( lib cell view )  
    prog( ( )  
        printf("In PostTranslate of defout\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```



## **definPreTranslate**

```
definPreTranslate(  
    lib  
    cell  
    view  
)
```

### **Description**

During DEF In, this function is called just before the translation starts.

### **Arguments**

|             |                                                                             |
|-------------|-----------------------------------------------------------------------------|
| <i>lib</i>  | Contains the destination library specified by the user.                     |
| <i>cell</i> | Contains the cell specified by the user or empty string if not specified.   |
| <i>view</i> | Contains the view specified by the user or the default view layout is used. |

### **Value Returned**

None

### **Example**

```
procedure( definPreTranslate( lib cell view )  
    prog( ( )  
        printf("In PreTranslate of defin\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```

## **definPostTranslate**

```
definPostTranslate(  
    lib  
    cell  
    view  
)
```

### **Description**

During DEF In translation, this function is called just after the translation is completed.

### **Arguments**

|             |                                                                             |
|-------------|-----------------------------------------------------------------------------|
| <i>lib</i>  | Contains the destination library specified by the user.                     |
| <i>cell</i> | Contains the cell specified by the user or empty string if not specified.   |
| <i>view</i> | Contains the view specified by the user or the default view layout is used. |

### **Value Returned**

None

### **Example**

```
procedure( definPostTranslate( lib cell view )  
    prog( ( )  
        printf("In PostTranslate of DefIn\n")  
        printf("Library: %s\n" lib)  
        printf("Cell: %s\n" cell)  
        printf("View: %s\n" view)  
    );prog  
)
```