

function	meaning
__copy_to_user_inatomic	Copy a block of data into user space, with less checking.
__copy_to_user	Copy a block of data into user space, with less checking.
__copy_from_user	Copy a block of data from user space, with less checking.
clear_user	Zero a block of memory in user space.
__clear_user	Zero a block of memory in user space, with less checking.
_copy_to_user	Copy a block of data into user space.
_copy_from_user	Copy a block of data from user space.