

dummy-irq module

```
1.  /*
2.   * Dummy IRQ handler driver.
3.   *
4.   * This module only registers itself as a handler that is specified to it
5.   * by the 'irq' parameter.
6.   *
7.   * The sole purpose of this module is to help with debugging of systems on
8.   * which spurious IRQs would happen on disabled IRQ vector.
9.   *
10. */
```

drivers/misc/dummy-irq.c

CONFIG_DUMMY_IRQ = y

```
static int irq = -1;
```

目前的irq定已成static,不太灵活。可以改成

```
1.  static int irq = -1;
2.  module_param(irq, int, 0644);
```

这样如果对某个interrupt有怀疑(是否产生了interrupt),就可以dynamic load该driver,并用参数指定monitor哪一个interrupt。